

10.1





Xilinx is disclosing this user guide, manual, release note, and/or specification (the "Documentation") to you solely for use in the development of designs to operate with Xilinx hardware devices. You may not reproduce, distribute, republish, download, display, post, or transmit the Documentation in any form or by any means including, but not limited to, electronic, mechanical, photocopying, recording, or otherwise, without the prior written consent of Xilinx. Xilinx expressly disclaims any liability arising out of your use of the Documentation. Xilinx reserves the right, at its sole discretion, to change the Documentation without notice at any time. Xilinx assumes no obligation to correct any errors contained in the Documentation, or to advise you of any corrections or updates. Xilinx expressly disclaims any liability in connection with technical support or assistance that may be provided to you in connection with the Information.

THE DOCUMENTATION IS DISCLOSED TO YOU "AS-IS" WITH NO WARRANTY OF ANY KIND. XILINX MAKES NO OTHER WARRANTIES, WHETHER EXPRESS, IMPLIED, OR STATUTORY, REGARDING THE DOCUMENTATION, INCLUDING ANY WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NONINFRINGEMENT OF THIRD-PARTY RIGHTS. IN NO EVENT WILL XILINX BE LIABLE FOR ANY CONSEQUENTIAL, INDIRECT, EXEMPLARY, SPECIAL, OR INCIDENTAL DAMAGES, INCLUDING ANY LOSS OF DATA OR LOST PROFITS, ARISING FROM YOUR USE OF THE DOCUMENTATION.

© 2002–2008 Xilinx, Inc. All rights reserved.

XILINX, the Xilinx logo, the Brand Window, and other designated brands included herein are trademarks of Xilinx, Inc. All other trademarks are the property of their respective owners

# Table of Contents

## Preface: About the XST User Guide

XST User Guide Contents	17
Additional Resources	18
Conventions	18
Typographical	
Online Document	19

### Chapter 1: Introduction to the XST User Guide

About XST
What's New in Release 10.1
Macro Inference
Constraints
Libraries Support
Setting XST Options 22

## Chapter 2: XST HDL Coding Techniques

Signed and Unsigned Support in XST	. 24
Registers HDL Coding Techniques	. 25
About Registers	
Registers Log File	
Registers Related Constraints	
Registers Coding Examples	. 26
Latches HDL Coding Techniques	. 34
About Latches	. 34
Latches Log File	
Latches Related Constraints	
Latches Coding Examples	. 35
Tristates HDL Coding Techniques	. 39
About Tristates	
Tristates Log File	
Tristates Related Constraints	
Tristates Coding Examples	. 40
Counters HDL Coding Techniques	
About Counters	. 43
Counters Log File	
Counters Related Constraints	
Counters Coding Examples	. 44
Accumulators HDL Coding Techniques	
About Accumulators	
Accumulators in Virtex-4 and Virtex-5 Devices	
Accumulators Log File	
Accumulators Related Constraints	
Accumulators Coding Examples	. 61

Shift Registers HDL Coding Techniques	
About Shift Registers	
Describing Shift Registers	
Implementing Shift Registers	
Shift Registers Log File	
Shift Registers Related Constraints	
Dynamic Shift Registers HDL Coding Techniques	83
Dynamic Shift Registers Log File	84
Dynamic Shift Registers Related Constraints	84
Dynamic Shift Registers Coding Examples	
Multiplexers HDL Coding Techniques	
About Multiplexers	87
Multiplexers Case Statements	88
Multiplexers Log File	
Multiplexers Related Constraints	
Multiplexers Coding Examples	
Decoders HDL Coding Techniques	
About Decoders	
Decoders Log File Decoders Related Constraints	
Decoders Coding Examples	
Priority Encoders HDL Coding Techniques	103
Priority Encoders Log File	
Priority Encoders Related Constraints	
Priority Encoders Coding Examples	
Logical Shifters HDL Coding Techniques	
About Logical Shifters	
Logical Shifters Log File	
Logical Shifters Related Constraints	
Logical Shifters Coding Examples	106
Arithmetic Operators HDL Coding Techniques	111
About Arithmetic Operators	
Arithmetic Operators Log File	
Arithmetic Operators Related Constraints	
Arithmetic Operators Coding Examples	
Adders, Subtractors, and Adders/Subtractors HDL Coding Techniques	
About Adders, Subtractors, and Adders/Subtractors	
Adders, Subtractors, and Adders/Subtractors Log File	
Adders, Subtractors, and Adders/Subtractors Related Constraints	
· ·	
Comparators HDL Coding Techniques	
Comparators Log File	
Comparators Related Constraints	
Comparators Coding Examples	
Multipliers HDL Coding Techniques	
About Multipliers.	
Large Multipliers Using Block Multipliers	128

Registered Multipliers	
Multipliers (Virtex-4, Virtex-5, and Spartan-3A D Devices)	128
Multiplication with Constant	129
Multipliers Log File	129
Multipliers Related Constraints	130
Multipliers Coding Examples	
Sequential Complex Multipliers HDL Coding Techniques	
About Sequential Complex Multipliers	101
About Sequential Complex Multipliers	101
Sequential Complex Multipliers Log File	102
Sequential Complex Multipliers Related Constraints	132
Sequential Complex Multipliers Coding Examples	
Pipelined Multipliers HDL Coding Techniques	135
About Pipelined Multipliers	135
Pipelined Multipliers Log File	136
Pipelined Multipliers Related Constraints	
Pipelined Multipliers Coding Examples	
Multiply Adder/Subtractors HDL Coding Techniques	
About Multiply Adder/Subtractors	143
Multiply Adder/Subtractors in Virtex-4 and Virtex- 5 Devices	143
Multiply Adder/Subtractors Log File	
Multiply Adder/Subtractors Related Constraints	
Multiply Adder/Subtractors Coding Examples	145
Multiply Accumulate HDL Coding Techniques	149
About Multiply Accumulate	149
Multiply Accumulate in Virtex-4 and Virtex-5 Devices	
Multiply Accumulate Log File	
Multiply Accumulate Related Constraints	
Multiply Accumulate Coding Examples	
Dividers HDL Coding Techniques	
About Dividers	
Dividers Log File	
Dividers Related Constraints	
Dividers Coding Examples	155
Resource Sharing HDL Coding Techniques	157
About Resource Sharing	
Resource Sharing Log File	
Resource Sharing Related Constraints	
Resource Sharing Coding Examples	
RAMs and ROMs HDL Coding Techniques	
About RAMs and ROMs	
RAMs and ROMs Log File	161
RAMs and ROMs Related Constraints	
RAMs and ROMs Coding Examples	
Initializing RAM Coding Examples	219
ROMs Using Block RAM Resources HDL Coding Techniques	227
About ROMs Using Block RAM Resources	
ROMs Using Block RAM Resources Log File	
ROMs Using Block RAM Resources Related Constraints	
ROMs Using Block RAM Resources Coding Examples	
Pipelined Distributed RAM HDL Coding Techniques	
About Pipelined Distributed RAM	235

Pipelined Distributed RAM Related Constraints237Pipelined Distributed RAM Coding Examples237Finite State Machines (FSMs) HDL Coding Techniques239About Finite State Machines (FSMs)239Describing Finite State Machines (FSMs)240State Encoding Techniques241RAM-Based FSM Synthesis243Safe FSM Implementation243Finite State Machines Log File244Finite State Machines Related Constraints245Finite State Machines Coding Examples245Black Boxes HDL Coding Techniques253About Black Boxes253	· · ·	
Finite State Machines (FSMs) HDL Coding Techniques239About Finite State Machines (FSMs)239Describing Finite State Machines (FSMs)240State Encoding Techniques241RAM-Based FSM Synthesis243Safe FSM Implementation243Finite State Machines Log File244Finite State Machines Related Constraints245Finite State Machines Coding Examples245	Pipelined Distributed RAM Related Constraints	37
About Finite State Machines (FSMs)239Describing Finite State Machines (FSMs)240State Encoding Techniques241RAM-Based FSM Synthesis243Safe FSM Implementation243Finite State Machines Log File244Finite State Machines Related Constraints245Finite State Machines Coding Examples245Black Boxes HDL Coding Techniques253	Pipelined Distributed RAM Coding Examples	37
Describing Finite State Machines (FSMs)240State Encoding Techniques241RAM-Based FSM Synthesis243Safe FSM Implementation243Finite State Machines Log File244Finite State Machines Related Constraints245Finite State Machines Coding Examples245Black Boxes HDL Coding Techniques253	Finite State Machines (FSMs) HDL Coding Techniques	39
State Encoding Techniques241RAM-Based FSM Synthesis243Safe FSM Implementation243Finite State Machines Log File244Finite State Machines Related Constraints245Finite State Machines Coding Examples245Black Boxes HDL Coding Techniques253	About Finite State Machines (FSMs) 23	39
RAM-Based FSM Synthesis243Safe FSM Implementation243Finite State Machines Log File244Finite State Machines Related Constraints245Finite State Machines Coding Examples245Black Boxes HDL Coding Techniques253	Describing Finite State Machines (FSMs) 24	40
Safe FSM Implementation243Finite State Machines Log File244Finite State Machines Related Constraints245Finite State Machines Coding Examples245Black Boxes HDL Coding Techniques253	State Encoding Techniques 24	41
Finite State Machines Log File244Finite State Machines Related Constraints245Finite State Machines Coding Examples245Black Boxes HDL Coding Techniques253	RAM-Based FSM Synthesis 24	43
Finite State Machines Log File244Finite State Machines Related Constraints245Finite State Machines Coding Examples245Black Boxes HDL Coding Techniques253	Safe FSM Implementation	43
Finite State Machines Coding Examples245Black Boxes HDL Coding Techniques253		
Black Boxes HDL Coding Techniques	Finite State Machines Related Constraints 24	45
	Finite State Machines Coding Examples 24	45
About Black Boyos	Black Boxes HDL Coding Techniques 25	53
About black boxes	About Black Boxes	53
Black Box Log File	Black Box Log File	53
Black Box Related Constraints		
	Black Box Coding Examples 25	54

## Chapter 3: XST FPGA Optimization

About XST FPGA Optimization	257
Virtex-Specific Synthesis Options	258
Macro Generation	259
Virtex Macro Generator	
Arithmetic Functions in Macro Generation	
Loadable Functions in Macro Generation	260
Multiplexers in Macro Generation	260
Priority Encoders in Macro Generation	260
Decoders in Macro Generation	
Shift Registers in Macro Generation	261
RAMs in Macro Generation	
ROMs in Macro Generation	263
DSP48 Block Resources	264
Mapping Logic Onto Block RAM	265
About Mapping Logic Onto Block RAM	
Mapping Logic Onto Block RAM Log Files	
Mapping Logic Onto Block RAM Coding Examples	
Flip-Flop Retiming	269
About Flip-Flop Retiming	
Limitations of Flip-Flop Retiming	
Controlling Flip-Flop Retiming	
Partitions	
Incremental Synthesis	270
About Incremental Synthesis	
Incremental Synthesis (INCREMENTAL_SYNTHESIS)	
Grouping Through Incremental Synthesis Diagram	
Resynthesize (RESYNTHESIZE)	272
Speed Optimization Under Area Constraint	275
About Speed Optimization Under Area Constraint	
Speed Optimization Under Area Constraint Examples	275
FPGA Optimization Log File	277

Design Optimization Report	277
Cell Usage Report	277
Timing Report	
Implementation Constraints	283
Virtex Primitive Support	283
Instantiating Virtex Primitives	283
Generating Primitives Through Attributes	284
Primitives and Black Boxes	284
VHDL and Verilog Virtex Libraries	
Virtex Primitives Log File	
Virtex Primitives Related Constraints	286
Virtex Primitives Coding Examples	286
Using the UNIMACRO Library	288
Cores Processing	288
Specifying INIT and RLOC	290
About Specifying INIT and RLOC	
Passing an INIT Value Via the LUT_MAP Constraint Coding Examples	
Specifying INIT Value for a Flip-Flop Coding Examples	
Specifying INIT and RLOC Values for a Flip-Flop Coding Examples	
Using PCI Flow With XST	295
Satisfying Placement Constraints and Meeting Timing Requirements	295
Preventing Logic and Flip-Flop Replication	
Disabling Read Cores	

## Chapter 4: XST CPLD Optimization

CPLD Synthesis Options	<i>)</i> 7
About CPLD Synthesis Options	<i></i> 7
CPLD Synthesis Supported Devices 29	<b>)</b> 8
Setting CPLD Synthesis Options 29	<b>)</b> 8
Implementation Details for Macro Generation         29	98
CPLD Synthesis Log File Analysis 29	<i>)</i> 9
CPLD Synthesis Constraints 30	)1
Improving Results in CPLD Synthesis	)1
About Improving Results in CPLD Synthesis	)1
Obtaining Better Frequency 30	)1
Fitting a Large Design	)2

## Chapter 5: XST Design Constraints

About Constraints	305
List of XST Design Constraints	306
XST General Constraints	306
XST HDL Constraints	307
XST FPGA Constraints (Non-Timing)	307
XST CPLD Constraints (Non-Timing)	309
XST Timing Constraints	309
XST Implementation Constraints	309
Third Party Constraints	309
Setting Global Constraints and Options	310
Setting Synthesis Options	310

Setting HDL Options	
Setting Xilinx-Specific Options	. 312
Setting Other XST Command Line Options	. 313
Custom Compile File List	. 313
VHDL Attribute Syntax	. 314
Verilog-2001 Attributes.	
About Verilog-2001 Attributes	
Verilog-2001 Attributes Syntax	
Verilog-2001 Limitations	. 315
Verilog-2001 Meta Comments	
XST Constraint File (XCF)	
Specifying the XST Constraint File (XCF)	. 316
XCF Syntax and Utilization	
Native and Non-Native User Constraint File (UCF) Constraints Syntax	
XCF Syntax Limitations.	
Constraints Priority	
XST-Specific Non-Timing Options	
XST Command Line Only Options	
XST Timing Options	
XST Timing Options: Project Navigator > Process Properties or Command Line.	
XST Timing Options: Xilinx Constraint File (XCF)	. 328
XST General Constraints	. 329
Add I/O Buffers (–iobuf)	
BoxType (BOX_TYPE)	
Bus Delimiter (–bus_delimiter)	
Case (-case)	
Case Implementation Style (–vlgcase)	
Verilog Macros (-define)	
Duplication Suffix (-duplication_suffix)	
Full Case (FULL_CASE)	
Generate RTL Schematic (–rtlview)	
Generics (-generics)	
Hierarchy Separator (–hierarchy_separator)	
I/O Standard (IOSTANDARD)	
Keep (KEEP)	
Keep Hierarchy (KEEP_HIERARCHY) Library Search Order (–lso)	. 341
5	
Netlist Hierarchy (-netlist_hierarchy)	
Optimization Effort (OPT_LEVEL)	
Optimization Goal (OPT_MODE)	
Parallel Case (PARALLEL_CASE)	
RLOC.	
Save (S / SAVE)	
Synthesis Constraint File (–uc)	
Translate Off (TRANSLATE_OFF) and Translate On (TRANSLATE_ON)	
Use Synthesis Constraints File (-iuc)	
Verilog Include Directories (-vlgincdir)	
Verilog 2001 (–verilog2001)	
HDL Library Mapping File (–xsthdpini)	
Work Directory (–xsthdpdir)	. 354
XST HDL Constraints	. 355

About XST HDL Constraints	
Automatic FSM Extraction (FSM_EXTRACT)	356
Enumerated Encoding (ENUM_ENCODING)	
Equivalent Register Removal (EQUIVALENT_REGISTER_REMOV)	<b>AL)</b> 358
FSM Encoding Algorithm (FSM_ENCODING)	359
Mux Extraction (MUX_EXTRACT)	
Register Power Up (REGISTER_POWERUP)	
Resource Sharing (RESOURCE_SHARING)	
Safe Recovery State (SAFE_RECOVERY_STATE)	
Safe Implementation (SAFE_IMPLEMENTATION)	
Signal Encoding (SIGNAL_ENCODING)	
XST FPGA Constraints (Non-Timing)	
Asynchronous to Synchronous (ASYNC_TO_SYNC)	
Automatic BRAM Packing (AUTO_BRAM_PACKING)	
BRAM Utilization Ratio (BRAM_UTILIZATION_RATIO)	
Buffer Type (BUFFER_TYPE)	
Extract BUFGCE (BUFGCE)	
Cores Search Directories (-sd)	
Decoder Extraction (DECODER_EXTRACT)	
DSP Utilization Ratio (DSP_UTILIZATION_RATIO)	
FSM Style (FSM_STYLE)	379
Power Reduction (POWER)	380
Read Cores (READ_CORES)	381
Resynthesize (RESYNTHESIZE)	383
Incremental Synthesis (INCREMENTAL_SYNTHESIS)	384
Logical Shifter Extraction (SHIFT_EXTRACT)	
LUT Combining (LC)	
Map Logic on BRAM (BRAM_MAP)	
Max Fanout (MAX_FANOUT)	
Move First Stage (MOVE_FIRST_STAGE)	
Move Last Stage (MOVE_LAST_STAGE)	
Multiplier Style (MULT_STYLE).	
Mux Style (MUX_STYLE)	
Number of Global Clock Buffers (–bufg)	
Number of Regional Clock Buffers (–bufr)	
Optimize Instantiated Primitives (OPTIMIZE_PRIMITIVES)	208
Pack I/O Registers Into IOBs (IOB)	
Priority Encoder Extraction (PRIORITY_EXTRACT)	
RAM Extraction (RAM_EXTRACT)	
RAM Style (RAM_STYLE)	
Reduce Control Sets (REDUCE_CONTROL_SETS)	
Register Balancing (REGISTER_BALANCING)	405
Register Duplication (REGISTER_DUPLICATION)	409
ROM Extraction (ROM_EXTRACT)	
ROM Style (ROM_STYLE)	
Shift Register Extraction (SHREG_EXTRACT)	
Slice Packing (–slice_packing)	414
Use Low Skew Lines (USELOWSKEWLINES)	
XOR Collapsing (XOR_COLLAPSE)	
Slice (LUT-FF Pairs) Utilization Ratio (SLICE_UTILIZATION_RATIO	<b>))</b> 416
Slice (LUT-FF Pairs) Utilization Ratio Delta	
(SLICE_UTILIZATION_RATIO_MAXMARGIN)	418
Map Entity on a Single LUT (LUT_MAP)	

Use Carry Chain (USE_CARRY_CHAIN)	
Convert Tristates to Logic (TRISTATE2LOGIC)	
Use Clock Enable (USE_CLOCK_ENABLE)	
Use Synchronous Set (USE_SYNC_SET)	
Use Synchronous Reset (USE_SYNC_RESET)	
Use DSP48 (USE_DSP48)	. 429
XST CPLD Constraints (Non-Timing)	. 430
Clock Enable (–pld_ce)	
Data Gate (DATA_GATE)	. 431
Macro Preserve (-pld_mp)	. 432
No Reduce (NOREDUCE)	
WYSIWYG (–wysiwyg)	
XOR Preserve (–pld_xp)	. 434
XST Timing Constraints	. 435
Applying Timing Constraints	
Cross Clock Analysis (-cross_clock_analysis)	
Write Timing Constraints (-write_timing_constraints)	. 437
Clock Signal (CLOCK_SIGNAL).	
Global Optimization Goal (–glob_opt)	. 438
XCF Timing Constraint Support	. 440
Period (PERIOD)	
Offset (OFFSET)	. 441
From-To (FROM-TO)	. 441
Timing Name (TNM)	. 441
Timing Name on a Net (TNM_NET)	
Timegroup (TIMEGRP)	. 442
Timing Ignore (TIG)	. 442
XST Implementation Constraints	. 442
About Implementation Constraints	
Implementation Constraints Syntax Examples	
RLOC	
NOREDUCE	
PWR_MODE	
XST-Supported Third Party Constraints	445
XST Equivalents to Third Party Constraints	
Third Party Constraints Syntax Examples	
	/

## Chapter 6: XST VHDL Language Support

451
452
452
452
453
453
453
453
455
456
457
457
458
• • • •

VHDL Multi-Dimensional Array Types	460
VHDL Record Types	461
VHDL Initial Values	461
About VHDL Initial Values	462
VHDL Local Reset/Global Reset	
Default Initial Values on Memory Elements in VHDL	463
VHDL Objects	464
Signals in VHDL	464
Variables in VHDL	
Constants in VHDL	
VHDL Operators	465
Entity and Architecture Descriptions in VHDL	466
VHDL Circuit Descriptions	
VHDL Entity Declarations	
VHDL Architecture Declarations	
VHDL Component Instantiation	
VHDL Recursive Component Instantiation	
VHDL Component Configuration	
VHDL Generic Parameter Declarations         VHDL Generic and Attribute Conflicts	
VHDL Combinatorial Circuits	
VHDL Concurrent Signal Assignments         VHDL Generate Statements	
VHDL Generate Statements	
VHDL IfElse Statements	
VHDL Case Statements	
VHDL ForLoop Statements	
VHDL Sequential Circuits	
About VHDL Sequential Circuits	480
VHDL Sequential Process With a Sensitivity List	
VHDL Sequential Process Without a Sensitivity List	
Register and Counter Descriptions VHDL Coding Examples	
VHDL Multiple Wait Statements Descriptions	
VHDL Functions and Procedures	485
About VHDL Functions and Procedures	
VHDL Functions and Procedures Examples	485
VHDL Assert Statements	487
About VHDL Assert Statements	
SINGLE_SRL Describing a Shift Register	487
Using Packages to Define VHDL Models	489
About Using Packages to Define VHDL Models	
Using Standard Packages to Define VHDL Models	
Using IEEE Packages to Define VHDL Models	
Using Synopsys Packages to Define VHDL Models	
VHDL Constructs Supported in XST	
VHDL Design Entities and Configurations	
VHDL Expressions.	
VHDL Statements	
VHDL Reserved Words	499

# Chapter 7: XST Verilog Language Support

About XST Verilog Language Support 501
Behavioral Verilog
Variable Part Selects
Structural Verilog Features
About Structural Verilog Features 502
Structural Verilog Coding Examples 503
Verilog Parameters
Verilog Parameter and Attribute Conflicts 506
About Verilog Parameter and Attribute Conflicts
Verilog Parameter and Attribute Conflicts Precedence
Verilog Limitations in XST
Verilog Case Sensitivity
Verilog Blocking and Nonblocking Assignments
Verilog Attributes and Meta Comments
About Verilog Attributes and Meta Comments
Verilog-2001 Attributes
Verilog Meta Comments
Verilog Constructs Supported in XST
Verilog Constants Supported in XST 511
Verilog Data Types Supported in XST 512
Verilog Continuous Assignments Supported in XST
Verilog Procedural Assignments Supported in XST       513         Verilog Design Hierarchies Supported in XST       517
Verilog Compiler Directives Supported in XST
Verilog System Tasks and Functions Supported in XST
Verilog Primitives
Verilog Reserved Keywords
<b>Verilog-2001 Support in XST</b>

## Chapter 8: XST Behavioral Verilog Language Support

Behavioral Verilog Variable Declarations	523
About Behavioral Verilog Variable Declarations	524
Behavioral Verilog Variable Declarations Coding Examples	524
Behavioral Verilog Initial Values	524
About Behavioral Verilog Initial Values	524
Behavioral Verilog Initial Values Coding Examples	525
Behavioral Verilog Local Reset	525
About Behavioral Verilog Local Reset	525
Behavioral Verilog Local Reset Coding Examples	525
Behavioral Verilog Arrays	526
Behavioral Verilog Multi-Dimensional Arrays	526
About Behavioral Verilog Multi-Dimensional Arrays	526
Behavioral Verilog Multi-Dimensional Arrays Coding Examples	527
Behavioral Verilog Data Types	527
About Behavioral Verilog Data Types	527
Behavioral Verilog Data Types Coding Examples	528

## XILINX<sup>®</sup>

Behavioral Verilog Legal Statements	. 528
Behavioral Verilog Expressions	. 529
About Behavioral Verilog Expressions	
Operators Supported in Behavioral Verilog	. 529
Expressions Supported in Behavioral Verilog	. 530
Results of Evaluating Expressions in Behavioral Verilog	. 531
Behavioral Verilog Blocks	. 532
Behavioral Verilog Modules	. 532
Behavioral Verilog Module Declarations	. 533
About Behavioral Verilog Module Declarations	. 533
Behavioral Verilog Module Declaration Coding Examples	. 533
Behavioral Verilog Continuous Assignments	
About Behavioral Verilog Continuous Assignments	
Behavioral Verilog Continuous Assignments Coding Examples	. 534
Behavioral Verilog Procedural Assignments	. 534
About Behavioral Verilog Procedural Assignments	. 534
Behavioral Verilog Combinatorial Always Blocks	
Behavioral Verilog IfElse Statement	
Behavioral Verilog Case Statements	
Behavioral Verilog For and Repeat Loops	
Behavioral Verilog While Loops	
Behavioral Verilog Sequential Always Blocks	
Behavioral Verilog Assign and Deassign Statements	
Behavioral Verilog Assignment Extension Past 32 Bits	
Behavioral Verilog Tasks and Functions	
Behavioral Verilog Recursive Tasks and Functions	
Behavioral Verilog Constant Functions	
Behavioral Verilog Blocking Versus Non-Blocking Procedural Assignments	
Behavioral Verilog Constants.	
Behavioral Verilog Macros	
Behavioral Verilog Include Files	
Behavioral Verilog Comments	. 547
Behavioral Verilog Generate Statements	
Behavioral Verilog Generate For Statements	. 547
Behavioral Verilog Generate If else Statements	
Behavioral Verilog Generate Case Statements	. 548

## Chapter 9: XST Mixed Language Support

About Mixed Language Support 5	551
Mixed Language Project Files 5	52
VHDL and Verilog Boundary Rules in Mixed Language Projects	52
Instantiating a Verilog Module in a VHDL Design	53
Instantiating a VHDL Design Unit in a Verilog Design	
Port Mapping in Mixed Language Projects	554
VHDL in Verilog Port Mapping 5	554
Verilog in VHDL Port Mapping 5	554
VHDL in Mixed Language Port Mapping 5	555
Verilog in Mixed Language Port Mapping 5	555
Generics Support in Mixed Language Projects 5	555

Library Search Order (LSO) Files in Mixed Language Projects	555
About the Library Search Order (LSO) File	555
Specifying the Library Search Order (LSO) File in Project Navigator	556
Specifying the Library Search Order (LSO) File in the Command Line	556
Library Search Order (LSO) Rules	556

## Chapter 10: XST Log Files

XST FPGA Log File Contents	51
XST FPGA Log File Copyright Statement 56	61
XST FPGA Log File Table of Contents 56	61
XST FPGA Log File Synthesis Options Summary	62
XST FPGA Log File HDL Compilation 56	62
XST FPGA Log File Design Hierarchy Analyzer	62
XST FPGA Log File HDL Analysis	62
XST FPGA Log File HDL Synthesis Report	62
XST FPGA Log File Advanced HDL Synthesis Report	62
XST FPGA Log File Low Level Synthesis 56	63
XST FPGA Log File Partition Report	
XST FPGA Log File Final Report 56	
Reducing the Size of the XST Log File 56	54
Use Message Filtering 56	54
Use Quiet Mode $\ldots$ 56	
	65
Hide Specific Messages 56	65
Macros in XST Log Files	66
<b>XST Log File Examples</b>	66

## Chapter 11: XST Naming Conventions

XST Net Naming Conventions	585
XST Instance Naming Conventions	585
XST Name Generation Control	586

## Chapter 12: XST Command Line Mode

Running XST in Command Line Mode 587
XST File Types in Command Line Mode 587
Temporary Files in Command Line Mode 588
Names With Spaces in Command Line Mode 588
Launching XST in Command Line Mode 588
Launching XST in Command Line Mode Using the XST Shell
Launching XST in Command Line Mode Using a Script File
Setting Up an XST Script
Setting Up an XST Script Using the Run Command
Setting Up an XST Script Using the Set Command
Setting Up an XST Script Using the Elaborate Command
Synthesizing VHDL Designs Using Command Line Mode 593
Synthesizing VHDL Designs Using Command Line Mode (Example) 593
Running XST in Script Mode (VHDL) 595
Synthesizing Verilog Designs Using Command Line Mode 596

. 596
. 597
. 598
. 599
. 599





# Preface

# About the XST User Guide

The XST User Guide:

- Describes Xilinx® Synthesis Technology (XST) support for Hardware Description Languages (HDLs), Xilinx devices, and design constraints for the Xilinx ISE<sup>TM</sup> software suite
- Discusses FPGA and CPLD optimization and coding techniques when creating designs for use with XST
- Explains how to run XST from the Project Navigator Process window, and from the command line

This chapter includes:

- "XST User Guide Contents"
- "Additional Resources"
- "Conventions"

### **XST User Guide Contents**

The XST User Guide includes:

- Chapter 1, "Introduction to the XST User Guide," provides general information about XST.
- Chapter 2, "XST HDL Coding Techniques," describes VHDL and Verilog coding techniques for digital logic circuits.
- Chapter 3, "XST FPGA Optimization," explains how constraints can be used to optimize FPGA devices; explains macro generation; and describes the supported Virtex<sup>™</sup> primitives.
- Chapter 4, "XST CPLD Optimization," discusses CPLD synthesis options and the implementation details for macro generation.
- Chapter 5, "XST Design Constraints," provides general information about XST design constraints, as well as information about specific constraints.
- Chapter 6, "XST VHDL Language Support," describes XST support for VHDL.
- Chapter 7, "XST Verilog Language Support," describes XST support for Verilog.
- Chapter 8, "XST Behavioral Verilog Language Support," describes XST support for Behavioral Verilog.
- Chapter 9, "XST Mixed Language Support," describes how to run an XST project that mixes Verilog and VHDL designs.
- Chapter 10, "XST Log Files," describes the XST log file.
- Chapter 11, "XST Naming Conventions," describes XST naming conventions.



• Chapter 12, "XST Command Line Mode," describes how to run XST using the command line.

## **Additional Resources**

To find additional documentation, see the Xilinx website at:

http://www.xilinx.com/literature

To search the Answer Database of silicon, software, and IP questions and answers, or to create a technical support WebCase, see the Xilinx website at:

http://www.xilinx.com/support

## **Conventions**

This document uses the following conventions. An example illustrates each convention.

### Typographical

The following typographical conventions are used in this document:

Convention	Meaning or Use	Example
Courier font	Messages, prompts, and program files that the system displays	speed grade: - 100
Courier bold	Literal commands that you enter in a syntactical statement	ngdbuild design_name
Helvetica bold	Commands that you select from a menu	File > Open
	Keyboard shortcuts	Ctrl+C
	Variables in a syntax statement for which you must supply values	ngdbuild design_name
Italic font	References to other manuals	See the <i>Development System</i> <i>Reference Guide</i> for more information.
	Emphasis in text	If a wire is drawn so that it overlaps the pin of a symbol, the two nets are <i>not</i> connected.
Square brackets []	An optional entry or parameter. However, in bus specifications, such as <b>bus [7:0]</b> , they are required.	<b>ngdbuild</b> [option_name] design_name
Braces { }	A list of items from which you must choose one or more	lowpwr ={on off}
Vertical bar	Separates items in a list of choices	lowpwr ={on off}

Convention	Meaning or Use	Example
Vertical ellipsis • • •	Repetitive material that has been omitted	IOB #1: Name = QOUT' IOB #2: Name = CLKIN'
Horizontal ellipsis	Repetitive material that has been omitted	<b>allow block</b> block_name loc1 loc2 locn;

## **Online Document**

The following conventions are used in this document:

Convention	Meaning or Use	Example
Blue text	Cross-reference link to a location in the current file or in another file in the current document	See the section "Additional Resources" for details. See "Title Formats" in Chapter 1 for details.
Red text	Cross-reference link to a location in another document	See Figure 2-5 in the Virtex-II <sup>TM</sup> Platform FPGA User Guide.
Blue, underlined text	Hyperlink to a website (URL)	Go to <u>http://www.xilinx.com</u> for the latest speed files.





# Chapter 1

# Introduction to the XST User Guide

This chapter (*Introduction to the XST User Guide*) provides general information about XST, and describes the changes to XST in this release. This chapter includes:

- "About XST"
- "What's New in Release 10.1"
- "Setting XST Options"

## About XST

Xilinx<sup>®</sup> Synthesis Technology (XST) is a Xilinx application that synthesizes Hardware Description Language (HDL) designs to create Xilinx-specific netlist files called NGC files. The NGC file is a netlist that contains both logical design data and constraints. The NGC file takes the place of both Electronic Data Interchange Format (EDIF) and Netlist Constraints File (NCF) files.

For more information about XST, see *Xilinx Synthesis Technology* (*XST*) - *Frequently Asked Questions* (*FAQ*) available from the Xilinx Support website at <u>http://www.xilinx.com/support</u>. Search for keyword XST FAQ.

### What's New in Release 10.1

Following are the major changes to XST for Release 10.1:

- "Macro Inference"
- "Constraints"
- "Libraries Support"

#### Macro Inference

- XST uses SRL dedicated resources if the shift register description contains a single asynchronous or synchronous set or reset signal. For more information, see "Shift Registers HDL Coding Techniques."
- XST provides improved RAM inference reporting. For detailed information about final RAM implementation, see the unit subsections of the Advanced HDL Synthesis step. For more information, see "RAMs and ROMs HDL Coding Techniques."

#### Constraints

 To disable automatic DSP resource management, specify a value of -1 for the "DSP Utilization Ratio (DSP\_UTILIZATION\_RATIO)" constraint.

- The "Netlist Hierarchy (-netlist\_hierarchy)" command line switch is now accessible from XST Synthesis Options in ISE.
- XST supports the "Save (S / SAVE)" constraint during synthesis optimization.
- The new "Reduce Control Sets (REDUCE\_CONTROL\_SETS)" command line switch allows control set management in XST for the Virtex-5 device family (LUT6 based architecture) in order to reduce area.
- The new "LUT Combining (LC)" command line switch enables LUT combining for the Virtex-5 device family (LUT6 based architecture) in orderto reduce area.

### Libraries Support

• XST now supports the new UNIMACRO library. UNIMACRO simplifies instantiation of complex Xilinx primitives. For more information, see "Virtex Primitive Support."

## **Setting XST Options**

Before synthesizing your design, you can set a variety of options for XST. For more information on setting XST options, see:

- ISE<sup>TM</sup> Help
- "XST Design Constraints"
- "XST Command Line Mode"

Designs are usually made up of combinatorial logic and macros such as flip-flops, adders, subtractors, counters, FSMs, and RAMs. The macros greatly improve performance of the synthesized designs. It is important to use coding techniques to model the macros so they are optimally processed by XST.

XST first tries to recognize (infer) as many macros as possible. These macros are then passed to the Low Level Optimization step. In order to obtain better optimization results, the macros are either preserved as separate blocks, or merged with surrounded logic. This filtering depends on the type and size of a macro. For example, by default, 2-to-1 multiplexers are not preserved by the optimization engine. Synthesis constraints control the processing of inferred macros. For more information, see "XST Design Constraints."



# Chapter 2

# **XST HDL Coding Techniques**

This chapter (*XST HDL Coding Techniques*) gives Hardware Description Language (HDL) coding examples for digital logic circuits. This chapter includes:

- "Signed and Unsigned Support in XST"
- "Registers HDL Coding Techniques"
- "Latches HDL Coding Techniques"
- "Tristates HDL Coding Techniques"
- "Counters HDL Coding Techniques"
- "Accumulators HDL Coding Techniques"
- "Shift Registers HDL Coding Techniques"
- "Dynamic Shift Registers HDL Coding Techniques"
- "Multiplexers HDL Coding Techniques"
- "Decoders HDL Coding Techniques"
- "Priority Encoders HDL Coding Techniques"
- "Logical Shifters HDL Coding Techniques"
- "Arithmetic Operators HDL Coding Techniques"
- "Adders, Subtractors, and Adders/Subtractors HDL Coding Techniques"
- "Comparators HDL Coding Techniques"
- "Multipliers HDL Coding Techniques"
- "Sequential Complex Multipliers HDL Coding Techniques"
- "Pipelined Multipliers HDL Coding Techniques"
- "Multiply Adder/Subtractors HDL Coding Techniques"
- "Multiply Accumulate HDL Coding Techniques"
- "Dividers HDL Coding Techniques"
- "Resource Sharing HDL Coding Techniques"
- "RAMs and ROMs HDL Coding Techniques"
- "Pipelined Distributed RAM HDL Coding Techniques"
- "Finite State Machines (FSMs) HDL Coding Techniques"
- "Black Boxes HDL Coding Techniques"

Most sections include:

- A general description of the macro
- A sample log file

- Constraints you can use to control the macro processing in XST
- VHDL and Verilog coding examples, including a schematic diagram and pin descriptions

For more information, see "XST FPGA Optimization" and "XST CPLD Optimization."

For information on accessing the synthesis templates from Project Navigator, see the ISE<sup>TM</sup> Help.

## Signed and Unsigned Support in XST

When using Verilog or VHDL in XST, some macros, such as adders or counters, can be implemented for signed and unsigned values.

To enable support for signed and unsigned values in Verilog, enable Verilog-2001 as follows:

- In Project Navigator, select **Verilog 2001** as instructed in the *Synthesis Options* topic of ISE Help, or
- Set the -verilog2001 command line option to yes.

For VHDL, depending on the operation and type of the operands, you must include additional packages in your code. For example, to create an unsigned adder, use the arithmetic packages and types that operate on unsigned values shown in Table 2-1, "Unsigned Adder."

Table 2-1: Unsigned Adder

PACKAGE	ТҮРЕ
numeric_std	unsigned
std_logic_arith	unsigned
std_logic_unsigned	std_logic_vector

To create a signed adder, use the arithmetic packages and types that operate on signed values shown in Table 2-2, "Signed Adder."

*Table 2-2:* Signed Adder

PACKAGE	ТҮРЕ
numeric_std	signed
std_logic_arith	signed
std_logic_signed	std_logic_vector

For more information about available types, see the IEEE VHDL Manual.

## **Registers HDL Coding Techniques**

This section discusses Registers HDL Coding Techniques, and includes:

- "About Registers"
- "Registers Log File"
- "Registers Related Constraints"
- "Registers Coding Examples"

#### About Registers

XST recognizes flip-flops with the following control signals:

- Asynchronous Set/Reset
- Synchronous Set/Reset
- Clock Enable


For more information, see "Specifying INIT and RLOC."

#### **Registers Log File**

The XST log file reports the type and size of recognized flip-flops during the Macro Recognition step.

```
. . .
_____
*
  HDL Synthesis
                            *
_____
Synthesizing Unit <registers_5>.
 Related source file is "registers_5.vhd".
 Found 4-bit register for signal <Q>.
 Summary:
   inferred 4 D-type flip-flop(s).
Unit <registers_5> synthesized.
HDL Synthesis Report
Macro Statistics
# Registers
                         : 1
4-bit register
                         : 1
_____
_____
*
       Advanced HDL Synthesis
                            *
_____
Advanced HDL Synthesis Report
Macro Statistics
# Registers
                         : 4
Flip-Flops/Latches
                         : 4
_____
. . .
```

www.xilinx.com



### **Registers Related Constraints**

- "Pack I/O Registers Into IOBs (IOB)"
- "Register Duplication (REGISTER\_DUPLICATION)"
- "Equivalent Register Removal (EQUIVALENT\_REGISTER\_REMOVAL)"
- "Register Balancing (REGISTER\_BALANCING)"

### **Registers Coding Examples**

This section gives the following Registers examples:

- "Flip-Flop With Positive-Edge Clock"
- "Flip-Flop With Negative-Edge Clock and Asynchronous Reset"
- "Flip-Flop With Positive-Edge Clock and Synchronous Set"
- "Flip-Flop With Positive-Edge Clock and Clock Enable"
- "4-Bit Register With Positive-Edge Clock, Asynchronous Set, and Clock Enable"

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>.

#### Flip-Flop With Positive-Edge Clock

This section discusses Flip-Flop With Positive-Edge Clock, and includes:

- "Flip-Flop With Positive-Edge Clock Diagram"
- "Flip-Flop With Positive-Edge Clock Pin Descriptions"
- "Flip-Flop With Positive Edge Clock VHDL Coding Example"
- "Flip-Flop With Positive-Edge Clock Verilog Coding Example"




Figure 2-1: Flip-Flop With Positive-Edge Clock Diagram

XILINX

Table 2-3. Flip-Flop With Positive-Edge Clock Fin Descriptions	
IO Pins	Description
D	Data Input
С	Positive-Edge Clock
Q	Data Output

Table 2-3: Flip-Flop With Positive-Edge Clock Pin Descriptions

Flip-Flop With Positive Edge Clock VHDL Coding Example

```
-- Flip-Flop with Positive-Edge Clock
_ _
library ieee;
use ieee.std_logic_1164.all;
entity registers_1 is
   port(C, D : in std_logic;
        Q : out std_logic);
end registers_1;
architecture archi of registers_1 is
begin
   process (C)
   begin
        if (C'event and C='1') then
           Q <= D;
        end if;
    end process;
end archi;
```

When using VHDL for a positive-edge clock, instead of using:

```
if (C'event and C='1') then
```

you can also use:

if (rising\_edge(C)) then


Flip-Flop With Positive-Edge Clock Verilog Coding Example

endmodule

#### Flip-Flop With Negative-Edge Clock and Asynchronous Reset

This section discusses Flip-Flop With Negative-Edge Clock and Asynchronous Reset, and includes:

- "Flip-Flop With Negative-Edge Clock and Asynchronous Reset Diagram"
- "Flip-Flop With Negative-Edge Clock and Asynchronous Reset Pin Descriptions"
- "Flip-Flop With Negative-Edge Clock and Asynchronous Reset VHDL Coding Example"
- "Flip-Flop With Negative-Edge Clock and Asynchronous Reset Verilog Coding Example"






Table 2-4:	Flip-Flop With Negative-Edge Clock and Asynchronous Reset Pin
Description	S

IO Pins	Description
D	Data Input
С	Negative-Edge Clock
CLR	Asynchronous Reset (Active High)
Q	Data Output

Flip-Flop With Negative-Edge Clock and Asynchronous Reset VHDL Coding Example

```
-- Flip-Flop with Negative-Edge Clock and Asynchronous Reset
--
library ieee;
use ieee.std_logic_1164.all;
entity registers_2 is
    port(C, D, CLR : in std_logic;
        Q : out std_logic);
end registers_2;
architecture archi of registers_2 is
begin
    process (C, CLR)
    begin
```

```
if (CLR = '1')then
    Q <= '0';
elsif (C'event and C='0')then
    Q <= D;
end if;
end process;
end archi;</pre>
```

Flip-Flop With Negative-Edge Clock and Asynchronous Reset Verilog Coding Example

```
11
// Flip-Flop with Negative-Edge Clock and Asynchronous Reset
11
module v_registers_2 (C, D, CLR, Q);
    input C, D, CLR;
    output Q;
   req
           0;
    always @(negedge C or posedge CLR)
   begin
        if (CLR)
            Q <= 1'b0;
        else
            Q \ll D;
    end
endmodule
```

#### Flip-Flop With Positive-Edge Clock and Synchronous Set

This section discusses Flip-Flop With Positive-Edge Clock and Synchronous Set, and includes:

- "Flip-Flop With Positive-Edge Clock and Synchronous Set Diagram"
- "Flip-Flop With Positive-Edge Clock and Synchronous Set Pin Descriptions"
- "Flip-Flop With Positive-Edge Clock and Synchronous Set VHDL Coding Example"
- "Flip-Flop With Positive-Edge Clock and Synchronous Set Verilog Coding Example"




Figure 2-3: Flip-Flop With Positive-Edge Clock and Synchronous Set Diagram

www.xilinx.com

\_ \_

IO Pins	Description
D	Data Input
С	Positive-Edge Clock
S	Synchronous Set (Active High)
Q	Data Output

Table 2-5: Flip-Flop With Positive-Edge Clock and Synchronous Set Pin Descriptions

Flip-Flop With Positive-Edge Clock and Synchronous Set VHDL Coding Example

```
-- Flip-Flop with Positive-Edge Clock and Synchronous Set
_ _
library ieee;
use ieee.std_logic_1164.all;
entity registers_3 is
   port(C, D, S : in std_logic;
        Q
               : out std_logic);
end registers_3;
architecture archi of registers_3 is
begin
   process (C)
   begin
        if (C'event and C='1') then
            if (S='1') then
                Q <= '1';
            else
                Q <= D;
            end if;
        end if;
    end process;
```

end archi;

Flip-Flop With Positive-Edge Clock and Synchronous Set Verilog Coding Example

```
//
// Flip-Flop with Positive-Edge Clock and Synchronous Set
//
module v_registers_3 (C, D, S, Q);
    input C, D, S;
    output Q;
    reg Q;
    always @(posedge C)
    begin
        if (S)
            Q <= 1'b1;
        else
            Q <= D;
        end</pre>
```

endmodule

#### Flip-Flop With Positive-Edge Clock and Clock Enable

This section discusses Flip-Flop With Positive-Edge Clock and Clock Enable, and includes:

- "Flip-Flop With Positive-Edge Clock and Clock Enable Diagram"
- "Flip-Flop With Positive-Edge Clock and Clock Enable Pin Descriptions"
- "Flip-Flop With Positive-Edge Clock and Clock Enable VHDL Coding Example"
- "Flip-Flop With Positive-Edge Clock and Clock Enable Verilog Coding Example"




Figure 2-4: Flip-Flop With Positive-Edge Clock and Clock Enable Diagram

IO Pins	Description
D	Data Input
С	Positive-Edge Clock
CE	Clock Enable (Active High)
Q	Data Output

Table 2-6: Flip-Flop With Positive-Edge Clock and Clock Enable Pin Descriptions

Flip-Flop With Positive-Edge Clock and Clock Enable VHDL Coding Example

```
-- Flip-Flop with Positive-Edge Clock and Clock Enable
library ieee;
use ieee.std_logic_1164.all;
entity registers_4 is
   port(C, D, CE : in std_logic;
                 : out std_logic);
         0
end registers_4;
architecture archi of registers_4 is
begin
    process (C)
   begin
        if (C'event and C='1') then
            if (CE='1') then
                Q <= D;
            end if;
        end if;
    end process;
end archi;
```




Flip-Flop With Positive-Edge Clock and Clock Enable Verilog Coding Example

```
//
// Flip-Flop with Positive-Edge Clock and Clock Enable
//
module v_registers_4 (C, D, CE, Q);
    input C, D, CE;
    output Q;
    reg Q;
    always @(posedge C)
    begin
        if (CE)
            Q <= D;
    end
endmodule</pre>
```

# 4-Bit Register With Positive-Edge Clock, Asynchronous Set, and Clock Enable

This section discusses 4-Bit Register With Positive-Edge Clock, Asynchronous Set, and Clock Enable, and includes:

- "Flip-Flop With Positive-Edge Clock and Clock Enable Diagram"
- "4-Bit Register With Positive-Edge Clock, Asynchronous Set, and Clock Enable Pin Descriptions"
- "4-Bit Register With Positive-Edge Clock, Asynchronous Set, and Clock Enable VHDL Coding Example"
- "4-Bit Register With Positive-Edge Clock, Asynchronous Set, and Clock Enable Verilog Coding Example"



*Figure 2-5:* 4-Bit Register With Positive-Edge Clock, Asynchronous Set, and Clock Enable Diagram

*Table 2-7:* 4-Bit Register With Positive-Edge Clock, Asynchronous Set, and Clock Enable Pin Descriptions

IO Pins	Description
D	Data Input
С	Positive-Edge Clock
PRE	Asynchronous Set (Active High)

*Table 2-7:* 4-Bit Register With Positive-Edge Clock, Asynchronous Set, and Clock Enable Pin Descriptions *(Cont'd)* 

IO Pins	Description
CE	Clock Enable (Active High)
Q	Data Output

4-Bit Register With Positive-Edge Clock, Asynchronous Set, and Clock Enable VHDL Coding Example

```
_ _
-- 4-bit Register with Positive-Edge Clock, Asynchronous Set and Clock
Enable
_ _
library ieee;
use ieee.std_logic_1164.all;
entity registers_5 is
   port(C, CE, PRE : in std_logic;
        D : in std_logic_vector (3 downto 0);
         Q
                   : out std_logic_vector (3 downto 0));
end registers_5;
architecture archi of registers_5 is
begin
    process (C, PRE)
    begin
        if (PRE='1') then
            Q <= "1111";
        elsif (C'event and C='1')then
            if (CE='1') then
                Q <= D;
            end if;
        end if;
    end process;
end archi;
```

4-Bit Register With Positive-Edge Clock, Asynchronous Set, and Clock Enable Verilog Coding Example

```
//
// 4-bit Register with Positive-Edge Clock, Asynchronous Set and Clock
Enable
//
module v_registers_5 (C, D, CE, PRE, Q);
    input C, CE, PRE;
    input [3:0] D;
    output [3:0] Q;
    reg [3:0] Q;
    always @(posedge C or posedge PRE)
    begin
        if (PRE)
```

www.xilinx.com



```
Q <= 4'b1111;
else
if (CE)
Q <= D;
end
endmodule
```

## Latches HDL Coding Techniques

This section discusses Latches HDL Coding Techniques, and includes:

- "About Latches"
- "Latches Log File"
- "Latches Related Constraints"
- "Latches Coding Examples"

#### **About Latches**

XST can recognize latches with asynchronous set/reset control signals. Latches can be described using:

- Process (VHDL) and always block (Verilog)
- Concurrent state assignment.

XST does not support Wait statements (VHDL) for latch descriptions.

#### Latches Log File

The XST log file reports the type and size of recognized latches during the Macro Recognition step.

```
. . .
Synthesizing Unit <latch>.
   Related source file is latch_1.vhd.
WARNING:Xst:737 - Found 1-bit latch for signal <q>.
   Summary:
       inferred 1 Latch(s).
Unit <latch> synthesized.
_____
HDL Synthesis Report
Macro Statistics
# Latches
                            • 1
  1-bit latch
                             : 1
_____
. . .
```

Latches Related Constraints

"Pack I/O Registers Into IOBs (IOB)"

### Latches Coding Examples

This section gives the following Latches examples:

- "Latch With Positive Gate"
- "Latch With Positive Gate and Asynchronous Reset"
- "4-Bit Latch With Inverted Gate and Asynchronous Set"

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>.

#### Latch With Positive Gate

This section discusses Latch With Positive Gate, and includes:

- "Latch With Positive Gate Diagram"
- "Latch With Positive Gate Pin Descriptions"
- "Latch With Positive Gate VHDL Coding Example"
- "Latch With Positive Gate Verilog Coding Example"




Figure 2-6: Latch With Positive Gate Diagram

Table 2-8: Latch With Positive Gate Pin Descriptions

IO Pins	Description
D	Data Input
G	Positive Gate
Q	Data Output

Latch With Positive Gate VHDL Coding Example

```
--
-- Latch with Positive Gate
--
library ieee;
use ieee.std_logic_1164.all;
entity latches_1 is
    port(G, D : in std_logic;
        Q : out std_logic);
end latches_1;
architecture archi of latches_1 is
begin
```



```
process (G, D)
begin
    if (G='1') then
        Q <= D;
        end if;
    end process;
end archi;</pre>
```

Latch With Positive Gate Verilog Coding Example

#### Latch With Positive Gate and Asynchronous Reset

This section discusses Latch With Positive Gate and Asynchronous Reset, and includes:

- "Latch With Positive Gate and Asynchronous Reset Diagram"
- "Latch With Positive Gate and Asynchronous Reset Pin Descriptions"
- "Latch With Positive Gate and Asynchronous Reset VHDL Coding Example"
- "Latch With Positive Gate and Asynchronous Reset Verilog Coding Example"




Figure 2-7: Latch With Positive Gate and Asynchronous Reset Diagram

IO Pins	Description			
D	Data Input			
G	Positive Gate			
CLR	Asynchronous Reset (Active High)			
Q	Data Output			

Table 2-9: Latch With Positive Gate and Asynchronous Reset Pin Descriptions

Latch With Positive Gate and Asynchronous Reset VHDL Coding Example

```
-- Latch with Positive Gate and Asynchronous Reset
_ _
library ieee;
use ieee.std_logic_1164.all;
entity latches_2 is
    port(G, D, CLR : in std_logic;
         Q : out std_logic);
end latches_2;
architecture archi of latches_2 is
begin
    process (CLR, D, G)
    begin
        if (CLR='1') then
            Q <= '0';
        elsif (G='1') then
            Q <= D;
        end if;
    end process;
end archi;
```

Latch With Positive Gate and Asynchronous Reset Verilog Coding Example

#### 4-Bit Latch With Inverted Gate and Asynchronous Set

This section discusses 4-Bit Latch With Inverted Gate and Asynchronous Set, and includes:

- "4-Bit Latch With Inverted Gate and Asynchronous Set Diagram"
- "4-Bit Latch With Inverted Gate and Asynchronous Set Pin Descriptions"
- "4-Bit Latch With Inverted Gate and Asynchronous Set VHDL Coding Example"
- "4-Bit Latch With Inverted Gate and Asynchronous Set Verilog Coding Example"

4-Bit Latch With Inverted Gate and Asynchronous Set Diagram




Figure 2-8: 4-Bit Latch With Inverted Gate and Asynchronous Set Diagram

4-Bit Latch With Inverted Gate and Asynchronous Set Pin Descriptions*Table 2-10:* 4-Bit Latch With Inverted Gate and Asynchronous Set Pin Descriptions

IO Pins	Description
D	Data Input
G	Inverted Gate
PRE	Asynchronous Preset (Active High)
Q	Data Output

4-Bit Latch With Inverted Gate and Asynchronous Set VHDL Coding Example

```
-- 4-bit Latch with Inverted Gate and Asynchronous Set
library ieee;
use ieee.std_logic_1164.all;
entity latches_3 is
   port(D : in std_logic_vector(3 downto 0);
        G, PRE : in std_logic;
               : out std_logic_vector(3 downto 0));
        Q
end latches_3;
architecture archi of latches_3 is
begin
   process (PRE, G, D)
   begin
        if (PRE='1') then
           Q <= "1111";
        elsif (G='0') then
```

```
Q <= D;
end if;
end process;
end archi;
```

4-Bit Latch With Inverted Gate and Asynchronous Set Verilog Coding Example

```
11
// 4-bit Latch with Inverted Gate and Asynchronous Set
11
module v_latches_3 (G, D, PRE, Q);
    input G, PRE;
    input [3:0] D;
    output [3:0] Q;
    reg [3:0] Q;
    always @(G or D or PRE)
    begin
        if (PRE)
           Q = 4'b1111;
        else if (~G)
           Q = D;
    end
endmodule
```

# **Tristates HDL Coding Techniques**

This section discusses Tristates HDL Coding Techniques, and includes:

- "About Tristates"
- "Tristates Log File"
- "Tristates Related Constraints"
- "Tristates Coding Examples"

#### **About Tristates**

Tristate elements can be described using:

- Combinatorial process (VHDL) and always block (Verilog)
- Concurrent assignment

In the "Tristates Coding Examples," comparing to 0 instead of 1 infers a BUFT primitive instead of a BUFE macro. The BUFE macro has an inverter on the E pin.

## **Tristates Log File**

The XST log file reports the type and size of recognized tristates during the Macro Recognition step.

```
Synthesizing Unit <three_st>.
Related source file is tristates_1.vhd.
Found 1-bit tristate buffer for signal <o>.
Summary:
```



```
inferred 1 Tristate(s).
Unit <three_st> synthesized.
HDL Synthesis Report
Macro Statistics
# Tristates : 1
1-bit tristate buffer : 1
```

# **Tristates Related Constraints**

"Convert Tristates to Logic (TRISTATE2LOGIC)"

#### **Tristates Coding Examples**

This section gives the following Tristate examples:

- "Tristate Description Using Combinatorial Process and Always Block"
- "Tristate Description Using Concurrent Assignment"

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>.

#### Tristate Description Using Combinatorial Process and Always Block

This section discusses Tristate Description Using Combinatorial Process and Always Block, and includes:

- "Tristate Description Using Combinatorial Process and Always Block Diagram"
- "Tristate Description Using Combinatorial Process and Always Block Pin Descriptions"
- "Tristate Description Using Combinatorial Process VHDL Coding Example"
- "Tristate Description Using Combinatorial Always Block Verilog Coding Example"




Figure 2-9: Tristate Description Using Combinatorial Process and Always Block Diagram

*Table 2-11:* Tristate Description Using Combinatorial Process and Always Block Pin Descriptions

IO Pins	Description		
Ι	Data Input		
Т	Output Enable (active Low)		
0	Data Output		

Tristate Description Using Combinatorial Process VHDL Coding Example

```
-- Tristate Description Using Combinatorial Process
_ _
library ieee;
use ieee.std_logic_1164.all;
entity three_st_1 is
    port(T : in std_logic;
        I : in std_logic;
        0 : out std_logic);
end three_st_1;
architecture archi of three_st_1 is
begin
   process (I, T)
   begin
        if (T='0') then
            O <= I;
        else
            O <= 'Z';
        end if;
    end process;
end archi;
```

Tristate Description Using Combinatorial Always Block Verilog Coding Example

```
11
// Tristate Description Using Combinatorial Always Block
11
module v_three_st_1 (T, I, O);
    input T, I;
    output O;
   reg
         0;
   always @(T or I)
   begin
        if (~T)
            0 = I;
        else
           O = 1'bZ;
    end
endmodule
```



#### Tristate Description Using Concurrent Assignment

This section discusses Tristate Description Using Concurrent Assignment, and includes:

- "Tristate Description Using Concurrent Assignment Diagram"
- "Tristate Description Using Concurrent Assignment Pin Descriptions"
- "Tristate Description Using Concurrent Assignment VHDL Coding Example"
- "Tristate Description Using Concurrent Assignment Verilog Coding Example"




Figure 2-10: Tristate Description Using Concurrent Assignment Diagram

Table 2-12:	Tristate Description	Using Concurre	nt Assianment Pin	Descriptions

IO Pins	Description
Ι	Data Input
Т	Output Enable (active Low)
0	Data Output

Tristate Description Using Concurrent Assignment VHDL Coding Example

```
-- Tristate Description Using Concurrent Assignment
--
library ieee;
use ieee.std_logic_1164.all;
entity three_st_2 is
    port(T : in std_logic;
        I : in std_logic;
        O : out std_logic);
end three_st_2;
architecture archi of three_st_2 is
begin
        O <= I when (T='0') else 'Z';
end archi;</pre>
```

Tristate Description Using Concurrent Assignment Verilog Coding Example

```
//
// Tristate Description Using Concurrent Assignment
//
module v_three_st_2 (T, I, O);
```

```
input T, I;
output O;
assign O = (~T) ? I: 1'bZ;
```

endmodule

# **Counters HDL Coding Techniques**

This section discusses Counters HDL Coding Techniques, and includes:

- "About Counters"
- "Counters Log File"
- "Counters Related Constraints"
- "Counters Coding Examples"

#### About Counters

XST recognizes counters with the following control signals:

- Asynchronous Set/Reset
- Synchronous Set/Reset
- Asynchronous/Synchronous Load (signal or constant or both)
- Clock Enable
- Modes (Up, Down, Up/Down)
- Mixture of all of the above

HDL coding styles for the following control signals are equivalent to those described in "Registers HDL Coding Techniques."

• Clock

. . .

- Asynchronous Set/Reset
- Synchronous Set/Reset

XST supports both unsigned and signed counters.

## **Counters Log File**

The XST log file reports the type and size of recognized counters during the Macro Recognition step.



```
4-bit up counter : 1
```

During synthesis, XST decomposes Counters on Adders and Registers if they do not contain synchronous load signals. This is done to create additional opportunities for timing optimization. Because of this, counters reported during the Macro Recognition step and in the overall statistics of recognized macros may not appear in the final report. Adders and registers are reported instead.

# **Counters Related Constraints**

- "Use DSP48 (USE\_DSP48)"
- "DSP Utilization Ratio (DSP\_UTILIZATION\_RATIO)"
- "Keep (KEEP)"

# Counters Coding Examples

This section gives the following Counters examples:

- "4-Bit Unsigned Up Counter With Asynchronous Reset"
- "4-Bit Unsigned Down Counter With Synchronous Set"
- "4-Bit Unsigned Up Counter With Asynchronous Load From Primary Input"
- "4-Bit Unsigned Up Counter With Synchronous Load With Constant"
- "4-Bit Unsigned Up Counter With Asynchronous Reset and Clock Enable"
- "4-Bit Unsigned Up/Down Counter With Asynchronous Reset"
- "4-Bit Signed Up Counter With Asynchronous Reset"
- "4-Bit Signed Up Counter With Asynchronous Reset and Modulo Maximum"

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>.

#### 4-Bit Unsigned Up Counter With Asynchronous Reset

This section discusses 4-Bit Unsigned Up Counter With Asynchronous Reset, and includes:

- "4-Bit Unsigned Up Counter With Asynchronous Reset Diagram"
- "4-Bit Unsigned Up Counter With Asynchronous Reset Pin Descriptions"
- "4-Bit Unsigned Up Counter With Asynchronous Reset VHDL Coding Example"
- "4-Bit Unsigned Up Counter With Asynchronous Reset Verilog Coding Example"




Figure 2-11: 4-Bit Unsigned Up Counter With Asynchronous Reset Diagram

Table 2-13: 4-Bit Unsigned Up Counter With Asynchronous Reset Pin Descriptions

IO Pins	Description
С	Positive-Edge Clock
CLR	Asynchronous Reset (Active High)
Q	Data Output

4-Bit Unsigned Up Counter With Asynchronous Reset VHDL Coding Example

```
_ _
-- 4-bit unsigned up counter with an asynchronous reset.
_ _
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity counters_1 is
    port(C, CLR : in std_logic;
         Q : out std_logic_vector(3 downto 0));
end counters_1;
architecture archi of counters_1 is
    signal tmp: std_logic_vector(3 downto 0);
begin
    process (C, CLR)
    begin
        if (CLR='1') then
            tmp <= "0000";</pre>
        elsif (C'event and C='1') then
            tmp \leq tmp + 1;
        end if;
    end process;
    Q <= tmp;
end archi;
```



4-Bit Unsigned Up Counter With Asynchronous Reset Verilog Coding Example

```
11
// 4-bit unsigned up counter with an asynchronous reset.
11
module v_counters_1 (C, CLR, Q);
    input C, CLR;
    output [3:0] Q;
    reg [3:0] tmp;
    always @(posedge C or posedge CLR)
    begin
        if (CLR)
            tmp <= 4'b0000;
        else
            tmp <= tmp + 1'b1;</pre>
    end
    assign Q = tmp;
endmodule
```

#### 4-Bit Unsigned Down Counter With Synchronous Set

This section discusses 4-Bit Unsigned Down Counter With Synchronous Set, and includes:

- "4-Bit Unsigned Down Counter With Synchronous Set VHDL Coding Example"
- "4-Bit Unsigned Down Counter With Synchronous Set Verilog Coding Example"




Figure 2-12: 4-Bit Unsigned Down Counter With Synchronous Set Diagram

Table 2-14:	4-Bit Unsigned Down	Counter With S	Synchronous Set Pin Descr	ptions

IO Pins	Description	
С	Positive-Edge Clock	
S	Synchronous Set (Active High)	
Q	Data Output	

\_\_\_

4-Bit Unsigned Down Counter With Synchronous Set VHDL Coding Example

```
-- 4-bit unsigned down counter with a synchronous set.
_ _
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity counters_2 is
    port(C, S : in std_logic;
         Q : out std_logic_vector(3 downto 0));
end counters_2;
architecture archi of counters_2 is
    signal tmp: std_logic_vector(3 downto 0);
begin
    process (C)
    begin
        if (C'event and C='1') then
            if (S='1') then
                tmp <= "1111";</pre>
            else
                tmp <= tmp - 1;</pre>
            end if;
        end if;
    end process;
    Q <= tmp;
end archi;
```

4-Bit Unsigned Down Counter With Synchronous Set Verilog Coding Example


```
11
// 4-bit unsigned down counter with a synchronous set.
11
module v_counters_2 (C, S, Q);
    input C, S;
    output [3:0] Q;
    reg [3:0] tmp;
    always @(posedge C)
    begin
        if (S)
            tmp <= 4'b1111;
        else
            tmp <= tmp - 1'b1;</pre>
    end
    assign Q = tmp;
endmodule
```



4-Bit Unsigned Up Counter With Asynchronous Load From Primary Input

This section discusses 4-Bit Unsigned Up Counter With Asynchronous Load From Primary Input, and includes:

- "4-Bit Unsigned Up Counter With Asynchronous Load From Primary Input Diagram"
- "4-Bit Unsigned Up Counter With Asynchronous Load From Primary Input Pin Descriptions"
- "4-Bit Unsigned Up Counter With Asynchronous Load From Primary Input VHDL Coding Example"
- "4-Bit Unsigned Up Counter With Asynchronous Load From Primary Input Verilog Coding Example"



*Figure 2-13:* 4-Bit Unsigned Up Counter With Asynchronous Load From Primary Input Diagram

*Table 2-15:* 4-Bit Unsigned Up Counter With Asynchronous Load From Primary Input Pin Descriptions

IO Pins	Description		
С	Positive-Edge Clock		
ALOAD	Asynchronous Load (Active High)		
D	Data Input		
Q	Data Output		

4-Bit Unsigned Up Counter With Asynchronous Load From Primary Input VHDL Coding Example

```
--
-- 4-bit Unsigned Up Counter with Asynchronous Load from Primary Input
--
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity counters_3 is
    port(C, ALOAD : in std_logic;
        D : in std_logic_vector(3 downto 0);
```

```
Q : out std_logic_vector(3 downto 0));
end counters_3;
architecture archi of counters_3 is
    signal tmp: std_logic_vector(3 downto 0);
begin
    process (C, ALOAD, D)
    begin
        if (ALOAD='1') then
            tmp <= D;
        elsif (C'event and C='1') then
            tmp <= tmp + 1;
        end if;
end process;
    Q <= tmp;
end archi;
```

4-Bit Unsigned Up Counter With Asynchronous Load From Primary Input Verilog Coding Example


```
11
// 4-bit Unsigned Up Counter with Asynchronous Load from Primary Input
11
module v_counters_3 (C, ALOAD, D, Q);
    input C, ALOAD;
    input [3:0] D;
   output [3:0] Q;
   reg [3:0] tmp;
    always @(posedge C or posedge ALOAD)
    begin
        if (ALOAD)
            tmp \leq D;
        else
            tmp <= tmp + 1'b1;</pre>
    end
    assign Q = tmp;
endmodule
```

#### 4-Bit Unsigned Up Counter With Synchronous Load With Constant

This section discusses 4-Bit Unsigned Up Counter With Synchronous Load With Constant, and includes:

- "4-Bit Unsigned Up Counter With Synchronous Load With Constant Diagram"
- "4-Bit Unsigned Up Counter With Synchronous Load With Constant Pin Descriptions"
- "4-Bit Unsigned Up Counter With Synchronous Load With Constant VHDL Coding Example"
- "4-Bit Unsigned Up Counter With Synchronous Load With Constant Verilog Coding Example"





X10529

Figure 2-14: 4-Bit Unsigned Up Counter With Synchronous Load With Constant Diagram

*Table 2-16:* 4-Bit Unsigned Up Counter With Synchronous Load With Constant Pin Descriptions

IO Pins	Description	
С	Positive-Edge Clock	
SLOAD	Synchronous Load (Active High)	
Q	Data Output	

4-Bit Unsigned Up Counter With Synchronous Load With Constant VHDL Coding Example

```
-- 4-bit Unsigned Up Counter with Synchronous Load with a Constant
_ _
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity counters_4 is
    port(C, SLOAD : in std_logic;
         Q : out std_logic_vector(3 downto 0));
end counters_4;
architecture archi of counters_4 is
    signal tmp: std_logic_vector(3 downto 0);
begin
   process (C)
    begin
        if (C'event and C='1') then
            if (SLOAD='1') then
                tmp <= "1010";</pre>
            else
                tmp <= tmp + 1;
            end if;
        end if;
    end process;
    Q \ll tmp;
end archi;
```


4-Bit Unsigned Up Counter With Synchronous Load With Constant Verilog Coding Example

```
11
\ensuremath{{//}} 4-bit Unsigned Up Counter with Synchronous Load with a Constant
11
module v_counters_4 (C, SLOAD, Q);
    input C, SLOAD;
    output [3:0] Q;
    reg [3:0] tmp;
    always @(posedge C)
    begin
        if (SLOAD)
            tmp <= 4'b1010;
        else
             tmp <= tmp + 1'b1;</pre>
    end
    assign Q = tmp;
endmodule
```

#### 4-Bit Unsigned Up Counter With Asynchronous Reset and Clock Enable

This section discusses 4-Bit Unsigned Up Counter With Asynchronous Reset and Clock Enable, and includes:

- "4-Bit Unsigned Up Counter With Asynchronous Reset and Clock Enable Diagram"
- "4-Bit Unsigned Up Counter With Asynchronous Reset and Clock Enable Pin Descriptions"
- "4-Bit Unsigned Up Counter With Asynchronous Reset and Clock Enable VHDL Coding Example"
- "4-Bit Unsigned Up Counter With Asynchronous Reset and Clock Enable Verilog Coding Example"



*Figure 2-15:* 4-Bit Unsigned Up Counter With Asynchronous Reset and Clock Enable Diagram

*Table 2-17:* 4-Bit Unsigned Up Counter With Asynchronous Reset and Clock Enable Pin Descriptions

IO Pins	Description		
С	Positive-Edge Clock		
CLR	Asynchronous Reset (Active High)		
CE	Clock Enable		
Q	Data Output		

4-Bit Unsigned Up Counter With Asynchronous Reset and Clock Enable VHDL Coding Example

```
-- 4-bit Unsigned Up Counter with Asynchronous Reset and Clock Enable
--
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity counters_5 is
    port(C, CLR, CE : in std_logic;
        Q : out std_logic_vector(3 downto 0));
```

```
end counters_5;
architecture archi of counters_5 is
    signal tmp: std_logic_vector(3 downto 0);
begin
    process (C, CLR)
    begin
        if (CLR='1') then
            tmp <= "0000";
        elsif (C'event and C='1') then
            if (CE='1') then
                tmp <= tmp + 1;</pre>
            end if;
        end if;
    end process;
    Q \ll tmp;
end archi;
```

4-Bit Unsigned Up Counter With Asynchronous Reset and Clock Enable Verilog Coding Example

```
11
// 4-bit Unsigned Up Counter with Asynchronous Reset and Clock Enable
11
module v_counters_5 (C, CLR, CE, Q);
    input C, CLR, CE;
    output [3:0] Q;
    reg [3:0] tmp;
    always @(posedge C or posedge CLR)
    begin
        if (CLR)
            tmp <= 4'b0000;
        else if (CE)
            tmp <= tmp + 1'b1;</pre>
    end
    assign Q = tmp;
endmodule
```

4-Bit Unsigned Up/Down Counter With Asynchronous Reset

This section discusses 4-Bit Unsigned Up/Down Counter With Asynchronous Reset, and includes:

- "4-Bit Unsigned Up/Down Counter With Asynchronous Reset Diagram"
- "4-Bit Unsigned Up/Down Counter With Asynchronous Reset Pin Descriptions"
- "4-Bit Unsigned Up/Down Counter With Asynchronous Reset VHDL Coding Example"
- "4-Bit Unsigned Up/Down Counter With Asynchronous Reset Verilog Coding Example"




Figure 2-16: 4-Bit Unsigned Up/Down Counter With Asynchronous Reset Diagram

Table 2-18:	4-Bit Unsigned	Up/Down	Counter	With	Asynchronous Reset Pin
Descriptions					

IO Pins	Description
С	Positive-Edge Clock
CLR	Asynchronous Reset (Active High)
UP_DOWN	Up/Down Count Mode Selector
Q	Data Output

4-Bit Unsigned Up/Down Counter With Asynchronous Reset VHDL Coding Example

```
-- -- 4-bit Unsigned Up/Down counter with Asynchronous Reset
--
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity counters_6 is
    port(C, CLR, UP_DOWN : in std_logic;
        Q : out std_logic_vector(3 downto 0));
end counters_6;
architecture archi of counters_6 is
    signal tmp: std_logic_vector(3 downto 0);
```

```
begin
    process (C, CLR)
    begin
        if (CLR='1') then
            tmp <= "0000";
    elsif (C'event and C='1') then
            if (UP_DOWN='1') then
            tmp <= tmp + 1;
            else
            tmp <= tmp - 1;
            end if;
        end if;
    end if;
    end process;
    Q <= tmp;
end archi;</pre>
```

4-Bit Unsigned Up/Down Counter With Asynchronous Reset Verilog Coding Example

```
11
// 4-bit Unsigned Up/Down counter with Asynchronous Reset
11
module v_counters_6 (C, CLR, UP_DOWN, Q);
    input C, CLR, UP_DOWN;
    output [3:0] Q;
    reg [3:0] tmp;
    always @(posedge C or posedge CLR)
    begin
        if (CLR)
           tmp <= 4'b0000;
        else if (UP_DOWN)
                tmp <= tmp + 1'b1;</pre>
            else
                tmp \leq tmp - 1'b1;
    end
    assign Q = tmp;
endmodule
```

#### 4-Bit Signed Up Counter With Asynchronous Reset

This section discusses 4-Bit Signed Up Counter With Asynchronous Reset, and includes:

- "4-Bit Signed Up Counter With Asynchronous Reset Diagram"
- "4-Bit Signed Up Counter With Asynchronous Reset Pin Descriptions"
- "4-Bit Signed Up Counter With Asynchronous Reset VHDL Coding Example"
- "4-Bit Signed Up Counter With Asynchronous Reset Verilog Coding Example"






Table 2-19: 4-Bit Signed Up Counter With Asynchronous Reset Pin Descriptions

IO Pins	Description
С	Positive-Edge Clock
CLR	Asynchronous Reset (Active High)
Q	Data Output

4-Bit Signed Up Counter With Asynchronous Reset VHDL Coding Example

```
-- 4-bit Signed Up Counter with Asynchronous Reset
_ _
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_signed.all;
entity counters_7 is
    port(C, CLR : in std_logic;
         Q : out std_logic_vector(3 downto 0));
end counters_7;
architecture archi of counters_7 is
    signal tmp: std_logic_vector(3 downto 0);
begin
   process (C, CLR)
   begin
        if (CLR='1') then
            tmp <= "0000";
```


4-Bit Signed Up Counter With Asynchronous Reset Verilog Coding Example

```
11
// 4-bit Signed Up Counter with Asynchronous Reset
11
module v_counters_7 (C, CLR, Q);
    input C, CLR;
    output signed [3:0] Q;
    reg signed [3:0] tmp;
    always @ (posedge C or posedge CLR)
    begin
        if (CLR)
            tmp <= 4'b0000;
        else
            tmp <= tmp + 1'b1;</pre>
    end
    assign Q = tmp;
endmodule
```

#### 4-Bit Signed Up Counter With Asynchronous Reset and Modulo Maximum

This section discusses 4-Bit Signed Up Counter With Asynchronous Reset and Modulo Maximum, and includes:

- "4-Bit Signed Up Counter With Asynchronous Reset and Modulo Maximum Diagram"
- "4-Bit Signed Up Counter With Asynchronous Reset and Modulo Maximum Pin Descriptions"
- "4-Bit Signed Up Counter With Asynchronous Reset and Modulo Maximum VHDL Coding Example"
- "4-Bit Signed Up Counter With Asynchronous Reset and Modulo Maximum Verilog Coding Example"



*Figure 2-18:* 4-Bit Signed Up Counter With Asynchronous Reset and Modulo Maximum Diagram

Table 2-20:	4-Bit Signed Up Counter	With Asynchronous	Reset and Modulo Maximum
Pin Descript	ions		

IO Pins	Description	
С	Positive-Edge Clock	
CLR	Asynchronous Reset (Active High)	
Q	Data Output	

4-Bit Signed Up Counter With Asynchronous Reset and Modulo Maximum VHDL Coding Example

```
--
-- 4-bit Signed Up Counter with Asynchronous Reset and Modulo Maximum
--
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_arith.all;
entity counters_8 is
   generic (MAX : integer := 16);
   port(C, CLR : in std_logic;
        Q : out integer range 0 to MAX-1);
```

```
end counters_8;
architecture archi of counters_8 is
    signal cnt : integer range 0 to MAX-1;
begin
    process (C, CLR)
    begin
        if (CLR='1') then
            cnt <= 0;
        elsif (rising_edge(C)) then
            cnt <= (cnt + 1) mod MAX ;
        end if;
    end process;
    Q <= cnt;
end archi;
```

4-Bit Signed Up Counter With Asynchronous Reset and Modulo Maximum Verilog Coding Example

```
11
// 4-bit Signed Up Counter with Asynchronous Reset and Modulo Maximum
11
module v_counters_8 (C, CLR, Q);
   parameter
        MAX_SQRT = 4,
        MAX = (MAX_SQRT*MAX_SQRT);
    input C, CLR;
    output [MAX_SQRT-1:0] Q;
    reg [MAX_SQRT-1:0] cnt;
    always @ (posedge C or posedge CLR)
    begin
        if (CLR)
           cnt <= 0;
        else
           cnt <= (cnt + 1) %MAX;
    end
    assign Q = cnt;
endmodule
```



# **Accumulators HDL Coding Techniques**

This section discusses Accumulators HDL Coding Techniques, and includes:

- "About Accumulators"
- "Accumulators in Virtex-4 and Virtex-5 Devices"
- "Accumulators Log File"
- "Accumulators Related Constraints"
- "Accumulators Coding Examples"

# About Accumulators

An accumulator differs from a counter in the nature of the operands of the add and subtract operation.

In a counter, the destination and first operand is a signal or variable and the other operand is a constant equal to 1:  $A \le A + 1$ .

In an accumulator, the destination and first operand is a signal or variable, and the second operand is either:

- A signal or variable: A <= A + B
- A constant not equal to 1: A <= A + Constant

An inferred accumulator can be up, down, or updown. For an updown accumulator, the accumulated data may differ between the up and down mode:

```
...
if updown = '1' then
    a <= a + b;
else
    a <= a - c;
...</pre>
```

XST can infer an accumulator with the same set of control signals available for counters. For more information, see "Counters HDL Coding Techniques."

## Accumulators in Virtex-4 and Virtex-5 Devices

Virtex-4 and Virtex-5 devices enable accumulators to be implemented on DSP48 resources. XST can push up to two levels of input registers into DSP48 blocks.

XST can implement an accumulator in a DSP48 block if its implementation requires only a single DSP48 resource. If an accumulator macro does not fit in a single DSP48, XST implements the entire macro using slice logic.

Macro implementation on DSP48 resources is controlled by the "Use DSP48 (USE\_DSP48)" constraint or command line option, with a default value of *auto*. In this mode, XST implements accumulators taking into account DSP48 resources on the device.

In *auto* mode, to control DSP48 resources for the synthesis use the "DSP Utilization Ratio (DSP\_UTILIZATION\_RATIO)" constraint. By default, XST tries to utilize all DSP48 resources. For more information, see "DSP48 Block Resources."

To deliver the best performance, XST by default tries to infer and implement the maximum macro configuration, including as many registers as possible in the DSP48. To shape a macro in a specific way, use the "Keep (KEEP)" constraint. For example, to exclude the first

register stage from the DSP48, place "Keep (KEEP)" constraints on the outputs of these registers.

As with other families, for Virtex-4 and Virtex-5, XST reports the details of inferred accumulators at the HDL Synthesis step. But in the Final Synthesis Report, accumulators are no longer visible, because they are implemented within the MAC implementation mechanism.

#### Accumulators Log File

The XST log file reports the type and size of recognized accumulators during the Macro Recognition step.

```
. . .
Synthesizing Unit <accum>.
    Related source file is accumulators_1.vhd.
    Found 4-bit up accumulator for signal <tmp>.
    Summary:
       inferred 1 Accumulator(s).
Unit <accum> synthesized.
_____
HDL Synthesis Report
Macro Statistics
# Accumulators
                              : 1
  4-bit up accumulator
                              : 1
_____
. . .
```

During synthesis, XST decomposes Accumulators on Adders and Registers if they do not contain synchronous load signals. This is done to create additional opportunities for timing optimization. Because of this, Accumulators reported during the Macro Recognition step and in the overall statistics of recognized macros may not appear in the final report. Adders/registers are reported instead.

#### Accumulators Related Constraints

- "Use DSP48 (USE\_DSP48)"
- "DSP Utilization Ratio (DSP\_UTILIZATION\_RATIO)"
- "Keep (KEEP)"

#### Accumulators Coding Examples

This section gives the following Accumulators examples:

"4-Bit Unsigned Up Accumulator With Asynchronous Reset"

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>.

#### 4-Bit Unsigned Up Accumulator With Asynchronous Reset

This section discusses 4-Bit Unsigned Up Accumulator With Asynchronous Reset, and includes:

- "4-Bit Unsigned Up Accumulator With Asynchronous Reset Diagram"
- "4-Bit Unsigned Up Accumulator With Asynchronous Reset Pin Descriptions"
- "4-Bit Unsigned Up Accumulator With Asynchronous Reset VHDL Coding Example"
- "4-Bit Unsigned Up Accumulator With Asynchronous Reset Verilog Coding Example"




Figure 2-19: 4-Bit Unsigned Up Accumulator With Asynchronous Reset Diagram

Table 2-21	4-Bit Unsigned Ur	Accumulator Wi	th Asynchronous	Reset Pin Descriptions
	4-Dit Ohaigheu Op	Accumulator W	III Asynchionous	

IO Pins	Description	
С	Positive-Edge Clock	
CLR	Asynchronous Reset (Active High)	
D	Data Input	
Q	Data Output	

4-Bit Unsigned Up Accumulator With Asynchronous Reset VHDL Coding Example

```
-- 4-bit Unsigned Up Accumulator with Asynchronous Reset
--
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity accumulators_1 is
    port(C, CLR : in std_logic;
        D : in std_logic_vector(3 downto 0);
        Q : out std_logic_vector(3 downto 0));
end accumulators_1;
architecture archi of accumulators_1 is
```

```
signal tmp: std_logic_vector(3 downto 0);
begin
    process (C, CLR)
    begin
        if (CLR='1') then
            tmp <= "0000";
        elsif (C'event and C='1') then
            tmp <= tmp + D;
        end if;
    end process;
    Q <= tmp;
end archi;
```

4-Bit Unsigned Up Accumulator With Asynchronous Reset Verilog Coding Example

```
11
// 4-bit Unsigned Up Accumulator with Asynchronous Reset
11
module v_accumulators_1 (C, CLR, D, Q);
    input C, CLR;
    input [3:0] D;
    output [3:0] Q;
    reg [3:0] tmp;
    always @(posedge C or posedge CLR)
   begin
        if (CLR)
           tmp = 4'b0000;
        else
           tmp = tmp + D;
        end
    assign Q = tmp;
endmodule
```

XILINX®

# Shift Registers HDL Coding Techniques

This section discusses Shift Registers HDL Coding Techniques, and includes:

- "About Shift Registers"
- "Describing Shift Registers"
- "Implementing Shift Registers"
- "Shift Registers Log File"
- "Shift Registers Related Constraints"
- "Shift Registers Coding Examples"

# **About Shift Registers**

In general, a shift register is characterized by the following control and data signals, which are fully recognized by XST:

- Clock
- Serial input
- Asynchronous set/reset
- Synchronous set/reset
- Synchronous/asynchronous parallel load
- Clock enable
- Serial or parallel output. The shift register output mode may be:
  - Serial

Only the contents of the last flip-flop are accessed by the rest of the circuit

Parallel

The contents of one or several flip-flops, other than the last one, are accessed

• Shift modes: for example, left, right

# **Describing Shift Registers**

Ways to describe shift registers in VHDL include:

• Concatenation operator

shreg <= shreg (6 downto 0) & SI;</pre>

• For loop construct

```
for i in 0 to 6 loop
   shreg(i+1) <= shreg(i);
end loop;
shreg(0) <= SI;</pre>
```

• Predefined shift operators; for example, SLL or SRL

For more information, see your VHDL and Verilog language reference manuals.

# **Implementing Shift Registers**

This section discusses Implementing Shift Registers, and includes:

- "Hardware Resources to Implement Shift Registers"
- "SRL16 and SRLC16"
- "SRL16 and SRLC16 Pin Layout Diagrams"

#### Hardware Resources to Implement Shift Registers

#### Table 2-22: Hardware Resources to Implement Shift Registers

	SRL16	SRL16E	SRLC16	SRLC16E	SRLC32E
Virtex <sup>™</sup> , Virtex-E	Yes	Yes	No	No	No
Spartan™-II, Spartan-IIE	Yes	Yes	No	No	No
Virtex-II, Virtex-II Pro	Yes	Yes	Yes	Yes	No
Spartan-3, Spartan-3-E, Spartan-3A	Yes	Yes	Yes	Yes	No
Virtex-4	Yes	Yes	Yes	Yes	No
Virtex-5	Yes	Yes	Yes	Yes	Yes

#### SRL16 and SRLC16

Both SRL16 and SRLC16 are available with or without a clock enable.

Synchronous and asynchronous control signals are not available in the SLRC16*x* primitives. However, XST takes advantage of dedicated SRL resources if a shift register description has only a single asynchronous or synchronous set or reset signal. Such implementation reduces area significantly.

SRL16 and SRLC16 support only LEFT shift operation for a limited number of IO signals:

- clock
- clock enable
- serial data in
- serial data out

If your shift register *does have*, for instance, a synchronous parallel load, or multiple set or reset signals, no SRL16 is implemented. XST uses specific internal processing which enables it to produce the best final results.

The XST log file reports recognized shift registers when it can be implemented using SRL16.

For more information, see "Specifying INIT and RLOC."

#### SRL16 and SRLC16 Pin Layout Diagrams

This section includes:

- "Pin Layout of SRL16E Diagram"
- "Pin Layout of SRLC16 Diagram"

Pin Layout of SRL16E Diagram




Figure 2-20: Pin Layout of SRL16E

Pin Layout of SRLC16 Diagram




Figure 2-21: Pin Layout of SRLC16

# Shift Registers Log File

. . .

XST recognizes shift registers in the Low Level Optimization step. The XST log file reports the size of recognized shift registers.

\* HDL Synthesis \*

Synthesizing Unit <shift\_registers\_1>.

Related source file is "shift\_registers\_1.vhd". Found 8-bit register for signal <tmp>. Summary: inferred 8 D-type flip-flop(s). Unit <shift\_registers\_1> synthesized. \_\_\_\_\_\_ Advanced HDL Synthesis ------Advanced HDL Synthesis Report Macro Statistics # Registers : 8 Flip-Flops : 8 \_\_\_\_\_\_ -----Low Level Synthesis \* \_\_\_\_\_ Processing Unit <shift\_registers\_1> : Found 8-bit shift register for signal <tmp\_7>. Unit <shift\_registers\_1> processed. ------Final Register Report Macro Statistics # Shift Registers : 1 8-bit shift register : 1 \_\_\_\_\_

## Shift Registers Related Constraints

• "Shift Register Extraction (SHREG\_EXTRACT)"

# Shift Registers Coding Examples

This section gives the following Shift Registers examples:


- "8-Bit Shift-Left Register With Positive-Edge Clock, Serial In and Serial Out"
- "8-Bit Shift-Left Register With Negative-Edge Clock, Clock Enable, Serial In and Serial Out"
- "8-Bit Shift-Left Register With Positive-Edge Clock, Asynchronous Reset, Serial In and Serial Out"
- "8-Bit Shift-Left Register With Positive-Edge Clock, Synchronous Set, Serial In and Serial Out"
- "8-Bit Shift-Left Register With Positive-Edge Clock, Serial In and Parallel Out"
- "8-Bit Shift-Left Register With Positive-Edge Clock, Asynchronous Parallel Load, Serial In and Serial Out"
- "8-Bit Shift-Left Register With Positive-Edge Clock, Synchronous Parallel Load, Serial In and Serial Out"
- "8-Bit Shift-Left/Shift-Right Register With Positive-Edge Clock, Serial In and Parallel Out"

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>

8-Bit Shift-Left Register With Positive-Edge Clock, Serial In and Serial Out

This section discusses 8-Bit Shift-Left Register With Positive-Edge Clock, Serial In and Serial Out, and includes:

- "8-Bit Shift-Left Register With Positive-Edge Clock, Serial In and Serial Out Diagram"
- "8-Bit Shift-Left Register With Positive-Edge Clock, Serial In and Serial Out Pin Descriptions"
- "8-Bit Shift-Left Register With Positive-Edge Clock, Serial In and Serial Out VHDL Coding Example"
- "8-Bit Shift-Left Register With Positive-Edge Clock, Serial In and Serial Out Verilog Coding Example"



X10534

*Figure 2-22:* 8-Bit Shift-Left Register With Positive-Edge Clock, Serial In and Serial Out Diagram

8-Bit Shift-Left Register With Positive-Edge Clock, Serial In and Serial Out Pin Descriptions *Table 2-23:* 8-Bit Shift-Left Register With Positive-Edge Clock, Serial In and Serial Out Pin Descriptions

IO Pins	Description
С	Positive-Edge Clock
SI	Serial In
SO	Serial Output

8-Bit Shift-Left Register With Positive-Edge Clock, Serial In and Serial Out VHDL Coding Example

```
--
-- 8-bit Shift-Left Register with Positive-Edge Clock, Serial In, and
Serial Out
--
library ieee;
use ieee.std_logic_1164.all;
entity shift_registers_1 is
    port(C, SI : in std_logic;
        SO : out std_logic);
end shift_registers_1;
```

```
architecture archi of shift_registers_1 is
    signal tmp: std_logic_vector(7 downto 0);
begin
    process (C)
    begin
        if (C'event and C='1') then
            for i in 0 to 6 loop
               tmp(i+1) <= tmp(i);
        end loop;
            tmp(0) <= SI;
        end if;
    end process;
    S0 <= tmp(7);
end archi;
```

8-Bit Shift-Left Register With Positive-Edge Clock, Serial In and Serial Out Verilog Coding Example


```
//
// 8-bit Shift-Left Register with Positive-Edge Clock,
// Serial In, and Serial Out
//
module v_shift_registers_1 (C, SI, SO);
    input C,SI;
    output SO;
    reg [7:0] tmp;
    always @(posedge C)
    begin
       tmp = {tmp[6:0], SI};
    end
    assign SO = tmp[7];
endmodule
```

# 8-Bit Shift-Left Register With Negative-Edge Clock, Clock Enable, Serial In and Serial Out


This section discusses 8-Bit Shift-Left Register With Negative-Edge Clock, Clock Enable, Serial In and Serial Out, and includes:

- "8-Bit Shift-Left Register With Negative-Edge Clock, Clock Enable, Serial In and Serial Out Diagram"
- "8-Bit Shift-Left Register With Negative-Edge Clock, Clock Enable, Serial In and Serial Out Pin Descriptions"
- "8-Bit Shift-Left Register With Negative-Edge Clock, Clock Enable, Serial In and Serial Out VHDL Coding Example"
- "8-Bit Shift-Left Register With Negative-Edge Clock, Clock Enable, Serial In and Serial Out Verilog Coding Example"





X10535



*Table 2-24:* 8-Bit Shift-Left Register With Negative-Edge Clock, Clock Enable, Serial In and Serial Out Pin Descriptions

IO Pins	Description
С	Negative-Edge Clock
SI	Serial In
CE	Clock Enable (Active High)
SO	Serial Output

8-Bit Shift-Left Register With Negative-Edge Clock, Clock Enable, Serial In and Serial Out VHDL Coding Example

```
_ _
-- 8-bit Shift-Left Register with Negative-Edge Clock, Clock Enable,
-- Serial In, and Serial Out
_ _
library ieee;
use ieee.std_logic_1164.all;
entity shift_registers_2 is
    port(C, SI, CE : in std_logic;
         S0 : out std_logic);
end shift_registers_2;
architecture archi of shift_registers_2 is
    signal tmp: std_logic_vector(7 downto 0);
begin
    process (C)
    begin
        if (C'event and C='0') then
            if (CE='1') then
                 for i in 0 to 6 loop
                     tmp(i+1) <= tmp(i);</pre>
                end loop;
                 tmp(0) <= SI;</pre>
            end if;
```

```
end if;
end process;
SO <= tmp(7);
end archi;
```


8-Bit Shift-Left Register With Negative-Edge Clock, Clock Enable, Serial In and Serial Out Verilog Coding Example

```
11
// 8-bit Shift-Left Register with Negative-Edge Clock, Clock Enable,
// Serial In, and Serial Out
11
module v_shift_registers_2 (C, CE, SI, SO);
    input C,SI, CE;
   output SO;
   reg [7:0] tmp;
   always @(negedge C)
   begin
        if (CE)
        begin
           tmp = {tmp[6:0], SI};
        end
    end
    assign SO = tmp[7];
endmodule
```

## 8-Bit Shift-Left Register With Positive-Edge Clock, Asynchronous Reset, Serial In and Serial Out

This section discusses 8-Bit Shift-Left Register With Positive-Edge Clock, Asynchronous Reset, Serial In and Serial Out, and includes:

- "8-Bit Shift-Left Register With Positive-Edge Clock, Asynchronous Reset, Serial In and Serial Out Diagram"
- "8-Bit Shift-Left Register With Positive-Edge Clock, Asynchronous Reset, Serial In and Serial Out Pin Descriptions"
- "8-Bit Shift-Left Register With Positive-Edge Clock, Asynchronous Reset, Serial In and Serial Out VHDL Coding Example"
- "8-Bit Shift-Left Register With Positive-Edge Clock, Asynchronous Reset, Serial In and Serial Out Verilog Coding Example"



*Figure 2-24:* 8-Bit Shift-Left Register With Positive-Edge Clock, Asynchronous Reset, Serial In and Serial Out Diagram

*Table 2-25:* 8-Bit Shift-Left Register With Positive-Edge Clock, Asynchronous Reset, Serial In and Serial Out Pin Descriptions

IO Pins	Description	
С	Positive-Edge Clock	
SI	Serial In	
CLR	Asynchronous Reset (Active High)	

8-Bit Shift-Left Register With Positive-Edge Clock, Asynchronous Reset, Serial In and Serial Out VHDL Coding Example

```
--
-- 8-bit Shift-Left Register with Positive-Edge Clock,
-- Asynchronous Reset,Serial In, and Serial Out
--
library ieee;
use ieee.std_logic_1164.all;
entity shift_registers_3 is
    port(C, SI, CLR : in std_logic;
        SO : out std_logic);
end shift_registers_3;
architecture archi of shift_registers_3 is
```

```
signal tmp: std_logic_vector(7 downto 0);
begin
    process (C, CLR)
    begin
        if (CLR='1') then
            tmp <= (others => '0');
        elsif (C'event and C='1') then
            tmp <= tmp(6 downto 0) & SI;
        end if;
    end process;
    S0 <= tmp(7);
end archi;
```


8-Bit Shift-Left Register With Positive-Edge Clock, Asynchronous Reset, Serial In and Serial Out Verilog Coding Example

```
11
// 8-bit Shift-Left Register with Positive-Edge Clock,
// Asynchronous Reset, Serial In, and Serial Out
11
module v_shift_registers_3 (C, CLR, SI, SO);
    input C,SI,CLR;
    output SO;
    reg [7:0] tmp;
    always @(posedge C or posedge CLR)
    begin
        if (CLR)
            tmp <= 8'b0000000;
        else
            tmp <= {tmp[6:0], SI};</pre>
    end
    assign SO = tmp[7];
endmodule
```

8-Bit Shift-Left Register With Positive-Edge Clock, Synchronous Set, Serial In and Serial Out

This section discusses 8-Bit Shift-Left Register With Positive-Edge Clock, Synchronous Set, Serial In and Serial Out, and includes:

- "8-Bit Shift-Left Register With Positive-Edge Clock, Synchronous Set, Serial In and Serial Out Diagram"
- "8-Bit Shift-Left Register With Positive-Edge Clock, Synchronous Set, Serial In and Serial Out Pin Descriptions"
- "8-Bit Shift-Left Register With Positive-Edge Clock, Synchronous Set, Serial In and Serial Out VHDL Coding Example"
- "8-Bit Shift-Left Register With Positive-Edge Clock, Synchronous Set, Serial In and Serial Out Verilog Coding Example"



X10537

*Figure 2-25:* 8-Bit Shift-Left Register With Positive-Edge Clock, Synchronous Set, Serial In and Serial Out Diagram

*Table 2-26:* 8-Bit Shift-Left Register With Positive-Edge Clock, Synchronous Set, Serial In and Serial Out Pin Descriptions

IO Pins	Description
С	Positive-Edge Clock
SI	Serial In
S	Synchronous Set (Active High)
SO	Serial Output

8-Bit Shift-Left Register With Positive-Edge Clock, Synchronous Set, Serial In and Serial Out VHDL Coding Example

```
--
--
-- 8-bit Shift-Left Register with Positive-Edge Clock, Synchronous Set,
-- Serial In, and Serial Out
--
library ieee;
use ieee.std_logic_1164.all;
```

```
entity shift_registers_4 is
   port(C, SI, S : in std_logic;
         SO : out std_logic);
end shift_registers_4;
architecture archi of shift_registers_4 is
    signal tmp: std_logic_vector(7 downto 0);
begin
    process (C, S)
   begin
        if (C'event and C='1') then
            if (S='1') then
                tmp <= (others => '1');
            else
                tmp <= tmp(6 downto 0) & SI;</pre>
            end if;
        end if;
    end process;
    SO <= tmp(7);
end archi;
```

8-Bit Shift-Left Register With Positive-Edge Clock, Synchronous Set, Serial In and Serial Out Verilog Coding Example


```
11
// 8-bit Shift-Left Register with Positive-Edge Clock, Synchronous Set,
// Serial In, and Serial Out
11
module v_shift_registers_4 (C, S, SI, SO);
    input C,SI,S;
    output SO;
    reg [7:0] tmp;
    always @(posedge C)
    begin
        if (S)
            tmp <= 8'b11111111;</pre>
        else
             tmp <= {tmp[6:0], SI};</pre>
    end
    assign SO = tmp[7];
endmodule
```



### 8-Bit Shift-Left Register With Positive-Edge Clock, Serial In and Parallel Out

This section discusses 8-Bit Shift-Left Register with Positive-Edge Clock, Serial In and Parallel Out, and includes:

- "8-Bit Shift-Left Register with Positive-Edge Clock, Serial In and Parallel Out Diagram"
- "8-Bit Shift-Left Register With Positive-Edge Clock, Serial In and Parallel Out Pin Descriptions"
- "8-Bit Shift-Left Register With Positive-Edge Clock, Serial In and Parallel Out VHDL Coding Example"
- "8-Bit Shift-Left Register With Positive-Edge Clock, Serial In and Parallel Out Verilog Coding Example"



X10538

*Figure 2-26:* 8-Bit Shift-Left Register with Positive-Edge Clock, Serial In and Parallel Out Diagram

*Table 2-27:* 8-Bit Shift-Left Register With Positive-Edge Clock, Serial In and Parallel Out Pin Descriptions

IO Pins	Description	
С	Positive-Edge Clock	
SI	Serial In	
РО	Parallel Output	

8-Bit Shift-Left Register With Positive-Edge Clock, Serial In and Parallel Out VHDL Coding Example

```
--
--
-- 8-bit Shift-Left Register with Positive-Edge Clock,
-- Serial In, and Parallel Out
--
library ieee;
use ieee.std_logic_1164.all;
entity shift_registers_5 is
   port(C, SI : in std_logic;
        PO : out std_logic_vector(7 downto 0));
```

```
end shift_registers_5;
architecture archi of shift_registers_5 is
    signal tmp: std_logic_vector(7 downto 0);
begin
    process (C)
    begin
        if (C'event and C='1') then
            tmp <= tmp(6 downto 0)& SI;
        end if;
    end process;
    P0 <= tmp;
end archi;
```

8-Bit Shift-Left Register With Positive-Edge Clock, Serial In and Parallel Out Verilog Coding Example


```
//
// 8-bit Shift-Left Register with Positive-Edge Clock,
// Serial In, and Parallel Out
//
module v_shift_registers_5 (C, SI, PO);
    input C,SI;
    output [7:0] PO;
    reg [7:0] tmp;
    always @(posedge C)
       tmp <= {tmp[6:0], SI};
    assign PO = tmp;
endmodule</pre>
```


### 8-Bit Shift-Left Register With Positive-Edge Clock, Asynchronous Parallel Load, Serial In and Serial Out

This section discusses 8-Bit Shift-Left Register With Positive-Edge Clock, Asynchronous Parallel Load, Serial In and Serial Out, and includes:

- "8-Bit Shift-Left Register With Positive-Edge Clock, Asynchronous Parallel Load, Serial In and Serial Out Diagram"
- "8-Bit Shift-Left Register With Positive-Edge Clock, Asynchronous Parallel Load, Serial In and Serial Out Pin Descriptions"
- "8-Bit Shift-Left Register With Positive-Edge Clock, Asynchronous Parallel Load, Serial In and Serial Out VHDL Coding Example"
- "8-Bit Shift-Left Register With Positive-Edge Clock, Asynchronous Parallel Load, Serial In and Serial Out Verilog Coding Example"







*Table 2-28:* 8-Bit Shift-Left Register With Positive-Edge Clock, Asynchronous Parallel Load, Serial In and Serial Out Pin Descriptions

IO Pins	Description
С	Positive-Edge Clock
SI	Serial In
ALOAD	Asynchronous Parallel Load (Active High)
D	Data Input
SO	Serial Output

8-Bit Shift-Left Register With Positive-Edge Clock, Asynchronous Parallel Load, Serial In and Serial Out VHDL Coding Example

```
_ _
-- 8-bit Shift-Left Register with Positive-Edge Clock,
-- Asynchronous Parallel Load, Serial In, and Serial Out
_ _
library ieee;
use ieee.std_logic_1164.all;
entity shift_registers_6 is
    port(C, SI, ALOAD : in std_logic;
         D : in std_logic_vector(7 downto 0);
         SO : out std_logic);
end shift_registers_6;
architecture archi of shift_registers_6 is
    signal tmp: std_logic_vector(7 downto 0);
begin
    process (C, ALOAD, D)
    begin
        if (ALOAD='1') then
            tmp <= D;</pre>
        elsif (C'event and C='1') then
            tmp <= tmp(6 downto 0) & SI;</pre>
```

```
end if;
end process;
SO <= tmp(7);
end archi;
```

8-Bit Shift-Left Register With Positive-Edge Clock, Asynchronous Parallel Load, Serial In and Serial Out Verilog Coding Example


```
11
// 8-bit Shift-Left Register with Positive-Edge Clock,
// Asynchronous Parallel Load, Serial In, and Serial Out
11
module v_shift_registers_6 (C, ALOAD, SI, D, SO);
    input C,SI,ALOAD;
    input [7:0] D;
    output SO;
    reg [7:0] tmp;
    always @(posedge C or posedge ALOAD)
    begin
        if (ALOAD)
           tmp <= D;
        else
            tmp <= {tmp[6:0], SI};</pre>
    end
    assign SO = tmp[7];
endmodule
```

### 8-Bit Shift-Left Register With Positive-Edge Clock, Synchronous Parallel Load, Serial In and Serial Out


This section discusses 8-Bit Shift-Left Register With Positive-Edge Clock, Synchronous Parallel Load, Serial In and Serial Out, and includes:

- "8-Bit Shift-Left Register With Positive-Edge Clock, Synchronous Parallel Load, Serial In and Serial Out Diagram"
- "8-Bit Shift-Left Register With Positive-Edge Clock, Synchronous Parallel Load, Serial In and Serial Out Pin Descriptions"
- "8-Bit Shift-Left Register With Positive-Edge Clock, Synchronous Parallel Load, Serial In and Serial Out VHDL Coding Example"
- "8-Bit Shift-Left Register With Positive-Edge Clock, Synchronous Parallel Load, Serial In and Serial Out Verilog Coding Example"





X10540



*Table 2-29:* 8-Bit Shift-Left Register With Positive-Edge Clock, Synchronous Parallel Load, Serial In and Serial Out Pin Descriptions

IO Pins	Description
С	Positive-Edge Clock
SI	Serial In
SLOAD	Synchronous Parallel Load (Active High)
D	Data Input
SO	Serial Output

8-Bit Shift-Left Register With Positive-Edge Clock, Synchronous Parallel Load, Serial In and Serial Out VHDL Coding Example

```
-- 8-bit Shift-Left Register with Positive-Edge Clock,
-- Synchronous Parallel Load, Serial In, and Serial Out
_ _
library ieee;
use ieee.std_logic_1164.all;
entity shift_registers_7 is
    port(C, SI, SLOAD : in std_logic;
         D : in std_logic_vector(7 downto 0);
         SO : out std_logic);
end shift_registers_7;
architecture archi of shift_registers_7 is
    signal tmp: std_logic_vector(7 downto 0);
begin
    process (C)
    begin
        if (C'event and C='1') then
            if (SLOAD='1') then
                tmp <= D;</pre>
            else
```

```
tmp <= tmp(6 downto 0) & SI;
end if;
end if;
end process;
S0 <= tmp(7);
end archi;
```

8-Bit Shift-Left Register With Positive-Edge Clock, Synchronous Parallel Load, Serial In and Serial Out Verilog Coding Example


```
11
// 8-bit Shift-Left Register with Positive-Edge Clock,
// Synchronous Parallel Load, Serial In, and Serial Out
11
module v_shift_registers_7 (C, SLOAD, SI, D, SO);
    input C,SI,SLOAD;
    input [7:0] D;
    output SO;
    reg [7:0] tmp;
    always @(posedge C)
    begin
        if (SLOAD)
            tmp <= D;
        else
            tmp <= {tmp[6:0], SI};</pre>
    end
    assign SO = tmp[7];
endmodule
```

# 8-Bit Shift-Left/Shift-Right Register With Positive-Edge Clock, Serial In and Parallel Out

This section discusses 8-Bit Shift-Left/Shift-Right Register With Positive-Edge Clock, Serial In and Parallel Out, and includes:

- "8-Bit Shift-Left/Shift-Right Register With Positive-Edge Clock, Serial In and Parallel Out Diagram"
- "8-Bit Shift-Left/Shift-Right Register With Positive-Edge Clock, Serial In and Parallel Out Pin Descriptions"
- "8-Bit Shift-Left/Shift-Right Register With Positive-Edge Clock, Serial In and Parallel Out VHDL Coding Example"
- "8-Bit Shift-Left/Shift-Right Register With Positive-Edge Clock, Serial In and Parallel Out Verilog Coding Example"





X10541

*Figure 2-29:* 8-Bit Shift-Left/Shift-Right Register With Positive-Edge Clock, Serial In and Parallel Out Diagram

*Table 2-30:* 8-Bit Shift-Left/Shift-Right Register With Positive-Edge Clock, Serial In and Parallel Out Pin Descriptions

IO Pins	Description
С	Positive-Edge Clock
SI	Serial In
LEFT_RIGHT	Left/right shift mode selector
РО	Parallel Output

8-Bit Shift-Left/Shift-Right Register With Positive-Edge Clock, Serial In and Parallel Out VHDL Coding Example

```
_ _
-- 8-bit Shift-Left/Shift-Right Register with Positive-Edge Clock,
-- Serial In, and Parallel Out
_ _
library ieee;
use ieee.std_logic_1164.all;
entity shift_registers_8 is
    port(C, SI, LEFT_RIGHT : in std_logic;
         PO : out std_logic_vector(7 downto 0));
end shift_registers_8;
architecture archi of shift_registers_8 is
    signal tmp: std_logic_vector(7 downto 0);
begin
    process (C)
    begin
        if (C'event and C='1') then
            if (LEFT_RIGHT='0') then
                 tmp <= tmp(6 downto 0) & SI;</pre>
            else
                 tmp <= SI & tmp(7 downto 1);</pre>
            end if;
        end if;
```

```
end process;
PO <= tmp;
end archi;
```

8-Bit Shift-Left/Shift-Right Register With Positive-Edge Clock, Serial In and Parallel Out Verilog Coding Example

```
11
// 8-bit Shift-Left/Shift-Right Register with Positive-Edge Clock,
// Serial In, and Parallel Out
11
module v_shift_registers_8 (C, SI, LEFT_RIGHT, PO);
    input C,SI,LEFT_RIGHT;
    output [7:0] PO;
    reg [7:0] tmp;
    always @(posedge C)
    begin
        if (LEFT_RIGHT==1'b0)
          tmp <= {tmp[6:0], SI};</pre>
        else
          tmp <= {SI, tmp[7:1]};</pre>
    end
    assign PO = tmp;
endmodule
```

# **Dynamic Shift Registers HDL Coding Techniques**

This section discusses Dynamic Shift Registers HDL Coding Techniques, and includes:

- "About Dynamic Shift Registers"
- "Dynamic Shift Registers Log File"
- "Dynamic Shift Registers Related Constraints"
- "Dynamic Shift Registers Coding Examples"

### About Dynamic Shift Registers

XST can infer Dynamic Shift Registers. Once a dynamic shift register has been identified, its characteristics are handed to the XST macro generator for optimal implementation using the primitives shown in Table 2-31, "Implementing Dynamic Shift Registers."

	SRL16	SRL16E	SRLC16	SRLC16E	SRLC32E
Virtex, Virtex-E	Yes	Yes	No	No	No
Spartan-II, Spartan-IIE	Yes	Yes	No	No	No
Virtex-II, Virtex-II Pro	Yes	Yes	Yes	Yes	No

Table 2-31: Implementing Dynamic Shift Registers

	SRL16	SRL16E	SRLC16	SRLC16E	SRLC32E
Spartan-3, Spartan-3-E, Spartan-3A	Yes	Yes	Yes	Yes	No
Virtex-4	Yes	Yes	Yes	Yes	No
Virtex-5	Yes	Yes	Yes	Yes	Yes

# Dynamic Shift Registers Log File

The recognition of dynamic shift registers happens in the Advanced HDL Synthesis step. The XST log file reports the size of recognized dynamic shift registers during the Macro Recognition step.

```
. . .
_____
*
         HDL Synthesis
-----
Synthesizing Unit <dynamic_shift_registers_1>.
  Related source file is "dynamic_shift_registers_1.vhd".
  Found 1-bit 16-to-1 multiplexer for signal <Q>.
  Found 16-bit register for signal <SRL_SIG>.
  Summary:
     inferred 16 D-type flip-flop(s).
     inferred 1 Multiplexer(s).
Unit <dynamic_shift_registers_1> synthesized.
_____
      Advanced HDL Synthesis
-----
Synthesizing (advanced) Unit <dynamic_shift_registers_1>.
     Found 16-bit dynamic shift register for signal <Q>.
Unit <dynamic_shift_registers_1> synthesized (advanced).
------
HDL Synthesis Report
Macro Statistics
                          : 1
# Shift Registers
16-bit dynamic shift register
                           : 1
_____
```

### **Dynamic Shift Registers Related Constraints**

• "Shift Register Extraction (SHREG\_EXTRACT)"

### **Dynamic Shift Registers Coding Examples**

This section gives the following Dynamic Shift Registers examples:


• "16-Bit Dynamic Shift Register With Positive-Edge Clock, Serial In and Serial Out"

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>.

### 16-Bit Dynamic Shift Register With Positive-Edge Clock, Serial In and Serial Out

This section discusses 16-Bit Dynamic Shift Register With Positive-Edge Clock, Serial In and Serial Out, and includes:

- "16-Bit Dynamic Shift Register With Positive-Edge Clock, Serial In and Serial Out"
- "16-Bit Dynamic Shift Register With Positive-Edge Clock, Serial In and Serial Out Pin Descriptions"
- "16-Bit Dynamic Shift Register With Positive-Edge Clock, Serial In and Serial Out VHDL Coding Example"
- "16-Bit Dynamic Shift Register With Positive-Edge Clock, Serial In and Serial Out Verilog Coding Example"



X10542

*Figure 2-30:* 16-Bit Dynamic Shift Register With Positive-Edge Clock, Serial In and Serial Out

Table 2-32, "16-Bit Dynamic Shift Register With Positive-Edge Clock, Serial In and Serial Out Pin Descriptions," shows pin descriptions for a dynamic register. The register can:

- Be either serial or parallel
- Be left or right
- Have a synchronous or asynchronous reset
- Have a depth up to 16 bits.

*Table 2-32:* 16-Bit Dynamic Shift Register With Positive-Edge Clock, Serial In and Serial Out Pin Descriptions

IO Pins	Description
С	Positive-Edge Clock
SI	Serial In
AClr	Asynchronous Reset
SClr	Synchronous Reset
SLoad	Synchronous Parallel Load
Data	Parallel Data Input Port
ClkEn	Clock Enable

www.xilinx.com

*Table 2-32:* 16-Bit Dynamic Shift Register With Positive-Edge Clock, Serial In and Serial Out Pin Descriptions *(Cont'd)* 

IO Pins	Description
LeftRight	Direction selection
SerialInRight	Serial Input Right for Bidirectional Shift Register
PSO	Serial or Parallel Output

16-Bit Dynamic Shift Register With Positive-Edge Clock, Serial In and Serial Out VHDL Coding Example

```
_ _
-- 16-bit dynamic shift register.
_ _
library IEEE;
use IEEE.std_logic_1164.all;
use IEEE.std_logic_unsigned.all;
entity dynamic_shift_registers_1 is
    port(CLK : in std_logic;
         DATA : in std_logic;
         CE : in std_logic;
         A : in std_logic_vector(3 downto 0);
         Q : out std_logic);
end dynamic_shift_registers_1;
architecture rtl of dynamic_shift_registers_1 is
    constant DEPTH_WIDTH : integer := 16;
    type SRL_ARRAY is array (0 to DEPTH_WIDTH-1) of std_logic;
    -- The type SRL_ARRAY can be array
    -- (0 to DEPTH_WIDTH-1) of
    -- std_logic_vector(BUS_WIDTH downto 0)
    -- or array (DEPTH_WIDTH-1 downto 0) of
    -- std_logic_vector(BUS_WIDTH downto 0)
    -- (the subtype is forward (see below))
    signal SRL_SIG : SRL_ARRAY;
begin
    PROC_SRL16 : process (CLK)
    begin
        if (CLK'event and CLK = '1') then
            if (CE = '1') then
                SRL_SIG <= DATA & SRL_SIG(0 to DEPTH_WIDTH-2);</pre>
            end if;
        end if;
    end process;
    Q <= SRL_SIG(conv_integer(A));</pre>
end rtl;
```

16-Bit Dynamic Shift Register With Positive-Edge Clock, Serial In and Serial Out Verilog Coding Example

# **Multiplexers HDL Coding Techniques**

This section discusses Multiplexers HDL Coding Techniques, and includes:

- "About Multiplexers"
- "Multiplexers Case Statements"
- "Multiplexers Log File"
- "Multiplexers Related Constraints"
- "Multiplexers Coding Examples"

### **About Multiplexers**

XST supports different description styles for multiplexers (MUXs), such as **If-Then-Else** or **Case**. When writing MUXs, pay special attention in order to avoid common traps. For example, if you describe a MUX using a **Case** statement, and you do not specify all values of the selector, the result may be latches instead of a multiplexer. Writing MUXs you can also use **don't cares** to describe selector values.

During the Macro Inference step, XST makes a decision to infer or not infer the MUXs. For example, if the MUX has several inputs that are the same, then XST can decide not to infer it. If you do want to infer the MUX, force XST by using the MUX\_EXTRACT constraint.

If you use Verilog, remember that Verilog **Case** statements can be full or not full, and they can also be parallel or not parallel. A **Case** statement is:

- FULL if all possible branches are specified
- PARALLEL if it does not contain branches that can be executed simultaneously



### **Multiplexers Case Statements**

This section discusses Multiplexers Case Statements, and includes:

- "Multiplexers Case Statement Examples"
- "Verilog Case Implementation Style Parameter"
- "Verilog Case Statement Resources"

#### Multiplexers Case Statement Examples

Following are three examples of **Case** statements:

- "Full and Parallel Case Statement Example"
- "Not Full But Parallel Case Statement Example"
- "Neither Full Nor Parallel Case Statement Example"

#### Full and Parallel Case Statement Example

```
module full (sel, i1, i2, i3, i4, o1);
input [1:0] sel;
input [1:0] i1, i2, i3, i4;
output [1:0] o1;
reg [1:0] o1;
always @(sel or i1 or i2 or i3 or i4)
begin
    case (sel)
    2'b00: o1 = i1;
    2'b01: o1 = i2;
    2'b10: o1 = i3;
    2'b11: o1 = i4;
    endcase
end
endmodule
```

#### Not Full But Parallel Case Statement Example

```
module notfull (sel, i1, i2, i3, o1);
input [1:0] sel;
input [1:0] i1, i2, i3;
output [1:0] o1;
reg [1:0] o1;
always @(sel or i1 or i2 or i3)
begin
    case (sel)
    2'b00: o1 = i1;
    2'b01: o1 = i2;
    2'b10: o1 = i3;
    endcase
end
endmodule
```

#### Neither Full Nor Parallel Case Statement Example

```
module notfull_notparallel (sel1, sel2, i1, i2, o1);
input [1:0] sel1, sel2;
input [1:0] i1, i2;
output [1:0] o1;
reg [1:0] o1;
always @(sel1 or sel2)
begin
    case (2'b00)
        sel1: o1 = i1;
        sel2: o1 = i2;
        endcase
end
endmodule
```

XST automatically determines the characteristics of the Case statements and generates logic using multiplexers, priority encoders, and latches that best implement the exact behavior of the Case statement.

### Verilog Case Implementation Style Parameter

This characterization of the Case statements can be guided or modified by using the Case Implementation Style parameter. For more information, see "XST Design Constraints." Accepted values for this parameter are **none**, **full**, **parallel**, and **full-parallel**.

- If **none** (default) is used, XST implements the exact behavior of the Case statements.
- If **full** is used, XST considers that Case statements are complete and avoids latch creation.
- If **parallel** is used, XST considers that the branches cannot occur in parallel and does not use a priority encoder.
- If **full-parallel** is used, XST considers that Case statements are complete and that the branches cannot occur in parallel, therefore saving latches and priority encoders.

### Verilog Case Statement Resources

Table 2-33, "Verilog Case Statement Resources," indicates the *resources* used to synthesize the "Multiplexers Case Statement Examples" using the four Case Implementation Styles. The term *resources* means the functionality. For example, if you code the Case statement neither full nor parallel with Case Implementation Style set to **none**, from the functionality point of view, XST implements a priority encoder + latch. But, it does not inevitably mean that XST infers the priority encoder during the Macro Recognition step.

Parameter Value		Case Implementation			
Falameter value	Full	Not Full	Neither Full nor Parallel		
none	MUX	Latch	Priority Encoder + Latch		
parallel	MUX	Latch	Latch		
full	MUX	MUX	Priority Encoder		
full-parallel	MUX	MUX	MUX		

Table 2-33: Verilog Case Statement Resources



Specifying **full**, **parallel** or **full-parallel** may result in an implementation with a behavior that may differ from the behavior of the initial model.

### **Multiplexers Log File**

The XST log file reports the type and size of recognized MUXs during the Macro Recognition step.

```
. . .
Synthesizing Unit <mux>.
    Related source file is multiplexers_1.vhd.
    Found 1-bit 4-to-1 multiplexer for signal <o>.
    Summary:
       inferred 1 Multiplexer(s).
Unit <mux> synthesized.
_____
HDL Synthesis Report
Macro Statistics
                              : 1
# Multiplexers
  1-bit 4-to-1 multiplexer
                               : 1
_____
. . .
```

### **Multiplexers Related Constraints**

- "Mux Extraction (MUX\_EXTRACT)"
- "Mux Style (MUX\_STYLE)"
- "Enumerated Encoding (ENUM\_ENCODING)"

### Multiplexers Coding Examples

This section gives the following Multiplexers examples:

- "4-to-1 1-Bit MUX Using IF Statement"
- "4-to-1 1-Bit MUX Using Case Statement"
- "4-to-1 1-Bit MUX Using Tristate Buffers"
- "No 4-to-1 MUX (3-to-1 1-Bit MUX With 1-Bit Latch)"

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>.

#### 4-to-1 1-Bit MUX Using IF Statement

This section discusses 4-to-1 1-Bit MUX Using IF Statement, and includes:

- "4-to-1 1-Bit MUX Using IF Statement Diagram"
- "4-to-1 1-Bit MUX Using IF Statement Pin Descriptions"
- "4-to-1 1-Bit MUX Using IF Statement VHDL Coding Example"
- "4-to-1 1-Bit MUX Using IF Statement Verilog Coding Example"




Figure 2-31: 4-to-1 1-Bit MUX Using IF Statement Diagram

Table 2-34: 4-to-1 1-Bit MUX Using IF Statement Pin Descriptions

IO Pins	Description
a, b, c, d	Data Inputs
S	MUX Selector
0	Data Output

4-to-1 1-Bit MUX Using IF Statement VHDL Coding Example

```
-- 4-to-1 1-bit MUX using an If statement.
_ _
library ieee;
use ieee.std_logic_1164.all;
entity multiplexers_1 is
    port (a, b, c, d : in std_logic;
          s : in std_logic_vector (1 downto 0);
          o : out std_logic);
end multiplexers_1;
architecture archi of multiplexers_1 is
begin
    process (a, b, c, d, s)
    begin
        if (s = "00") then o <= a;
        elsif (s = "01") then o \leq b;
        elsif (s = "10") then o \leq c;
        else o <= d;
        end if;
    end process;
end archi;
```

4-to-1 1-Bit MUX Using IF Statement Verilog Coding Example

```
11
// 4-to-1 1-bit MUX using an If statement.
11
module v_multiplexers_1 (a, b, c, d, s, o);
    input a,b,c,d;
    input [1:0] s;
    output o;
    reg o;
    always @(a or b or c or d or s)
    begin
        if (s == 2'b00) \circ = a;
        else if (s == 2'b01) o = b;
        else if (s == 2'b10) o = c;
        else o = d;
    end
endmodule
```

### 4-to-1 1-Bit MUX Using Case Statement

This section discusses 4-to-1 1-Bit MUX Using Case Statement, and includes:

- "4-to-1 1-Bit MUX Using Case Statement Diagram"
- "4-to-1 1-Bit MUX Using Case Statement Pin Descriptions"
- "4-to-1 1-Bit MUX Using Case Statement VHDL Coding Example"
- "4-to-1 1-Bit MUX Using Case Statement Verilog Coding Example"




Figure 2-32: 4-to-1 1-Bit MUX Using Case Statement Diagram

Table 2-35: 4-to-1 1-Bit MUX Using Case Statement Pin Descriptions

IO Pins	Description
a, b, c, d	Data Inputs

Table 2-35: 4-to-1 1-Bit MUX Using Case Statement Pin Descriptions (Cont'd)

IO Pins	Description
S	MUX Selector
0	Data Output

4-to-1 1-Bit MUX Using Case Statement VHDL Coding Example

```
_ _
-- 4-to-1 1-bit MUX using a Case statement.
_ _
library ieee;
use ieee.std_logic_1164.all;
entity multiplexers_2 is
    port (a, b, c, d : in std_logic;
          s : in std_logic_vector (1 downto 0);
          o : out std_logic);
end multiplexers_2;
architecture archi of multiplexers_2 is
begin
   process (a, b, c, d, s)
   begin
        case s is
            when "00" => o <= a;
            when "01" => o <= b;
            when "10" => o <= c;
            when others \Rightarrow o <= d;
        end case;
    end process;
end archi;
```

4-to-1 1-Bit MUX Using Case Statement Verilog Coding Example

```
11
// 4-to-1 1-bit MUX using a Case statement.
11
module v_multiplexers_2 (a, b, c, d, s, o);
    input a,b,c,d;
    input [1:0] s;
    output o;
    reg o;
    always @(a or b or c or d or s)
    begin
        case (s)
            2'b00 : o = a;
            2'b01 : o = b;
            2'b10 : o = c;
            default : o = d;
        endcase
    end
endmodule
```



#### 4-to-1 1-Bit MUX Using Tristate Buffers

This section discusses 4-to-1 1-Bit MUX Using Tristate Buffers, and includes:

- "4-to-1 1-Bit MUX Using Tristate Buffers Diagram"
- "4-to-1 1-Bit MUX Using Tristate Buffers Pin Descriptions"
- "4-to-1 1-Bit MUX Using Tristate Buffers VHDL Coding Example"
- "4-to-1 1-Bit MUX Using Tristate Buffers Verilog Coding Example"




Figure 2-33: 4-to-1 1-Bit MUX Using Tristate Buffers Diagram

Table 2-36: 4-to-1 1-Bit MUX Using Tristate Buffers Pin Descriptions

IO Pins	Description
a, b, c, d	Data Inputs
s	MUX Selector
0	Data Output

4-to-1 1-Bit MUX Using Tristate Buffers VHDL Coding Example

```
-- 4-to-1 1-bit MUX using tristate buffers.
_ _
library ieee;
use ieee.std_logic_1164.all;
entity multiplexers_3 is
    port (a, b, c, d : in std_logic;
          s : in std_logic_vector (3 downto 0);
          o : out std logic);
end multiplexers_3;
architecture archi of multiplexers_3 is
begin
    o \ll a when (s(0)='0') else 'Z';
    o \leq b when (s(1)='0') else 'Z';
    o <= c when (s(2)='0') else 'Z';</pre>
    o \le d when (s(3)='0') else 'Z';
end archi;
```

4-to-1 1-Bit MUX Using Tristate Buffers Verilog Coding Example

```
//
// 4-to-1 1-bit MUX using tristate buffers.
//
module v_multiplexers_3 (a, b, c, d, s, o);
input a,b,c,d;
input [3:0] s;
output 0;
assign o = s[3] ? a :1'bz;
assign o = s[2] ? b :1'bz;
assign o = s[1] ? c :1'bz;
assign o = s[0] ? d :1'bz;
endmodule
```

#### No 4-to-1 MUX (3-to-1 1-Bit MUX With 1-Bit Latch)

This section discusses No 4-to-1 MUX (3-to-1 1-Bit MUX With 1-Bit Latch), and includes:


- "XST HDL Advisor Message Example"
- "3-to-1 1-Bit MUX With 1-Bit Latch Diagram"
- "3-to-1 1-Bit MUX With 1-Bit Latch Pin Descriptions"
- "3-to-1 1-Bit MUX With 1-Bit Latch VHDL Coding Example"
- "3-to-1 1-Bit MUX With 1-Bit Latch Verilog Coding Example"

#### XST HDL Advisor Message Example

The following XST HDL Advisor Message does not generate a 4-to-1 1-bit MUX, but rather a 3-to-1 MUX With 1-Bit Latch. Since not all selector values were described in the **If** statement, XST assumes that, for the **s=11 case**, **o** keeps its old value, and that a memory element is needed.

WARNING:Xst:737 - Found 1-bit latch for signal <o1>.

INFO:Xst - HDL ADVISOR - Logic functions respectively driving the data and gate enable inputs of this latch share common terms. This situation will potentially lead to setup/hold violations and, as a result, to simulation problems. This situation may come from an incomplete case statement (all selector values are not covered). You should carefully review if it was in your intentions to describe such a latch



X10545

#### Figure 2-34: 3-to-1 1-Bit MUX With 1-Bit Latch Diagram

Table 2-37: 3-to-1 1-Bit MUX With 1-Bit Latch Pin Descriptions

IO Pins	Description
a, b, c	Data Inputs
s	MUX Selector
0	Data Output

3-to-1 1-Bit MUX With 1-Bit Latch VHDL Coding Example

```
-- 3-to-1 1-bit MUX with a 1-bit latch.
_ _
library ieee;
use ieee.std_logic_1164.all;
entity multiplexers_4 is
    port (a, b, c: in std_logic;
          s : in std_logic_vector (1 downto 0);
          o : out std_logic);
end multiplexers_4;
architecture archi of multiplexers_4 is
begin
    process (a, b, c, s)
    begin
        if (s = "00") then o \le a;
        elsif (s = "01") then o \leq b;
        elsif (s = "10") then o \leq c;
        end if;
    end process;
end archi;
```

3-to-1 1-Bit MUX With 1-Bit Latch Verilog Coding Example

```
//
// 3-to-1 1-bit MUX with a 1-bit latch.
//
module v_multiplexers_4 (a, b, c, s, o);
    input a,b,c;
    input [1:0] s;
    output o;
    reg o;
    always @(a or b or c or s)
    begin
        if (s == 2'b00) o = a;
        else if (s == 2'b01) o = b;
        else if (s == 2'b10) o = c;
    end
endmodule
```

# **Decoders HDL Coding Techniques**

This section discusses Decoders HDL Coding Techniques, and includes:

- "About Decoders"
- "Decoders Log File"
- "Decoders Related Constraints"
- "Decoders Coding Examples"

### About Decoders

A decoder is a multiplexer whose inputs are all constant with distinct one-hot (or one-cold) coded values. For more information, see "Multiplexers HDL Coding Techniques."

### **Decoders Log File**

The XST log file reports the type and size of recognized decoders during the Macro Recognition step.

### **Decoders Related Constraints**

• "Decoder Extraction (DECODER\_EXTRACT)"

### **Decoders Coding Examples**

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>

- "1-of-8 Decoder (One-Hot)"
- "1-of-8 Decoder (One-Cold)"
- "Decoder With Unselected Outputs"

#### 1-of-8 Decoder (One-Hot)

This section discusses 1-of-8 Decoder (One-Hot), and includes:

- "1-of-8 Decoder (One-Hot) Diagram"
- "1-of-8 Decoders (One-Hot) Pin Descriptions"
- "1-of-8 Decoder (One-Hot) VHDL Coding Example"
- "1-of-8 decoder (One-Hot) Verilog Coding Example"




Figure 2-35: 1-of-8 Decoder (One-Hot) Diagram

Table 2-38: 1-of-8 Decoders (One-Hot) Pin Descriptions

IO Pins	Description
S	Selector
res	Data Output

1-of-8 Decoder (One-Hot) VHDL Coding Example

```
--
-- 1-of-8 decoder (One-Hot)
--
library ieee;
use ieee.std_logic_1164.all;
entity decoders_1 is
```

```
port (sel: in std_logic_vector (2 downto 0);
        res: out std_logic_vector (7 downto 0));
    end decoders_1;
architecture archi of decoders_1 is
begin
    res <= "00000001" when sel = "000" else
        "0000010" when sel = "001" else
        "0000100" when sel = "010" else
        "00001000" when sel = "011" else
        "00010000" when sel = "100" else
        "00100000" when sel = "101" else
        "01000000" when sel = "101" else
        "1000000";
end archi;
```

1-of-8 decoder (One-Hot) Verilog Coding Example

```
11
// 1-of-8 decoder (One-Hot)
11
module v_decoders_1 (sel, res);
    input [2:0] sel;
    output [7:0] res;
    reg [7:0] res;
    always @(sel or res)
   begin
        case (sel)
            3'b000 : res = 8'b00000001;
            3'b001 : res = 8'b00000010;
            3'b010 : res = 8'b00000100;
            3'b011 : res = 8'b00001000;
            3'b100 : res = 8'b00010000;
            3'b101 : res = 8'b00100000;
            3'b110 : res = 8'b01000000;
            default : res = 8'b1000000;
        endcase
    end
endmodule
```

1-of-8 Decoder (One-Cold)

This section discusses 1-of-8 Decoder (One-Cold), and includes:

- "1-of-8 Decoder (One-Cold) Pin Descriptions"
- "1-of-8 decoder (One-Cold) VHDL Coding Example"

• "1-of-8 Decoder (One-Cold) Verilog Coding Example"

Table 2-39:	1-of-8 Decoder (	(One-Cold)	Pin Descriptions

IO Pins	Description
S	Selector
res	Data Output

www.xilinx.com



1-of-8 decoder (One-Cold) VHDL Coding Example

```
___
-- 1-of-8 decoder (One-Cold)
___
library ieee;
use ieee.std_logic_1164.all;
entity decoders_2 is
    port (sel: in std_logic_vector (2 downto 0);
          res: out std_logic_vector (7 downto 0));
end decoders_2;
architecture archi of decoders_2 is
begin
    res <= "11111110" when sel = "000" else
           "11111101" when sel = "001" else
           "11111011" when sel = "010" else
           "11110111" when sel = "011" else
           "11101111" when sel = "100" else
           "11011111" when sel = "101" else
           "10111111" when sel = "110" else
           "01111111";
end archi;
```

1-of-8 Decoder (One-Cold) Verilog Coding Example

```
11
// 1-of-8 decoder (One-Cold)
11
module v_decoders_2 (sel, res);
    input [2:0] sel;
    output [7:0] res;
    reg [7:0] res;
    always @(sel)
    begin
        case (sel)
            3'b000 : res = 8'b11111110;
            3'b001 : res = 8'b11111101;
            3'b010 : res = 8'b11111011;
            3'b011 : res = 8'b11110111;
            3'b100 : res = 8'b11101111;
            3'b101 : res = 8'b11011111;
            3'b110 : res = 8'b10111111;
            default : res = 8'b01111111;
        endcase
    end
endmodule
```

### Decoder With Unselected Outputs

This section discusses Decoder With Unselected Outputs, and includes:

- "Decoder With Unselected Outputs Pin Descriptions"
- "No Decoder Inference (Unused Decoder Output) VHDL Coding Example"
- "No Decoder Inference (Unused Decoder Output) Verilog Coding Example"
- "No Decoder Inference (Some Selector Values Unused) VHDL Coding Example"
- "No Decoder Inference (Some Selector Values Unused) Verilog Coding Example"

Table 2-40: Decoder With Unselected Outputs Pin Descriptions

IO Pins	Description
S	Selector
res	Data Output

No Decoder Inference (Unused Decoder Output) VHDL Coding Example

```
-- No Decoder Inference (unused decoder output)
_ _
library ieee;
use ieee.std_logic_1164.all;
entity decoders_3 is
   port (sel: in std_logic_vector (2 downto 0);
         res: out std_logic_vector (7 downto 0));
end decoders_3;
architecture archi of decoders_3 is
begin
   res <= "00000001" when sel = "000" else
           -- unused decoder output
           "XXXXXXXX" when sel = "001" else
           "00000100" when sel = "010" else
           "00001000" when sel = "011" else
           "00010000" when sel = "100" else
           "00100000" when sel = "101" else
           "01000000" when sel = "110" else
           "10000000";
end archi;
```

No Decoder Inference (Unused Decoder Output) Verilog Coding Example

```
//
// No Decoder Inference (unused decoder output)
//
module v_decoders_3 (sel, res);
    input [2:0] sel;
    output [7:0] res;
    reg [7:0] res;
    always @(sel)
    begin
```



```
case (sel)
    3'b000 : res = 8'b00000001;
    // unused decoder output
    3'b001 : res = 8'bxxxxxxx;
    3'b010 : res = 8'b00000000;
    3'b011 : res = 8'b00010000;
    3'b100 : res = 8'b00100000;
    3'b101 : res = 8'b01000000;
    3'b110 : res = 8'b01000000;
    default : res = 8'b10000000;
    endcase
    end
endmodule
```

No Decoder Inference (Some Selector Values Unused) VHDL Coding Example

```
_ _
-- No Decoder Inference (some selector values are unused)
_ _
library ieee;
use ieee.std_logic_1164.all;
entity decoders_4 is
    port (sel: in std_logic_vector (2 downto 0);
          res: out std_logic_vector (7 downto 0));
end decoders_4;
architecture archi of decoders_4 is
begin
    res <= "00000001" when sel = "000" else
           "00000010" when sel = "001" else
           "00000100" when sel = "010" else
           "00001000" when sel = "011" else
           "00010000" when sel = "100" else
           "00100000" when sel = "101" else
           -- 110 and 111 selector values are unused
           "XXXXXXXX";
end archi;
```

No Decoder Inference (Some Selector Values Unused) Verilog Coding Example

```
//
// No Decoder Inference (some selector values are unused)
//
module v_decoders_4 (sel, res);
    input [2:0] sel;
    output [7:0] res;
    reg [7:0] res;
    always @(sel or res)
    begin
        case (sel)
            3'b000 : res = 8'b0000001;
            3'b010 : res = 8'b0000010;
            3'b010 : res = 8'b0000100;
            3'b011 : res = 8'b00000100;
            3'b010 : res = 8'b00000100;
            3'b010 : res = 8'b000
```

```
3'bl00 : res = 8'b00010000;
3'bl01 : res = 8'b00100000;
// 110 and 111 selector values are unused
default : res = 8'bxxxxxxx;
endcase
end
endmodule
```

# **Priority Encoders HDL Coding Techniques**

This section discusses Priority Encoders HDL Coding Techniques, and includes:

- "About Priority Encoders"
- "Priority Encoders Log File"
- "Priority Encoders Related Constraints"
- "Priority Encoders Coding Examples"

### **About Priority Encoders**

XST can recognize a priority encoder, but in most cases XST does not infer it. To force priority encoder inference, use "Priority Encoder Extraction (PRIORITY\_EXTRACT)" with the value *force*. Xilinx® recommends that you use "Priority Encoder Extraction (PRIORITY\_EXTRACT)" on a signal-by-signal basis. Otherwise, "Priority Encoder Extraction (PRIORITY\_EXTRACT)" may guide you towards sub-optimal results.

### **Priority Encoders Log File**

The XST log file reports the type and size of recognized priority encoders during the Macro Recognition step.

### **Priority Encoders Related Constraints**

• "Priority Encoder Extraction (PRIORITY\_EXTRACT)"

### Priority Encoders Coding Examples

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>.

• "3-Bit 1-of-9 Priority Encoder"

#### 3-Bit 1-of-9 Priority Encoder

This section discusses 3-Bit 1-of-9 Priority Encoder, and includes:

- "3-Bit 1-of-9 Priority Encoder Pin Descriptions"
- "3-Bit 1-of-9 Priority Encoder VHDL Coding Example"
- "3-Bit 1-of-9 Priority Encoder Verilog Coding Example"

For this example XST may infer a priority encoder. Use "Priority Encoder Extraction (PRIORITY\_EXTRACT)" with a value *force* to force its inference.

IO Pins	Description
sel	Selector
code	Encoded Output Bus

3-Bit 1-of-9 Priority Encoder VHDL Coding Example

```
-- 3-Bit 1-of-9 Priority Encoder
_ _
library ieee;
use ieee.std_logic_1164.all;
entity priority_encoder_1 is
   port ( sel : in std_logic_vector (7 downto 0);
           code :out std_logic_vector (2 downto 0));
   attribute priority_extract: string;
   attribute priority_extract of priority_encoder_1: entity is "force";
end priority_encoder_1;
architecture archi of priority_encoder_1 is
begin
   code <= "000" when sel(0) = '1' else
            "001" when sel(1) = '1' else
            "010" when sel(2) = '1' else
            "011" when sel(3) = '1' else
            "100" when sel(4) = '1' else
            "101" when sel(5) = '1' else
            "110" when sel(6) = '1' else
            "111" when sel(7) = '1' else
            "---";
```

```
end archi;
3-Bit 1-of-9 Priority Encoder Verilog Coding Example
   11
   // 3-Bit 1-of-9 Priority Encoder
   11
   (* priority_extract="force" *)
   module v_priority_encoder_1 (sel, code);
       input [7:0] sel;
       output [2:0] code;
       reg [2:0] code;
       always @(sel)
       begin
           if
                  (sel[0]) code = 3'b000;
           else if (sel[1]) code = 3'b001;
           else if (sel[2]) code = 3'b010;
           else if (sel[3]) code = 3'b011;
           else if (sel[4]) code = 3'b100;
           else if (sel[5]) code = 3'b101;
           else if (sel[6]) code = 3'b110;
           else if (sel[7]) code = 3'b111;
           else
                            code = 3'bxxx;
       end
```

endmodule

# Logical Shifters HDL Coding Techniques

This section discusses Logical Shifters HDL Coding Techniques, and includes:

- "About Logical Shifters"
- "Logical Shifters Log File"
- "Logical Shifters Related Constraints"
- "Logical Shifters Coding Examples"

## **About Logical Shifters**

Xilinx defines a logical shifter as a combinatorial circuit with 2 inputs and 1 output:

- The first input is a data input that is shifted.
- The second input is a selector whose binary value defines the shift distance.
- The output is the result of the shift operation.

All of these I/Os are mandatory. Otherwise, XST does not infer a logical shifter.



Follow these rules when writing your HDL code:

- Use only logical, arithmetic and rotate shift operators. Shift operations that fill vacated positions with values from another signal are not recognized.
- For VHDL, you can use predefined shift (for example, SLL, SRL, ROL) or concatenation operations only. For more information on predefined shift operations, see the IEEE VHDL reference manual.
- Use only one type of shift operation.
- The *n* value in the shift operation must be incremented or decremented only by 1 for each consequent binary value of the selector.
- The *n* value can be positive only.
- All values of the selector must be presented.

### Logical Shifters Log File

The XST log file reports the type and size of a recognized logical shifter during the Macro Recognition step.

### Logical Shifters Related Constraints

• "Logical Shifter Extraction (SHIFT\_EXTRACT)"

### Logical Shifters Coding Examples


The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>.

- "Logical Shifter One"
- "Logical Shifter Two"
- "Logical Shifter Three"

### Logical Shifter One

This section discusses Logical Shifter One, and includes:

- "Logical Shifter One Diagram"
- "Logical Shifter One Pin Descriptions"
- "Logical Shifter One VHDL Coding Example"
- "Logical Shifter One Verilog Coding Example"



X10548

Figure 2-36: Logical Shifter One Diagram

Table 2-42. Logical Shinter One Fin Descriptions	Table 2-42:	Logical Shifter One Pin Descriptions
--	-------------	--------------------------------------

IO Pins	Description
DI	Data Input
SEL	Shift Distance Selector
SO	Data Output

Logical Shifter One VHDL Coding Example

```
_ _
-- Following is the VHDL code for a logical shifter.
_ _
library ieee;
use ieee.std_logic_1164.all;
use ieee.numeric_std.all;
entity logical_shifters_1 is
    port(DI : in unsigned(7 downto 0);
         SEL : in unsigned(1 downto 0);
         SO : out unsigned(7 downto 0));
end logical_shifters_1;
architecture archi of logical_shifters_1 is
begin
    with SEL select
        SO <= DI when "00",
        DI sll 1 when "01",
        DI sll 2 when "10",
        DI sll 3 when others;
end archi;
```



Logical Shifter One Verilog Coding Example

```
11
// Following is the Verilog code for a logical shifter.
11
module v_logical_shifters_1 (DI, SEL, SO);
    input [7:0] DI;
    input [1:0] SEL;
    output [7:0] SO;
    reg [7:0] SO;
    always @(DI or SEL)
   begin
        case (SEL)
            2'b00 : SO = DI;
            2'b01 : SO = DI << 1;
            2'b10 : SO = DI << 2;
            default : SO = DI << 3;
        endcase
    end
endmodule
```

Logical Shifter Two

This section discusses Logical Shifter Two, and includes:

- "Logical Shifter Two Pin Descriptions"
- "Logical Shifter Two VHDL Coding Example"
- "Logical Shifter Two Verilog Coding Example"

XST does *not* infer a logical shifter for Logical Shifter Two, since not all selector values are presented.

Table 2-43:	Logical Shifter	Two Pin	Descriptions

IO Pins	Description
DI	Data Input
SEL	Shift Distance Selector
SO	Data Output

Logical Shifter Two VHDL Coding Example

```
--
-- XST does not infer a logical shifter for this example,
-- as not all of the selector values are presented.
--
library ieee;
use ieee.std_logic_1164.all;
use ieee.numeric_std.all;
entity logical_shifters_2 is
    port(DI : in unsigned(7 downto 0);
        SEL : in unsigned(1 downto 0);
        SO : out unsigned(7 downto 0));
end logical_shifters_2;
```

```
architecture archi of logical_shifters_2 is
begin
    with SEL select
        SO <= DI when "00",
        DI sll 1 when "01",
        DI sll 2 when others;
end archi;</pre>
```

Logical Shifter Two Verilog Coding Example

```
11
// XST does not infer a logical shifter for this example,
// as not all of the selector values are presented.
11
module v_logical_shifters_2 (DI, SEL, SO);
    input [7:0] DI;
    input [1:0] SEL;
    output [7:0] SO;
    reg [7:0] SO;
    always @(DI or SEL)
    begin
        case (SEL)
            2'b00 : SO = DI;
            2'b01 : SO = DI << 1;
            default : SO = DI << 2;
        endcase
    end
endmodule
```

## Logical Shifter Three

This section discusses Logical Shifter Three, and includes:

- "Logical Shifter Three Pin Descriptions"
- "Logical Shifter Three VHDL Coding Example"
- "Logical Shifter Three Verilog Coding Example"

XST does *not* infer a logical shifter for this example, as the value is not incremented by 1 for each consequent binary value of the selector.

Table 2-44:	Logical Shifter	Three Pin	Descriptions
	Eogloal Ornitor		Booonpaione

IO Pins	Description
DI	Data Input
SEL	Shift Distance Selector
SO	Data Output

Logical Shifter Three VHDL Coding Example

-- XST does not infer a logical shifter for this example,
-- as the value is not incremented by 1 for each consequent
-- binary value of the selector.



```
library ieee;
use ieee.std_logic_1164.all;
use ieee.numeric_std.all;
entity logical_shifters_3 is
    port(DI : in unsigned(7 downto 0);
         SEL : in unsigned(1 downto 0);
         SO : out unsigned(7 downto 0));
end logical_shifters_3;
architecture archi of logical_shifters_3 is
begin
    with SEL select
        SO <= DI when "00",
        DI sll 1 when "01",
        DI sll 3 when "10",
        DI sll 2 when others;
end archi;
```

Logical Shifter Three Verilog Coding Example

```
11
// XST does not infer a logical shifter for this example,
// as the value is not incremented by 1 for each consequent
// binary value of the selector.
11
module v_logical_shifters_3 (DI, SEL, SO);
    input [7:0] DI;
    input [1:0] SEL;
    output [7:0] SO;
    reg[7:0] SO;
    always @(DI or SEL)
    begin
        case (SEL)
            2'b00 : SO = DI;
            2'b01 : SO = DI << 1;
            2'b10 : SO = DI << 3;
            default : SO = DI << 2;
        endcase
    end
endmodule
```

# **Arithmetic Operators HDL Coding Techniques**

This section discusses Arithmetic Operators HDL Coding Techniques, and includes:

- "About Arithmetic Operators"
- "Arithmetic Operators Log File"
- "Arithmetic Operators Related Constraints"
- "Arithmetic Operators Coding Examples"

### About Arithmetic Operators

XST supports the following arithmetic operators:

- Adders with:
  - Carry In
  - Carry Out
  - ♦ Carry In/Out
- Subtractors
- Adders/Subtractors
- Comparators (=, /=,<, <=, >, >=)
- Multipliers
- Dividers

Adders, subtractors, comparators and multipliers are supported for signed and unsigned operators.

For more information on signed and unsigned operators support in VHDL, see "Registers HDL Coding Techniques."

Moreover, XST performs resource sharing for adders, subtractors, adders/subtractors and multipliers.

## Arithmetic Operators Log File

The XST log file reports the type and size of recognized adder, subtractor and adder/subtractor during the Macro Recognition step.

## Arithmetic Operators Related Constraints

- "Use DSP48 (USE\_DSP48)"
- "DSP Utilization Ratio (DSP\_UTILIZATION\_RATIO)"
- "Keep (KEEP)"

## Arithmetic Operators Coding Examples

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>. For examples of Arithmetic Operators, see the examples contained in the following sections:

- "Adders, Subtractors, and Adders/Subtractors HDL Coding Techniques"
- "Comparators HDL Coding Techniques"
- "Multipliers HDL Coding Techniques"
- "Sequential Complex Multipliers HDL Coding Techniques"
- "Pipelined Multipliers HDL Coding Techniques"
- "Multiply Adder/Subtractors HDL Coding Techniques"
- "Multiply Accumulate HDL Coding Techniques"
- "Dividers HDL Coding Techniques"
- "Resource Sharing HDL Coding Techniques"

# Adders, Subtractors, and Adders/Subtractors HDL Coding Techniques

This section discusses Adders, Subtractors, and Adders/Subtractors HDL Coding Techniques, and includes:

- "About Adders, Subtractors, and Adders/Subtractors"
- "Adders, Subtractors, and Adders/Subtractors Log File"
- "Adders, Subtractors, and Adders/Subtractors Related Constraints"
- "Adders, Subtractors, and Adders/Subtractors Coding Examples"

### About Adders, Subtractors, and Adders/Subtractors

The Virtex-4, Virtex-5, and Spartan-3A D families allow adders/subtractors to be implemented on DSP48 resources. XST supports the one level of output registers into DSP48 blocks. If the Carry In or Add/Sub operation selectors are registered, XST pushes these registers into the DSP48 as well.

XST can implement an adder/subtractor in a DSP48 block if its implementation requires only a single DSP48 resource. If an adder/subtractor macro does not fit in a single DSP48, XST implements the entire macro using slice logic.

Macro implementation on DSP48 blocks is controlled by "DSP Utilization Ratio (DSP\_UTILIZATION\_RATIO)" with a default value of **auto**. In **auto** mode, if an adder/subtractor is a part of a more complex macro such as a filter, XST automatically places it on the DSP block. Otherwise, XST implements adders/subtractors using LUTs. Set the value of "Use DSP48 (USE\_DSP48)" to **yes** to force XST to push these macros into a DSP48. When placing an Adder/Subtractor on a DSP block, XST checks to see if it is connected to other DSP chains. If so, XST tries to take advantage of fast DSP connections, and connects this adder/subtractor to the DSP chain using these fast connections.

When implementing adders/subtractors on DSP48 blocks, XST performs automatic DSP48 resource control.

To deliver the best performance, XST by default tries to infer and implement the maximum macro configuration, including as many registers in the DSP48 as possible. Use the "Keep (KEEP)" constraint to shape a macro in a specific way. For example, to exclude the first register stage from the DSP48, place "Keep (KEEP)" constraints on the outputs of these registers.

## Adders, Subtractors, and Adders/Subtractors Log File

```
Synthesizing Unit <v_adders_4>.
  Related source file is "v_adders_4.v".
  Found 8-bit adder carry in/out for signal <$addsub0000>.
  Summary:
 inferred 1 Adder/Subtractor(s).
Unit <v_adders_4> synthesized.
_____
===
HDL Synthesis Report
Macro Statistics
# Adders/Subtractors
                                       : 1
8-bit adder carry in/out
                                       : 1
_____
===
```

## Adders, Subtractors, and Adders/Subtractors Related Constraints

- "Use DSP48 (USE\_DSP48)"
- "DSP Utilization Ratio (DSP\_UTILIZATION\_RATIO)"
- "Keep (KEEP)"

## Adders, Subtractors, and Adders/Subtractors Coding Examples

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>.

- "Unsigned 8-Bit Adder"
- "Unsigned 8-Bit Adder With Carry In"
- "Unsigned 8-Bit Adder With Carry Out"
- "Unsigned 8-Bit Adder With Carry In and Carry Out"
- "Signed 8-Bit Adder"
- "Unsigned 8-Bit Subtractor"
- "Unsigned 8-Bit Subtractor With Borrow In"
- "Unsigned 8-Bit Adder/Subtractor"



### **Unsigned 8-Bit Adder**

This section discusses Unsigned 8-Bit Adder, and includes:

- "Unsigned 8-Bit Adder Diagram"
- "Unsigned 8-Bit Adder Pin Descriptions"
- "Unsigned 8-Bit Adder VHDL Coding Example"
- "Unsigned 8-Bit Adder Verilog Coding Example"




Figure 2-37: Unsigned 8-Bit Adder Diagram

Table 2-45:	Unsigned 8-Bit Adder Pin Descriptions

IO Pins	Description
А, В	Add Operands
SUM	Add Result

Unsigned 8-Bit Adder VHDL Coding Example

\_ \_

```
-- Unsigned 8-bit Adder
--
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity adders_1 is
    port(A,B : in std_logic_vector(7 downto 0);
        SUM : out std_logic_vector(7 downto 0));
end adders_1;
architecture archi of adders_1 is
begin
    SUM <= A + B;
end archi;
```

#### Unsigned 8-Bit Adder Verilog Coding Example

```
//
// Unsigned 8-bit Adder
//
module v_adders_1(A, B, SUM);
    input [7:0] A;
    input [7:0] B;
    output [7:0] SUM;
    assign SUM = A + B;
endmodule
```

## Unsigned 8-Bit Adder With Carry In

This section discusses Unsigned 8-Bit Adder With Carry In, and includes:

- "Unsigned 8-Bit Adder With Carry In Diagram"
- "Unsigned 8-Bit Adder With Carry In Pin Descriptions"
- "Unsigned 8-Bit Adder With Carry In VHDL Coding Example"
- "Unsigned 8-Bit Adder With Carry In Verilog Coding Example"




Figure 2-38: Unsigned 8-Bit Adder With Carry In Diagram

#### Table 2-46: Unsigned 8-Bit Adder With Carry In Pin Descriptions

IO Pins	Description
А, В	Add Operands
CI	Carry In
SUM	Add Result

#### Unsigned 8-Bit Adder With Carry In VHDL Coding Example

```
-- Unsigned 8-bit Adder with Carry In
```

```
library ieee;
```

\_ \_

www.xilinx.com



Unsigned 8-Bit Adder With Carry In Verilog Coding Example

```
//
// Unsigned 8-bit Adder with Carry In
//
module v_adders_2(A, B, CI, SUM);
    input [7:0] A;
    input [7:0] B;
    input CI;
    output [7:0] SUM;
    assign SUM = A + B + CI;
endmodule
```

## Unsigned 8-Bit Adder With Carry Out

This section discusses Unsigned 8-Bit Adder With Carry Out, and includes:

- "Unsigned 8-Bit Adder With Carry Out Diagram"
- "Unsigned 8-Bit Adder With Carry Out Pin Descriptions"
- "Unsigned 8-Bit Adder With Carry Out VHDL Coding Example"
- "Unsigned 8-Bit Adder With Carry Out Verilog Coding Example"

Before writing a + (plus) operation with carry out in VHDL, read the arithmetic package you plan to use. For example, **std\_logic\_unsigned** does not allow you to write + (plus) in the following form to obtain Carry Out:

Res(9-bit) = A(8-bit) + B(8-bit)

The reason is that the size of the result for + (plus) in this package is equal to the size of the longest argument (8 bits).

One solution for the example is to adjust the size of operands  ${\tt A}~$  and  ${\tt B}$  to 9 bits using concatenation.

Res <= ("0" & A) + ("0" & B);

In this case, XST recognizes that this 9-bit adder can be implemented as an 8-bit adder with carry out.

Another solution is:

- Convert **A** and **B** to integers
- Convert the result back to the **std\_logic** vector
- Specify the size of the vector equal to 9




Figure 2-39: Unsigned 8-Bit Adder With Carry Out Diagram

Table 2-47:	Unsigned 8-Bit	Adder With	Carry Out P	in Descriptions

IO Pins	Description
А, В	Add Operands
SUM	Add Result
СО	Carry Out

Unsigned 8-Bit Adder With Carry Out VHDL Coding Example

```
-- Unsigned 8-bit Adder with Carry Out
_ _
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_arith.all;
use ieee.std_logic_unsigned.all;
entity adders_3 is
    port(A,B : in std_logic_vector(7 downto 0);
         SUM : out std_logic_vector(7 downto 0);
         CO : out std_logic);
end adders_3;
architecture archi of adders_3 is
    signal tmp: std_logic_vector(8 downto 0);
begin
    tmp <= conv_std_logic_vector((conv_integer(A) +</pre>
conv_integer(B)),9);
    SUM <= tmp(7 \text{ downto } 0);
```



```
CO <= tmp(8);
```

end archi;

The preceding example uses two arithmetic packages:

std\_logic\_arith

Contains the integer to **std\_logic** conversion function (**conv\_std\_logic\_vector**)

std\_logic\_unsigned

Contains the unsigned + (plus) operation

Unsigned 8-Bit Adder With Carry Out Verilog Coding Example

```
//
// Unsigned 8-bit Adder with Carry Out
//
module v_adders_3(A, B, SUM, CO);
    input [7:0] A;
    input [7:0] B;
    output [7:0] SUM;
    output CO;
    wire [8:0] tmp;
    assign tmp = A + B;
    assign SUM = tmp [7:0];
    assign CO = tmp [8];
```

endmodule

### Unsigned 8-Bit Adder With Carry In and Carry Out

This section discusses Unsigned 8-Bit Adder With Carry In and Carry Out, and includes:

- "Unsigned 8-Bit Adder With Carry In and Carry Out Diagram"
- "Unsigned 8-Bit Adder With Carry In and Carry Out Pin Descriptions"
- "Unsigned 8-Bit Adder With Carry In and Carry Out VHDL Coding Example"
- "Unsigned 8-Bit Adder With Carry In and Carry Out Verilog Coding Example"






Figure 2-40: Unsigned 8-Bit Adder With Carry In and Carry Out Diagram

IO Pins	Description
А, В	Add Operands
CI	Carry In
SUM	Add Result
СО	Carry Out

Table 2-48: Unsigned 8-Bit Adder With Carry In and Carry Out Pin Descriptions

Unsigned 8-Bit Adder With Carry In and Carry Out VHDL Coding Example

```
-- Unsigned 8-bit Adder with Carry In and Carry Out
--
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_arith.all;
use ieee.std_logic_unsigned.all;
entity adders_4 is
    port(A,B : in std_logic_vector(7 downto 0);
        CI : in std_logic;
        SUM : out std_logic_vector(7 downto 0);
        CO : out std_logic);
end adders_4;
architecture archi of adders_4 is
        signal tmp: std_logic_vector(8 downto 0);
```



begin

end archi;

```
tmp <= conv_std_logic_vector((conv_integer(A) + conv_integer(B) +
conv_integer(CI)),9);
SUM <= tmp(7 downto 0);
CO <= tmp(8);</pre>
```

Unsigned 8-Bit Adder With Carry In and Carry Out Verilog Coding Example

```
//
// Unsigned 8-bit Adder with Carry In and Carry Out
//
module v_adders_4(A, B, CI, SUM, CO);
    input CI;
    input [7:0] A;
    input [7:0] B;
    output [7:0] SUM;
    output CO;
    wire [8:0] tmp;
    assign tmp = A + B + CI;
    assign SUM = tmp [7:0];
    assign CO = tmp [8];
```

endmodule

### Signed 8-Bit Adder

This section discusses Signed 8-Bit Adder, and includes:

- "Signed 8-Bit Adder Diagram"
- "Signed 8-Bit Adder Pin Descriptions"
- "Signed 8-Bit Adder VHDL Coding Example"
- "Signed 8-Bit Adder Verilog Coding Example"




Figure 2-41: Signed 8-Bit Adder Diagram

IO Pins	Description
А, В	Add Operands
SUM	Add Result

Table 2-49: Signed 8-Bit Adder Pin Descriptions

Signed 8-Bit Adder VHDL Coding Example

```
--
-- Signed 8-bit Adder
--
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_signed.all;
entity adders_5 is
    port(A,B : in std_logic_vector(7 downto 0);
        SUM : out std_logic_vector(7 downto 0));
end adders_5;
architecture archi of adders_5 is
begin
    SUM <= A + B;
end archi;</pre>
```

Signed 8-Bit Adder Verilog Coding Example

```
//
// Signed 8-bit Adder
//
module v_adders_5 (A,B,SUM);
    input signed [7:0] A;
    input signed [7:0] B;
    output signed [7:0] SUM;
    wire signed [7:0] SUM;
    assign SUM = A + B;
endmodule
```



### **Unsigned 8-Bit Subtractor**

This section discusses Unsigned 8-Bit Subtractor, and includes:

- "Unsigned 8-Bit Subtractor Diagram"
- "Unsigned 8-Bit Subtractor Pin Descriptions"
- "Unsigned 8-Bit Subtractor VHDL Coding Example"
- "Unsigned 8-Bit Subtractor Verilog Coding Example"




Figure 2-42: Unsigned 8-Bit Subtractor Diagram

IO Pins	Description
А, В	Sub Operands
RES	Sub Result

Unsigned 8-Bit Subtractor VHDL Coding Example

```
-- Unsigned 8-bit Subtractor
--
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity adders_6 is
    port(A,B : in std_logic_vector(7 downto 0);
        RES : out std_logic_vector(7 downto 0));
end adders_6;
architecture archi of adders_6 is
begin
    RES <= A - B;
end archi;
```

#### Unsigned 8-Bit Subtractor Verilog Coding Example

```
//
// Unsigned 8-bit Subtractor
//
module v_adders_6(A, B, RES);
    input [7:0] A;
    input [7:0] B;
    output [7:0] RES;
    assign RES = A - B;
endmodule
```

### Unsigned 8-Bit Subtractor With Borrow In

This section discusses Unsigned 8-Bit Subtractor With Borrow In, and includes:

- "Unsigned 8-Bit Subtractor With Borrow In Pin Descriptions"
- "Unsigned 8-Bit Subtractor With Borrow In VHDL Coding Example"
- "Unsigned 8-Bit Subtractor With Borrow In Verilog Coding Example"

Table 2-51: Unsigned 8-Bit Subtractor With Borrow In Pin Descriptions

IO Pins	Description
А, В	Sub Operands
BI	Borrow In
RES	Sub Result

Unsigned 8-Bit Subtractor With Borrow In VHDL Coding Example

```
--
-- Unsigned 8-bit Subtractor with Borrow In
--
library IEEE;
use IEEE.STD_LOGIC_1164.ALL;
use IEEE.STD_LOGIC_UNSIGNED.ALL;
entity adders_8 is
    port(A,B : in std_logic_vector(7 downto 0);
        BI : in std_logic;
        RES : out std_logic_vector(7 downto 0));
end adders_8;
architecture archi of adders_8 is
begin
    RES <= A - B - BI;
end archi;
```




Unsigned 8-Bit Subtractor With Borrow In Verilog Coding Example

```
//
// Unsigned 8-bit Subtractor with Borrow In
//
module v_adders_8(A, B, BI, RES);
    input [7:0] A;
    input [7:0] B;
    input BI;
    output [7:0] RES;
    assign RES = A - B - BI;
endmodule
```

### Unsigned 8-Bit Adder/Subtractor

This section discusses Unsigned 8-Bit Adder/Subtractor, and includes:

- "Unsigned 8-Bit Adder/Subtractor Diagram"
- "Unsigned 8-Bit Adder/Subtractor Pin Descriptions"
- "Unsigned 8-Bit Adder/Subtractor VHDL Coding Example"
- "Unsigned 8-Bit Adder/Subtractor Verilog Coding Example"





#### Table 2-52: Unsigned 8-Bit Adder/Subtractor Pin Descriptions

IO Pins	Description
А, В	Add/Sub Operands
OPER	Add/Sub Select
SUM	Add/Sub Result

#### Unsigned 8-Bit Adder/Subtractor VHDL Coding Example

```
-- Unsigned 8-bit Adder/Subtractor
--
library ieee;
use ieee.std_logic_1164.all;
```

\_ \_

```
use ieee.std_logic_unsigned.all;
entity adders_7 is
    port(A,B : in std_logic_vector(7 downto 0);
        OPER: in std_logic;
        RES : out std_logic_vector(7 downto 0));
end adders_7;
architecture archi of adders_7 is
begin
    RES <= A + B when OPER='0'
    else A - B;
end archi;
```

Unsigned 8-Bit Adder/Subtractor Verilog Coding Example

```
//
// Unsigned 8-bit Adder/Subtractor
//
module v_adders_7(A, B, OPER, RES);
    input OPER;
    input [7:0] A;
    input [7:0] B;
    output [7:0] RES;
    reg [7:0] RES;
    always @(A or B or OPER)
    begin
        if (OPER==1'b0) RES = A + B;
        else RES = A - B;
    end
endmodule
```

# **Comparators HDL Coding Techniques**

This section discusses Comparators and HDL Coding Techniques, and includes:

- "About Comparators"
- "Comparators Log File"
- "Comparators Related Constraints"
- "Comparators Coding Examples"

## **About Comparators**

Not applicable

## **Comparators Log File**

The XST log file reports the type and size of recognized comparators during the Macro Recognition step.



```
. . .
Synthesizing Unit <compar>.
 Related source file is comparators_1.vhd.
 Found 8-bit comparator greategual for signal <$n0000> created at line 10.
    Summary:
       inferred
                1 Comparator(s).
Unit <compar> synthesized.
-----
HDL Synthesis Report
Macro Statistics
# Comparators
                               : 1
                           : 1
  8-bit comparator greatequal
------
```

## **Comparators Related Constraints**

• None

## **Comparators Coding Examples**

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>.

• "Unsigned 8-Bit Greater or Equal Comparator"

#### Unsigned 8-Bit Greater or Equal Comparator

This section discusses Unsigned 8-Bit Greater or Equal Comparator, and includes:

- "Unsigned 8-Bit Greater or Equal Comparator Diagram"
- "Unsigned 8-Bit Greater or Equal Comparator Pin Descriptions"
- "Unsigned 8-Bit Greater or Equal Comparator VHDL Coding Example"
- "Unsigned 8-Bit Greater or Equal Comparator Verilog Coding Example"




Figure 2-44: Unsigned 8-Bit Greater or Equal Comparator Diagram

Table 2-53:	Unsigned 8-Bit Greater or Equal Comparator Pin Descriptions

IO Pins	Description
А, В	Comparison Operands
СМР	Comparison Result

Unsigned 8-Bit Greater or Equal Comparator VHDL Coding Example

```
-- Unsigned 8-bit Greater or Equal Comparator
--
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity comparator_1 is
    port(A,B : in std_logic_vector(7 downto 0);
        CMP : out std_logic);
end comparator_1;
architecture archi of comparator_1 is
begin
    CMP <= '1' when A >= B else '0';
end archi;
```

Unsigned 8-Bit Greater or Equal Comparator Verilog Coding Example

```
//
// Unsigned 8-bit Greater or Equal Comparator
//
module v_comparator_1 (A, B, CMP);
    input [7:0] A;
    input [7:0] B;
    output CMP;
    assign CMP = (A >= B) ? 1'b1 : 1'b0;
endmodule
```

# **Multipliers HDL Coding Techniques**

\_\_\_

This section discusses Multipliers and HDL Coding Techniques, and includes:

- "About Multipliers"
- "Large Multipliers Using Block Multipliers"
- "Registered Multipliers"
- "Multipliers (Virtex-4, Virtex-5, and Spartan-3A D Devices)"
- "Multiplication with Constant"
- "Multipliers Log File"
- "Multipliers Related Constraints"
- "Multipliers Coding Examples"

## **About Multipliers**

When implementing a multiplier, the size of the resulting signal is equal to the sum of 2 operand lengths. If you multiply A (8-bit signal) by B (4-bit signal), then the size of the result must be declared as a 12-bit signal.

## Large Multipliers Using Block Multipliers

XST can generate large multipliers using an 18x18 bit block multiplier in the following devices:

- Virtex-II
- Virtex-II Pro

For multipliers larger than this, XST can generate larger multipliers using multiple 18x18 bit block multipliers.

## **Registered Multipliers**

In instances where a multiplier would have a registered output, XST infers a unique registered multiplier for the following devices:

- Virtex-II
- Virtex-II Pro
- Virtex-4
- Virtex-5

This registered multiplier is 18x18 bits.

Under the following conditions, a registered multiplier is not used, and a multiplier + register is used instead.

- Output from the multiplier goes to any component other than the register.
- The "Multiplier Style (MULT\_STYLE)" constraint is set to **lut**.
- The multiplier is asynchronous.
- The multiplier has control signals other than synchronous reset or clock enable.
- The multiplier does not fit in a single 18x18 bit block multiplier.

The following pins are optional for a registered multiplier.

- Clock enable port
- Synchronous and asynchronous reset, and load ports

## Multipliers (Virtex-4, Virtex-5, and Spartan-3A D Devices)

The Virtex-4, Virtex-5, and Spartan-3A D families allow multipliers to be implemented on DSP48 resources. XST supports the registered version of these macros and can push up to 2 levels of input registers and 2 levels of output registers into DSP48 blocks.

If a multiplier implementation requires multiple DSP48 resources, XST automatically decomposes it onto multiple DSP48 blocks. Depending on the operand size, and to obtain the best performance, XST may implement most of a multiplier using DSP48 blocks, and use slice logic for the rest of the macro. For example, it is not sufficient to use a single DSP48 to implement an 18x18 unsigned multiplier. In this case, XST implements most of the logic in one DSP48, and the rest in LUTs.

For Virtex-4, Virtex-5, and Spartan-3A D devices, XST can infer pipelined multipliers, not only for the LUT implementation, but for the DSP48 implementation as well. For more information, see "XST Limitations."

Macro implementation on DSP48 blocks is controlled by the "Use DSP48 (USE\_DSP48)" constraint or command line option, with a default value of *auto*. In this mode, XST implements multipliers taking into account available DSP48 resources in the device.

In *auto* mode, use "DSP Utilization Ratio (DSP\_UTILIZATION\_RATIO)" to control DSP48 resources for the synthesis. By default, XST tries to utilize all DSP48 resources. For more information, see "DSP48 Block Resources."

XST can automatically recognize the "Multiplier Style (MULT\_STYLE)" constraint with values *lut* and *block* and then convert internally to "Use DSP48 (USE\_DSP48)". Xilinx recommends using the "Use DSP48 (USE\_DSP48)" constraint for Virtex-4 and Virtex-5 designs to define FPGA resources used for multiplier implementation. Xilinx recommends using the "Multiplier Style (MULT\_STYLE)" constraint to define the multiplier implementation method on the selected FPGA resources. If "Use DSP48 (USE\_DSP48)" is set to *auto* or **yes**, you may use mult\_style=pipe\_block to pipeline the DSP48 implementation if the multiplier implementation requires multiple DSP48 blocks. If "Use DSP48 (USE\_DSP48)" is set to *no*, use mult\_style=pipe\_lut|KCM|CSD to define the multiplier implementation method on LUTs.

To deliver the best performance, XST by default tries to infer and implement the maximum macro configuration, including as many registers in the DSP48 as possible. To shape a macro in a specific way, use the "Keep (KEEP)" constraint. For example, to exclude the first register stage from the DSP48, place "Keep (KEEP)" constraints on the outputs of these registers.

## Multiplication with Constant

When one of the arguments is a constant, XST can create efficient dedicated implementations of a multiplier with a constant using two methods:

- Constant Coefficient Multiplier (KCM)
- Canonical Signed Digit (CSD)

Dedicated implementations do not always provide the best results for multiplication with constants. XST can automatically choose between KCM or standard multiplier implementation. The CSD method cannot be automatically chosen. Use the "Mux Style (MUX\_STYLE)" constraint to force CSD implementation.

XST does not support KCM or CSD implementation for signed numbers.

If the either of the arguments is larger than 32 bits, XST does not use KCM or CSD implementation, even if it is specified with the "Multiplier Style (MULT\_STYLE)" constraint.

## Multipliers Log File

The XST log file reports the type and size of recognized multipliers during the Macro Recognition step.

```
Synthesizing Unit <mult>.
Related source file is multipliers_1.vhd.
Found 8x4-bit multiplier for signal <res>.
Summary:
```



```
inferred 1 Multiplier(s).
Unit <mult> synthesized.
HDL Synthesis Report
Macro Statistics
# Multipliers : 1
8x4-bit multiplier : 1
```

## **Multipliers Related Constraints**

- "Multiplier Style (MULT\_STYLE)"
- "Use DSP48 (USE\_DSP48)"
- "DSP Utilization Ratio (DSP\_UTILIZATION\_RATIO)"
- "Keep (KEEP)"

## **Multipliers Coding Examples**

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>.

• "Unsigned 8x4-Bit Multiplier"

### Unsigned 8x4-Bit Multiplier

This section discusses Unsigned 8x4-Bit Multiplier, and includes:

- "Unsigned 8x4-Bit Multiplier Diagram"
- "Unsigned 8x4-Bit Multiplier Pin Descriptions"
- "Unsigned 8x4-Bit Multiplier VHDL Coding Example"
- "Unsigned 8x4-Bit Multiplier Verilog Coding Example"




Figure 2-45: Unsigned 8x4-Bit Multiplier Diagram

<i>Table 2-54:</i> Unsigned 8x4-Bit Multiplier Pin Descriptions
---

IO Pins	Description
А, В	MULT Operands
RES	MULT Result

Unsigned 8x4-Bit Multiplier VHDL Coding Example

```
--
--
-- Unsigned 8x4-bit Multiplier
--
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity multipliers_1 is
    port(A : in std_logic_vector(7 downto 0);
        B : in std_logic_vector(3 downto 0);
        RES : out std_logic_vector(11 downto 0));
end multipliers_1;
architecture beh of multipliers_1 is
begin
        RES <= A * B;
end beh;</pre>
```

Unsigned 8x4-Bit Multiplier Verilog Coding Example

```
//
// Unsigned 8x4-bit Multiplier
//
module v_multipliers_1(A, B, RES);
    input [7:0] A;
    input [3:0] B;
    output [11:0] RES;
    assign RES = A * B;
endmodule
```

# **Sequential Complex Multipliers HDL Coding Techniques**

This section discusses Sequential Complex Multipliers HDL Coding Techniques, and includes:

- "About Sequential Complex Multipliers"
- "Sequential Complex Multipliers Log File"
- "Sequential Complex Multipliers Related Constraints"
- "Sequential Complex Multipliers Coding Examples"

## About Sequential Complex Multipliers

A sequential complex multiplier is a complex multiplier that requires four cycles to make a complete multiplication by accumulating intermediate results. From the implementation point of view, it requires one DSP block.

Multiplying two complex numbers A and B requires four cycles.

The first two first cycles compute:

Res\_real = A\_real \* B\_real - A\_imag \* B\_imag

www.xilinx.com

The second two cycles compute:

Res\_imag = A\_real \* B\_imag + A\_imag \* B\_real

While several templates could be used to describe the above functionality, XST does not support using **enum** or **integer** types to describe the different DSP modes and store the **enum** values. Instead, Xilinx recommends a very regular template to ease XST inferencing. This general accumulator template allows XST to inference a single DSP to perform the following operations:

- Load: P <= Value
- Load: P <= -Value
- Accumulate: P <= P + Value
- Accumulate: P <= P Value

This template works with two control signals, **load** and **addsub**, that perform the above four operations when combined.

## Sequential Complex Multipliers Log File

• None

## Sequential Complex Multipliers Related Constraints

• None

## Sequential Complex Multipliers Coding Examples

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>.

• "Signed 18x18-bit Sequential Complex Multiplier"

#### Signed 18x18-bit Sequential Complex Multiplier

This section discusses Signed 18x18-bit Sequential Complex Multiplier, and includes:

- "Signed 18x18-bit Sequential Complex Multiplier Pin Descriptions"
- "Signed 18x18-bit Sequential Complex Multiplier VHDL Coding Example"
- "Signed 18x18-bit Sequential Complex Multiplier Verilog Coding Example"

#### Table 2-55: Signed 18x18-bit Sequential Complex Multiplier Pin Descriptions

IO Pins	Description
CLK	Clock Signal
Oper_Load, Oper_AddSub	Control Signals controlling Load and AddSub Operations
А, В	MULT Operands
RES	MULT Result

Signed 18x18-bit Sequential Complex Multiplier VHDL Coding Example

```
_ _
-- Sequential Complex Multiplier
___
library ieee;
use ieee.std_logic_1164.all;
use ieee.numeric_std.all;
entity multipliers_8 is
    generic(A_WIDTH: positive:=18;
        B_WIDTH: positive:=18;
        RES_WIDTH: positive:=48);
        port(CLK: in std logic:
    port(
            CLK:
                             in std_logic;
             A:
                             in signed(A_WIDTH-1 downto 0);
                             in signed(B_WIDTH-1 downto 0);
             B:
             Oper_Load: in std_logic;
Oper_AddSub: in std_logic;
             -- Oper_Load Oper_AddSub Operation
                     0
             _ _
                0
                                          R= +A*B
             -- 0
                           1
                                          R= -A*B
             -- 1
                           0
                                          R=R+A*B
                          1
             -- 1
                                           R=R-A*B
             RES:
                             out signed(RES_WIDTH-1 downto 0)
    );
end multipliers_8;
architecture beh of multipliers_8 is
    constant P_WIDTH: integer:=A_WIDTH+B_WIDTH;
    signal oper_load0: std_logic:='0';
    signal oper_addsub0: std_logic:='0';
    signal p1: signed(P_WIDTH-1 downto 0):=(others=>'0');
    signal oper_load1: std_logic:='0';
    signal oper_addsub1: std_logic:='0';
    signal res0: signed(RES_WIDTH-1 downto 0);
begin
    process (clk)
        variable acc: signed(RES_WIDTH-1 downto 0);
    begin
        if rising_edge(clk) then
             oper_load0 <= Oper_Load;</pre>
             oper_addsub0 <= Oper_AddSub;</pre>
             p1 <= A*B;
             oper_load1
                         <= oper_load0;
             oper_addsub1 <= oper_addsub0;</pre>
             if (oper_load1='1') then
                 acc := res0;
             else
                 acc := (others=>'0');
```



```
end if;
if (oper_addsub1='1') then
    res0 <= acc-p1;
else
    res0 <= acc+p1;
end if;
end if;
end process;
RES <= res0;
end architecture;
```

Signed 18x18-bit Sequential Complex Multiplier Verilog Coding Example

```
module v_multipliers_8(CLK, A, B, Oper_Load, Oper_AddSub, RES);
   parameter A_WIDTH
                      = 18;
   parameter B_WIDTH = 18;
   parameter RES_WIDTH = 48;
   parameter P_WIDTH = A_WIDTH+B_WIDTH;
   input CLK;
    input signed [A_WIDTH-1:0] A, B;
   input Oper_Load, Oper_AddSub;
   // Oper_Load Oper_AddSub Operation
            0 R= +A*B
   // 0
   // 0
                 1
                             R= -A*B
   // 1
                  0
                             R=R+A*B
   // 1
                              R=R-A*B
                  1
   output [RES_WIDTH-1:0] RES;
   reg oper_load0
                   = 0;
   reg oper_addsub0 = 0;
   reg signed [P_WIDTH-1:0] p1 = 0;
   reg oper_load1 = 0;
   reg oper_addsub1 = 0;
   reg signed [RES_WIDTH-1:0] res0 = 0;
   reg signed [RES_WIDTH-1:0] acc;
   always @(posedge CLK)
   begin
       oper_load0 <= Oper_Load;</pre>
       oper_addsub0 <= Oper_AddSub;</pre>
       p1 <= A*B;
       oper_load1
                   <= oper_load0;
       oper_addsub1 <= oper_addsub0;</pre>
       if (oper load1==1'b1)
           acc = res0;
       else
           acc = 0;
```

```
if (oper_addsub1==1'b1)
    res0 <= acc-p1;
else
    res0 <= acc+p1;
end
assign RES = res0;
endmodule</pre>
```

# **Pipelined Multipliers HDL Coding Techniques**

This section discusses Pipelined Multipliers HDL Coding Techniques, and includes:

- "About Pipelined Multipliers"
- "Pipelined Multipliers Log File"
- "Pipelined Multipliers Related Constraints"
- "Pipelined Multipliers Coding Examples"

## About Pipelined Multipliers

To increase the speed of designs with large multipliers, XST can infer pipelined multipliers. By interspersing registers between the stages of large multipliers, pipelining can significantly increase the overall frequency of your design. The effect of pipelining is similar to flip-flop retiming which is described in "Flip-Flop Retiming."

To insert pipeline stages, describe the necessary registers in your HDL code and place them after any multipliers, then set the "Multiplier Style (MULT\_STYLE)" constraint to *pipe\_lut*. If the target is a Virtex-4 or Virtex-5 device, and implementation of a multiplier requires multiple DSP48 blocks, XST can pipeline this implementation as well. Set "Multiplier Style (MULT\_STYLE)" for this instance to **pipe\_block**.

When XST detects valid registers for pipelining and "Multiplier Style (MULT\_STYLE)" is set to **pipe\_lut** or **pipe\_block**, XST uses the maximum number of available registers to reach the maximum multiplier speed. XST automatically calculates the maximum number of registers for each multiplier to obtain the best frequency.

If you have not specified sufficient register stages, and "Multiplier Style (MULT\_STYLE)" is coded directly on a signal, the XST HDL Advisor advises you to specify the optimum number of register stages. XST does this during the Advanced HDL Synthesis step. If the number of registers placed after the multiplier exceeds the maximum required, and shift register extraction is activated, then XST implements the unused stages as shift registers.

XST has the following limitations:

- XST cannot pipeline hardware Multipliers (implementation using MULT18X18S resource).
- XST cannot pipeline Multipliers if registers contain asynch set/reset or synch reset signals. XST *can* pipeline if registers contain synch reset signals.



## **Pipelined Multipliers Log File**

Following is a Pipelined Multipliers log file.

```
_____
                  HDL Synthesis
_____
Synthesizing Unit <multipliers_2>.
  Related source file is "multipliers_2.vhd".
  Found 36-bit register for signal <MULT>.
  Found 18-bit register for signal <a_in>.
  Found 18-bit register for signal <b_in>.
  Found 18x18-bit multiplier for signal <mult_res>.
  Found 36-bit register for signal <pipe_1>.
  Found 36-bit register for signal <pipe_2>.
  Found 36-bit register for signal <pipe_3>.
  Summary:
     inferred 180 D-type flip-flop(s).
     inferred 1 Multiplier(s).
Unit <multipliers_2> synthesized.
. . .
_____
*
                Advanced HDL Synthesis
_____
Synthesizing (advanced) Unit <multipliers_2>.
     Found pipelined multiplier on signal <mult_res>:
          - 4 pipeline level(s) found in a register connected to the
multiplier macro output.
           Pushing register(s) into the multiplier macro.
INFO:Xst - HDL ADVISOR - You can improve the performance of the
multiplier Mmult_mult_res by adding 1 register level(s).
Unit <multipliers_2> synthesized (advanced).
_____
HDL Synthesis Report
Macro Statistics
# Multipliers
                            : 1
18x18-bit registered multiplier : 1
```

## **Pipelined Multipliers Related Constraints**

- "Use DSP48 (USE\_DSP48)"
- "DSP Utilization Ratio (DSP\_UTILIZATION\_RATIO)"
- "Keep (KEEP)"
- "Multiplier Style (MULT\_STYLE)"

## **Pipelined Multipliers Coding Examples**

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>.

- "Pipelined Multiplier (Outside, Single)"
- "Pipelined Multiplier (Inside, Single)"
- "Pipelined Multiplier (Outside, Shift)"

### Pipelined Multiplier (Outside, Single)

This section discusses Pipelined Multiplier (Outside, Single), and includes:

- "Pipelined Multiplier (Outside, Single) Diagram"
- "Pipelined Multiplier (Outside, Single) Pin Descriptions"
- "Pipelined Multiplier (Outside, Single) VHDL Coding Example"
- "Pipelined Multiplier (Outside, Single) Verilog Coding Example"






Table 2-56: Pipelined Multiplier (Outside, Single) Pin Descriptions

IO Pins	Description
clk	Positive-Edge Clock
А, В	MULT Operands
MULT	MULT Result

Pipelined Multiplier (Outside, Single) VHDL Coding Example

```
--
--
-- Pipelined multiplier
-- The multiplication operation placed outside the
-- process block and the pipeline stages represented
-- as single registers.
--
library ieee;
use ieee.std_logic_1164.all;
use ieee.numeric_std.all;
entity multipliers_2 is
    generic(A_port_size : integer := 18;
```

www.xilinx.com



```
B_port_size : integer := 18);
port(clk : in std_logic;
A : in unsigned (A_port_size-1 downto 0);
B : in unsigned (B_port_size-1 downto 0);
MULT : out unsigned ( (A_port_size+B_port_size-1) downto 0));
attribute mult_style: string;
attribute mult_style of multipliers_2: entity is "pipe_lut";
end multipliers_2;
architecture beh of multipliers_2 is
signal a_in, b_in : unsigned (A_port_size-1 downto 0);
signal mult_res : unsigned ( (A_port_size+B_port_size-1) downto 0);
signal pipe_1,
pipe_2,
pipe_3 : unsigned ((A_port_size+B_port_size-1) downto 0);
```

begin

```
mult_res <= a_in * b_in;
process (clk)
begin
    if (clk'event and clk='1') then
        a_in <= A; b_in <= B;
        pipe_1 <= mult_res;
        pipe_2 <= pipe_1;
        pipe_3 <= pipe_2;
        MULT <= pipe_3;
        end if;
end process;
end beh;
```

Pipelined Multiplier (Outside, Single) Verilog Coding Example

```
11
// Pipelined multiplier
      The multiplication operation placed outside the
11
      always block and the pipeline stages represented
11
11
      as single registers.
11
(*mult_style="pipe_lut"*)
module v_multipliers_2(clk, A, B, MULT);
    input clk;
    input [17:0] A;
    input [17:0] B;
    output [35:0] MULT;
    reg [35:0] MULT;
    reg [17:0] a_in, b_in;
    wire [35:0] mult_res;
    reg [35:0] pipe_1, pipe_2, pipe_3;
    assign mult_res = a_in * b_in;
    always @(posedge clk)
```

```
begin
    a_in <= A; b_in <= B;
    pipe_1 <= mult_res;
    pipe_2 <= pipe_1;
    pipe_3 <= pipe_2;
    MULT <= pipe_3;
    end
endmodule</pre>
```

## Pipelined Multiplier (Inside, Single)

This section discusses Pipelined Multiplier (Inside, Single), and includes:

- "Pipelined Multiplier (Inside, Single) Pin Descriptions"
- "Pipelined Multiplier (Inside, Single) VHDL Coding Example"
- "Pipelined Multiplier (Inside, Single) Verilog Coding Example"

Table 2-57: Pipelined Multiplier (Inside, Single) Pin Descriptions

IO Pins	Description
clk	Positive-Edge Clock
A, B	MULT Operands
MULT	MULT Result

Pipelined Multiplier (Inside, Single) VHDL Coding Example

```
-- Pipelined multiplier
     The multiplication operation placed inside the
_ _
     process block and the pipeline stages represented
_ _
     as single registers.
_ _
library ieee;
use ieee.std_logic_1164.all;
use ieee.numeric_std.all;
entity multipliers_3 is
   generic(A_port_size: integer := 18;
           B_port_size: integer := 18);
   port(clk : in std_logic;
         A : in unsigned (A_port_size-1 downto 0);
         B : in unsigned (B_port_size-1 downto 0);
         MULT : out unsigned ((A_port_size+B_port_size-1) downto 0));
   attribute mult_style: string;
   attribute mult_style of multipliers_3: entity is "pipe_lut";
end multipliers_3;
architecture beh of multipliers_3 is
   signal a_in, b_in : unsigned (A_port_size-1 downto 0);
    signal mult_res : unsigned ((A_port_size+B_port_size-1) downto 0);
    signal pipe_2,
           pipe_3 : unsigned ((A_port_size+B_port_size-1) downto 0);
```



```
begin
    process (clk)
    begin
        if (clk'event and clk='1') then
            a_in <= A; b_in <= B;
            mult_res <= a_in * b_in;
            pipe_2 <= mult_res;
            pipe_3 <= pipe_2;
            MULT <= pipe_3;
            end if;
        end process;
end beh;</pre>
```

Pipelined Multiplier (Inside, Single) Verilog Coding Example

```
11
// Pipelined multiplier
      The multiplication operation placed inside the
11
11
      process block and the pipeline stages are represented
11
      as single registers.
11
(*mult_style="pipe_lut"*)
module v_multipliers_3(clk, A, B, MULT);
    input clk;
    input [17:0] A;
    input [17:0] B;
    output [35:0] MULT;
    reg [35:0] MULT;
    reg [17:0] a_in, b_in;
    reg [35:0] mult_res;
    reg [35:0] pipe_2, pipe_3;
    always @(posedge clk)
    begin
        a_in <= A; b_in <= B;
        mult_res <= a_in * b_in;</pre>
        pipe_2 <= mult_res;</pre>
        pipe_3 <= pipe_2;</pre>
        MULT <= pipe_3;</pre>
    end
endmodule
```

## Pipelined Multiplier (Outside, Shift)

\_ \_

This section discusses Pipelined Multiplier (Outside, Shift), and includes:

- "Pipelined Multiplier (Outside, Shift) Pin Descriptions"
- "Pipelined Multiplier (Outside, Shift) VHDL Coding Example"

"Pipelined Multiplier (Outside, Shift) Verilog Coding Example"

Table 2-58: Pipelined Multiplier (Outside, Shift) Pin Descriptions

IO Pins	Description
clk	Positive-Edge Clock
А, В	MULT Operands
MULT	MULT Result

Pipelined Multiplier (Outside, Shift) VHDL Coding Example

```
-- Pipelined multiplier
     The multiplication operation placed outside the
_ _
___
     process block and the pipeline stages represented
      as shift registers.
library ieee;
use ieee.std_logic_1164.all;
use ieee.numeric_std.all;
entity multipliers_4 is
    generic(A_port_size: integer := 18;
           B_port_size: integer := 18);
    port(clk : in std_logic;
         A : in unsigned (A_port_size-1 downto 0);
         B : in unsigned (B_port_size-1 downto 0);
         MULT : out unsigned ( (A_port_size+B_port_size-1) downto 0));
    attribute mult_style: string;
    attribute mult_style of multipliers_4: entity is "pipe_lut";
end multipliers_4;
architecture beh of multipliers_4 is
    signal a_in, b_in : unsigned (A_port_size-1 downto 0);
    signal mult_res : unsigned ((A_port_size+B_port_size-1) downto 0);
    type pipe_reg_type is array (2 downto 0) of unsigned
((A_port_size+B_port_size-1) downto 0);
    signal pipe_regs : pipe_reg_type;
begin
    mult_res <= a_in * b_in;</pre>
   process (clk)
    begin
        if (clk'event and clk='1') then
            a_in <= A; b_in <= B;
```

www.xilinx.com



```
pipe_regs <= mult_res & pipe_regs(2 downto 1);</pre>
                MULT <= pipe_regs(0);</pre>
            end if;
        end process;
   end beh;
Pipelined Multiplier (Outside, Shift) Verilog Coding Example
   11
   // Pipelined multiplier
         The multiplication operation placed outside the
   11
   11
          always block and the pipeline stages represented
   11
          as shift registers.
   11
   (*mult_style="pipe_lut"*)
   module v_multipliers_4(clk, A, B, MULT);
        input clk;
        input [17:0] A;
        input [17:0] B;
        output [35:0] MULT;
        reg [35:0] MULT;
       reg [17:0] a_in, b_in;
       wire [35:0] mult_res;
        reg [35:0] pipe_regs [2:0];
        integer i;
        assign mult_res = a_in * b_in;
        always @(posedge clk)
        begin
            a_in <= A; b_in <= B;
            pipe_regs[2] <= mult_res;</pre>
            for (i=0; i<=1; i=i+1) pipe_regs[i] <= pipe_regs[i+1];</pre>
            MULT <= pipe_regs[0];</pre>
        end
```

endmodule

XILINX®

# **Multiply Adder/Subtractors HDL Coding Techniques**

This section discusses Multiply Adder/Subtractors HDL Coding Techniques, and includes:

- "About Multiply Adder/Subtractors"
- "Multiply Adder/Subtractors in Virtex-4 and Virtex-5 Devices"
- "Multiply Adder/Subtractors Log File"
- "Multiply Adder/Subtractors Related Constraints"
- "Multiply Adder/Subtractors Coding Examples"

## About Multiply Adder/Subtractors

The Multiply Adder/Subtractor macro is a complex macro consisting of several basic macros such as multipliers, adder/subtractors and registers. The recognition of this complex macro enables XST to implement it on dedicated DSP48 resources in Virtex-4 and Virtex-5 devices.

## Multiply Adder/Subtractors in Virtex-4 and Virtex-5 Devices

XST supports the registered version of this macro and can push up to 2 levels of input registers on multiplier inputs, 1 register level on the Adder/Subtractor input and 1 level of output register into the DSP48 block. If the Carry In or Add/Sub operation selectors are registered, XST pushes these registers into the DSP48. In addition, the multiplication operation could be registered as well.

XST can implement a multiply adder/subtractor in a DSP48 block if its implementation requires only a single DSP48 resource. If the macro exceeds the limits of a single DSP48, XST processes it as two separate Multiplier and Adder/Subtractor macros, making independent decisions on each macro. For more information, see "Multipliers HDL Coding Techniques" and "Adders, Subtractors, and Adders/Subtractors HDL Coding Techniques"

Macro implementation on DSP48 blocks is controlled by the "Use DSP48 (USE\_DSP48)" constraint or command line option, with default value of *auto*. In this mode, XST implements multiply adder/subtractors taking into account DSP48 resources in the device.

In auto mode, use the "DSP Utilization Ratio (DSP\_UTILIZATION\_RATIO)" constraint to control DSP48 resources for the synthesis. By default, XST tries to utilize all available DSP48 resources. For more information, see "DSP48 Block Resources."

To deliver the best performance, XST by default tries to infer and implement the maximum macro configuration, including as many registers in the DSP48 as possible. To shape a macro in a specific way, use the "Keep (KEEP)" constraint. For example, to exclude the first register stage from the DSP48, place "Keep (KEEP)" constraints on the outputs of these registers.

In the log file, XST reports the details of inferred multipliers, adders, subtractors, and registers at the HDL Synthesis step. XST reports about inferred MACs during the Advanced HDL Synthesis Step where the MAC implementation mechanism takes place.

# Multiply Adder/Subtractors Log File

In the log file, XST reports the details of inferred multipliers, adder/subtractors and registers at the HDL Synthesis step. The composition of multiply adder/subtractor macros happens at the Advanced HDL Synthesis step. XST reports information about inferred MACs, because they are implemented within the MAC implementation mechanism.

```
_____
                    HDL Synthesis
_____
Synthesizing Unit <multipliers_6>.
   Related source file is "multipliers 6.vhd".
   Found 8-bit register for signal <A_reg1>.
   Found 8-bit register for signal <A_reg2>.
   Found 8-bit register for signal <B_reg1>.
   Found 8-bit register for signal <B_reg2>.
   Found 8x8-bit multiplier for signal <mult>.
   Found 16-bit addsub for signal <multaddsub>.
   Summary:
      inferred 32 D-type flip-flop(s).
      inferred 1 Adder/Subtractor(s).
      inferred 1 Multiplier(s).
Unit <multipliers_6> synthesized.
. . .
_____
               Advanced HDL Synthesis
_____
. . .
Synthesizing (advanced) Unit <Mmult_mult>.
      Multiplier <Mmult mult> in block <multipliers 6> and
adder/subtractor <Maddsub_multaddsub> in block <multipliers_6> are
combined into a MAC<Mmac_Maddsub_multaddsub>.
      The following registers are also absorbed by the MAC: <A_reg2>
in block <multipliers_6>, <A_reg1> in block <multipliers_6>, <B_reg2>
in block <multipliers_6>, <B_reg1> in block <multipliers_6>.
Unit <Mmult_mult> synthesized (advanced).
______
HDL Synthesis Report
Macro Statistics
# MACs
                           : 1
8x8-to-16-bit MAC
                           : 1
```

\_\_\_\_\_\_

## Multiply Adder/Subtractors Related Constraints

- "Use DSP48 (USE\_DSP48)"
- "DSP Utilization Ratio (DSP\_UTILIZATION\_RATIO)"
- "Keep (KEEP)"

## Multiply Adder/Subtractors Coding Examples


The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>.

- "Multiplier Adder With 2 Register Levels on Multiplier Inputs"
- "Multiplier Adder/Subtractor With 2 Register Levels On Multiplier Inputs"

#### Multiplier Adder With 2 Register Levels on Multiplier Inputs

This section discusses Multiplier Adder With 2 Register Levels on Multiplier Inputs, and includes:

- "Multiplier Adder With 2 Register Levels on Multiplier Inputs Diagram"
- "Multiplier Adder With 2 Register Levels on Multiplier Inputs Pin Descriptions"
- "Multiplier Adder With 2 Register Levels on Multiplier Inputs VHDL Coding Example"
- "Multiplier Adder With 2 Register Levels on Multiplier Inputs Verilog Coding Example"






Table 2-59:	Multiplier Adder	With 2 Register L	evels on Multiplier Ing	outs Pin Descriptions

IO Pins	Description
clk	Positive-Edge Clock
A, B, C	MULT-Add Operands
RES	MULT-Add Result

Multiplier Adder With 2 Register Levels on Multiplier Inputs VHDL Coding Example



```
generic (p_width: integer:=8);
    port (clk : in std_logic;
          A, B, C : in std_logic_vector(p_width-1 downto 0);
          RES : out std_logic_vector(p_width*2-1 downto 0));
end multipliers_5;
architecture beh of multipliers_5 is
    signal A_reg1, A_reg2,
           B_reg1, B_reg2 : std_logic_vector(p_width-1 downto 0);
    signal multaddsub : std_logic_vector(p_width*2-1 downto 0);
begin
    multaddsub <= A_reg2 * B_reg2 + C;</pre>
    process (clk)
    begin
        if (clk'event and clk='1') then
            A_reg1 <= A; A_reg2 <= A_reg1;</pre>
            B_reg1 <= B; B_reg2 <= B_reg1;</pre>
        end if;
    end process;
    RES <= multaddsub;
end beh;
```


Multiplier Adder With 2 Register Levels on Multiplier Inputs Verilog Coding Example

```
11
// Multiplier Adder with 2 Register Levels on Multiplier Inputs
11
module v_multipliers_5 (clk, A, B, C, RES);
    input clk;
    input [7:0] A;
    input [7:0] B;
    input [7:0] C;
    output [15:0] RES;
         [7:0] A_reg1, A_reg2, B_reg1, B_reg2;
    reg
         [15:0] multaddsub;
    wire
    always @(posedge clk)
    begin
        A_reg1 <= A; A_reg2 <= A_reg1;</pre>
        B_reg1 <= B; B_reg2 <= B_reg1;</pre>
    end
    assign multaddsub = A_reg2 * B_reg2 + C;
    assign RES = multaddsub;
endmodule
```

#### Multiplier Adder/Subtractor With 2 Register Levels On Multiplier Inputs

This section discusses Multiplier Adder/Subtractor With 2 Register Levels On Multiplier Inputs, and includes:

- "Multiplier Adder/Subtractor With 2 Register Levels On Multiplier Inputs Diagram"
- "Multiplier Adder/Subtractor With 2 Register Levels On Multiplier Inputs Pin Descriptions"
- "Multiplier Adder/Subtractor With 2 Register Levels On Multiplier Inputs VHDL Coding Example"
- "Multiplier Adder/Subtractor With 2 Register Levels On Multiplier Inputs Verilog Coding Example"



*Figure 2-48:* Multiplier Adder/Subtractor With 2 Register Levels On Multiplier Inputs Diagram

*Table 2-60:* Multiplier Adder/Subtractor With 2 Register Levels On Multiplier Inputs Pin Descriptions

IO Pins	Description
clk	Positive-Edge Clock
add_sub	AddSub Selector
A, B, C	MULT-AddSub Operands
RES	MULT-AddSub Result

Multiplier Adder/Subtractor With 2 Register Levels On Multiplier Inputs VHDL Coding Example

```
---
-- Multiplier Adder/Subtractor with
-- 2 Register Levels on Multiplier Inputs
--
library IEEE;
use IEEE.STD_LOGIC_1164.ALL;
use IEEE.STD_LOGIC_UNSIGNED.ALL;
entity multipliers_6 is
    generic (p_width: integer:=8);
```



```
port (clk,add_sub: in std_logic;
          A, B, C: in std_logic_vector(p_width-1 downto 0);
          RES: out std_logic_vector(p_width*2-1 downto 0));
end multipliers_6;
architecture beh of multipliers_6 is
    signal A_reg1, A_reg2,
           B_reg1, B_reg2 : std_logic_vector(p_width-1 downto 0);
    signal mult, multaddsub : std_logic_vector(p_width*2-1 downto 0);
begin
    mult <= A_reg2 * B_reg2;</pre>
    multaddsub <= C + mult when add_sub = '1' else C - mult;</pre>
    process (clk)
    begin
        if (clk'event and clk='1') then
            A_reg1 <= A; A_reg2 <= A_reg1;</pre>
            B_reg1 <= B; B_reg2 <= B_reg1;</pre>
        end if;
    end process;
    RES <= multaddsub;
end beh;
```

Multiplier Adder/Subtractor With 2 Register Levels On Multiplier Inputs Verilog Coding Example

```
11
// Multiplier Adder/Subtractor with
// 2 Register Levels on Multiplier Inputs
11
module v_multipliers_6 (clk, add_sub, A, B, C, RES);
    input clk,add_sub;
    input [7:0] A;
    input [7:0] B;
    input [7:0] C;
    output [15:0] RES;
    rea
           [7:0] A_reg1, A_reg2, B_reg1, B_reg2;
    wire
         [15:0] mult, multaddsub;
    always @(posedge clk)
    begin
        A_reg1 <= A; A_reg2 <= A_reg1;</pre>
        B_reg1 <= B; B_reg2 <= B_reg1;</pre>
    end
    assign mult = A_reg2 * B_reg2;
    assign multaddsub = add_sub ? C + mult : C - mult;
    assign RES = multaddsub;
```

endmodule

# **Multiply Accumulate HDL Coding Techniques**

This section discusses Multiply Accumulate HDL Coding Techniques, and includes:

- "About Multiply Accumulate"
- "Multiply Accumulate in Virtex-4 and Virtex-5 Devices"
- "Multiply Accumulate Log File"
- "Multiply Accumulate Related Constraints"
- "Multiply Accumulate Coding Examples"

### About Multiply Accumulate

The Multiply Accumulate macro is a complex macro consisting of several basic macros such as multipliers, accumulators, and registers. The recognition of this complex macro enables XST to implement it on dedicated DSP48 resources in Virtex-4 and Virtex-5 devices.

### Multiply Accumulate in Virtex-4 and Virtex-5 Devices

The Multiply Accumulate macro is a complex macro consisting of several basic macros as multipliers, accumulators, and registers. The recognition of this complex macro enables XST to implement it on dedicated DSP48 resources in Virtex-4 and Virtex-5 devices.

XST supports the registered version of this macro, and can push up to 2 levels of input registers into the DSP48 block. If Adder/Subtractor operation selectors are registered, XST pushes these registers into the DSP48. In addition, the multiplication operation could be registered as well.

XST can implement a multiply accumulate in a DSP48 block if its implementation requires only a single DSP48 resource. If the macro exceeds the limits of a single DSP48, XST processes it as two separate Multiplier and Accumulate macros, making independent decisions on each macro. For more information, see "Multipliers HDL Coding Techniques" and "Accumulators HDL Coding Techniques"

Macro implementation on DSP48 blocks is controlled by the "Use DSP48 (USE\_DSP48)" constraint or command line option, with default value of *auto*. In auto mode, XST implements multiply accumulate taking into account available DSP48 resources in the device.

In auto mode, use "DSP Utilization Ratio (DSP\_UTILIZATION\_RATIO)" to control DSP48 resources. XST tries to utilize as many DSP48 resources as possible. For more information, see "DSP48 Block Resources."

To deliver the best performance, XST by default tries to infer and implement the maximum macro configuration, including as many registers in the DSP48 as possible. To shape a macro in a specific way, use the "Keep (KEEP)" constraint. For example, to exclude the first register stage from the DSP48, place "Keep (KEEP)" constraints on the outputs of these registers.

In the log file, XST reports the details of inferred multipliers, accumulators and registers at the HDL Synthesis step. The composition of multiply accumulate macros happens at Advanced HDL Synthesis step.



# Multiply Accumulate Log File

In the log file, XST reports the details of inferred multipliers, accumulators and registers at the HDL Synthesis step. The composition of multiply accumulate macros happens at the Advanced HDL Synthesis step.

```
_____
*
                HDL Synthesis
                                              *
_____
. . .
Synthesizing Unit <multipliers_7a>.
  Related source file is "multipliers_7a.vhd".
  Found 8x8-bit multiplier for signal <$n0002> created at line 28.
  Found 16-bit up accumulator for signal <accum>.
  Found 16-bit register for signal <mult>.
  Summary:
     inferred 1 Accumulator(s).
     inferred 16 D-type flip-flop(s).
     inferred 1 Multiplier(s).
Unit <multipliers_7a> synthesized....
_____
*
             Advanced HDL Synthesis
______
Synthesizing (advanced) Unit <Mmult_n0002>.
     Multiplier <Mmult_n0002> in block <multipliers_7a> and
accumulator <accum> in block <multipliers 7a> are combined into a
MAC<Mmac_accum>.
     The following registers are also absorbed by the MAC: <mult> in
block <multipliers_7a>.
Unit <Mmult__n0002> synthesized (advanced).
_____
HDL Synthesis Report
Macro Statistics
# MACs
                        : 1
8x8-to-16-bit MAC
                        : 1
______
```

## Multiply Accumulate Related Constraints

- "Use DSP48 (USE\_DSP48)"
- "DSP Utilization Ratio (DSP\_UTILIZATION\_RATIO)"
- "Keep (KEEP)"

# Multiply Accumulate Coding Examples


The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>.

- "Multiplier Up Accumulate With Register After Multiplication"
- "Multiplier Up/Down Accumulate With Register After Multiplication"

#### Multiplier Up Accumulate With Register After Multiplication

This section discusses Multiplier Up Accumulate With Register After Multiplication, and includes:

- "Multiplier Up Accumulate With Register After Multiplication"
- "Multiplier Up Accumulate With Register After Multiplication Pin Descriptions"
- "Multiplier Up Accumulate With Register After Multiplication VHDL Coding Example"
- "Multiplier Up Accumulate With Register After Multiplication Verilog Coding Example"





IO Pins	Description	
clk	Positive-Edge Clock	
reset	Synchronous Reset	
А, В	MAC Operands	
RES	MAC Result	

Table 2-61: Multiplier Up Accumulate With Register After Multiplication Pin Descriptions

Multiplier Up Accumulate With Register After Multiplication VHDL Coding Example



```
RES: out std_logic_vector(p_width*2-1 downto 0));
end multipliers_7a;
architecture beh of multipliers_7a is
    signal mult, accum: std_logic_vector(p_width*2-1 downto 0);
begin
    process (clk)
    begin
        if (clk'event and clk='1') then
            if (reset = '1') then
                accum <= (others => '0');
                mult <= (others => '0');
            else
                accum <= accum + mult;</pre>
                mult <= A * B;</pre>
            end if;
        end if;
    end process;
    RES <= accum;
```

end beh;

Multiplier Up Accumulate With Register After Multiplication Verilog Coding Example

```
11
// Multiplier Up Accumulate with Register After Multiplication
11
module v_multipliers_7a (clk, reset, A, B, RES);
    input clk, reset;
    input [7:0] A;
    input [7:0] B;
    output [15:0] RES;
    req
           [15:0] mult, accum;
    always @(posedge clk)
    begin
        if (reset)
            mult <= 16'b00000000000000;</pre>
        else
            mult <= A * B;</pre>
    end
    always @(posedge clk)
    begin
        if (reset)
            accum <= 16'b00000000000000;
        else
            accum <= accum + mult;</pre>
    end
    assign RES = accum;
endmodule
```

#### Multiplier Up/Down Accumulate With Register After Multiplication

This section discusses Multiplier Up/Down Accumulate With Register After Multiplication, and includes:

- "Multiplier Up/Down Accumulate With Register After Multiplication Diagram"
- "Multiplier Up/Down Accumulate With Register After Multiplication Pin Descriptions"
- "Multiplier Up/Down Accumulate With Register After Multiplication VHDL Coding Example"
- "Multiplier Up/Down Accumulate With Register After Multiplication Verilog Coding Example"




Figure 2-50: Multiplier Up/Down Accumulate With Register After Multiplication Diagram

Table 2-62:	Multiplier Up/Down Accumulate With Register After Multiplication Pin
Descriptions	

IO Pins	Description
clk	Positive-Edge Clock
reset	Synchronous Reset
add_sub	AddSub Selector
А, В	MAC Operands
RES	MAC Result

Multiplier Up/Down Accumulate With Register After Multiplication VHDL Coding Example

```
-- Multiplier Up/Down Accumulate with Register After Multiplication.
```

```
library IEEE;
use IEEE.STD_LOGIC_1164.ALL;
```



```
use IEEE.STD_LOGIC_UNSIGNED.ALL;
entity multipliers_7b is
    generic (p_width: integer:=8);
   port (clk, reset, add_sub: in std_logic;
          A, B: in std_logic_vector(p_width-1 downto 0);
          RES: out std_logic_vector(p_width*2-1 downto 0));
end multipliers_7b;
architecture beh of multipliers_7b is
    signal mult, accum: std_logic_vector(p_width*2-1 downto 0);
begin
    process (clk)
   begin
        if (clk'event and clk='1') then
            if (reset = '1') then
                accum <= (others => '0');
                mult <= (others => '0');
            else
                if (add_sub = '1') then
                     accum <= accum + mult;</pre>
                else
                     accum <= accum - mult;</pre>
                end if;
                mult <= A * B;</pre>
            end if;
        end if;
    end process;
    RES <= accum;
```

end beh;

Multiplier Up/Down Accumulate With Register After Multiplication Verilog Coding Example

```
11
// Multiplier Up/Down Accumulate with Register After Multiplication.
11
module v_multipliers_7b (clk, reset, add_sub, A, B, RES);
    input clk, reset, add_sub;
    input [7:0] A;
    input [7:0] B;
    output [15:0] RES;
         [15:0] mult, accum;
    req
    always @(posedge clk)
    begin
        if (reset)
            mult <= 16'b00000000000000;</pre>
        else
            mult <= A * B;</pre>
    end
    always @(posedge clk)
    begin
```

# **Dividers HDL Coding Techniques**

This section discusses Dividers HDL Coding Techniques, and includes:

- "About Dividers"
- "Dividers Log File"
- "Dividers Related Constraints"
- "Dividers Coding Examples"

### About Dividers

Dividers are supported only when the divisor is a constant and is a power of 2. In that case, the operator is implemented as a shifter. Otherwise, XST issues an error message.

### **Dividers Log File**

When you implement a divider with a constant with the power of 2, XST does not issue any message during the Macro Recognition step. In case your divider does not correspond to the case supported by XST, XST issues the following error message:

```
...
ERROR:Xst:719 - file1.vhd (Line 172).
Operator is not supported yet : 'DIVIDE'
...
```

## **Dividers Related Constraints**

None

#### Dividers Coding Examples

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>.

"Division by Constant 2 Divider"



#### Division by Constant 2 Divider

This section discusses Division by Constant 2 Divider, and includes:

- "Division by Constant 2 Divider Diagram"
- "Division by Constant 2 Divider Pin Descriptions"
- "Division by Constant 2 Divider VHDL Coding Example"
- "Division by Constant 2 Divider Verilog Coding Example"




Figure 2-51: Division by Constant 2 Divider Diagram

#### Table 2-63: Division by Constant 2 Divider Pin Descriptions

IO Pins	Description
DI	Division Operands
DO	Division Result

Division by Constant 2 Divider VHDL Coding Example

```
-- Division By Constant 2
--
library ieee;
use ieee.std_logic_1164.all;
use ieee.numeric_std.all;
entity divider_1 is
    port(DI : in unsigned(7 downto 0);
        DO : out unsigned(7 downto 0));
end divider_1;
architecture archi of divider_1 is
begin
    DO <= DI / 2;
end archi;</pre>
```

Division by Constant 2 Divider Verilog Coding Example

```
//
// Division By Constant 2
//
module v_divider_1 (DI, DO);
```

```
input [7:0] DI;
output [7:0] DO;
assign DO = DI / 2;
endmodule
```

# **Resource Sharing HDL Coding Techniques**

This section discusses Resource Sharing HDL Coding Techniques, and includes:

- "About Resource Sharing"
- "Resource Sharing Log File"
- "Resource Sharing Related Constraints"
- "Resource Sharing Coding Examples"

### About Resource Sharing

The goal of resource sharing (also known as folding) is to minimize the number of operators and the subsequent logic in the synthesized design. This optimization is based on the principle that two similar arithmetic resources may be implemented as one single arithmetic operator if they are never used at the same time. XST performs both resource sharing and, if required, reduces the number of multiplexers.

XST supports resource sharing for adders, subtractors, adders/subtractors and multipliers.

If the optimization goal is SPEED, disabling resource sharing may give better results. To improve clock frequency, XST recommends deactivating resource sharing at the Advanced HDL Synthesis step.

### Resource Sharing Log File

. . .

The XST log file reports the type and size of recognized arithmetic blocks and multiplexers during the Macro Recognition step.

```
Synthesizing Unit <addsub>.
    Related source file is resource_sharing_1.vhd.
    Found 8-bit addsub for signal <res>.
    Found 8 1-bit 2-to-1 multiplexers.
    Summary:
        inferred 1 Adder/Subtracter(s).
        inferred 8 Multiplexer(s).
Unit <addsub> synthesized.
-------
HDL Synthesis Report
Macro Statistics
                                  : 1
 # Multiplexers
2-to-1 multiplexer
# Adders/Subtractors
                                   : 1
                                   : 1
  8-bit addsub
                                   : 1
```

\_\_\_\_\_



```
* Advanced HDL Synthesis *

INFO:Xst - HDL ADVISOR - Resource sharing has identified that some

arithmetic operations in this design can share the same physical

resources for reduced device utilization. For improved clock frequency

you may try to disable resource sharing.
```

## **Resource Sharing Related Constraints**

• "Resource Sharing (RESOURCE\_SHARING)"

# **Resource Sharing Coding Examples**

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>.

• "Resource Sharing"

#### **Resource Sharing**

This section discusses Resource Sharing, and includes:

- "Resource Sharing Diagram"
- "Resource Sharing Pin Descriptions"
- "Resource Sharing VHDL Coding Example"
- "Resource Sharing Verilog Coding Example"

For the following VHDL and Verilog examples, XST gives the following solution.




Figure 2-52: Resource Sharing Diagram

IO Pins	Description
A, B, C	Operands
OPER	Operation Selector
RES	Data Output

Resource Sharing VHDL Coding Example

```
--
--
Resource Sharing
--
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity resource_sharing_1 is
    port(A,B,C : in std_logic_vector(7 downto 0);
        OPER : in std_logic;
        RES : out std_logic_vector(7 downto 0));
end resource_sharing_1;
architecture archi of resource_sharing_1 is
begin
    RES <= A + B when OPER='0' else A - C;
end archi;</pre>
```

Resource Sharing Verilog Coding Example

```
//
// Resource Sharing
//
module v_resource_sharing_1 (A, B, C, OPER, RES);
    input [7:0] A, B, C;
    input OPER;
    output [7:0] RES;
    wire [7:0] RES;
    assign RES = !OPER ? A + B : A - C;
endmodule
```

# **RAMs and ROMs HDL Coding Techniques**

This section discusses RAMs and ROMs HDL Coding Techniques, and includes:

- "About RAMs and ROMs"
- "RAMs and ROMs Log File"
- "RAMs and ROMs Related Constraints"
- "RAMs and ROMs Coding Examples"
- "Initializing RAM Coding Examples"

### About RAMs and ROMs

If you do not want to instantiate RAM primitives to keep your HDL code architecture independent, use XST automatic RAM recognition. XST can infer distributed as well as block RAM. It covers the following characteristics, offered by these RAM types:



- Synchronous write
- Write enable
- RAM enable
- Asynchronous or synchronous read
- Reset of the data output latches
- Data output reset
- Single, dual or multiple-port read
- Single-port/Dual-port write
- Parity bits (Supported for all FPGA devices except Virtex, Virtex-E, Spartan-II, and Spartan-IIE)
- Block Ram with Byte-Wide Write Enable
- Simple dual-port BRAM

XST does not support RAMs and ROMs with negative addresses.

The type of inferred RAM depends on its description.

- RAM descriptions with an asynchronous read generate a distributed RAM macro.
- RAM descriptions with a synchronous read generate a block RAM macro. In some cases, a block RAM macro can actually be implemented with distributed RAM. The decision on the actual RAM implementation is done by the macro generator.

If a given template can be implemented using Block and Distributed RAM, XST implements BLOCK ones. Use the "RAM Style (RAM\_STYLE)" constraint to control RAM implementation and select a desirable RAM type. For more information, see "XST Design Constraints."

The following block RAM features are *not* yet supported:

- Parity bits (Virtex, Virtex-E, Spartan-II, and Spartan-IIE are not supported)
- Different aspect ratios on each port
- Simple dual-port distributed RAMs
- Quad-port distributed RAMs

XST uses speed-oriented implementation to implement RAMs on BRAM resources. This gives good results for speed, but may require more BRAM resources than area-oriented implementation. XST does not support area-oriented BRAM implementation. Xilinx recommends Core Generator for area-oriented implementation.

For more information on RAM implementation, see "XST FPGA Optimization."

XST can implement Finite State Machines (see "Finite State Machines (FSMs) HDL Coding Techniques") and map general logic (see "Mapping Logic Onto Block RAM") on block RAMs.

XST automatically controls BRAM resources on the target device. "BRAM Utilization Ratio (BRAM\_UTILIZATION\_RATIO)" allows you to specify the number of BRAM blocks that XST must not exceed during synthesis.

BRAM management goes through the following steps.

• To achieve better design speed, XST implements small RAMs and ROMs using distributed resources. RAMs and ROMs are considered *small* if their sizes follow the rules shown in Table 2-65, "Rules for Small RAMs and ROMs."

FPGA Devices	Size (bits) * Width (bits)
Virtex, Virtex-E	<= 256
Virtex-II, Virtex-II Pro, Virtex-4	<= 512
Virtex-5	<= 512

Table 2-65: Rules for Small RAMs and ROMs

Use "RAM Style (RAM\_STYLE)" and "ROM Style (ROM\_STYLE)" to force implementation of small RAMs and ROMs on BRAM resources.

XST calculates the available BRAM resources for inference using the following formula:

Total\_Number\_of\_Available\_BRAMs - Number\_of\_Reserved\_BRAMs

In this formula **Total\_Number\_of\_Available\_BRAMs** is the number of BRAMs specified by the "BRAM Utilization Ratio (BRAM\_UTILIZATION\_RATIO)" constraint. By default it is 100%. The **Number of Reserved\_BRAMs** encapsulates:

- The number of instantiated BRAMs in the HDL code from the UNISIM library
- The number of RAM which were forced to be implemented as BRAMs by the "RAM Style (RAM\_STYLE)" and "ROM Style (ROM\_STYLE)" constraints
- The number of BRAMs generated using BRAM mapping optimizations (BRAM\_MAP).

Where there are available BRAM resources, XST implements the largest inferred RAMs and ROMs using BRAM, and the smallest on distributed resources.

If the **Number\_of\_Reserved\_BRAMs** exceeds available resources, XST implements them as block RAMs, and all inferred RAMs are implemented on distributed memory.

As soon as this process is completed, XST can automatically pack two small single-port BRAMs in a single BRAM primitive. This optimization is controlled by the "Automatic BRAM Packing (AUTO\_BRAM\_PACKING)" constraint. It is disabled by default.

For more information, see "BRAM Utilization Ratio (BRAM\_UTILIZATION\_RATIO)" and "Automatic BRAM Packing (AUTO\_BRAM\_PACKING)."

## RAMs and ROMs Log File

The XST log file reports the type and size of recognized RAM as well as complete information on its I/O ports. RAM recognition consists of two steps.

- During the HDL Synthesis step, XST recognizes the presence of the memory structure in the HDL code.
- During the Advanced HDL Synthesis step, XST decides how to implement a specific memory (that is, whether to use Block or Distributed memory resources).

\* HDL Synthesis \*

Synthesizing Unit <rams\_16>.
 Related source file is "rams\_16.vhd".
 Found 64x16-bit dual-port RAM <Mram\_RAM> for signal <RAM>.
 Found 16-bit register for signal <doa>.
 Found 16-bit register for signal <dob>.



```
Summary:
inferred 1 RAM(s).
inferred 32 D-type flip-flop(s).
Unit <rams_16> synthesized.
_____
HDL Synthesis Report
Macro Statistics
# RAMs
                                : 1
                                : 1
64x16-bit dual-port RAM
                                : 2
# Registers
16-bit register
                                : 2
_____
_____
             Advanced HDL Synthesis
_____
Synthesizing (advanced) Unit <rams_16>.
INFO:Xst - The RAM <Mram_RAM> will be implemented as a BLOCK RAM, absorbing the following
register(s): <doa> <dob>
  _____
         Block
  ram_type
                                    _____
   Port A
     aspect ratio | 64-word x 16-bit
              write-first
     mode
                                    | rise
     clkA
              connected to signal <clka>
     enA
              | connected to signal <ena>
                                     | high
            connected to signal <wea>
connected to signal <addra>
     weA
                                     | high
     addrA
     diA
              | connected to signal <dia>
     doA
              | connected to signal <doa>
  _____
  | optimization
             speed
                                     _____
   Port B
     aspect ratio | 64-word x 16-bit
              write-first
     mode
                                    | rise
     clkB
              connected to signal <clkb>
              | connected to signal <enb>
     enB
                                     | high
     weB
              | connected to signal <web>
                                     | high
     addrB
             connected to signal <addrb>
     diB
             connected to signal <dib>
             | connected to signal <dob>
     doB
  _____
  optimization speed
                                     _____
Unit <rams_16> synthesized (advanced).
_____
```

Advanced HDL Synthesis Report

```
Macro Statistics
# RAMs : 1
64x16-bit dual-port block RAM : 1
```

. . .

# RAMs and ROMs Related Constraints

- "BRAM Utilization Ratio (BRAM\_UTILIZATION\_RATIO)"
- "Automatic BRAM Packing (AUTO\_BRAM\_PACKING)"
- "RAM Extraction (RAM\_EXTRACT)"
- "RAM Style (RAM\_STYLE)"
- "ROM Extraction (ROM\_EXTRACT)"
- "ROM Style (ROM\_STYLE)"

XST accepts LOC and "RLOC" constraints on inferred RAMs that can be implemented in a single block RAM primitive. The LOC and RLOC constraints are propagated to the NGC netlist.

# RAMs and ROMs Coding Examples

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>

- "Single-Port RAM in Read-First Mode"
- "Single-Port RAM in Write-First Mode"
- "Single-Port RAM In No-Change Mode"
- "Single-Port RAM With Asynchronous Read"
- "Single-Port RAM With False Synchronous Read"
- "Single-Port RAM With False Synchronous Read and Reset on the Output"
- "Single-Port RAM With Synchronous Read (Read Through)"
- "Single-Port RAM With Enable"
- "Dual-Port RAM With Asynchronous Read"
- "Dual-Port RAM With False Synchronous Read"
- "Dual-Port RAM With Synchronous Read (Read Through)"
- "Dual-Port RAM With Synchronous Read (Read Through) and Two Clocks"
- "Dual-Port RAM With One Enable Controlling Both Ports"
- "Dual Port RAM With Enable on Each Port"
- "Dual-Port Block RAM With Different Clocks"
- "Dual-Port Block RAM With Two Write Ports"
- "Block Ram with Byte-Wide Write Enable"
- "Multiple-Port RAM Descriptions"
- "Block RAM With Reset"
- "Block RAM With Optional Output Registers"



#### RAM Read/Write Modes Virtex-II and Higher

Block RAM resources in the following devices offer different read/write synchronization modes:

- Virtex-II
- Virtex-II Pro
- Virtex-4
- Virtex-5
- Spartan-3
- Spartan-3E
- Spartan-3A

The following coding examples describe a single-port block RAM. You can deduce descriptions of dual-port block RAMs from these examples. Dual-port block RAMs can be configured with a different read/write mode on each port. Inference supports this capability.

Table 2-66, "Support For Read/Write Modes," summarizes support for read/write modes according to the targeted devices and how XST handles it.

Table 2-66: Support For Read/Write Modes

Devices	Inferred Modes	Behavior
<ul> <li>Spartan-3, Spartan-3E, Spartan-3A</li> <li>Virtex-II, Virtex-II Pro,</li> <li>Virtex-4, Virtex-5</li> </ul>	<ul><li>write-first</li><li>read-first</li><li>no-change</li></ul>	<ul> <li>Macro inference and generation</li> <li>Attach adequate WRITE_MODE, WRITE_MODE_A, WRITE_MODE_B constraints to generated block RAMs in NCF</li> </ul>
<ul> <li>Virtex, Virtex-E</li> <li>Spartan-II Spartan-IIE</li> </ul>	• write-first	<ul> <li>Macro inference and generation</li> <li>No constraint to attach on generated block RAMs</li> </ul>
• CPLD	• none	RAM inference completely disabled

#### Single-Port RAM in Read-First Mode

This section discusses Single-Port RAM in Read-First Mode, and includes:

- "Single-Port RAM in Read-First Mode Diagram"
- "Single-Port RAM in Read-First Mode Pin Descriptions"
- "Single-Port RAM in Read-First Mode VHDL Coding Example"
- "Single-Port RAM in Read-First Mode Verilog Coding Example"






Table 2-67: Single-Port RAM in Read-First Mode Pin Descriptions

IO Pins	Description
clk	Positive-Edge Clock
we	Synchronous Write Enable (Active High)
en	Clock Enable
addr	Read/Write Address
di	Data Input
do	Data Output

Single-Port RAM in Read-First Mode VHDL Coding Example

```
-- Read-First Mode
--
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity rams_01 is
    port (clk : in std_logic;
        we : in std_logic;
        en : in std_logic;
        addr : in std_logic;
        di : in std_logic_vector(5 downto 0);
        di : in std_logic_vector(15 downto 0);
```



```
: out std_logic_vector(15 downto 0));
          do
end rams_01;
architecture syn of rams_01 is
    type ram_type is array (63 downto 0) of std_logic_vector (15 downto
0);
    signal RAM: ram_type;
begin
    process (clk)
    begin
        if clk'event and clk = '1' then
            if en = '1' then
                 if we = '1' then
                     RAM(conv_integer(addr)) <= di;</pre>
                 end if;
                 do <= RAM(conv_integer(addr)) ;</pre>
            end if;
        end if;
    end process;
end syn;
```

Single-Port RAM in Read-First Mode Verilog Coding Example

```
11
// Read-First Mode
11
module v_rams_01 (clk, en, we, addr, di, do);
    input clk;
    input we;
    input en;
    input [5:0] addr;
    input [15:0] di;
    output [15:0] do;
          [15:0] RAM [63:0];
    req
           [15:0] do;
    reg
    always @(posedge clk)
    begin
        if (en)
        begin
            if (we)
               RAM[addr]<=di;</pre>
            do <= RAM[addr];</pre>
        end
    end
```

endmodule

#### Single-Port RAM in Write-First Mode

This section discusses Single-Port RAM In Write-First Mode, and includes:

- "Single-Port RAM in Write-First Mode Diagram"
- "Single-Port RAM in Write-First Mode Pin Descriptions"
- "Single-Port RAM in Write-First Mode VHDL Coding Example One"
- "Single-Port RAM in Write-First Mode VHDL Coding Example Two"
- "Single-Port RAM In Write-First Mode Verilog Coding Example One"
- "Single-Port RAM In Write-First Mode Verilog Coding Example Two"




Figure 2-54: Single-Port RAM in Write-First Mode Diagram

Table 2-68: Sin	le-Port RAM in Write-First Mode Pin Descriptions
-----------------	--

IO Pins	Description	
clk	Positive-Edge Clock	
we	Synchronous Write Enable (Active High)	
en	Clock Enable	
addr	Read/Write Address	
di	Data Input	
do	Data Output	

Single-Port RAM in Write-First Mode VHDL Coding Example One

```
-- Write-First Mode (template 1)

-- Write-First Mode (template 1)

--

library ieee;

use ieee.std_logic_1164.all;

use ieee.std_logic_unsigned.all;

entity rams_02a is

port (clk : in std_logic;

we : in std_logic;
```



```
: in std_logic;
          en
          addr : in std_logic_vector(5 downto 0);
              : in std_logic_vector(15 downto 0);
          di
          do
               : out std_logic_vector(15 downto 0));
end rams_02a;
architecture syn of rams_02a is
    type ram_type is array (63 downto 0)
         of std_logic_vector (15 downto 0);
    signal RAM : ram_type;
begin
    process (clk)
   begin
        if clk'event and clk = '1' then
            if en = '1' then
                 if we = '1' then
                     RAM(conv_integer(addr)) <= di;</pre>
                    do <= di;
                else
                     do <= RAM( conv_integer(addr));</pre>
                end if;
            end if;
        end if;
    end process;
```

end syn;

Single-Port RAM in Write-First Mode VHDL Coding Example Two

```
-- Write-First Mode (template 2)
_ _
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity rams_02b is
port (clk : in std_logic;
      we : in std_logic;
      en : in std_logic;
      addr : in std_logic_vector(5 downto 0);
      di : in std_logic_vector(15 downto 0);
          : out std_logic_vector(15 downto 0));
      do
end rams_02b;
architecture syn of rams_02b is
   type ram_type is array (63 downto 0) of std_logic_vector (15 downto
0);
    signal RAM : ram_type;
    signal read_addr: std_logic_vector(5 downto 0);
begin
    process (clk)
    begin
        if clk'event and clk = '1' then
            if en = '1' then
```

Single-Port RAM In Write-First Mode Verilog Coding Example One

```
11
// Write-First Mode (template 1)
11
module v_rams_02a (clk, we, en, addr, di, do);
    input clk;
    input we;
    input en;
    input [5:0] addr;
    input [15:0] di;
    output [15:0] do;
          [15:0] RAM [63:0];
    reg
           [15:0] do;
    reg
    always @(posedge clk)
    begin
        if (en)
        begin
            if (we)
            begin
                RAM[addr] <= di;</pre>
                 do <= di;
            end
            else
                do <= RAM[addr];</pre>
        end
    end
endmodule
```

Single-Port RAM In Write-First Mode Verilog Coding Example Two

```
//
// Write-First Mode (template 2)
//
module v_rams_02b (clk, we, en, addr, di, do);
    input clk;
    input clk;
    input we;
    input we;
    input en;
    input [5:0] addr;
    input [15:0] di;
```



```
output [15:0] do;
    reg
            [15:0] RAM [63:0];
            [5:0] read_addr;
    reg
    always @(posedge clk)
    begin
        if (en)
        begin
             if (we)
               RAM[addr] <= di;</pre>
             read_addr <= addr;</pre>
         end
    end
    assign do = RAM[read_addr];
endmodule
```

### Single-Port RAM In No-Change Mode

This section discusses Single-Port RAM In No-Change Mode, and includes:

- "Single-Port RAM In No-Change Mode Diagram"
- "Single-Port RAM In No-Change Mode Pin Descriptions"
- "Single-Port RAM In No-Change Mode VHDL Coding Example"
- "Single-Port RAM In No-Change Mode Verilog Coding Example"




Figure 2-55: Single-Port RAM In No-Change Mode Diagram

Table 2-69: Single-Port RAM In No-Change Mode Pin Descriptions

IO Pins	Description	
clk	Positive-Edge Clock	
we	Synchronous Write Enable (Active High)	
en	Clock Enable	

IO Pins	Description
addr	Read/Write Address
di	Data Input
do	Data Output

Table 2-69: Single-Port RAM In No-Change Mode Pin Descriptions (Cont'd)

Single-Port RAM In No-Change Mode VHDL Coding Example

```
-- No-Change Mode (template 1)
_ _
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity rams_03 is
    port (clk : in std_logic;
          we : in std_logic;
          en : in std_logic;
          addr : in std_logic_vector(5 downto 0);
          di : in std_logic_vector(15 downto 0);
              : out std_logic_vector(15 downto 0));
          do
end rams_03;
architecture syn of rams_03 is
   type ram_type is array (63 downto 0) of std_logic_vector (15 downto
0);
    signal RAM : ram_type;
begin
    process (clk)
    begin
        if clk'event and clk = '1' then
            if en = '1' then
                if we = '1' then
                    RAM(conv_integer(addr)) <= di;</pre>
                else
                    do <= RAM( conv_integer(addr));</pre>
                end if;
            end if;
        end if;
    end process;
end syn;
```

Single-Port RAM In No-Change Mode Verilog Coding Example

```
//
// No-Change Mode (template 1)
//
module v_rams_03 (clk, we, en, addr, di, do);
    input clk;
    input we;
```

```
input
       en;
input [5:0] addr;
input [15:0] di;
output [15:0] do;
reg
       [15:0] RAM [63:0];
reg
       [15:0] do;
always @(posedge clk)
begin
    if (en)
    begin
        if (we)
           RAM[addr] <= di;</pre>
        else
           do <= RAM[addr];</pre>
    end
end
```

endmodule

#### Single-Port RAM With Asynchronous Read

This section discusses Single-Port RAM With Asynchronous Read, and includes:

- "Single-Port RAM With Asynchronous Read Diagram"
- "Single-Port RAM With Asynchronous Read Pin Descriptions"
- "Single-Port RAM With Asynchronous Read VHDL Coding Example"
- "Single-Port RAM With Asynchronous Read Verilog Coding Example"

The following descriptions are directly mappable onto distributed RAM only.






Table 2-70:	Single-Port RAM	With	Asynchronous Read	Pin Descriptions

IO Pins	Description
clk	Positive-Edge Clock
we	Synchronous Write Enable (Active High)
a	Read/Write Address
di	Data Input
do	Data Output

Single-Port RAM With Asynchronous Read VHDL Coding Example

```
___
   -- Single-Port RAM with Asynchronous Read
   ___
   library ieee;
   use ieee.std_logic_1164.all;
   use ieee.std_logic_unsigned.all;
   entity rams_04 is
       port (clk : in std_logic;
             we : in std_logic;
             a : in std_logic_vector(5 downto 0);
             di : in std_logic_vector(15 downto 0);
             do : out std_logic_vector(15 downto 0));
   end rams_04;
   architecture syn of rams_04 is
       type ram_type is array (63 downto 0) of std_logic_vector (15 downto
   0);
       signal RAM : ram_type;
   begin
       process (clk)
       begin
            if (clk'event and clk = '1') then
               if (we = '1') then
                    RAM(conv_integer(a)) <= di;</pre>
                end if;
           end if;
       end process;
       do <= RAM(conv_integer(a));</pre>
   end syn;
Single-Port RAM With Asynchronous Read Verilog Coding Example
   11
```

```
// Single-Port RAM with Asynchronous Read
11
module v_rams_04 (clk, we, a, di, do);
    input clk;
    input we;
    input [5:0] a;
    input [15:0] di;
    output [15:0] do;
          [15:0] ram [63:0];
    reg
    always @(posedge clk) begin
        if (we)
            ram[a] <= di;</pre>
    end
    assign do = ram[a];
endmodule
```

#### Single-Port RAM With False Synchronous Read

This section discusses Single-Port RAM With False Synchronous Read, and includes:

- "Single-Port RAM With False Synchronous Read Diagram"
- "Single-Port RAM With False Synchronous Read Pin Descriptions"
- "Single-Port RAM With False Synchronous Read VHDL Coding Example"
- "Single-Port RAM With False Synchronous Read Verilog Coding Example"

The following descriptions do not implement true synchronous read access as defined by the Virtex block RAM specification, where the read address is registered. They are mappable only onto distributed RAM with an additional buffer on the data output for the Virtex and Virtex-E families, as shown in Figure 2-57, "Single-Port RAM With False Synchronous Read Diagram." For Virtex-II devices and higher, this code is mappable on block RAM.




Figure 2-57: Single-Port RAM With False Synchronous Read Diagram

Table 2-71: Single-Port RAM With False Synchronous Read Pin Descriptions

IO Pins	Description		
clk	Positive-Edge Clock		
we	Synchronous Write Enable (Active High)		
a	Read/Write Address		
di	Data Input		
do	Data Output		

Single-Port RAM With False Synchronous Read VHDL Coding Example

```
: in std_logic_vector(5 downto 0);
          а
          di : in std_logic_vector(15 downto 0);
          do : out std_logic_vector(15 downto 0));
end rams_05;
architecture syn of rams_05 is
    type ram_type is array (63 downto 0)
         of std_logic_vector (15 downto 0);
    signal RAM : ram_type;
begin
    process (clk)
    begin
        if (clk'event and clk = '1') then
            if (we = '1') then
                RAM(conv_integer(a)) <= di;</pre>
            end if;
            do <= RAM(conv_integer(a));</pre>
        end if;
    end process;
end syn;
```

Single-Port RAM With False Synchronous Read Verilog Coding Example

```
11
// Single-Port RAM with "False" Synchronous Read
11
module v_rams_05 (clk, we, a, di, do);
    input clk;
    input we;
    input [5:0] a;
    input [15:0] di;
    output [15:0] do;
    req
         [15:0] ram [63:0];
           [15:0] do;
    reg
    always @(posedge clk) begin
        if (we)
            ram[a] <= di;</pre>
        do <= ram[a];</pre>
    end
endmodule
```

Single-Port RAM With False Synchronous Read and Reset on the Output

This section discusses Single-Port RAM With False Synchronous Read and Reset on the Output, and includes:

- "Single-Port RAM With False Synchronous Read and Reset on the Output Diagram"
- "Single-Port RAM With False Synchronous Read and Reset on the Output Pin Descriptions"
- "Single-Port RAM With False Synchronous Read and Reset on the Output VHDL Coding Example"
- "Single-Port RAM With False Synchronous Read and Reset on the Output Verilog Coding Example"

The following descriptions, featuring an additional reset of the RAM output, are also *only mappable onto Distributed RAM* with an additional resetable buffer on the data output as shown in Figure 2-58, "Single-Port RAM With False Synchronous Read and Reset on the Output Diagram."




Figure 2-58: Single-Port RAM With False Synchronous Read and Reset on the Output Diagram

Table 2-72:	Single-Port RAM	With False	Synchronous	Read and	Reset on	the Output
Pin Descripti	ions					

IO Pins	Description	
clk	Positive-Edge Clock	
we	Synchronous Write Enable (Active High)	
rst	Synchronous Output Reset (Active High)	
a	Read/Write Address	
di	Data Input	
do	Data Output	

Single-Port RAM With False Synchronous Read and Reset on the Output VHDL Coding Example

```
-- Single-Port RAM with "False" Synchronous Read with
-- an additional reset of the RAM output,
library ieee;
use ieee.std_logic_1164.all;
```

```
use ieee.std_logic_unsigned.all;
entity rams_06 is
    port (clk : in std_logic;
          we : in std_logic;
          rst : in std_logic;
          a : in std_logic_vector(5 downto 0);
          di : in std_logic_vector(15 downto 0);
              : out std_logic_vector(15 downto 0));
          do
end rams_06;
architecture syn of rams_06 is
   type ram_type is array (63 downto 0) of std_logic_vector (15 downto
0);
    signal RAM : ram_type;
begin
    process (clk)
    begin
        if (clk'event and clk = '1') then
            if (we = '1') then
                RAM(conv_integer(a)) <= di;</pre>
            end if;
            if (rst = '1') then
                do <= (others => '0');
            else
                do <= RAM(conv_integer(a));</pre>
            end if;
        end if;
    end process;
```

end syn;

Single-Port RAM With False Synchronous Read and Reset on the Output Verilog Coding Example

```
11
// Single-Port RAM with "False" Synchronous Read with
// an additional reset of the RAM output,
11
module v_rams_06 (clk, we, rst, a, di, do);
    input clk;
    input we;
    input rst;
    input [5:0] a;
    input [15:0] di;
    output [15:0] do;
    reg
          [15:0] ram [63:0];
    reg
          [15:0] do;
    always @(posedge clk) begin
        if (we)
            ram[a] <= di;</pre>
```



## Single-Port RAM With Synchronous Read (Read Through)

This section discusses Single-Port RAM With Synchronous Read (Read Through), and includes:

- "Single-Port RAM With Synchronous Read (Read Through) Diagram"
- "Single-Port RAM With Synchronous Read (Read Through) Pin Descriptions"
- "Single-Port RAM With Synchronous Read (Read Through) VHDL Coding Example"
- "Single-Port RAM With Synchronous Read (Read Through) Verilog Coding Example"

The following description implements a true synchronous read. A true synchronous read is the synchronization mechanism in Virtex block RAMs, where the read address is registered on the RAM clock edge. Such descriptions are *directly mappable onto block RAM*, as shown in Figure 2-59, "Single-Port RAM With Synchronous Read (Read Through) Diagram." The same descriptions can also be mapped onto *Distributed RAM*.






Table 2-73: S	Single-Port RAM With	Synchronous Read	l (Read Through	) Pin Descriptions
---------------	----------------------	------------------	-----------------	--------------------

IO Pins	Description	
clk	Positive-Edge Clock	
we	Synchronous Write Enable (Active High)	
a	Read/Write Address	
di	Data Input	
do	Data Output	

\_ \_

Single-Port RAM With Synchronous Read (Read Through) VHDL Coding Example

```
-- Single-Port RAM with Synchronous Read (Read Through)
___
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity rams_07 is
    port (clk : in std_logic;
          we : in std_logic;
          a : in std_logic_vector(5 downto 0);
          di : in std_logic_vector(15 downto 0);
          do : out std_logic_vector(15 downto 0));
end rams_07;
architecture syn of rams_07 is
   type ram_type is array (63 downto 0) of std_logic_vector (15 downto
0);
    signal RAM : ram_type;
    signal read_a : std_logic_vector(5 downto 0);
begin
    process (clk)
    begin
        if (clk'event and clk = '1') then
            if (we = '1') then
                RAM(conv_integer(a)) <= di;</pre>
            end if;
            read_a <= a;</pre>
        end if;
    end process;
    do <= RAM(conv_integer(read_a));</pre>
end syn;
```

Single-Port RAM With Synchronous Read (Read Through) Verilog Coding Example

```
11
// Single-Port RAM with Synchronous Read (Read Through)
11
module v_rams_07 (clk, we, a, di, do);
    input clk;
    input we;
    input [5:0] a;
    input [15:0] di;
    output [15:0] do;
          [15:0] ram [63:0];
    reg
           [5:0] read_a;
    reg
    always @(posedge clk) begin
        if (we)
            ram[a] <= di;</pre>
        read_a <= a;</pre>
```




```
end
assign do = ram[read_a];
endmodule
```

### Single-Port RAM With Enable

This section discusses Single-Port RAM With Enable, and includes:

- "Single-Port RAM With Enable Diagram"
- "Single-Port RAM With Enable Pin Descriptions"
- "Single-Port RAM With Enable VHDL Coding Example"
- "Single-Port RAM With Enable Verilog Coding Example"



X9478

Figure 2-60: Single-Port RAM With Enable Diagram

Table 2-74:	Single-Port	<b>RAM With Enable</b>	Pin Descriptions
-------------	-------------	------------------------	------------------

IO Pins	Description
clk	Positive-Edge Clock
en	Global Enable
we	Synchronous Write Enable (Active High)
a	Read/Write Address
di	Data Input
do	Data Output

Single-Port RAM With Enable VHDL Coding Example

```
_ _
-- Single-Port RAM with Enable
___
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity rams_08 is
   port (clk : in std_logic;
          en : in std_logic;
          we : in std_logic;
          a : in std_logic_vector(5 downto 0);
          di : in std_logic_vector(15 downto 0);
          do : out std_logic_vector(15 downto 0));
end rams_08;
architecture syn of rams_08 is
   type ram_type is array (63 downto 0) of std_logic_vector (15 downto
0);
    signal RAM : ram_type;
    signal read_a : std_logic_vector(5 downto 0);
begin
    process (clk)
   begin
        if (clk'event and clk = '1') then
            if (en = '1') then
                if (we = '1') then
                    RAM(conv_integer(a)) <= di;</pre>
                end if;
                read_a <= a;</pre>
            end if;
        end if;
    end process;
    do <= RAM(conv_integer(read_a));</pre>
end syn;
```

Single-Port RAM With Enable Verilog Coding Example

```
//
// Single-Port RAM with Enable
//
module v_rams_08 (clk, en, we, a, di, do);
input clk;
input en;
input en;
input [5:0] a;
input [5:0] a;
input [15:0] di;
output [15:0] do;
reg [15:0] ram [63:0];
reg [5:0] read_a;
```

# Dual-Port RAM With Asynchronous Read

This section discusses Dual-Port RAM With Asynchronous Read, and includes:

- "Dual-Port RAM With Asynchronous Read Diagram"
- "Dual-Port RAM With Asynchronous Read Pin Descriptions"
- "Dual-Port RAM With Asynchronous Read VHDL Coding Example"
- "Dual-Port RAM With Asynchronous Read Verilog Coding Example"

Figure 2-61, "Dual-Port RAM With Asynchronous Read Diagram," shows where the two output ports are used. It is directly mappable onto *Distributed RAM only*.




Figure 2-61: Dual-Port RAM With Asynchronous Read Diagram

IO Pins	Description
clk	Positive-Edge Clock
we	Synchronous Write Enable (Active High)
a	Write Address/Primary Read Address
dpra	Dual Read Address
di	Data Input
spo	Primary Output Port
dpo	Dual Output Port

\_ \_

Dual-Port RAM With Asynchronous Read VHDL Coding Example

```
-- Dual-Port RAM with Asynchronous Read
___
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity rams_09 is
   port (clk : in std_logic;
          we : in std_logic;
          a : in std_logic_vector(5 downto 0);
          dpra : in std_logic_vector(5 downto 0);
          di
              : in std_logic_vector(15 downto 0);
          spo : out std_logic_vector(15 downto 0);
          dpo : out std_logic_vector(15 downto 0));
end rams_09;
architecture syn of rams_09 is
   type ram_type is array (63 downto 0) of std_logic_vector (15 downto
0);
    signal RAM : ram_type;
begin
    process (clk)
   begin
        if (clk'event and clk = '1') then
            if (we = '1') then
                RAM(conv_integer(a)) <= di;</pre>
            end if;
        end if;
    end process;
    spo <= RAM(conv_integer(a));</pre>
    dpo <= RAM(conv_integer(dpra));</pre>
end syn;
```

Dual-Port RAM With Asynchronous Read Verilog Coding Example

```
//
// Dual-Port RAM with Asynchronous Read
//
module v_rams_09 (clk, we, a, dpra, di, spo, dpo);
input clk;
input clk;
input [5:0] a;
input [5:0] dpra;
input [5:0] dpra;
input [15:0] di;
output [15:0] spo;
output [15:0] dpo;
reg [15:0] ram [63:0];
always @(posedge clk) begin
if (we)
```



```
ram[a] <= di;
end
assign spo = ram[a];
assign dpo = ram[dpra];
endmodule
```

# Dual-Port RAM With False Synchronous Read

This section discusses Dual-Port RAM With False Synchronous Read, and includes:

- "Dual-Port RAM With False Synchronous Read Diagram"
- "Dual-Port RAM With False Synchronous Read Pin Descriptions"
- "Dual-Port RAM With False Synchronous Read VHDL Coding Example"
- "Dual-Port RAM With False Synchronous Read Verilog Coding Example"

The following description is mapped onto Distributed RAM with additional registers on the data outputs for Virtex and Virtex-E devices. For Virtex-II devices and higher, this code is mappable on block RAM.




Figure 2-62: Dual-Port RAM With False Synchronous Read Diagram

IO Pins	Description
clk	Positive-Edge Clock
we	Synchronous Write Enable (Active High)
a	Write Address/Primary Read Address
dpra	Dual Read Address
di	Data Input
spo	Primary Output Port
dpo	Dual Output Port

\_ \_

Dual-Port RAM With False Synchronous Read VHDL Coding Example

```
-- Dual-Port RAM with False Synchronous Read
___
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity rams_10 is
   port (clk : in std_logic;
          we : in std_logic;
          a : in std_logic_vector(5 downto 0);
          dpra : in std_logic_vector(5 downto 0);
          di
             : in std_logic_vector(15 downto 0);
          spo : out std_logic_vector(15 downto 0);
          dpo : out std_logic_vector(15 downto 0));
end rams_10;
architecture syn of rams_10 is
   type ram_type is array (63 downto 0) of std_logic_vector (15 downto
0);
    signal RAM : ram_type;
begin
    process (clk)
   begin
        if (clk'event and clk = '1') then
            if (we = '1') then
                RAM(conv_integer(a)) <= di;</pre>
            end if;
            spo <= RAM(conv_integer(a));</pre>
            dpo <= RAM(conv_integer(dpra));</pre>
        end if;
    end process;
end syn;
```

Dual-Port RAM With False Synchronous Read Verilog Coding Example

```
11
// Dual-Port RAM with False Synchronous Read
11
module v_rams_10 (clk, we, a, dpra, di, spo, dpo);
    input clk;
    input we;
    input [5:0] a;
    input [5:0] dpra;
    input [15:0] di;
    output [15:0] spo;
    output [15:0] dpo;
          [15:0] ram [63:0];
    reg
    reg
           [15:0] spo;
         [15:0] dpo;
    reg
```



```
always @(posedge clk) begin
    if (we)
        ram[a] <= di;
    spo <= ram[a];
    dpo <= ram[dpra];
    end
endmodule
```

# Dual-Port RAM With Synchronous Read (Read Through)

This section discusses Dual-Port RAM With Synchronous Read (Read Through), and includes:

- "Dual-Port RAM With Synchronous Read (Read Through) Diagram"
- "Dual-Port RAM With Synchronous Read (Read Through) Pin Descriptions"
- "Dual-Port RAM With Synchronous Read (Read Through) VHDL Coding Example"
- "Dual-Port RAM With Synchronous Read (Read Through) Verilog Coding Example"

The following descriptions are directly mappable onto block RAM, as shown in Figure 2-63, "Dual-Port RAM With Synchronous Read (Read Through) Diagram." They may also be implemented with Distributed RAM.




Figure 2-63: Dual-Port RAM With Synchronous Read (Read Through) Diagram

IO Pins	Description
clk	Positive-Edge Clock
we	Synchronous Write Enable (Active High)
a	Write Address/Primary Read Address
dpra	Dual Read Address
di	Data Input
spo	Primary Output Port
dpo	Dual Output Port

Table 2-77:	Dual-Port RAM	With Synchronous	Read (Read	Through)	Pin Descriptions
-------------	---------------	------------------	------------	----------	------------------

\_ \_

Dual-Port RAM With Synchronous Read (Read Through) VHDL Coding Example

```
-- Dual-Port RAM with Synchronous Read (Read Through)
___
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity rams_11 is
   port (clk : in std_logic;
          we : in std_logic;
          a : in std_logic_vector(5 downto 0);
          dpra : in std_logic_vector(5 downto 0);
          di : in std_logic_vector(15 downto 0);
          spo : out std_logic_vector(15 downto 0);
          dpo : out std_logic_vector(15 downto 0));
end rams_11;
architecture syn of rams_11 is
    type ram_type is array (63 downto 0)
         of std_logic_vector (15 downto 0);
    signal RAM : ram_type;
    signal read_a : std_logic_vector(5 downto 0);
    signal read_dpra : std_logic_vector(5 downto 0);
begin
    process (clk)
   begin
        if (clk'event and clk = '1') then
            if (we = '1') then
                RAM(conv_integer(a)) <= di;</pre>
            end if;
            read_a <= a;</pre>
            read_dpra <= dpra;</pre>
        end if;
    end process;
    spo <= RAM(conv_integer(read_a));</pre>
    dpo <= RAM(conv_integer(read_dpra));</pre>
end syn;
```

Dual-Port RAM With Synchronous Read (Read Through) Verilog Coding Example


//
// Dual-Port RAM with Synchronous Read (Read Through)
//
module v\_rams\_11 (clk, we, a, dpra, di, spo, dpo);
 input clk;
 input clk;
 input [5:0] a;
 input [5:0] dpra;
 input [15:0] di;
 output [15:0] spo;
 output [15:0] dpo;

```
reg [15:0] ram [63:0];
reg [5:0] read_a;
reg [5:0] read_dpra;
always @(posedge clk) begin
    if (we)
        ram[a] <= di;
    read_a <= a;
    read_dpra <= dpra;
end
assign spo = ram[read_a];
assign dpo = ram[read_dpra];
```

# Dual-Port RAM With Synchronous Read (Read Through) and Two Clocks

This section discusses Dual-Port RAM With Synchronous Read (Read Through) and Two Clocks, and includes:

- "Dual-Port RAM With Synchronous Read (Read Through) and Two Clocks Diagram"
- "Dual-Port RAM With Synchronous Read (Read Through) and Two Clocks Pin Descriptions"
- "Dual-Port RAM With Synchronous Read (Read Through) and Two Clocks VHDL Coding Example"
- "Dual-Port RAM With Synchronous Read (Read Through) and Two Clocks Verilog Coding Example"



*Figure 2-64:* Dual-Port RAM With Synchronous Read (Read Through) and Two Clocks Diagram

Table 2-78:	Dual-Port RAM With Synchronous Read (Read Through) and Two Clocks
Pin Descripti	ons

IO Pins	Description
clk1	Positive-Edge Write/Primary Read Clock
clk2	Positive-Edge Dual Read Clock
we	Synchronous Write Enable (Active High)
add1	Write/Primary Read Address
add2	Dual Read Address
di	Data Input

*Table 2-78:* Dual-Port RAM With Synchronous Read (Read Through) and Two Clocks *(Cont'd)* Pin Descriptions

IO Pins	Description
do1	Primary Output Port
do2	Dual Output Port

Dual-Port RAM With Synchronous Read (Read Through) and Two Clocks VHDL Coding Example

```
_ _
-- Dual-Port RAM with Synchronous Read (Read Through)
-- using More than One Clock
_ _
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity rams_12 is
   port (clk1 : in std_logic;
          clk2 : in std_logic;
          we : in std_logic;
          add1 : in std_logic_vector(5 downto 0);
          add2 : in std_logic_vector(5 downto 0);
               : in std_logic_vector(15 downto 0);
          di
              : out std_logic_vector(15 downto 0);
          do1
          do2
              : out std_logic_vector(15 downto 0));
end rams_12;
architecture syn of rams_12 is
   type ram_type is array (63 downto 0) of std_logic_vector (15 downto
0);
    signal RAM : ram_type;
    signal read_add1 : std_logic_vector(5 downto 0);
    signal read_add2 : std_logic_vector(5 downto 0);
begin
    process (clk1)
    begin
        if (clk1'event and clk1 = '1') then
            if (we = '1') then
                RAM(conv_integer(add1)) <= di;</pre>
            end if;
            read_add1 <= add1;</pre>
        end if;
    end process;
    do1 <= RAM(conv_integer(read_add1));</pre>
    process (clk2)
    begin
        if (clk2'event and clk2 = '1') then
            read_add2 <= add2;</pre>
        end if;
    end process;
```



```
do2 <= RAM(conv_integer(read_add2));</pre>
```

end syn;

Dual-Port RAM With Synchronous Read (Read Through) and Two Clocks Verilog Coding Example


```
//
// Dual-Port RAM with Synchronous Read (Read Through)
// using More than One Clock
11
module v_rams_12 (clk1, clk2, we, add1, add2, di, do1, do2);
    input clk1;
    input clk2;
    input we;
    input [5:0] add1;
    input [5:0] add2;
    input [15:0] di;
    output [15:0] do1;
    output [15:0] do2;
           [15:0] ram [63:0];
    reg
           [5:0] read_add1;
    reg
    reg
           [5:0] read_add2;
    always @(posedge clk1) begin
        if (we)
            ram[add1] <= di;</pre>
        read_add1 <= add1;</pre>
    end
    assign do1 = ram[read_add1];
    always @(posedge clk2) begin
        read_add2 <= add2;</pre>
    end
    assign do2 = ram[read_add2];
```

endmodule

### Dual-Port RAM With One Enable Controlling Both Ports

This section discusses Dual-Port RAM With One Enable Controlling Both Ports and includes:

- "Dual-Port RAM With One Enable Controlling Both Ports Diagram"
- "Dual-Port RAM With One Enable Controlling Both Ports Pin Descriptions"
- "Dual-Port RAM With One Enable Controlling Both Ports VHDL Coding Example"
- "Dual-Port RAM With One Enable Controlling Both Ports Verilog Coding Example"





IO Pins	Description
clk	Positive-Edge Clock
en	Primary Global Enable (Active High)
we	Primary Synchronous Write Enable (Active High)
addra	Write Address/Primary Read Address
addrb	Dual Read Address
di	Primary Data Input
doa	Primary Output Port
dob	Dual Output Port

Table 2-79:	Dual-Port RAM With	One Enable Controlling Bo	th Ports Pin Descriptions

Dual-Port RAM With One Enable Controlling Both Ports VHDL Coding Example

```
---
-- Dual-Port RAM with One Enable Controlling Both Ports
---
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity rams_13 is
    port (clk : in std_logic;
        en : in std_logic;
        we : in std_logic;
```

www.xilinx.com



```
addra : in std_logic_vector(5 downto 0);
          addrb : in std_logic_vector(5 downto 0);
          di
                : in std_logic_vector(15 downto 0);
          doa
               : out std_logic_vector(15 downto 0);
          dob
               : out std_logic_vector(15 downto 0));
end rams_13;
architecture syn of rams_13 is
   type ram_type is array (63 downto 0) of std_logic_vector (15 downto
0);
    signal RAM : ram_type;
    signal read_addra : std_logic_vector(5 downto 0);
    signal read_addrb : std_logic_vector(5 downto 0);
begin
    process (clk)
    begin
        if (clk'event and clk = '1') then
            if (en = '1') then
                 if (we = '1') then
                     RAM(conv_integer(addra)) <= di;</pre>
                 end if;
                 read_addra <= addra;</pre>
                 read_addrb <= addrb;</pre>
            end if;
        end if;
    end process;
    doa <= RAM(conv_integer(read_addra));</pre>
    dob <= RAM(conv_integer(read_addrb));</pre>
```

end syn;

#### Dual-Port RAM With One Enable Controlling Both Ports Verilog Coding Example

```
11
// Dual-Port RAM with One Enable Controlling Both Ports
11
module v_rams_13 (clk, en, we, addra, addrb, di, doa, dob);
    input clk;
    input en;
    input we;
    input [5:0] addra;
    input [5:0] addrb;
    input [15:0] di;
   output [15:0] doa;
   output [15:0] dob;
           [15:0] ram [63:0];
   reg
           [5:0] read_addra;
    reg
   reg
           [5:0] read_addrb;
    always @(posedge clk) begin
        if (en)
        begin
            if (we)
```

```
ram[addra] <= di;
read_addra <= addra;
read_addrb <= addrb;
end
end
assign doa = ram[read_addra];
assign dob = ram[read_addrb];
```

# Dual Port RAM With Enable on Each Port

This section discusses Dual Port RAM With Enable on Each Port and includes:

- "Dual Port RAM With Enable on Each Port Diagram"
- "Dual Port RAM With Enable on Each Port Pin Descriptions"
- "Dual Port RAM With Enable on Each Port VHDL Coding Example"
- "Dual Port RAM With Enable on Each Port Verilog Coding Example"

The following descriptions are directly mappable onto block RAM, as shown in Figure 2-66, "Dual Port RAM With Enable on Each Port Diagram."




Figure 2-66: Dual Port RAM With Enable on Each Port Diagram

IO Pins	Description
clk	Positive-Edge Clock
ena	Primary Global Enable (Active High)
enb	Dual Global Enable (Active High)
wea	Primary Synchronous Write Enable (Active High)
addra	Write Address/Primary Read Address
addrb	Dual Read Address
dia	Primary Data Input

Table 2-80: Dual Port RAM With Enable on Each Port Pin Descriptions

www.xilinx.com



IO Pins	Description
doa	Primary Output Port
dob	Dual Output Port

Dual Port RAM With Enable on Each Port VHDL Coding Example

```
-- Dual-Port RAM with Enable on Each Port
_ _
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity rams_14 is
    port (clk : in std_logic;
          ena
               : in std_logic;
          enb
                : in std_logic;
          wea
                : in std_logic;
          addra : in std_logic_vector(5 downto 0);
          addrb : in std_logic_vector(5 downto 0);
          dia : in std_logic_vector(15 downto 0);
          doa : out std_logic_vector(15 downto 0);
          dob : out std_logic_vector(15 downto 0));
end rams_14;
architecture syn of rams_14 is
   type ram_type is array (63 downto 0) of std_logic_vector (15 downto
0);
    signal RAM : ram_type;
    signal read_addra : std_logic_vector(5 downto 0);
    signal read_addrb : std_logic_vector(5 downto 0);
begin
    process (clk)
    begin
        if (clk'event and clk = '1') then
            if (ena = '1') then
                if (wea = '1') then
                     RAM (conv_integer(addra)) <= dia;</pre>
                end if;
                read_addra <= addra;</pre>
            end if;
            if (enb = '1') then
                read_addrb <= addrb;</pre>
            end if;
        end if;
    end process;
    doa <= RAM(conv_integer(read_addra));</pre>
    dob <= RAM(conv_integer(read_addrb));</pre>
end syn;
```

Dual Port RAM With Enable on Each Port Verilog Coding Example

```
11
// Dual-Port RAM with Enable on Each Port
11
module v_rams_14 (clk,ena,enb,wea,addra,addrb,dia,doa,dob);
    input clk;
    input ena;
    input enb;
    input wea;
    input [5:0] addra;
    input [5:0] addrb;
    input [15:0] dia;
    output [15:0] doa;
    output [15:0] dob;
           [15:0] ram [63:0];
    reg
           [5:0] read_addra;
    reg
           [5:0] read_addrb;
    reg
    always @(posedge clk) begin
        if (ena)
        begin
            if (wea)
                ram[addra] <= dia;</pre>
            read_addra <= addra;</pre>
        end
        if (enb)
            read_addrb <= addrb;</pre>
    end
    assign doa = ram[read_addra];
    assign dob = ram[read_addrb];
```

endmodule



### **Dual-Port Block RAM With Different Clocks**

This section discusses Dual-Port Block RAM With Different Clocks and includes:

- "Dual-Port Block RAM With Different Clocks Diagram"
- "Dual-Port Block RAM With Different Clock Pin Descriptions"
- "Dual-Port Block RAM With Different Clocks VHDL Coding Example"
- "Dual-Port Block RAM With Different Clocks Verilog Coding Example"




Figure 2-67: Dual-Port Block RAM With Different Clocks Diagram

ons

IO Pins	Description
clka	Positive-Edge Clock
clkb	Positive-Edge Clock
wea	Primary Synchronous Write Enable (Active High)
addra	Write Address/Primary Read Address
addrb	Dual Read Address
dia	Primary Data Input
doa	Primary Output Port
dob	Dual Output Port

Dual-Port Block RAM With Different Clocks VHDL Coding Example

```
--
-- Dual-Port Block RAM with Different Clocks
--
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity rams_15 is
    port (clka : in std_logic;
        clkb : in std_logic;
        wea : in std_logic;
        addra : in std_logic;
        addra : in std_logic_vector(5 downto 0);
```

```
addrb : in std_logic_vector(5 downto 0);
              dia : in std_logic_vector(15 downto 0);
              doa
                  : out std_logic_vector(15 downto 0);
              dob
                  : out std_logic_vector(15 downto 0));
   end rams_15;
   architecture syn of rams_15 is
       type ram_type is array (63 downto 0) of std_logic_vector (15 downto
   0);
       signal RAM : ram_type;
       signal read_addra : std_logic_vector(5 downto 0);
       signal read_addrb : std_logic_vector(5 downto 0);
   begin
       process (clka)
       begin
            if (clka'event and clka = '1') then
                if (wea = '1') then
                    RAM(conv_integer(addra)) <= dia;</pre>
                end if;
                read_addra <= addra;</pre>
            end if;
       end process;
       process (clkb)
       begin
            if (clkb'event and clkb = '1') then
                read_addrb <= addrb;</pre>
            end if;
       end process;
       doa <= RAM(conv_integer(read_addra));</pre>
       dob <= RAM(conv_integer(read_addrb));</pre>
   end syn;
Dual-Port Block RAM With Different Clocks Verilog Coding Example
   11
   // Dual-Port Block RAM with Different Clocks
   11
   module v_rams_15 (clka, clkb, wea, addra, addrb, dia, doa, dob);
        input clka;
       input clkb;
       input wea;
       input [5:0] addra;
       input [5:0] addrb;
       input [15:0] dia;
       output [15:0] doa;
       output [15:0] dob;
               [15:0] RAM [63:0];
       reg
       reg
               [5:0] read_addra;
       reg
               [5:0] read_addrb;
       always @(posedge clka)
       begin
            if (wea == 1'b1)
```

www.xilinx.com




```
RAM[addra] <= dia;
read_addra <= addra;
end
always @(posedge clkb)
begin
read_addrb <= addrb;
end
assign doa = RAM[read_addra];
assign dob = RAM[read_addrb];
```

## Dual-Port Block RAM With Two Write Ports

This section discusses Dual-Port Block RAM With Two Write Ports and includes:

- "Dual-Port Block RAM With Two Write Ports Diagram"
- "Dual-Port Block RAM With Two Write Ports Pin Descriptions"
- "Dual-Port Block RAM With Two Write Ports VHDL Coding Example"
- "Dual-Port Block RAM With Two Write Ports Verilog Coding Example"

XST supports dual-port block RAMs with two write ports for VHDL and Verilog. The concept of dual-write ports implies not only distinct data ports, but the possibility of distinct write clocks and write enables as well. Distinct write clocks also mean distinct read clocks, since the dual-port block RAM offers two clocks, one shared by the primary read and write port, the other shared by the secondary read and write port. In VHDL, the description of this type of block RAM is based on the usage of shared variables. The XST VHDL analyzer accepts shared variables, but errors out in the HDL Synthesis step if a shared variable does not describe a valid RAM macro.





IO Pins	Description
clka, clkb	Positive-Edge Clock
ena	Primary Global Enable (Active High)
enb	Dual Global Enable (Active High)
wea, web	Primary Synchronous Write Enable (Active High)
addra	Write Address/Primary Read Address
addrb	Dual Read Address
dia	Primary Data Input
dib	Dual Data Input
doa	Primary Output Port
dob	Dual Output Port

Table 2-82:	Dual-Port Block RAM With Two Write Ports Pin Descriptions
-------------	---

Dual-Port Block RAM With Two Write Ports VHDL Coding Example

This is the most general example. It has different clocks, enables, and write enables.

```
_ _
-- Dual-Port Block RAM with Two Write Ports
_ _
library IEEE;
use IEEE.std_logic_1164.all;
use IEEE.std_logic_unsigned.all;
entity rams_16 is
   port(clka : in std_logic;
         clkb : in std_logic;
         ena : in std_logic;
         enb : in std_logic;
         wea : in std_logic;
         web
             : in std_logic;
         addra : in std_logic_vector(5 downto 0);
         addrb : in std_logic_vector(5 downto 0);
         dia
              : in std_logic_vector(15 downto 0);
               : in std_logic_vector(15 downto 0);
         dib
         doa
               : out std_logic_vector(15 downto 0);
               : out std_logic_vector(15 downto 0));
         dob
end rams_16;
architecture syn of rams_16 is
   type ram_type is array (63 downto 0) of std_logic_vector(15 downto
0);
    shared variable RAM : ram_type;
begin
    process (CLKA)
    begin
        if CLKA'event and CLKA = '1' then
```



```
if ENA = '1' then
                 if WEA = '1' then
                     RAM(conv_integer(ADDRA)) := DIA;
                 end if;
                 DOA <= RAM(conv_integer(ADDRA));</pre>
             end if;
        end if;
    end process;
    process (CLKB)
    begin
        if CLKB'event and CLKB = '1' then
            if ENB = '1' then
                 if WEB = '1' then
                     RAM(conv_integer(ADDRB)) := DIB;
                 end if;
            DOB <= RAM(conv_integer(ADDRB));</pre>
        end if;
    end if;
    end process;
end syn;
```

Because of the shared variable, the description of the different read/write synchronizations may be different from coding examples recommended for single-write RAMs. The order of appearance of the different lines of code is significant.

Dual-Port Block RAM With Two Write Ports Verilog Coding Example

This is the most general example. It has different clocks, enables, and write enables.

```
11
// Dual-Port Block RAM with Two Write Ports
11
module v_rams_16
(clka,clkb,ena,enb,wea,web,addra,addrb,dia,dib,doa,dob);
    input clka,clkb,ena,enb,wea,web;
    input [5:0] addra,addrb;
    input [15:0] dia,dib;
    output [15:0] doa,dob;
           [15:0] ram [63:0];
    rea
           [15:0] doa,dob;
    reg
    always @(posedge clka) begin
        if (ena)
        begin
            if (wea)
                ram[addra] <= dia;</pre>
            doa <= ram[addra];</pre>
        end
    end
    always @(posedge clkb) begin
        if (enb)
        begin
            if (web)
```

```
ram[addrb] <= dib;
dob <= ram[addrb];
end
end
```

endmodule

Write-First Synchronization Coding Example One

```
process (CLKA)
begin
  if CLKA'event and CLKA = '1' then
    if WEA = '1' then
        RAM(conv_integer(ADDRA)) := DIA;
        DOA <= DIA;
    else
        DOA <= RAM(conv_integer(ADDRA));
    end if;
    end if;
end process;</pre>
```

Write-First Synchronization Coding Example Two

In this example, the read statement necessarily comes after the write statement.

Although they may look the same except for the signal/variable difference, it is also important to understand the functional difference between this template and the following well known template which describes a read-first synchronization in a single-write RAM.

```
signal RAM : RAMtype;
process (CLKA)
begin
  if CLKA'event and CLKA = '1' then
    if WEA = '1' then
        RAM(conv_integer(ADDRA)) <= DIA;
    end if;
    DOA <= RAM(conv_integer(ADDRA));
  end if;
end process;
```

Read-First Synchronization Coding Example

A read-first synchronization is described as follows, where the read statement must come BEFORE the write statement.

```
process (CLKA)
begin
if CLKA'event and CLKA = '1' then
DOA <= RAM(conv_integer(ADDRA)); -- The read statement must come
-- BEFORE the write statement</pre>
```



```
if WEA = '1' then
        RAM(conv_integer(ADDRA)) := DIA;
    end if;
end if;
end process;
```

#### No-Change Synchronization Coding Example

The following is a description for a no-change synchronization.

```
process (CLKA)
begin
  if CLKA'event and CLKA = '1' then
    if WEA = '1' then
        RAM(conv_integer(ADDRA)) := DIA;
    else
        DOA <= RAM(conv_integer(ADDRA));
    end if;
    end if;
end process;</pre>
```

### Block Ram with Byte-Wide Write Enable

This section discusses Block Ram with Byte-Wide Write Enable, and includes:

- "Multiple Write Statement VHDL Coding Example"
- "Multiple Write Statement Verilog Coding Example"
- "Single Write Statement VHDL Coding Example"
- "Single Write Statement Verilog Coding Example"

XST supports single and dual-port block RAM with Byte-wide Write Enable for VHDL and Verilog. The RAM can be seen as a collection of equal size columns. During a write cycle, you separately control writing into each of these columns.

In the Multiple Write Statement method, there is one separate write access statement, including the description of the related write enable, for each column.

The Single Write Statement method allows you to describe only one write access statement. The write enables are described separately outside the main sequential process.

The two methods for describing column-based RAM writes are shown in the following coding examples.

XST currently supports the second solution only (Single Write Statement).

#### Multiple Write Statement VHDL Coding Example

Multiple Write Statement Verilog Coding Example

```
reg [2*DI_WIDTH-1:0] RAM [SIZE-1:0];
always @(posedge clk)
begin
    if (we[1]) then
        RAM[addr][2*WIDTH-1:WIDTH] <= di[2*WIDTH-1:WIDTH];
    end if;
    if (we[0]) then
        RAM[addr][WIDTH-1:0] <= di[WIDTH-1:0;
    end if;
    do <= RAM[addr];
end
```

#### Single Write Statement VHDL Coding Example

```
type ram_type is array (SIZE-1 downto 0)
              of std_logic_vector (2*WIDTH-1 downto 0);
signal RAM : ram_type;
signal di0, di1 : std_logic_vector (WIDTH-1 downto 0);
(...)
-- Write enables described outside main sequential process
process(we, di)
begin
  if we(1) = '1' then
    di1 <= di(2*WIDTH-1 downto WIDTH);</pre>
  else
    di1 <= RAM(conv_integer(addr))(2*WIDTH-1 downto WIDTH);</pre>
  end if;
 if we(0) = '1' then
    di0 <= di(WIDTH-1 downto 0);
  else
    di0 <= RAM(conv_integer(addr))(WIDTH-1 downto 0);</pre>
  end if;
end process;
process(clk)
begin
  if posedge(clk) then
    if en = '1' then
      RAM(conv_integer(addr)) <= di1 & di0; -- single write access</pre>
statement
      do <= RAM(conv_integer(addr));</pre>
    end if;
```



```
end if;
   end process;
Single Write Statement Verilog Coding Example
           [2*DI_WIDTH-1:0] RAM [SIZE-1:0];
   reg
           [DI_WIDTH-1:0]
                            di0, di1;
   reg
   always @(we or di)
   begin
       if (we[1])
            di1 = di[2*DI_WIDTH-1:1*DI_WIDTH];
       else
            di1 = RAM[addr][2*DI_WIDTH-1:1*DI_WIDTH];
       if (we[0])
            di0 = di[DI_WIDTH-1:0];
       else
           di0 = RAM[addr][DI_WIDTH-1:0];
   end
   always @(posedge clk)
   begin
      RAM[addr]<={di1,di0};</pre>
      do <= RAM[addr];</pre>
   end
```

## Read-First Mode: Single-Port BRAM With Byte-Wide Write Enable (2 Bytes)

This section discusses Read-First Mode: Single-Port BRAM With Byte-Wide Write Enable (2 Bytes, and includes:

- "Read-First Mode: Single-Port BRAM with Byte-wide Write Enable (2 Bytes) Pin Descriptions"
- "Read-First Mode: Single-Port BRAM With Byte-Wide Write Enable (2 Bytes) VHDL Coding Example"
- "Read-First Mode: Single-Port BRAM With Byte-wide Write Enable (2 Bytes) Verilog Coding Example"

To simplify the understanding of byte-wide write enable templates, the following coding examples use single-port block RAMs. XST supports dual-port Block RAM, as well as byte-wide write enable

*Table 2-83:* Read-First Mode: Single-Port BRAM with Byte-wide Write Enable (2 Bytes) Pin Descriptions

IO Pins	Description
clk	Positive-Edge Clock
we	Write Enable
addr	Write/Read Address
di	Data Input
do	RAM Output Port

Read-First Mode: Single-Port BRAM With Byte-Wide Write Enable (2 Bytes) VHDL Coding Example

```
-- Single-Port BRAM with Byte-wide Write Enable (2 bytes) in Read-First
Mode
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity rams_24 is
    generic (SIZE
                       : integer := 512;
             ADDR_WIDTH : integer := 9;
             DI_WIDTH : integer := 8);
    port (clk : in std_logic;
          we
              : in std_logic_vector(1 downto 0);
          addr : in std_logic_vector(ADDR_WIDTH-1 downto 0);
          di : in std_logic_vector(2*DI_WIDTH-1 downto 0);
          do : out std_logic_vector(2*DI_WIDTH-1 downto 0));
end rams_24;
architecture syn of rams_24 is
    type ram_type is array (SIZE-1 downto 0) of std_logic_vector
(2*DI_WIDTH-1 downto 0);
    signal RAM : ram_type;
    signal di0, di1 : std_logic_vector (DI_WIDTH-1 downto 0);
begin
    process(we, di)
    begin
        if we(1) = '1' then
            di1 <= di(2*DI_WIDTH-1 downto 1*DI_WIDTH);</pre>
        else
            di1 <= RAM(conv_integer(addr))(2*DI_WIDTH-1 downto</pre>
1*DI_WIDTH);
        end if;
        if we(0) = '1' then
            di0 <= di(DI_WIDTH-1 downto 0);</pre>
        else
            di0 <= RAM(conv_integer(addr))(DI_WIDTH-1 downto 0);</pre>
        end if;
    end process;
    process(clk)
    begin
        if (clk'event and clk = '1') then
            RAM(conv_integer(addr)) <= di1 & di0;</pre>
            do <= RAM(conv_integer(addr));</pre>
        end if;
    end process;
end syn;
```



Read-First Mode: Single-Port BRAM With Byte-wide Write Enable (2 Bytes) Verilog Coding Example

```
11
// Single-Port BRAM with Byte-wide Write Enable (2 bytes) in Read-First
Mode
11
module v_rams_24 (clk, we, addr, di, do);
                       = 512;
    parameter SIZE
    parameter ADDR_WIDTH = 9;
    parameter DI_WIDTH = 8;
    input clk;
    input [1:0] we;
    input [ADDR_WIDTH-1:0] addr;
    input [2*DI_WIDTH-1:0] di;
    output [2*DI_WIDTH-1:0] do;
    reg
          [2*DI_WIDTH-1:0] RAM [SIZE-1:0];
           [2*DI_WIDTH-1:0] do;
    reg
                            di0, di1;
    reg
           [DI_WIDTH-1:0]
    always @(we or di)
    begin
        if (we[1])
            di1 = di[2*DI_WIDTH-1:1*DI_WIDTH];
        else
            di1 = RAM[addr][2*DI_WIDTH-1:1*DI_WIDTH];
        if (we[0])
            di0 = di[DI_WIDTH-1:0];
        else
            di0 = RAM[addr][DI_WIDTH-1:0];
    end
    always @(posedge clk)
    begin
        RAM[addr]<={di1,di0};</pre>
        do <= RAM[addr];</pre>
    end
endmodule
```

## Write-First Mode: Single-Port BRAM with Byte-Wide Write Enable (2 Bytes)

This section discusses Write-First Mode: Single-Port BRAM With Byte-Wide Write Enable (2 Bytes, and includes:

- "Write-First Mode: Single-Port BRAM with Byte-wide Write Enable (2 Bytes) Pin Descriptions"
- "Write-First Mode: Single-Port BRAM with Byte-Wide Write Enable (2 Bytes) VHDL Coding Example"
- "Write-First Mode: Single-Port BRAM with Byte-Wide Write Enable (2 Bytes) Verilog Coding Example"

*Table 2-84:* Write-First Mode: Single-Port BRAM with Byte-wide Write Enable (2 Bytes) Pin Descriptions

IO Pins	Description
Clk	Positive-Edge Clock
We	Write Enable
Addr	Write/Read Address
Di	Data Input
Do	RAM Output Port

Write-First Mode: Single-Port BRAM with Byte-Wide Write Enable (2 Bytes) VHDL Coding Example

```
-- Single-Port BRAM with Byte-wide Write Enable (2 bytes) in Write-First
Mode
_ _
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity rams_25 is
    generic (SIZE
                    : integer := 512;
            ADDR_WIDTH : integer := 9;
            DI_WIDTH : integer := 8);
    port (clk : in std_logic;
          we : in std_logic_vector(1 downto 0);
          addr : in std_logic_vector(ADDR_WIDTH-1 downto 0);
          di : in std_logic_vector(2*DI_WIDTH-1 downto 0);
          do : out std_logic_vector(2*DI_WIDTH-1 downto 0));
end rams_25;
architecture syn of rams_25 is
   type ram_type is array (SIZE-1 downto 0) of std_logic_vector
(2*DI_WIDTH-1 downto 0);
   signal RAM : ram_type;
   signal di0, di1 : std_logic_vector (DI_WIDTH-1 downto 0);
   signal do0, do1 : std_logic_vector (DI_WIDTH-1 downto 0);
begin
```



```
process(we, di)
    begin
        if we(1) = '1' then
             di1 <= di(2*DI_WIDTH-1 downto 1*DI_WIDTH);</pre>
             do1 <= di(2*DI_WIDTH-1 downto 1*DI_WIDTH);</pre>
        else
             di1 <= RAM(conv_integer(addr))(2*DI_WIDTH-1 downto
1*DI_WIDTH);
             do1 <= RAM(conv_integer(addr))(2*DI_WIDTH-1 downto</pre>
1*DI_WIDTH);
        end if;
        if we(0) = '1' then
             di0 <= di(DI_WIDTH-1 downto 0);</pre>
             do0 <= di(DI_WIDTH-1 downto 0);</pre>
        else
             di0 <= RAM(conv_integer(addr))(DI_WIDTH-1 downto 0);</pre>
             do0 <= RAM(conv_integer(addr))(DI_WIDTH-1 downto 0);</pre>
        end if;
    end process;
    process(clk)
    begin
        if (clk'event and clk = '1') then
             RAM(conv_integer(addr)) <= di1 & di0;</pre>
             do <= do1 & do0;
        end if;
    end process;
```

end syn;

Write-First Mode: Single-Port BRAM with Byte-Wide Write Enable (2 Bytes) Verilog Coding Example

```
11
// Single-Port BRAM with Byte-wide Write Enable (2 bytes) in Write-First
Mode
11
module v_rams_25 (clk, we, addr, di, do);
    parameter SIZE
                         = 512;
    parameter ADDR_WIDTH = 9;
    parameter DI_WIDTH
                         = 8;
    input clk;
    input [1:0] we;
    input [ADDR_WIDTH-1:0] addr;
    input [2*DI_WIDTH-1:0] di;
    output [2*DI_WIDTH-1:0] do;
    rea
           [2*DI_WIDTH-1:0] RAM [SIZE-1:0];
    reg
           [2*DI_WIDTH-1:0] do;
           [DI_WIDTH-1:0]
                            di0, di1;
    rea
           [DI_WIDTH-1:0]
                            do0, do1;
    reg
    always @(we or di)
    begin
```

```
if (we[1])
             begin
                  di1 = di[2*DI_WIDTH-1:1*DI_WIDTH];
                  do1 = di[2*DI_WIDTH-1:1*DI_WIDTH];
             end
        else
             begin
                  di1 = RAM[addr][2*DI_WIDTH-1:1*DI_WIDTH];
                  do1 = RAM[addr][2*DI_WIDTH-1:1*DI_WIDTH];
             end
        if (we[0])
             begin
                 di0 <= di[DI_WIDTH-1:0];</pre>
                  do0 <= di[DI_WIDTH-1:0];</pre>
             end
        else
             begin
                  di0 <= RAM[addr][DI_WIDTH-1:0];</pre>
                  do0 <= RAM[addr][DI_WIDTH-1:0];</pre>
             end
    end
    always @(posedge clk)
    begin
        RAM[addr]<={di1,di0};</pre>
        do <= {do1,do0};</pre>
    end
endmodule
```

# No-Change Mode: Single-Port BRAM with Byte-Wide Write Enable (2 Bytes)

This section discusses No-Change Mode: Single-Port BRAM With Byte-Wide Write Enable (2 Bytes, and includes:

- "No-Change Mode: Single-Port BRAM with Byte-Wide Write Enable (2 Bytes) Pin Descriptions"
- "No-Change Mode: Single-Port BRAM with Byte-Wide Write Enable (2 Bytes) VHDL Coding Example"
- "No-Change Mode: Single-Port BRAM with Byte-Wide Write Enable (2 Bytes) in Verilog Coding Example"

*Table 2-85:* No-Change Mode: Single-Port BRAM with Byte-Wide Write Enable (2 Bytes) Pin Descriptions

IO Pins	Description
Clk	Positive-Edge Clock
We	Write Enable
Addr	Write/Read Address
Di	Data Input
Do	RAM Output Port

www.xilinx.com

XST infers latches for **do1** and **do0** signals during the basic HDL Synthesis. These latches are absorbed by BRAM during the Advanced HDL Synthesis step.

No-Change Mode: Single-Port BRAM with Byte-Wide Write Enable (2 Bytes) VHDL Coding Example

```
_ _
-- Single-Port BRAM with Byte-wide Write Enable (2 bytes) in No-Change
Mode
_ _
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity rams_26 is
    generic (SIZE
                     : integer := 512;
             ADDR_WIDTH : integer := 9;
             DI_WIDTH : integer := 8);
    port (clk : in std_logic;
          we : in std_logic_vector(1 downto 0);
          addr : in std_logic_vector(ADDR_WIDTH-1 downto 0);
          di : in std_logic_vector(2*DI_WIDTH-1 downto 0);
          do : out std_logic_vector(2*DI_WIDTH-1 downto 0));
end rams_26;
architecture syn of rams_26 is
   type ram_type is array (SIZE-1 downto 0) of std_logic_vector
(2*DI_WIDTH-1 downto 0);
   signal RAM : ram_type;
   signal di0, di1 : std_logic_vector (DI_WIDTH-1 downto 0);
   signal do0, do1 : std_logic_vector (DI_WIDTH-1 downto 0);
begin
    process(we, di)
    begin
        if we(1) = '1' then
            di1 <= di(2*DI_WIDTH-1 downto 1*DI_WIDTH);</pre>
        else
            di1 <= RAM(conv_integer(addr))(2*DI_WIDTH-1 downto
1*DI_WIDTH);
            do1 <= RAM(conv_integer(addr))(2*DI_WIDTH-1 downto</pre>
1*DI_WIDTH);
        end if;
        if we(0) = '1' then
            di0 <= di(DI_WIDTH-1 downto 0);
        else
            di0 <= RAM(conv_integer(addr))(DI_WIDTH-1 downto 0);</pre>
            do0 <= RAM(conv_integer(addr))(DI_WIDTH-1 downto 0);</pre>
        end if;
    end process;
    process(clk)
    begin
        if (clk'event and clk = '1') then
            RAM(conv_integer(addr)) <= di1 & di0;</pre>
```

```
do <= do1 & do0;
end if;
end process;
```

end syn;

No-Change Mode: Single-Port BRAM with Byte-Wide Write Enable (2 Bytes) in Verilog Coding Example

```
11
// Single-Port BRAM with Byte-wide Write Enable (2 bytes) in No-Change
Mode
11
module v_rams_26 (clk, we, addr, di, do);
    parameter SIZE
                         = 512;
    parameter ADDR_WIDTH = 9;
    parameter DI_WIDTH
                         = 8;
    input clk;
    input [1:0] we;
    input [ADDR_WIDTH-1:0] addr;
    input [2*DI_WIDTH-1:0] di;
    output [2*DI_WIDTH-1:0] do;
    reg
           [2*DI_WIDTH-1:0] RAM [SIZE-1:0];
    reg
           [2*DI_WIDTH-1:0] do;
                             di0, di1;
    rea
           [DI_WIDTH-1:0]
           [DI_WIDTH-1:0]
                             do0, do1;
    reg
    always @(we or di)
    begin
        if (we[1])
            di1 = di[2*DI_WIDTH-1:1*DI_WIDTH];
        else
            begin
                di1 = RAM[addr][2*DI_WIDTH-1:1*DI_WIDTH];
                 do1 = RAM[addr][2*DI_WIDTH-1:1*DI_WIDTH];
             end
        if (we[0])
            di0 <= di[DI_WIDTH-1:0];</pre>
        else
            begin
                 di0 <= RAM[addr][DI_WIDTH-1:0];</pre>
                 do0 <= RAM[addr][DI_WIDTH-1:0];</pre>
             end
    end
    always @(posedge clk)
    begin
        RAM[addr]<={di1,di0};</pre>
        do <= {do1,do0};</pre>
    end
endmodule
```



### Multiple-Port RAM Descriptions

This section discusses Multiple-Port RAM Descriptions, and includes:

- "Multiple-Port RAM Descriptions Diagram"
- "Multiple-Port RAM Descriptions Pin Descriptions"
- "Multiple-Port RAM Descriptions VHDL Coding Example"
- "Multiple-Port RAM Descriptions Verilog Coding Example"

XST can identify RAM descriptions with two or more read ports that access the RAM contents at addresses different from the write address. However, there can only be one write port. XST implements the following descriptions by replicating the RAM contents for each output port, as shown in Table 2-69, "Multiple-Port RAM Descriptions Diagram."




Figure 2-69: Multiple-Port RAM Descriptions Diagram

Table 2-86:	Multiple-Port RAM	Descriptions	Pin Descriptions
Table 2-00.		Descriptions	

IO Pins	Description
clk	Positive-Edge Clock
we	Synchronous Write Enable (Active High)
wa	Write Address
ra1	Read Address of the First RAM
ra2	Read Address of the Second RAM
di	Data Input
do1	First RAM Output Port
do2	Second RAM Output Port

#### Multiple-Port RAM Descriptions VHDL Coding Example

```
-- Multiple-Port RAM Descriptions
--
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity rams_17 is
```

```
port (clk : in std_logic;
        we : in std_logic;
        wa : in std_logic_vector(5 downto 0);
        ra1 : in std_logic_vector(5 downto 0);
        ra2 : in std_logic_vector(5 downto 0);
        di : in std_logic_vector(15 downto 0);
        do1 : out std_logic_vector(15 downto 0);
        do2 : out std_logic_vector(15 downto 0));
end rams_17;
architecture syn of rams_17 is
   type ram_type is array (63 downto 0) of std_logic_vector (15 downto
0);
    signal RAM : ram_type;
begin
   process (clk)
   begin
       if (clk'event and clk = '1') then
          if (we = '1') then
            RAM(conv_integer(wa)) <= di;</pre>
          end if;
       end if;
    end process;
    do1 <= RAM(conv_integer(ra1));</pre>
    do2 <= RAM(conv_integer(ra2));</pre>
end syn;
```

Multiple-Port RAM Descriptions Verilog Coding Example

```
11
// Multiple-Port RAM Descriptions
11
module v_rams_17 (clk, we, wa, ra1, ra2, di, do1, do2);
    input clk;
    input we;
    input [5:0] wa;
    input [5:0] ra1;
    input [5:0] ra2;
    input [15:0] di;
    output [15:0] do1;
    output [15:0] do2;
         [15:0] ram [63:0];
    reg
    always @(posedge clk)
    begin
        if (we)
            ram[wa] <= di;</pre>
    end
    assign do1 = ram[ra1];
    assign do2 = ram[ra2];
endmodule
```

www.xilinx.com



### Block RAM With Reset

This section discusses Block RAM With Reset, and includes:

- "Block RAM With Reset Pin Descriptions"
- "Block RAM With Reset VHDL Coding Example"
- "Block RAM With Reset Verilog Coding Example"

XST supports block RAM with reset on the data outputs, as offered with Virtex, Virtex-II, Virtex-II Pro, Virtex-4, Virtex-5, and related block RAM resources. Optionally, you can include a synchronously controlled initialization of the RAM data outputs.

Block RAM with the following synchronization modes can have resetable data ports.

- Read-First Block RAM with Reset
- Write-First Block RAM with Reset
- No-Change Block RAM with Reset
- Registered ROM with Reset
- Supported Dual-Port Templates

Because XST does not support block RAMs with dual-write in a dual-read block RAM description, both data outputs may be reset, but the various read-write synchronizations are allowed for the primary data output only. The dual output may be used in Read-First Mode only.

IO Pins	Description
clk	Positive-Edge Clock
en	Global Enable
we	Write Enable (Active High)
addr	Read/Write Address
rst	Reset for data output
di	Data Input
do	RAM Output Port

Table 2-87: Block RAM With Reset Pin Descriptions

Block RAM With Reset VHDL Coding Example

```
--
-- Block RAM with Reset
--
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity rams_18 is
    port (clk : in std_logic;
        en : in std_logic;
        we : in std_logic;
        rst : in std_logic;
        addr : in std_logic_vector(5 downto 0);
        di : in std_logic_vector(15 downto 0);
```

```
do
                   : out std_logic_vector(15 downto 0));
   end rams_18;
   architecture syn of rams_18 is
       type ram_type is array (63 downto 0) of std_logic_vector (15 downto
   0);
       signal ram : ram_type;
   begin
       process (clk)
       begin
          if clk'event and clk = '1' then
             if en = '1' then -- optional enable
                if we = '1' then -- write enable
                  ram(conv_integer(addr)) <= di;</pre>
                 end if;
               if rst = '1' then -- optional reset
                  do <= (others => '0');
                 else
                 do <= ram(conv_integer(addr)) ;</pre>
                 end if;
              end if;
           end if;
       end process;
   end syn;
Block RAM With Reset Verilog Coding Example
   11
   // Block RAM with Reset
   11
   module v_rams_18 (clk, en, we, rst, addr, di, do);
       input clk;
       input en;
       input we;
       input rst;
       input [5:0] addr;
       input [15:0] di;
       output [15:0] do;
               [15:0] ram [63:0];
       reg
               [15:0] do;
       reg
       always @(posedge clk)
       begin
            if (en) // optional enable
            begin
                if (we) // write enable
                    ram[addr] <= di;</pre>
                if (rst) // optional reset
                    do <= 16'h0000;
```

do <= ram[addr];</pre>

else



```
end
end
```

# Block RAM With Optional Output Registers

This section discusses Block RAM With Optional Output Registers, and includes:

- "Block RAM With Optional Output Registers Diagram"
- "Block RAM With Optional Output Registers Pin Descriptions"
- "Block RAM With Optional Output Registers VHDL Coding Example"
- "Block RAM With Optional Output Registers Verilog Coding Example"




Figure 2-70: Block RAM With Optional Output Registers Diagram

Table 2-88: Block RAM With Optional Output Registers Pin Description
--

IO Pins	Description
clk1, clk2	Positive-Edge Clock
we	Write Enable
en1, en2	Clock Enable (Active High)
addr1	Primary Read Address
addr2	Dual Read Address
di	Data Input
res1	Primary Output Port
res2	Dual Output Port

Block RAM With Optional Output Registers VHDL Coding Example

```
_ _
-- Block RAM with Optional Output Registers
___
library IEEE;
library IEEE;
use IEEE.STD_LOGIC_1164.ALL;
use IEEE.STD_LOGIC_UNSIGNED.ALL;
entity rams_19 is
    port (clk1, clk2
                      : in std_logic;
          we, en1, en2 : in std_logic;
          addr1
                      : in std_logic_vector(5 downto 0);
          addr2
                       : in std_logic_vector(5 downto 0);
          di
                       : in std_logic_vector(15 downto 0);
                       : out std_logic_vector(15 downto 0);
          res1
          res2
                       : out std_logic_vector(15 downto 0));
end rams_19;
architecture beh of rams_19 is
   type ram_type is array (63 downto 0) of std_logic_vector (15 downto
0);
    signal ram : ram_type;
    signal do1 : std_logic_vector(15 downto 0);
    signal do2 : std_logic_vector(15 downto 0);
begin
    process (clk1)
    begin
        if rising_edge(clk1) then
            if we = '1' then
                ram(conv_integer(addr1)) <= di;</pre>
            end if;
            do1 <= ram(conv_integer(addr1));</pre>
        end if;
    end process;
    process (clk2)
    begin
        if rising_edge(clk2) then
            do2 <= ram(conv_integer(addr2));</pre>
        end if;
    end process;
    process (clk1)
    begin
        if rising_edge(clk1) then
            if en1 = '1' then
                res1 <= do1;</pre>
            end if;
        end if;
    end process;
    process (clk2)
    begin
        if rising_edge(clk2) then
            if en2 = '1' then
```



```
res2 <= do2;
                end if;
            end if;
       end process;
   end beh;
Block RAM With Optional Output Registers Verilog Coding Example
   11
   // Block RAM with Optional Output Registers
   11
   module v_rams_19 (clk1, clk2, we, en1, en2, addr1, addr2, di, res1,
   res2);
       input clk1;
       input clk2;
       input we, en1, en2;
       input [5:0] addr1;
       input [5:0] addr2;
       input [15:0] di;
       output [15:0] res1;
       output [15:0] res2;
       reg
              [15:0] res1;
              [15:0] res2;
       reg
              [15:0] RAM [63:0];
       reg
              [15:0] do1;
       reg
              [15:0] do2;
       reg
       always @(posedge clk1)
       begin
          if (we == 1'b1)
             RAM[addr1] <= di;</pre>
          do1 <= RAM[addr1];</pre>
       end
       always @(posedge clk2)
       begin
          do2 <= RAM[addr2];</pre>
       end
       always @(posedge clk1)
       begin
          if (en1 == 1'b1)
              res1 <= do1;
       end
       always @(posedge clk2)
       begin
          if (en2 == 1'b1)
              res2 <= do2;
       end
   endmodule
```

# Initializing RAM Coding Examples

This section discusses Initializing RAM Coding Examples, and includes:

- "Initializing RAM Directly in HDL Code"
- "Initializing RAM From an External File"

Block and distributed RAM initial contents can be specified by initialization of the signal describing the memory array in your HDL code. Do this directly in your HDL code, or specify a file containing the initialization data.

XST supports initialization for single and dual-port RAMs. This mechanism is supported for the following device families only:

- Virtex-II, Virtex-II Pro
- Spartan-3, Spartan-3E, Spartan-3A
- Virtex-4, Virtex-5

XST supports RAM initialization in both VHDL and Verilog.

### Initializing RAM Directly in HDL Code

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>.

- "RAM Initial Contents VHDL Coding Example (Hexadecimal)"
- "Initializing Block RAM Verilog Coding Example (Hexadecimal)"
- "RAM Initial Contents VHDL Coding Example (Binary)"
- "Initializing Block RAM Verilog Coding Example (Binary)"
- "Initializing RAM From an External File"
- "Initializing Block RAM (External Data File)"

#### RAM Initial Contents VHDL Coding Example (Hexadecimal)

To specify RAM initial contents, initialize the signal describing the memory array in the VHDL code as shown in the following coding example:

```
type ram_type is array (0 to 63) of std_logic_vector(19 downto 0);
signal RAM : ram_type :=
  (
 X"0200A", X"00300", X"08101", X"04000", X"08601", X"0233A",
 X"00300", X"08602", X"02310", X"0203B", X"08300", X"04002",
 X"08201", X"00500", X"04001", X"02500", X"00340", X"00241",
 X"04002", X"08300", X"08201", X"00500", X"08101", X"00602",
 X"04003", X"0241E", X"00301", X"00102", X"02122", X"02021",
 X"00301", X"00102", X"02222", X"04001", X"00342", X"0232B",
 x"00900", x"00302", x"00102", x"04002", x"00900", x"08201",
 x"02023", x"00303", x"02433", x"00301", x"04004", x"00301",
 X"00102", X"02137", X"02036", X"00301", X"00102", X"02237",
 X"04004", X"00304", X"04040", X"02500", X"02500", X"02500",
 X"0030D", X"02341", X"08201", X"0400D");
. . .
process (clk)
begin
 if rising_edge(clk) then
   if we = '1' then
```



```
RAM(conv_integer(a)) <= di;
end if;
ra <= a;
end if;
end process;
...
do <= RAM(conv_integer(ra));</pre>
```

Initializing Block RAM Verilog Coding Example (Hexadecimal)

To specify RAM initial contents, initialize the signal describing the memory array in your Verilog code using initial statements as shown in the following coding example:

```
...
reg [19:0] ram [63:0];
initial begin
    ram[63] = 20'h0200A; ram[62] = 20'h00300; ram[61] = 20'h08101;
    ram[60] = 20'h04000; ram[59] = 20'h08601; ram[58] = 20'h0233A;
    ...
ram[2] = 20'h02341; ram[1] = 20'h08201; ram[0] = 20'h0400D;
end
...
always @(posedge clk)
begin
    if (we)
        ram[addr] <= di;
    do <= ram[addr];
end</pre>
```

RAM Initial Contents VHDL Coding Example (Binary)

RAM initial contents can be specified in hexadecimal, as shown in "RAM Initial Contents VHDL Coding Example (Hexadecimal)," or in binary as shown in the following coding example:

```
...
type ram_type is array (0 to SIZE-1) of std_logic_vector(15 downto 0);
signal RAM : ram_type :=
  (
   "0111100100000101",
   "0000010110111101",
   "1100001101010000",
   ...
   "0000100101110011");
```

Initializing Block RAM Verilog Coding Example (Binary)

RAM initial contents can be specified in hexadecimal, as shown in "Initializing Block RAM Verilog Coding Example (Hexadecimal)," or in binary as shown in the following coding example:

```
...
reg [15:0] ram [63:0];
initial begin
    ram[63] = 16'b0111100100000101;
    ram[62] = 16'b000010110111101;
    ram[61] = 16'b1100001101010000;
    ...
    ram[0] = 16'b0000100101110011;
end
...
```



#### Single-Port BRAM Initial Contents VHDL Coding Example

```
-- Initializing Block RAM (Single-Port BRAM)
_ _
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity rams_20a is
   port (clk : in std_logic;
          we : in std_logic;
          addr : in std_logic_vector(5 downto 0);
          di
              : in std_logic_vector(19 downto 0);
          do
              : out std_logic_vector(19 downto 0));
end rams_20a;
architecture syn of rams_20a is
    type ram_type is array (63 downto 0) of std_logic_vector (19 downto 0);
    signal RAM : ram_type:= (X"0200A", X"00300", X"08101", X"04000", X"08601", X"0233A",
                             X"00300", X"08602", X"02310", X"0203B", X"08300", X"04002",
                             X"08201", X"00500", X"04001", X"02500", X"00340", X"00241",
                             X"04002", X"08300", X"08201", X"00500", X"08101", X"00602",
                             X"04003", X"0241E", X"00301", X"00102", X"02122", X"02021",
                             X"00301", X"00102", X"02222", X"04001", X"00342", X"0232B",
                             X"00900", X"00302", X"00102", X"04002", X"00900", X"08201",
                             X"02023", X"00303", X"02433", X"00301", X"04004", X"00301",
                             X"00102", X"02137", X"02036", X"00301", X"00102", X"02237",
                             X"04004", X"00304", X"04040", X"02500", X"02500", X"02500",
                            X"0030D", X"02341", X"08201", X"0400D");
begin
    process (clk)
    begin
        if rising_edge(clk) then
            if we = '1' then
                RAM(conv_integer(addr)) <= di;</pre>
            end if:
        do <= RAM(conv_integer(addr));</pre>
        end if;
    end process;
end syn;
                 Single-Port BRAM Initial Contents Verilog Coding Example
                    11
                    // Initializing Block RAM (Single-Port BRAM)
                    11
                    module v_rams_20a (clk, we, addr, di, do);
                        input clk;
                        input we;
                        input [5:0] addr;
                        input [19:0] di;
                        output [19:0] do;
```



```
reg [19:0] ram [63:0];
reg [19:0] do;
initial begin
   ram[63] = 20'h0200A; ram[62] = 20'h00300; ram[61] = 20'h08101;
   ram[60] = 20'h04000; ram[59] = 20'h08601; ram[58] = 20'h0233A;
   ram[57] = 20'h00300; ram[56] = 20'h08602; ram[55] = 20'h02310;
    ram[54] = 20'h0203B; ram[53] = 20'h08300; ram[52] = 20'h04002;
   ram[51] = 20'h08201; ram[50] = 20'h00500; ram[49] = 20'h04001;
   ram[48] = 20'h02500; ram[47] = 20'h00340; ram[46] = 20'h00241;
   ram[45] = 20'h04002; ram[44] = 20'h08300; ram[43] = 20'h08201;
    ram[42] = 20'h00500; ram[41] = 20'h08101; ram[40] = 20'h00602;
   ram[39] = 20'h04003; ram[38] = 20'h0241E; ram[37] = 20'h00301;
   ram[36] = 20'h00102; ram[35] = 20'h02122; ram[34] = 20'h02021;
    ram[33] = 20'h00301; ram[32] = 20'h00102; ram[31] = 20'h02222;
    ram[30] = 20'h04001; ram[29] = 20'h00342; ram[28] = 20'h0232B;
   ram[27] = 20'h00900; ram[26] = 20'h00302; ram[25] = 20'h00102;
   ram[24] = 20'h04002; ram[23] = 20'h00900; ram[22] = 20'h08201;
   ram[21] = 20'h02023; ram[20] = 20'h00303; ram[19] = 20'h02433;
    ram[18] = 20'h00301; ram[17] = 20'h04004; ram[16] = 20'h00301;
   ram[15] = 20'h00102; ram[14] = 20'h02137; ram[13] = 20'h02036;
   ram[12] = 20'h00301; ram[11] = 20'h00102; ram[10] = 20'h02237;
   ram[9] = 20'h04004; ram[8] = 20'h00304; ram[7] = 20'h04040;
    ram[6] = 20'h02500; ram[5] = 20'h02500; ram[4] = 20'h02500;
   ram[3] = 20'h0030D; ram[2] = 20'h02341; ram[1] = 20'h08201;
    ram[0] = 20'h0400D;
end
always @(posedge clk)
begin
    if (we)
        ram[addr] <= di;</pre>
    do <= ram[addr];</pre>
end
```

endmodule

Dual-Port RAM Initial Contents VHDL Coding Example

```
-- Initializing Block RAM (Dual-Port BRAM)
--
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity rams_20b is
    port (clk1 : in std_logic;
        clk2 : in std_logic;
        we : in std_logic;
        addr1 : in std_logic_vector(7 downto 0);
        addr2 : in std_logic_vector(7 downto 0);
        di : in std_logic_vector(15 downto 0);
        do1 : out std_logic_vector(15 downto 0);
        do2 : out std_logic_vector(15 downto 0));
end rams_20b;
```



architecture syn of rams\_20b is

type ram\_type is array (255 downto 0) of std\_logic\_vector (15 downto 0); signal RAM : ram\_type:= (255 downto 100 => X"B8B8", 99 downto 0 => X"8282"); begin process (clk1) begin if rising\_edge(clk1) then if we = '1' then RAM(conv\_integer(addr1)) <= di;</pre> end if; do1 <= RAM(conv\_integer(addr1));</pre> end if; end process; process (clk2) begin if rising\_edge(clk2) then do2 <= RAM(conv\_integer(addr2));</pre> end if; end process; end syn; Dual-Port RAM Initial Contents Verilog Coding Example 11 // Initializing Block RAM (Dual-Port BRAM) 11 module v\_rams\_20b (clk1, clk2, we, addr1, addr2, di, do1, do2); input clk1, clk2; input we; input [7:0] addr1, addr2; input [15:0] di; output [15:0] do1, do2; reg [15:0] ram [255:0]; reg [15:0] do1, do2; integer index; initial begin for (index = 0 ; index <= 99 ; index = index + 1) begin ram[index] = 16'h8282; end for (index = 100; index <= 255; index = index + 1) begin ram[index] = 16'hB8B8; end end always @(posedge clk1) begin if (we) ram[addr1] <= di;</pre> do1 <= ram[addr1];</pre>

```
end
```

endmodule

## Initializing RAM From an External File

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>.

- "Initializing Block RAM (External Data File) VHDL Coding Example"
- "Initializing Block RAM (External Data File) Verilog Coding Example"

To initialize RAM from values contained in an external file, use a read function in the VHDL code. For more information, see "XST VHDL File Type Support" in Chapter 6. Set up the initialization file as follows.

- Use each line of the initialization file to represent the initial contents of a given row in the RAM.
- RAM contents can be represented in binary or hexadecimal.
- There should be as many lines in the file as there are rows in the RAM array.
- Following is an example of the contents of a file initializing an 8 x 32-bit RAM with binary values:

## Initializing Block RAM (External Data File)

RAM initial values may be stored in an external data file that is accessed from within the HDL code. The data file must be pure binary or hexadecimal content with no comments or other information. Following is an example of the contents of a file initializing an 8 x 32-bit RAM with binary values. For both examples, the data file referenced is called rams\_20c.data.



Initializing Block RAM (External Data File) VHDL Coding Example

In the following coding example, the loop that generates the initial value is controlled by testing that we are in the RAM address range. The following coding examples show initializing Block RAM from an external data file.

```
-- Initializing Block RAM from external data file
_ _
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
use std.textio.all;
entity rams_20c is
   port(clk : in std_logic;
         we : in std_logic;
         addr : in std_logic_vector(5 downto 0);
         din : in std_logic_vector(31 downto 0);
         dout : out std_logic_vector(31 downto 0));
end rams_20c;
architecture syn of rams_20c is
    type RamType is array(0 to 63) of bit_vector(31 downto 0);
 impure function InitRamFromFile (RamFileName : in string) return RamType is
        FILE RamFile
                         : text is in RamFileName;
        variable RamFileLine : line;
        variable RAM
                             : RamType;
   begin
        for I in RamType'range loop
            readline (RamFile, RamFileLine);
            read (RamFileLine, RAM(I));
        end loop;
        return RAM;
    end function;
    signal RAM : RamType := InitRamFromFile("rams_20c.data");
begin
    process (clk)
    begin
        if clk'event and clk = '1' then
            if we = '1' then
                RAM(conv_integer(addr)) <= to_bitvector(din);</pre>
            end if;
            dout <= to_stdlogicvector(RAM(conv_integer(addr)));</pre>
        end if;
    end process;
end syn;
```

If there are not enough lines in the external data file, XST issues the following message.

ERROR:Xst - raminitfile1.vhd line 40: Line <RamFileLine> has not enough elements for target <RAM<63>>.



Initializing Block RAM (External Data File) Verilog Coding Example

To initialize RAM from values contained in an external file, use a **\$readmemb** or **\$readmemb** system task in your Verilog code. For more information, see "XST Behavioral Verilog Language Support." Set up the initialization file as follows.

- Arrange each line of the initialization file to represent the initial contents of a given row in the RAM.
- RAM contents can be represented in binary or hexadecimal.
- Use **\$readmemb** for binary and **\$readmemh** for hexadecimal representation. To avoid the possible difference between XST and simulator behavior, Xilinx recommends that you use index parameters in these system tasks. See the following coding example:

```
$readmemb("rams_20c.data",ram, 0, 7);
```

Create as many lines in the file as there are rows in the RAM array.

```
11
// Initializing Block RAM from external data file
11
module v_rams_20c (clk, we, addr, din, dout);
    input clk;
    input we;
    input [5:0] addr;
    input [31:0] din;
    output [31:0] dout;
    reg [31:0] ram [0:63];
    reg [31:0] dout;
    initial
    begin
        $readmemb("rams_20c.data",ram, 0, 63);
    end
    always @(posedge clk)
    begin
        if (we)
            ram[addr] <= din;</pre>
        dout <= ram[addr];</pre>
    end
```

endmodule

# **ROMs Using Block RAM Resources HDL Coding Techniques**

This section discusses ROMs Using Block RAM Resources HDL Coding Techniques, and includes:

- "About ROMs Using Block RAM Resources"
- "ROMs Using Block RAM Resources Log File"
- "ROMs Using Block RAM Resources Related Constraints"
- "ROMs Using Block RAM Resources Coding Examples"

# About ROMs Using Block RAM Resources

XST can use block RAM resources to implement ROMs with synchronous outputs or address inputs. These ROMs are implemented as single-port or dual-port block RAMs depending on the HDL description.

XST can infer block ROM across hierarchies if the "Keep Hierarchy (KEEP\_HIERARCHY)" command line option is set to **no**. In this case, ROM and the data output or address register can be described in separate hierarchy blocks. This inference is performed during Advanced HDL Synthesis.

Using block RAM resources to implement ROMs is controlled by the "ROM Style (ROM\_STYLE)" constraint. For more information about the "ROM Style (ROM\_STYLE)" attribute, see "XST Design Constraints." For more information about ROM implementation, see "XST FPGA Optimization."

# ROMs Using Block RAM Resources Log File

*	HDL Synthes	is	*	
Found 64x20-k Found 20-bit Summary: inferred	ce file is "rams_21a.vh pit ROM for signal <\$va register for signal <d 1 ROM(s). 20 D-type flip-flop(s)</d 	rindex0000> created ata>.	at line 38.	
HDL Synthesis Reg Macro Statistics # ROMs 64x20-bit ROM # Registers 20-bit register	oort	: 1 : 1 : 1 : 1 : 1		
*	Advanced HDL Sy	nthesis	*	
	rams_21a> : The ROM <mrc bing the register: <dat< td=""><td></td><td>l be implemente</td><td>ed as a read-only</td></dat<></mrc 		l be implemente	ed as a read-only
ram_type	Block			
Port A				



aspect ratio mode clkA enA weA addrA diA doA	64-word x 20-bit (6.9%) write-first connected to signal <clk> connected to signal <en> connected to internal node connected to signal <addr> connected to internal node connected to signal <data></data></addr></en></clk>		rise   high   high   
Advanced HDL Synthesis Rep Macro Statistics # RAMs 64x20-bit single-port bloc	ort	: 1 : 1	

# **ROMs Using Block RAM Resources Related Constraints**

• "ROM Style (ROM\_STYLE)"

# ROMs Using Block RAM Resources Coding Examples

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>

- "ROM With Registered Output"
- "ROM With Registered Address"

## **ROM With Registered Output**

This section discusses ROM With Registered Output, and includes:

- "ROM With Registered Output Diagram"
- "ROM With Registered Output Pin Descriptions"
- "ROM With Registered Output VHDL Coding Example One"
- "ROM With Registered Output VHDL Coding Example Two"
- "ROM With Registered Output Verilog Coding Example One"
- "ROM With Registered Output Verilog Coding Example Two"




Figure 2-71: ROM With Registered Output Diagram

IO Pins	Description
clk	Positive-Edge Clock
en	Synchronous Enable (Active High)
addr	Read Address
data	Data Output

Table 2-89: ROM With Registered Output Pin Descriptions

ROM With Registered Output VHDL Coding Example One

```
-- ROMs Using Block RAM Resources.
-- VHDL code for a ROM with registered output (template 1)
_ _
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity rams_21a is
   port (clk : in std_logic;
             : in std_logic;
          en
          addr : in std_logic_vector(5 downto 0);
          data : out std_logic_vector(19 downto 0));
end rams_21a;
architecture syn of rams_21a is
   type rom_type is array (63 downto 0) of std_logic_vector (19 downto 0);
    signal ROM : rom_type:= (X"0200A", X"00300", X"08101", X"04000", X"08601", X"0233A",
                             X"00300", X"08602", X"02310", X"0203B", X"08300", X"04002",
                             X"08201", X"00500", X"04001", X"02500", X"00340", X"00241",
                             X"04002", X"08300", X"08201", X"00500", X"08101", X"00602",
                             X"04003", X"0241E", X"00301", X"00102", X"02122", X"02021",
                             X"00301", X"00102", X"02222", X"04001", X"00342", X"0232B",
                             X"00900", X"00302", X"00102", X"04002", X"00900", X"08201",
                             X"02023", X"00303", X"02433", X"00301", X"04004", X"00301",
                             X"00102", X"02137", X"02036", X"00301", X"00102", X"02237",
                             x"04004", x"00304", x"04040", x"02500", x"02500", x"02500",
                            X"0030D", X"02341", X"08201", X"0400D");
begin
   process (clk)
   begin
        if (clk'event and clk = '1') then
            if (en = '1') then
                data <= ROM(conv_integer(addr));</pre>
            end if;
        end if;
    end process;
end syn;
```

\_ \_



ROM With Registered Output VHDL Coding Example Two

```
-- ROMs Using Block RAM Resources.
-- VHDL code for a ROM with registered output (template 2)
___
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity rams_21b is
port (clk : in std_logic;
      en : in std_logic;
      addr : in std_logic_vector(5 downto 0);
      data : out std_logic_vector(19 downto 0));
end rams_21b;
architecture syn of rams_21b is
    type rom_type is array (63 downto 0) of std_logic_vector (19 downto 0);
    signal ROM : rom_type:= (X"0200A", X"00300", X"08101", X"04000", X"08601", X"0233A",
                              X"00300", X"08602", X"02310", X"0203B", X"08300", X"04002",
                              X"08201", X"00500", X"04001", X"02500", X"00340", X"00241",
                              X"04002", X"08300", X"08201", X"00500", X"08101", X"00602",
                              X"04003", X"0241E", X"00301", X"00102", X"02122", X"02021",
                              X"00301", X"00102", X"02222", X"04001", X"00342", X"0232B",
                              X"00900", X"00302", X"00102", X"04002", X"00900", X"08201",
                              X"02023", X"00303", X"02433", X"00301", X"04004", X"00301",
                              X"00102", X"02137", X"02036", X"00301", X"00102", X"02237",
                              X"04004", X"00304", X"04040", X"02500", X"02500", X"02500",
                            X"0030D", X"02341", X"08201", X"0400D");
    signal rdata : std_logic_vector(19 downto 0);
begin
    rdata <= ROM(conv_integer(addr));</pre>
    process (clk)
    begin
        if (clk'event and clk = '1') then
            if (en = '1') then
                data <= rdata;</pre>
            end if;
        end if;
    end process;
end syn;
                 ROM With Registered Output Verilog Coding Example One
11
// ROMs Using Block RAM Resources.
// Verilog code for a ROM with registered output (template 1)
11
module v_rams_21a (clk, en, addr, data);
    input
               clk;
    input
               en;
```

<pre>input [5:0] addr; output reg [19:0] data;</pre>	
always @(posedge clk) begin if (en)	
case(addr)	
6'b000000: data <= 20'h0200A	A; 6'b100000: data <= 20'h02222;
6'b000001: data <= 20'h00300	); 6'b100001: data <= 20'h04001;
6'b000010: data <= 20'h08101	; 6'b100010: data <= 20'h00342;
6'b000011: data <= 20'h04000	); 6'b100011: data <= 20'h0232B;
6'b000100: data <= 20'h08601	; 6'b100100: data <= 20'h00900;
6'b000101: data <= 20'h0233A	A; 6'b100101: data <= 20'h00302;
6'b000110: data <= 20'h00300	); 6'b100110: data <= 20'h00102;
6'b000111: data <= 20'h08602	2; 6'b100111: data <= 20'h04002;
6'b001000: data <= 20'h02310	); 6'b101000: data <= 20'h00900;
6'b001001: data <= 20'h0203E	3; 6'b101001: data <= 20'h08201;
6'b001010: data <= 20'h08300	); 6'b101010: data <= 20'h02023;
6'b001011: data <= 20'h04002	2; 6'b101011: data <= 20'h00303;
6'b001100: data <= 20'h08201	; 6'b101100: data <= 20'h02433;
6'b001101: data <= 20'h00500	); 6'b101101: data <= 20'h00301;
6'b001110: data <= 20'h04001	; 6'b101110: data <= 20'h04004;
6'b001111: data <= 20'h02500	); 6'b101111: data <= 20'h00301;
6'b010000: data <= 20'h00340	); 6'b110000: data <= 20'h00102;
6'b010001: data <= 20'h00241	; 6'b110001: data <= 20'h02137;
6'b010010: data <= 20'h04002	2; 6'b110010: data <= 20'h02036;
6'b010011: data <= 20'h08300	); 6'b110011: data <= 20'h00301;
6'b010100: data <= 20'h08201	; 6'b110100: data <= 20'h00102;
6'b010101: data <= 20'h00500	); 6'b110101: data <= 20'h02237;
6'b010110: data <= 20'h08101	; 6'b110110: data <= 20'h04004;
6'b010111: data <= 20'h00602	2; 6'b110111: data <= 20'h00304;
6'b011000: data <= 20'h04003	; 6'b111000: data <= 20'h04040;
6'b011001: data <= 20'h0241E	<pre>c; 6'b111001: data &lt;= 20'h02500;</pre>
6'b011010: data <= 20'h00301	; 6'b111010: data <= 20'h02500;
6'b011011: data <= 20'h00102	2; 6'b111011: data <= 20'h02500;
6'b011100: data <= 20'h02122	2; 6'b111100: data <= 20'h0030D;
6'b011101: data <= 20'h02021	; 6'b111101: data <= 20'h02341;
6'b011110: data <= 20'h00301	; 6'b111110: data <= 20'h08201;
6'b011111: data <= 20'h00102	2; 6'b111111: data <= 20'h0400D;

endcase

end

endmodule

#### ROM With Registered Output Verilog Coding Example Two

```
//
// ROMs Using Block RAM Resources.
// Verilog code for a ROM with registered output (template 2)
//
module v_rams_21b (clk, en, addr, data);
input clk;
input clk;
input en;
input [5:0] addr;
output reg [19:0] data;
reg [19:0] rdata;
```



```
always @(addr) begin
    case(addr)
            6'b000000: rdata <= 20'h0200A;
                                              6'b100000: rdata <= 20'h02222;
            6'b000001: rdata <= 20'h00300;
                                              6'b100001: rdata <= 20'h04001;
            6'b000010: rdata <= 20'h08101;
                                              6'b100010: rdata <= 20'h00342;
            6'b000011: rdata <= 20'h04000;
                                              6'b100011: rdata <= 20'h0232B;
            6'b000100: rdata <= 20'h08601;
                                              6'b100100: rdata <= 20'h00900;
            6'b000101: rdata <= 20'h0233A;
                                              6'b100101: rdata <= 20'h00302;
            6'b000110: rdata <= 20'h00300;
                                              6'b100110: rdata <= 20'h00102;
            6'b000111: rdata <= 20'h08602;
                                              6'b100111: rdata <= 20'h04002;
            6'b001000: rdata <= 20'h02310;
                                              6'b101000: rdata <= 20'h00900;
            6'b001001: rdata <= 20'h0203B;
                                              6'b101001: rdata <= 20'h08201;
            6'b001010: rdata <= 20'h08300;
                                              6'b101010: rdata <= 20'h02023;
            6'b001011: rdata <= 20'h04002;
                                              6'b101011: rdata <= 20'h00303;
            6'b001100: rdata <= 20'h08201;
                                              6'b101100: rdata <= 20'h02433;
            6'b001101: rdata <= 20'h00500;
                                              6'b101101: rdata <= 20'h00301;
            6'b001110: rdata <= 20'h04001;
                                              6'b101110: rdata <= 20'h04004;
            6'b001111: rdata <= 20'h02500;
                                              6'b101111: rdata <= 20'h00301;
            6'b010000: rdata <= 20'h00340;
                                              6'b110000: rdata <= 20'h00102;
            6'b010001: rdata <= 20'h00241;
                                              6'b110001: rdata <= 20'h02137;
            6'b010010: rdata <= 20'h04002;
                                              6'b110010: rdata <= 20'h02036;
            6'b010011: rdata <= 20'h08300;
                                              6'b110011: rdata <= 20'h00301;
            6'b010100: rdata <= 20'h08201;
                                              6'b110100: rdata <= 20'h00102;
            6'b010101: rdata <= 20'h00500;
                                              6'b110101: rdata <= 20'h02237;
            6'b010110: rdata <= 20'h08101;
                                              6'b110110: rdata <= 20'h04004;
            6'b010111: rdata <= 20'h00602;
                                              6'b110111: rdata <= 20'h00304;
            6'b011000: rdata <= 20'h04003;
                                              6'b111000: rdata <= 20'h04040;
            6'b011001: rdata <= 20'h0241E;
                                              6'b111001: rdata <= 20'h02500;
            6'b011010: rdata <= 20'h00301;
                                              6'b111010: rdata <= 20'h02500;
            6'b011011: rdata <= 20'h00102;
                                              6'b111011: rdata <= 20'h02500;
            6'b011100: rdata <= 20'h02122;
                                              6'b111100: rdata <= 20'h0030D;
                                              6'b111101: rdata <= 20'h02341;
            6'b011101: rdata <= 20'h02021;
            6'b011110: rdata <= 20'h00301;
                                              6'b111110: rdata <= 20'h08201;
            6'b011111: rdata <= 20'h00102;
                                              6'b111111: rdata <= 20'h0400D;
    endcase
end
```

always @(posedge clk) begin
 if (en)
 data <= rdata;
end</pre>

```
endmodule
```

## **ROM With Registered Address**

This section discusses ROM With Registered Address, and includes:

- "ROM With Registered Address Diagram"
- "ROM With Registered Address Pin Descriptions"
- "ROM With Registered Address VHDL Coding Example"
- "ROM With Registered Address Verilog Coding Example"






Table 2-90: ROM With Registered Address Pin Descriptions

IO Pins	Description
clk	Positive-Edge Clock
en	Synchronous Enable (Active High)
addr	Read Address
data	Data Output
clk	Positive-Edge Clock

#### ROM With Registered Address VHDL Coding Example

```
-- ROMs Using Block RAM Resources.
-- VHDL code for a ROM with registered address
_ _
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity rams_21c is
port (clk : in std_logic;
      en : in std_logic;
      addr : in std_logic_vector(5 downto 0);
      data : out std_logic_vector(19 downto 0));
end rams_21c;
architecture syn of rams_21c is
   type rom_type is array (63 downto 0) of std_logic_vector (19 downto 0);
    signal ROM : rom_type:= (X"0200A", X"00300", X"08101", X"04000", X"08601", X"0233A",
                             X"00300", X"08602", X"02310", X"0203B", X"08300", X"04002",
                             X"08201", X"00500", X"04001", X"02500", X"00340", X"00241",
                             X"04002", X"08300", X"08201", X"00500", X"08101", X"00602",
                             X"04003", X"0241E", X"00301", X"00102", X"02122", X"02021",
```



```
X"00301", X"00102", X"02222", X"04001", X"00342", X"0232B",
                             X"00900", X"00302", X"00102", X"04002", X"00900", X"08201",
                             X"02023", X"00303", X"02433", X"00301", X"04004", X"00301",
                             X"00102", X"02137", X"02036", X"00301", X"00102", X"02237",
                             x"04004", x"00304", x"04040", x"02500", x"02500", x"02500",
                            X"0030D", X"02341", X"08201", X"0400D");
    signal raddr : std_logic_vector(5 downto 0);
begin
    process (clk)
    begin
        if (clk'event and clk = '1') then
            if (en = '1') then
                raddr <= addr;</pre>
            end if:
        end if;
    end process;
    data <= ROM(conv_integer(raddr));</pre>
end syn;
                 ROM With Registered Address Verilog Coding Example
11
// ROMs Using Block RAM Resources.
// Verilog code for a ROM with registered address
11
module v_rams_21c (clk, en, addr, data);
    input
               clk;
    input
               en;
               [5:0] addr;
    input
    output reg [19:0] data;
               [5:0] raddr;
    reg
    always @(posedge clk) begin
        if (en)
            raddr <= addr;</pre>
    end
    always @(raddr) begin
       case(raddr)
                6'b000000: data <= 20'h0200A;
                                                 6'b100000: data <= 20'h02222;
                6'b000001: data <= 20'h00300;
                                                 6'b100001: data <= 20'h04001;
                6'b000010: data <= 20'h08101;
                                                 6'b100010: data <= 20'h00342;
                6'b000011: data <= 20'h04000;
                                                6'b100011: data <= 20'h0232B;
                6'b000100: data <= 20'h08601;
                                                 6'b100100: data <= 20'h00900;
                6'b000101: data <= 20'h0233A;
                                                 6'b100101: data <= 20'h00302;
                6'b000110: data <= 20'h00300;
                                                 6'b100110: data <= 20'h00102;
                6'b000111: data <= 20'h08602;
                                                 6'b100111: data <= 20'h04002;
                6'b001000: data <= 20'h02310;
                                                 6'b101000: data <= 20'h00900;
                6'b001001: data <= 20'h0203B;
                                                 6'b101001: data <= 20'h08201;
                6'b001010: data <= 20'h08300;
                                                 6'b101010: data <= 20'h02023;
                6'b001011: data <= 20'h04002;
                                                 6'b101011: data <= 20'h00303;
                6'b001100: data <= 20'h08201;
                                                 6'b101100: data <= 20'h02433;
                6'b001101: data <= 20'h00500;
                                                 6'b101101: data <= 20'h00301;
```

6'b0011	L10: data <= 2	20'h04001; 6	'b101110: data	<= 20'h04004;
6'b0011	l11: data <= 2	0'h02500; 6	'b101111: data	<= 20'h00301;
6'b0100	000: data <= 2	20'h00340; 6	'b110000: data	<= 20'h00102;
6'b0100	001: data <= 2	20'h00241; 6	'b110001: data	<= 20'h02137;
6'b0100	)10: data <= 2	20'h04002; 6	'b110010: data	<= 20'h02036;
6'b0100	)11: data <= 2	0'h08300; 6	'b110011: data	<= 20'h00301;
6'b0101	L00: data <= 2	20'h08201; 6	'b110100: data	<= 20'h00102;
6'b0101	L01: data <= 2	20'h00500; 6	'b110101: data	<= 20'h02237;
6'b0101	L10: data <= 2	20'h08101; 6	'b110110: data	<= 20'h04004;
6'b0101	l11: data <= 2	20'h00602; 6	'b110111: data	<= 20'h00304;
6'b0110	000: data <= 2	20'h04003; 6	'b111000: data	<= 20'h04040;
6'b0110	001: data <= 2	20'h0241E; 6	'b111001: data	<= 20'h02500;
6'b0110	)10: data <= 2	20'h00301; 6	'b111010: data	<= 20'h02500;
6'b0110	)11: data <= 2	20'h00102; 6	'b111011: data	<= 20'h02500;
6'b0111	L00: data <= 2	20'h02122; 6	'b111100: data	<= 20'h0030D;
6'b0111	L01: data <= 2	20'h02021; 6	'b111101: data	<= 20'h02341;
6'b0111	L10: data <= 2	20'h00301; 6	'b111110: data	<= 20'h08201;
6'b0111	l11: data <= 2	20'h00102; 6	'b111111: data	<= 20'h0400D;
endcase				
_				

```
end
```

endmodule

# **Pipelined Distributed RAM HDL Coding Techniques**

This section discusses Pipelined Distributed RAM HDL Coding Techniques, and includes:

- "About Pipelined Distributed RAM"
- "Pipelined Distributed RAM Log File"
- "Pipelined Distributed RAM Related Constraints"
- "Pipelined Distributed RAM Coding Examples"

# About Pipelined Distributed RAM

To increase the speed of designs, XST can infer pipelined distributed RAM. By interspersing registers between the stages of distributed RAM, pipelining can significantly increase the overall frequency of your design. The effect of pipelining is similar to flip-flop retiming which is described in "Flip-Flop Retiming."

To insert pipeline stages, describe the necessary registers in your HDL code and place them after any distributed RAM, then set the "RAM Style (RAM\_STYLE)" constraint to *pipe\_distributed*.

When it detects valid registers for pipelining and RAM \_STYLE is set to *pipe\_distributed*, XST uses the maximum number of available registers to reach the maximum distributed RAM speed. XST automatically calculates the maximum number of registers for each RAM to obtain the best frequency.

If you have not specified sufficient register stages and RAM \_STYLE is coded directly on a signal, the XST HDL Advisor advises you to specify the optimum number of register stages. XST does this during the Advanced HDL Synthesis step. If the number of registers placed after the multiplier exceeds the maximum required, and shift register extraction is activated, then XST implements the unused stages as shift registers.

XST cannot pipeline RAM if registers contain asynchronous set/reset signals. XST can pipeline RAM if registers contain synchronous reset signals.



# Pipelined Distributed RAM Log File

Following is the log file for Pipelined Distributed RAM.

```
_____
                  HDL Synthesis
_____
Synthesizing Unit <rams_22>.
  Related source file is "rams_22.vhd".
  Found 64x4-bit single-port RAM for signal <RAM>.
  Found 4-bit register for signal <do>.
  Summary:
 inferred 1 RAM(s).
 inferred 4 D-type flip-flop(s).
Unit <rams_22> synthesized.
_____
HDL Synthesis Report
Macro Statistics
# RAMs
                                       : 1
64x4-bit single-port RAM
                                       : 1
# Registers
                                       : 1
4-bit register
                                       : 1
_____
_____
             Advanced HDL Synthesis
_____
INFO:Xst - Unit <rams_22> : The RAM <Mram_RAM> will be implemented as a distributed RAM,
absorbing the following register(s): <do>.
  _____
  aspect ratio64-word x 4-bitclockconnected to signal <clk>write enableconnected to signal <we>addressconnected to signal <addr>data inconnected to signal <di>
                                      rise
                                      high
   data out
                 connected to internal node
  ram_style distributed
   _____
Synthesizing (advanced) Unit <rams_22>.
 Found pipelined ram on signal <_varindex0000>:
  - 1 pipeline level(s) found in a register on signal <_varindex0000>.
  Pushing register(s) into the ram macro.
INFO:Xst:2390 - HDL ADVISOR - You can improve the performance of the ram Mram_RAM by adding
1 register level(s) on output signal _varindex0000.
Unit <rams_22> synthesized (advanced).
_____
Advanced HDL Synthesis Report
Macro Statistics
# RAMs
                                      : 1
64x4-bit registered single-port distributed RAM
                                      : 1
_____
```

# Pipelined Distributed RAM Related Constraints

- "RAM Extraction (RAM\_EXTRACT)"
- "RAM Style (RAM\_STYLE)"
- "ROM Extraction (ROM\_EXTRACT)"
- "ROM Style (ROM\_STYLE)"
- "BRAM Utilization Ratio (BRAM\_UTILIZATION\_RATIO)"
- "Automatic BRAM Packing (AUTO\_BRAM\_PACKING)"

# Pipelined Distributed RAM Coding Examples


The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>.

• "Pipelined Distributed RAM"

# Pipelined Distributed RAM

This section discusses Pipelined Distributed RAM, and includes:

- "Pipelined Distributed RAM Diagram"
- "Pipelined Distributed RAM Pin Descriptions"
- "Pipelined Distributed RAM VHDL Coding Example"
- "Pipelined Distributed RAM Verilog Coding Example"



X10572

Figure 2-73: Pipelined Distributed RAM Diagram

Table 2-91:	Pipelined Distributed RAM Pin Descriptions
-------------	--

IO Pins	Description
clk	Positive-Edge Clock
we	Synchronous Write Enable (Active High)
addr	Read/Write Address

www.xilinx.com



Table 2-91: Pipelined Distributed RAM Pin Descriptions

IO Pins	Description
di	Data Input
do	Data Output

#### Pipelined Distributed RAM VHDL Coding Example

```
-- Pipeline distributed RAMs
_ _
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
entity rams_22 is
   port (clk : in std_logic;
          we : in std_logic;
          addr : in std_logic_vector(8 downto 0);
              : in std_logic_vector(3 downto 0);
          di
              : out std_logic_vector(3 downto 0));
          do
end rams_22;
architecture syn of rams_22 is
    type ram_type is array (511 downto 0) of std_logic_vector (3 downto 0);
    signal RAM : ram_type;
    signal pipe_reg: std_logic_vector(3 downto 0);
    attribute ram_style: string;
    attribute ram_style of RAM: signal is "pipe_distributed";
begin
    process (clk)
   begin
        if clk'event and clk = '1' then
                if we = '1' then
                    RAM(conv_integer(addr)) <= di;</pre>
                else
                    pipe_reg <= RAM( conv_integer(addr));</pre>
                end if;
           do <= pipe_reg;</pre>
        end if;
    end process;
end syn;
```

#### Pipelined Distributed RAM Verilog Coding Example

```
//
// Pipeline distributed RAMs
//
```

```
module v_rams_22 (clk, we, addr, di, do);
```

```
input clk;
    input we;
    input [8:0] addr;
    input [3:0] di;
    output [3:0] do;
    (*ram_style="pipe_distributed"*)
  reg
          [3:0] RAM [511:0];
    reg
           [3:0] do;
          [3:0] pipe_reg;
  reg
    always @(posedge clk)
    begin
        if (we)
          RAM[addr] <= di;</pre>
        else
          pipe_reg <= RAM[addr];</pre>
     do <= pipe_reg;</pre>
    end
endmodule
```

# Finite State Machines (FSMs) HDL Coding Techniques

This section discusses Finite State Machines (FSMs) HDL Coding Techniques, and includes:


- "About Finite State Machines (FSMs)"
- "Describing Finite State Machines (FSMs)"
- "State Encoding Techniques"
- "RAM-Based FSM Synthesis"
- "Safe FSM Implementation"
- "Finite State Machines Log File"
- "Finite State Machines Related Constraints"
- "Finite State Machines Coding Examples"


# About Finite State Machines (FSMs)

XST proposes a large set of templates to describe Finite State Machines (FSMs). By default, XST tries to distinguish FSMs from VHDL or Verilog code, and apply several state encoding techniques (it can re-encode your initial encoding) to obtain better performance or less area. To disable FSM extraction, use the "Automatic FSM Extraction (FSM\_EXTRACT)" constraint. XST can handle only synchronous state machines.

# Describing Finite State Machines (FSMs)

There are many ways to describe FSMs. A traditional FSM representation incorporates Mealy and Moore machines, as shown in Figure 2-74, "FSM Representation Incorporating Mealy and Moore Machines Diagram." XST supports both models.






For HDL, process (VHDL) and always blocks (Verilog) are the most suitable ways for describing FSMs. Xilinx uses *process* to refer to both VHDL processes and Verilog always blocks.

You may have several processes (1, 2 or 3) in your description, depending upon how you consider and decompose the different parts of the preceding model. Following is an example of the Moore Machine with Asynchronous Reset, RESET.

- 4 states: s1, s2, s3, s4
- 5 transitions
- 1 input: **x1**
- 1 output: outp

This model is represented by the following bubble diagram:



*Figure 2-75:* Bubble Diagram

## State Registers

State registers must be initialized with an asynchronous or synchronous signal, or have the power-up value defined by "Register Power Up (REGISTER\_POWERUP)" Otherwise, XST does not recognize FSM. See "Registers HDL Coding Techniques" for coding examples on how to write Asynchronous and Synchronous initialization signals.

In VHDL, the type of a state register can be a different type, such as:

- integer
- bit\_vector
- std\_logic\_vector

But it is common and convenient to define an enumerated type containing all possible state values and to declare your state register with that type.

In Verilog, the type of state register can be an integer or a set of defined parameters. In the following Verilog examples the state assignments could have been made as follows:

```
parameter [3:0]
s1 = 4'b0001,
s2 = 4'b0010,
s3 = 4'b0100,
s4 = 4'b1000;
reg [3:0] state;
```

These parameters can be modified to represent different state encoding schemes.

#### Next State Equations

Next state equations can be described directly in the sequential process or in a distinct combinational process. The simplest coding example is based on a Case statement. If using a separate combinational process, its sensitivity list should contain the state signal and all FSM inputs.

#### **Unreachable States**

XST can detect unreachable states in an FSM. It lists them in the log file in the HDL Synthesis step.

#### FSM Outputs

Non-registered outputs are described either in the combinational process or in concurrent assignments. Registered outputs must be assigned within the sequential process.

#### FSM Inputs

Registered inputs are described using internal signals, which are assigned in the sequential process.

## State Encoding Techniques

XST supports the following state encoding techniques:

- "Auto State Encoding"
- "One-Hot State Encoding"
- "Gray State Encoding"

- "Compact State Encoding"
- "Johnson State Encoding"
- "Sequential State Encoding"
- "Speed1 State Encoding"
- "User State Encoding"

## Auto State Encoding

In Auto State Encoding, XST tries to select the best suited encoding algorithm for each FSM.

## **One-Hot State Encoding**

One-Hot State Encoding is the default encoding scheme. Its principle is to associate one code bit and also one flip-flop to each state. At a given clock cycle during operation, one and only one bit of the state variable is asserted. Only two bits toggle during a transition between two states. One-Hot State Encoding is appropriate with most FPGA targets where a large number of flip-flops are available. It is also a good alternative when trying to optimize speed or to reduce power dissipation.

### Gray State Encoding

Gray State Encoding guarantees that only one bit switches between two consecutive states. It is appropriate for controllers exhibiting long paths without branching. In addition, this coding technique minimizes hazards and glitches. Very good results can be obtained when implementing the state register with T flip-flops.

## **Compact State Encoding**

Compact State Encoding consists of minimizing the number of bits in the state variables and flip-flops. This technique is based on hypercube immersion. Compact State Encoding is appropriate when trying to optimize area.

## Johnson State Encoding

Like Gray State Encoding, Johnson State Encoding shows benefits with state machines containing long paths with no branching.

## Sequential State Encoding

Sequential State Encoding consists of identifying long paths and applying successive radix two codes to the states on these paths. Next state equations are minimized.

## Speed1 State Encoding

Speed1 State Encoding is oriented for speed optimization. The number of bits for a state register depends on the particular FSM, but generally it is greater than the number of FSM states.

## User State Encoding

In User State Encoding, XST uses the original encoding specified in the HDL file. For example, if you use enumerated types for a state register, use the "Enumerated Encoding"

(ENUM\_ENCODING)" constraint to assign a specific binary value to each state. For more information, see "XST Design Constraints."

# **RAM-Based FSM Synthesis**

Large FSMs can be made more compact and faster by implementing them in the block RAM resources provided in Virtex and later technologies. "FSM Style (FSM\_STYLE)" directs XST to use block RAM resources for FSMs.

Values for "FSM Style (FSM\_STYLE)" are:

• lut (default)

XST maps the FSM using LUTs.

• bram

XST maps the FSM onto block RAM.

Invoke "FSM Style (FSM\_STYLE)" as follows:

• Project Navigator

Select LUT or Block RAM as instructed in the HDL Options topics of ISE Help.

Command line

Use the **-fsm\_style** command line option.

HDL code

Use "FSM Style (FSM\_STYLE)"

If it cannot implement a state machine on block RAM, XST:

- Issues a warning in the Advanced HDL Synthesis step of the log file.
- Automatically implements the state machine using LUTs.

For example, if FSM has an asynchronous reset, it cannot be implemented using block RAM. In this case XST informs you:

\* Advanced HDL Synthesis \*

WARNING:Xst - Unable to fit FSM <FSM\_0> in BRAM (reset is asynchronous). Selecting encoding for FSM\_0 ... Optimizing FSM <FSM\_0> on signal <current\_state> with one-hot encoding. ...

## Safe FSM Implementation

XST can add logic to your FSM implementation that will let your state machine recover from an invalid state. If during its execution, a state machine enters an invalid state, the logic added by XST will bring it back to a known state, called a recovery state. This is known as Safe Implementation mode.

To activate Safe FSM implementation:

• In Project Navigator, select Safe Implementation as instructed in the *HDL Options* topic of ISE Help, or

• Apply the "Safe Implementation (SAFE\_IMPLEMENTATION)" constraint to the hierarchical block or signal that represents the state register.

By default, XST automatically selects a reset state as the recovery state. If the FSM does not have an initialization signal, XST selects a power-up state as the recovery state. To manually define the recovery state, apply the "Safe Recovery State (SAFE\_RECOVERY\_STATE)" constraint.

# Finite State Machines Log File

The XST log file reports the full information of recognized FSM during the Macro Recognition step. Moreover, if you allow XST to choose the best encoding algorithm for your FSMs, it reports the one it chose for each FSM.

As soon as encoding is selected, XST reports the original and final FSM encoding. If the target is an FPGA device, XST reports this encoding at the HDL Synthesis step. If the target is a CPLD device, then XST reports this encoding at the Low Level Optimization step.

```
. . .
Synthesizing Unit <fsm_1>.
    Related source file is "/state_machines_1.vhd".
    Found finite state machine <FSM_0> for signal <state>.
    _____
    States 4

      States
      4

      Transitions
      5

      Inputs
      1

      Outputs
      4

      Clock
      clk (rising_edge)

      Reset
      reset (positive)

      Reset type
      asynchronous

      Reset State
      s1

      Power Up State
      s1

      Encoding
      automatic

    | Encoding | automatic
| Implementation | LUT
    _____
    Found 1-bit register for signal <outp>.
    Summary:
        inferred 1 Finite State Machine(s).
        inferred 1 D-type flip-flop(s).
Unit <fsm_1> synthesized.
_____
HDL Synthesis Report
Macro Statistics
# Registers
                                   : 1
1-bit register
                                    : 1
_____
_____
     Advanced HDL Synthesis
                                                       *
*
_____
Advanced Registered AddSub inference ...
Analyzing FSM <FSM_0> for best encoding.
Optimizing FSM <state/FSM_0> on signal <state[1:2]> with gray encoding.
```

State	Encoding
	00 01 11 10
HDL Synt	hesis Report
Macro St # FSMs	atistics : 1
========	

# Finite State Machines Related Constraints

- "Automatic FSM Extraction (FSM\_EXTRACT)"
- "FSM Style (FSM\_STYLE)"
- "FSM Encoding Algorithm (FSM\_ENCODING)"
- "Enumerated Encoding (ENUM\_ENCODING)"
- "Safe Implementation (SAFE\_IMPLEMENTATION)"
- "Safe Recovery State (SAFE\_RECOVERY\_STATE)"

# Finite State Machines Coding Examples

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>.

- "FSM With One Process"
- "FSM With Two Processes"
- "FSM With Three Processes"

## FSM With One Process

This section discusses FSM With One Process, and includes:

- "FSM With One Process Pin Descriptions"
- "FSM With One Process VHDL Coding Example"
- "FSM With Single Always Block Verilog Coding Example"

*Table 2-92:* FSM With One Process Pin Descriptions

IO Pins	Description
clk	Positive-Edge Clock
reset	Asynchronous Reset (Active High)
x1	FSM Input
outp	FSM Output



FSM With One Process VHDL Coding Example

```
___
-- State Machine with a single process.
_ _
library IEEE;
use IEEE.std_logic_1164.all;
entity fsm_1 is
    port ( clk, reset, x1 : IN std_logic;
         outp : OUT std_logic);
end entity;
architecture beh1 of fsm_1 is
    type state_type is (s1,s2,s3,s4);
    signal state: state_type ;
begin
    process (clk, reset)
    begin
        if (reset ='1') then
            state <=s1;</pre>
            outp<='1';
        elsif (clk='1' and clk'event) then
            case state is
                when s1 \Rightarrow if x1='1' then
                                 state <= s2;</pre>
                                 outp <= '1';
                             else
                                 state <= s3;</pre>
                                 outp <= '0';
                             end if;
                when s2 => state <= s4; outp <= '0';
                when s3 => state <= s4; outp <= '0';
                when s4 => state <= s1; outp <= '1';
            end case;
        end if;
    end process;
end beh1;
11
// State Machine with a single always block.
11
module v_fsm_1 (clk, reset, x1, outp);
```

FSM With Single Always Block Verilog Coding Example

```
input clk, reset, x1;
output outp;
reg outp;
      [1:0] state;
reg
parameter s1 = 2'b00; parameter s2 = 2'b01;
parameter s_3 = 2'b_{10}; parameter s_4 = 2'b_{11};
initial begin
    state = 2'b00;
end
```

```
always@(posedge clk or posedge reset)
begin
    if (reset)
         begin
             state <= s1; outp <= 1'b1;</pre>
         end
    else
         begin
              case (state)
                  s1: begin
                           if (x1==1'b1)
                                begin
                                     state <= s2;</pre>
                                     outp <= 1'b1;</pre>
                                end
                           else
                                begin
                                     state <= s3;</pre>
                                     outp <= 1'b0;
                                end
                       end
                  s2: begin
                           state <= s4; outp <= 1'b1;</pre>
                       end
                  s3: begin
                           state <= s4; outp <= 1'b0;</pre>
                       end
                  s4: begin
                           state <= s1; outp <= 1'b0;</pre>
                       end
              endcase
         end
end
```

endmodule




### FSM With Two Processes

This section discusses FSM With Two Processes, and includes:

- "FSM With Two Processes Diagram."
- "FSM With Two Processes Pin Descriptions"
- "FSM With Two Processes VHDL Coding Example"
- "FSM With Two Always Blocks Verilog Coding Example"

To eliminate a register from the **outputs**, remove all assignments **outp** <=... from the Clock synchronization section. This can be done by introducing two processes as shown in "FSM With Two Processes Diagram."



#### Figure 2-76: FSM With Two Processes Diagram

#### Table 2-93: FSM With Two Processes Pin Descriptions

IO Pins	Description
clk	Positive-Edge Clock
reset	Asynchronous Reset (Active High)
x1	FSM Input
outp	FSM Output

FSM With Two Processes VHDL Coding Example

```
--
--
-- State Machine with two processes.
--
library IEEE;
use IEEE.std_logic_1164.all;
entity fsm_2 is
    port ( clk, reset, x1 : IN std_logic;
        outp : OUT std_logic);
end entity;
architecture beh1 of fsm_2 is
    type state_type is (s1,s2,s3,s4);
    signal state: state_type ;
begin
```

```
process1: process (clk, reset)
begin
    if (reset ='1') then state <=s1;
    elsif (clk='1' and clk'Event) then
        case state is
             when s1 \Rightarrow if x1='1' then
                              state <= s2;
                          else
                              state <= s3;
                          end if;
             when s2 => state <= s4;
             when s3 \Rightarrow state <= s4;
             when s4 => state <= s1;
         end case;
    end if;
end process process1;
process2 : process (state)
begin
    case state is
        when s1 \Rightarrow outp <= '1';
        when s2 => outp <= '1';
        when s3 => outp <= '0';
        when s4 => outp <= '0';
    end case;
end process process2;
```

end beh1;

FSM With Two Always Blocks Verilog Coding Example

```
11
// State Machine with two always blocks.
11
module v_fsm_2 (clk, reset, x1, outp);
    input clk, reset, x1;
    output outp;
    reg
         outp;
    reg
          [1:0] state;
    parameter s1 = 2'b00; parameter s2 = 2'b01;
    parameter s3 = 2'b10; parameter s4 = 2'b11;
    initial begin
        state = 2'b00;
    end
    always @(posedge clk or posedge reset)
    begin
        if (reset)
            state <= s1;</pre>
        else
            begin
                case (state)
                     s1: if (x1==1'b1)
                             state <= s2;</pre>
                         else
```



```
state <= s3;</pre>
                 s2: state <= s4;
                 s3: state <= s4;
                 s4: state <= s1;
             endcase
        end
end
always @(state)
begin
    case (state)
        s1: outp = 1'b1;
        s2: outp = 1'b1;
        s3: outp = 1'b0;
        s4: outp = 1'b0;
    endcase
end
```

endmodule

## FSM With Three Processes

This section discusses FSM With Three Processes, and includes:

- "FSM With Three Processes Diagram."
- "FSM With Three Processes Pin Descriptions"
- "FSM With Three Processes VHDL Coding Example"
- "FSM With Three Always Blocks Verilog Coding Example"

You can also separate the NEXT State function from the state register.




Figure 2-77: FSM With Three Processes Diagram

#### Table 2-94: FSM With Three Processes Pin Descriptions

IO Pins	Description
clk	Positive-Edge Clock
reset	Asynchronous Reset (Active High)

IO Pins	Description
x1	FSM Input
outp	FSM Output

Table 2-94: FSM With Three Processes Pin Descriptions

#### FSM With Three Processes VHDL Coding Example

```
-- State Machine with three processes.
_ _
library IEEE;
use IEEE.std_logic_1164.all;
entity fsm_3 is
    port ( clk, reset, x1 : IN std_logic;
                          : OUT std_logic);
          outp
end entity;
architecture beh1 of fsm_3 is
    type state_type is (s1,s2,s3,s4);
    signal state, next_state: state_type ;
begin
    process1: process (clk, reset)
    begin
        if (reset ='1') then
            state <=s1;</pre>
        elsif (clk='1' and clk'Event) then
            state <= next_state;</pre>
        end if;
    end process process1;
    process2 : process (state, x1)
    begin
        case state is
            when s1 \Rightarrow if x1='1' then
                             next_state <= s2;</pre>
                         else
                              next_state <= s3;</pre>
                         end if;
            when s2 => next_state <= s4;
            when s3 => next_state <= s4;
            when s4 => next_state <= s1;
        end case;
    end process process2;
    process3 : process (state)
    begin
        case state is
            when s1 \Rightarrow outp <= '1';
            when s2 => outp <= '1';
            when s3 => outp <= '0';
            when s4 => outp <= '0';
        end case;
    end process process3;
```

end beh1;



FSM With Three Always Blocks Verilog Coding Example

```
11
// State Machine with three always blocks.
11
module v_fsm_3 (clk, reset, x1, outp);
    input clk, reset, x1;
    output outp;
    reg outp;
    reg [1:0] state;
    reg [1:0] next_state;
    parameter s1 = 2'b00; parameter s2 = 2'b01;
    parameter s3 = 2'b10; parameter s4 = 2'b11;
    initial begin
        state = 2'b00;
    end
    always @(posedge clk or posedge reset)
    begin
        if (reset) state <= s1;
        else state <= next_state;</pre>
    end
    always @(state or x1)
    begin
        case (state)
            s1: if (x1==1'b1)
                    next_state = s2;
                else
                    next_state = s3;
            s2: next_state = s4;
            s3: next_state = s4;
            s4: next_state = s1;
        endcase
    end
    always @(state)
    begin
        case (state)
            s1: outp = 1'b1;
            s2: outp = 1'b1;
            s3: outp = 1'b0;
            s4: outp = 1'b0;
        endcase
    end
endmodule
```

# **Black Boxes HDL Coding Techniques**

This section discusses Black Boxes HDL Coding Techniques, and includes:

- "About Black Boxes"
- "Black Box Log File"
- "Black Box Related Constraints"
- "Black Box Coding Examples"

## About Black Boxes

Your design may contain Electronic Data Interchange Format (EDIF) or NGC files generated by synthesis tools, schematic editors or any other design entry mechanism. These modules must be instantiated in your code to be connected to the rest of your design. To do so in XST, use Black Box instantiation in the VHDL or Verilog code. The netlist is propagated to the final top-level netlist without being processed by XST. Moreover, XST enables you to attach specific constraints to these Black Box instantiations, which are passed to the NGC file.

In addition, you may have a design block for which you have an RTL model, as well as your own implementation of this block in the form of an EDIF netlist. The RTL model is valid for simulation purposes only. Use the "BoxType (BOX\_TYPE)" constraint to direct XST to skip synthesis of this RTL code and create a Black Box. The EDIF netlist is linked to the synthesized design during NGDBuild. For more information, see "XST General Constraints" and the Xilinx *Constraints Guide*.

Once you make a design a Black Box, each instance of that design is a Black Box. While you can attach constraints to the instance, XST ignores any constraint attached to the original design.

#### Black Box Log File

From the flow point of view, the recognition of Black Boxes in XST is done before macro inference. Therefore the log file differs from the one generated for other macros.

```
...
Analyzing Entity <black_b> (Architecture <archi>).
WARNING:Xst:766 - black_box_1.vhd (Line 15). Generating a Black Box
for component <my_block>.
Entity <black_b> analyzed. Unit <black_b> generated
....
```

#### Black Box Related Constraints

"BoxType (BOX\_TYPE)"

"BoxType (BOX\_TYPE)" was introduced for Virtex Primitive instantiation in XST. See "Virtex Primitive Support" before using "BoxType (BOX\_TYPE)."



## Black Box Coding Examples

This section discusses Black Boxes, and includes:

- "Black Box VHDL Coding Example"
- "Black Box Verilog Coding Example"

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>.

Black Box VHDL Coding Example

```
_ _
   -- Black Box
   library ieee;
   use ieee.std_logic_1164.all;
   entity black_box_1 is
       port(DI_1, DI_2 : in std_logic;
            DOUT : out std_logic);
   end black_box_1;
   architecture archi of black_box_1 is
       component my_block
       port (I1 : in std_logic;
             I2 : in std_logic;
             0 : out std_logic);
       end component;
   begin
       inst: my_block port map (I1=>DI_1,I2=>DI_2,O=>DOUT);
   end archi;
Black Box Verilog Coding Example
   11
   // Black Box
   11
   module v_my_block (in1, in2, dout);
       input in1, in2;
       output dout;
   endmodule
   module v_black_box_1 (DI_1, DI_2, DOUT);
```

input DI\_1, DI\_2; output DOUT;

```
v_my_block inst (
    .in1(DI_1),
    .in2(DI_2),
    .dout(DOUT));
```

endmodule

For more information on component instantiation, see your VHDL and Verilog language reference manuals.





# Chapter 3

# **XST FPGA Optimization**

This chapter (*XST FPGA Optimization*) explains how constraints can be used to optimize FPGA devices; explains macro generation; and describes the supported Virtex<sup>TM</sup> primitives. This chapter includes:

- "About XST FPGA Optimization"
- "Virtex-Specific Synthesis Options"
- "Macro Generation"
- "DSP48 Block Resources"
- "Mapping Logic Onto Block RAM"
- "Flip-Flop Retiming"
- "Partitions"
- "Incremental Synthesis"
- "Resynthesize (RESYNTHESIZE)"
- "Speed Optimization Under Area Constraint"
- "FPGA Optimization Log File"
- "Implementation Constraints"
- "Virtex Primitive Support"
- "Cores Processing"
- "Specifying INIT and RLOC"
- "Using PCI Flow With XST"

# **About XST FPGA Optimization**

XST performs the following steps during FPGA synthesis and optimization:

- Mapping and optimization on an entity by entity or module by module basis
- Global optimization on the complete design

The output is an NGC file.

This chapter describes:

- The constraints that can be applied to fine-tune synthesis and optimization
- Macro generation
- The log file
- The timing models used during synthesis and optimization
- The constraints available for timing-driven synthesis



- The generated NGC file
- Support for primitives

# **Virtex-Specific Synthesis Options**

XST supports options to fine-tune synthesis in accordance with user constraints. For information about each option, see "XST FPGA Constraints (Non-Timing)."

The following options relate to the FPGA-specific optimization of synthesis:

- "Extract BUFGCE (BUFGCE)"
- "Cores Search Directories (-sd)"
- "Decoder Extraction (DECODER\_EXTRACT)"
- "FSM Style (FSM\_STYLE)"
- "Global Optimization Goal (-glob\_opt)"
- "Incremental Synthesis (INCREMENTAL\_SYNTHESIS)"
- "Keep Hierarchy (KEEP\_HIERARCHY)"
- "Logical Shifter Extraction (SHIFT\_EXTRACT)"
- "Map Logic on BRAM (BRAM\_MAP)"
- "Max Fanout (MAX\_FANOUT)"
- "Move First Stage (MOVE\_FIRST\_STAGE)"
- "Move Last Stage (MOVE\_LAST\_STAGE)"
- "Multiplier Style (MULT\_STYLE)"
- "Mux Style (MUX\_STYLE)"
- "Number of Global Clock Buffers (–bufg)"
- "Optimize Instantiated Primitives (OPTIMIZE\_PRIMITIVES)"
- "Pack I/O Registers Into IOBs (IOB)"
- "Priority Encoder Extraction (PRIORITY\_EXTRACT)"
- "RAM Style (RAM\_STYLE)"
- "Register Balancing (REGISTER\_BALANCING)"
- "Register Duplication (REGISTER\_DUPLICATION)"
- "Resynthesize (RESYNTHESIZE)"
- "Signal Encoding (SIGNAL\_ENCODING)"
- "Signal Encoding (SIGNAL\_ENCODING)"
- "Slice Packing (-slice\_packing)"
- "Use Carry Chain (USE\_CARRY\_CHAIN)"
- "Write Timing Constraints (-write\_timing\_constraints)"
- "XOR Collapsing (XOR\_COLLAPSE)"

# **Macro Generation**

This section discusses Macro Generation, and includes:

- "Virtex Macro Generator"
- "Arithmetic Functions in Macro Generation"
- "Loadable Functions in Macro Generation"
- "Multiplexers in Macro Generation"
- "Priority Encoders in Macro Generation"
- "Decoders in Macro Generation"
- "Shift Registers in Macro Generation"
- "RAMs in Macro Generation"
- "ROMs in Macro Generation"

#### Virtex Macro Generator

The Virtex Macro Generator module provides the XST HDL Flow with a catalog of functions. These functions are identified by the inference engine from the Hardware Description Language (HDL) description. Their characteristics are handed to the Macro Generator for optimal implementation. The set of inferred functions ranges in complexity from simple arithmetic operators (such as adders, accumulators, counters and multiplexers), to more complex building blocks (such as multipliers, shift registers and memories).

Inferred functions are optimized to deliver the highest levels of performance and efficiency for Virtex architectures, and then integrated into the rest of the design. In addition, the generated functions are optimized through their borders depending on the design context.

This section categorizes, by function, all available macros and briefly describes technology resources used in the building and optimization phase.

Macro Generation can be controlled through attributes. These attributes are listed in each subsection. For general information on attributes see "XST Design Constraints."

XST uses dedicated carry chain logic to implement many macros. In some situations carry chain logic may lead to sub-optimal optimization results. Use the "Use Carry Chain (USE\_CARRY\_CHAIN)" constraint to deactivate this feature.

## Arithmetic Functions in Macro Generation

For Arithmetic Functions, XST provides the following elements:

- Adders, Subtractors and Adder/Subtractors
- Cascadable Binary Counters
- Accumulators
- Incrementers, Decrementers and Incrementer/Decrementers
- Signed and Unsigned Multipliers

XST uses fast carry logic (MUXCY) to provide fast arithmetic carry capability for highspeed arithmetic functions. The sum logic formed from two XOR gates is implemented using LUTs and the dedicated carry-XORs (XORCY). In addition, XST benefits from a dedicated carry-ANDs (MULTAND) resource for high-speed multiplier implementation.



## Loadable Functions in Macro Generation

For Loadable functions XST provides the following elements:

- Loadable Up, Down and Up/Down Binary Counters
- Loadable Up, Down and Up/Down Accumulators

XST can provide synchronously loadable, cascadable binary counters and accumulators inferred in the HDL flow. Fast carry logic is used to cascade the different stages of the macros. Synchronous loading and count functions are packed in the same LUT primitive for optimal implementation.

For Up/Down counters and accumulators, XST uses dedicated carry-ANDs to improve performance.

## Multiplexers in Macro Generation

For multiplexers, the Macro Generator provides the following two architectures:

- MUXF*x* based multiplexers
- Dedicated Carry-MUXs based multiplexers

For Virtex-E, MUXF*x* based multiplexers are generated by using the optimal tree structure of MUXF5, MUXF6 primitives, which allows compact implementation of large inferred multiplexers. For example, XST can implement an 8:1 multiplexer in a single CLB. In some cases dedicated carry-MUXs are generated. These can provide more efficient implementations, especially for very large multiplexers.

For Virtex-II, Virtex-II Pro, and Virtex-4 devices, XST can implement a 16:1 multiplexer in a single CLB using a MUXF7 primitive, and it can implement a 32:1 multiplexer across two CLBs using a MUXF8.

To have better control of the implementation of the inferred multiplexer, XST offers a way to select the generation of either the MUXF5/MUXF6 or Dedicated Carry-MUXs architectures. The attribute MUX\_STYLE specifies that an inferred multiplexer be implemented on a MUXF*x* based architecture if the value is MUXF, or a Dedicated Carry-MUXs based architecture if the value is MUXCY.

You can apply this attribute to either a signal that defines the multiplexer or the instance name of the multiplexer. This attribute can also be global.

The attribute MUX\_EXTRACT with, respectively, the value *no* or *force* can be used to disable or force the inference of the multiplexer.

You still may have MUXFx elements in the final netlist even if multiplexer inference is disabled using the MUX\_EXTRACT constraint. These elements come from the general mapping procedure of Boolean equations.

## Priority Encoders in Macro Generation

The if/elsif structure described in "Priority Encoders HDL Coding Techniques" is implemented with a *1-of-n* priority encoder.

XST uses the MUXCY primitive to chain the conditions of the priority encoder, which results in its high-speed implementation.

Use the "Priority Encoder Extraction (PRIORITY\_EXTRACT)" constraint to enable or disable priority encoder inference.

XST does not generally, infer, and so does not generate, a large number of priority encoders. To enable priority encoders, use the "Priority Encoder Extraction (PRIORITY\_EXTRACT)" constraint with the **force** option.

## **Decoders in Macro Generation**

A decoder is a demultiplexer whose inputs are all constant with distinct one-hot (or onecold) coded values. An *n*-bit or 1-of-*m* decoder is mainly characterized by an *m*-bit data output and an *n*-bit selection input, such that  $n^{**}(2-1) < m <= n^{**}2$ .

Once XST has inferred the decoder, the implementation uses the MUXF5 or MUXCY primitive depending on the size of the decoder.

Use the "Decoder Extraction (DECODER\_EXTRACT)" constraint to enable or disable decoder inference.

## Shift Registers in Macro Generation

XST builds two types of shift registers:

- Serial shift register with single output
- Parallel shift register with multiple outputs

The length of the shift register can vary from 1 bit to 16 bits as determined from the following formula:

Width = (8\*A3) + (4\*A2) + (2\*A1) + A0 + 1

If A3, A2, A1 and A0 are all zeros (0000), the shift register is one-bit long. If they are all ones (1111), it is 16-bits long.

For serial shift register SRL16, flip-flops are chained to the appropriate width.

For a parallel shift register, each output provides a width of a given shift register. For each width a serial shift register is built, it drives one output, and the input of the next shift register.

Use the "Shift Register Extraction (SHREG\_EXTRACT)" constraint to enable and disable shift register inference.

#### RAMs in Macro Generation

This section discusses RAMs in Macro Generation, and includes:

- "RAM Available During Inference and Generation"
- "Primitives Used by XST (Virtex Devices and Higher)"
- "Primitives Used by XST (Virtex-II Devices and Higher)"
- "Controlling Implementation of Inferred RAM"

#### RAM Available During Inference and Generation

Two types of RAM are available during inference and generation:

Distributed RAM
 If the RAM is asynchronous READ, Distributed RAM is inferred and generated.



• Block RAM

If the RAM is synchronous READ, block RAM is inferred. In this case, XST can implement block RAM or distributed RAM. The default is block RAM.

### Primitives Used by XST (Virtex Devices and Higher)

This section applies to the following devices:

- Virtex, Virtex-E
- Virtex-II, Virtex-II Pro
- Virtex-4
- Spartan<sup>TM</sup>-II, Spartan-IIE
- Spartan-3

For these devices, XST uses the primitives shown in Table 3-1, "Primitives Used by XST (Virtex Devices and Higher)."

Table 3-1:	Primitives Used by	XST (Virtex	Devices and Higher)
------------	--------------------	-------------	---------------------

RAM	Primitives
Single-Port Synchronous Distributed RAM	RAM16X1S RAM32X1S
Dual-Port Synchronous Distributed RAM	RAM16X1D

#### Primitives Used by XST (Virtex-II Devices and Higher)

This section applies to the following devices:

- Virtex-II, Virtex-II Pro
- Virtex-4
- Spartan-3

For these devices, XST uses the primitives shown Table 3-2, "Primitives Used by XST (Virtex-II Devices and Higher)."

*Table 3-2:* Primitives Used by XST (Virtex-II Devices and Higher)

RAM	Clock Edge	Primitives
Single-Port Synchronous Distributed RAM	Distributed Single-Port RAM with <i>positive</i> clock edge	RAM16X1S, RAM16X2S, RAM16X4S, RAM16X8S, RAM32X1S, RAM32X2S, RAM32X4S, RAM32X8S, RAM64X1S,RAM64X2S, RAM128X1S
Single-Port Synchronous Distributed RAM	Distributed Single-Port RAM with <i>negative</i> clock edge	RAM16X1S_1, RAM32X1S_1, RAM64X1S_1, RAM128X1S_1
Dual-Port Synchronous Distributed RAM	Distributed Dual-Port RAM with <i>positive</i> clock edge	RAM16X1D, RAM32X1D, RAM64X1D
Dual-Port Synchronous Distributed RAM	Distributed Dual-Port RAM with <i>negative</i> clock edge	RAM16X1D_1, RAM32X1D_1, RAM64X1D_1

#### Table 3-2: Primitives Used by XST (Virtex-II Devices and Higher) (Cont'd)

RAM	Clock Edge	Primitives
Single-Port Synchronous Block RAM	N/A	RAMB4_Sn
Dual-Port Synchronous Block RAM	N/A	RAMB4_Sm_Sn

#### Controlling Implementation of Inferred RAM

To better control the implementation of the inferred RAM, XST offers a way to control RAM inference, and to select the generation of distributed RAM or block RAMs (if possible).

The "RAM Style (RAM\_STYLE)" attribute specifies that an inferred RAM be generated using:

- Block RAM if the value is *block*
- Distributed RAM if the value is *distributed*

Apply the "RAM Style (RAM\_STYLE)" attribute to:

- A signal that defines the RAM, or
- The instance name of the RAM

The "RAM Style (RAM\_STYLE)" attribute can also be global.

If the RAM resources are limited, XST can generate additional RAMs using registers. To generate additional RAMs using registers, use "RAM Extraction (RAM\_EXTRACT)" with the value set to *no*.

#### **ROMs in Macro Generation**

A ROM can be inferred when all assigned contexts in a **Case** or **If...else** statement are constants. Macro inference considers only ROMs of at least 16 words with no width restriction. For example, the following HDL equation can be implemented with a ROM of 16 words of 4 bits:

```
data = if address = 0000 then 0010
    if address = 0001 then 1100
    if address = 0010 then 1011
    ...
    if address = 1111 then 0001
```

A ROM can also be inferred from an array composed entirely of constants, as shown in the following coding example:

```
type ROM_TYPE is array(15 downto 0)of std_logic_vector(3 downto 0);
constant ROM : rom_type := ("0010", "1100", "1011", ..., "0001");
...
data <= ROM(conv_integer(address));</pre>
```

"ROM Extraction (ROM\_EXTRACT)" can be used to disable the inference of ROMs. Set the value to **yes** to enable ROM inference. Set the value to **no** to disable ROM inference. The default is **yes**.

Two types of ROM are available during inference and generation:

• Distributed ROM

Distributed ROMs are generated by using the optimal tree structure of LUT, MUXF5, MUXF6, MUXF7 and MUXF8 primitives, which allows compact implementation of large inferred ROMs.

Block ROM

Block ROMs are generated by using block RAM resources. When a synchronous ROM is identified, it can be inferred either as a distributed ROM plus a register, or it can be inferred using block RAM resources.

"ROM Style (ROM\_STYLE)" specifies which type of synchronous ROM XST infers:

- If set to **block**, and the ROM fits entirely on a single block of RAM, XST infers the ROM using block RAM resources.
- If set to distributed, XST infers a distributed ROM plus register.
- If set to **auto**, XST determines the most efficient method to use, and infers the ROM accordingly. **Auto** is the default.

You can apply "RAM Style (RAM\_STYLE)" as a VHDL attribute or a Verilog meta comment to an individual signal, or to the entity or module of the ROM. "RAM Style (RAM\_STYLE)" can also be applied globally from **Project Navigator > Process Properties**, or from the command line.

## **DSP48 Block Resources**

XST can automatically implement the following macros on a DSP48 block:

- Adders/subtractors
- Accumulators
- Multipliers
- Multiply adder/subtractors
- Multiply accumulate (MAC)

XST also supports the registered versions of these macros.

Macro implementation on DSP48 blocks is controlled by the "Use DSP48 (USE\_DSP48)" constraint or command line option with a default value of **auto**.

In **auto** mode, XST attempts to implement accumulators, multipliers, multiply adder/subtractors and MACs on DSP48 resources. XST does not implement adders/subtractors on DSP48 resources in **auto** mode. To push adder/subtractors into a DSP48, set the "Use DSP48 (USE\_DSP48)" constraint or command line option value to **yes**.

XST performs automatic resource control in auto mode for all macros. Use the "DSP Utilization Ratio (DSP\_UTILIZATION\_RATIO)" constraint in this mode to control available DSP48 resources for the synthesis. By default, XST tries to utilize all available DSP48 resources as much as possible.

If the number of user-specified DSP slices exceeds the number of available DSP resources on the target FPGA device, XST issues a warning, and uses only available DSP resources on the chip for synthesis. Disable automatic DSP resource management to see the number of DSPs that XST can potentially infer for a specific design. To disable automatic DSP resource management, set *value* = -1.

To deliver the best performance, XST by default tries to infer and implement the maximum macro configuration, including as many registers in the DSP48 as possible. Use "Keep (KEEP)" to shape a macro in a specific way. For example, if your design has a multiplier with two register levels on each input, place "Keep (KEEP)" constraints on the outputs of these registers to exclude the first register stage from the DSP48.

DSP48 blocks do not support registers with Asynchronous Set/Reset signals. Since such registers cannot be absorbed by DSP48, this may lead to sub-optimal performance. The "Asynchronous to Synchronous (ASYNC\_TO\_SYNC)" constraint allows you to replace Asynchronous Set/Reset signals with Synchronous signals throughout the entire design. This allows absorption of registers by DSP48, thereby improving quality of results.

Replacing Asynchronous Set/Reset signals by Synchronous signals makes the generated NGC netlist NOT equivalent to the initial RTL description. You must ensure that the synthesized design satisfies the initial specification. For more information, see"Asynchronous to Synchronous (ASYNC\_TO\_SYNC)"

For more information on individual macro processing, see "XST HDL Coding Techniques."

If your design contains several interconnected macros, where each macro can be implemented on DSP48, XST attempts to interconnect DSP48 blocks using fast BCIN/BCOUT and PCIN/PCOUT connections. Such situations are typical in filter and complex multiplier descriptions.

XST can build complex DSP macros and DSP48 chains across the hierarchy when the "Keep Hierarchy (KEEP\_HIERARCHY)" command line option is set to **no**. This is the default in ISE <sup>TM</sup>.

# Mapping Logic Onto Block RAM

This section discusses Mapping Logic Onto Block RAM, and includes:

- "About Mapping Logic Onto Block RAM"
- "Mapping Logic Onto Block RAM Log Files"
- "Mapping Logic Onto Block RAM Coding Examples"

## About Mapping Logic Onto Block RAM

If your design does not fit into the target device, you can place some of the design logic into unused block RAM:

- 1. Put the part of the RTL description to be placed into block RAM in a separate hierarchical block.
- 2. Attach a "Map Logic on BRAM (BRAM\_MAP)" constraint to the separate hierarchical block, either directly in HDL code, or in the XST Constraint File (XCF).

XST cannot automatically decide which logic can be placed in block RAM.

Logic placed into a separate block must satisfy the following criteria:

- All outputs are registered.
- The block contains only one level of registers, which are output registers.
- All output registers have the same control signals.
- The output registers have a Synchronous Reset signal.

- The block does not contain multisources or tristate busses.
- "Keep (KEEP)" is not allowed on intermediate signals.

XST attempts to map the logic onto block RAM during the Advanced Synthesis step. If any of the listed requirements are not satisfied, XST does not map the logic onto block RAM, and issues a warning. If the logic cannot be placed in a single block RAM primitive, XST spreads it over several block RAMs.

## Mapping Logic Onto Block RAM Log Files

This section contains examples of Mapping Logic Onto Block RAM Log Files:

- "Mapping Logic Onto Block RAM Log Files Example One"
- "Mapping Logic Onto Block RAM Log Files Example Two"

Mapping Logic Onto Block RAM Log Files Example One

```
. . .
_____
              HDL Synthesis
______
Synthesizing Unit <logic_bram_1>.
  Related source file is "bram_map_1.vhd".
  Found 4-bit register for signal <RES>.
  Found 4-bit adder for signal <$n0001> created at line 29.
  Summary:
    inferred 4 D-type flip-flop(s).
    inferred 1 Adder/Subtractor(s).
Unit <logic_bram_1> synthesized.
_____
             Advanced HDL Synthesis
_____
. . .
Entity <logic_bram_1> mapped on BRAM.
. . .
_____
HDL Synthesis Report
Macro Statistics
# Block RAMs
                   : 1
256x4-bit single-port block RAM : 1
_____
. . .
```

Mapping Logic Onto Block RAM Log Files Example Two

...
\* Advanced HDL Synthesis \*
...
INF0:Xst:1789 - Unable to map block <no\_logic\_bram> on BRAM.
Output FF <RES> must have a synchronous reset.

## Mapping Logic Onto Block RAM Coding Examples

This section gives the following Mapping Logic Onto Block RAM coding examples:

- "8-Bit Adders With Constant in a Single Block Ram Primitive VHDL Coding Example"
- "8-Bit Adders With Constant in a Single Block Ram Primitive Verilog Coding Example"
- "Asynchronous Reset VHDL Coding Example"
- "Asynchronous Reset Verilog Coding Example"

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>.

8-Bit Adders With Constant in a Single Block Ram Primitive VHDL Coding Example

```
-- The following example places 8-bit adders with
-- constant in a single block RAM primitive
___
library ieee;
use ieee.std_logic_1164.all;
use ieee.numeric_std.all;
entity logic_bram_1 is
port (clk, rst : in std_logic;
      A,B : in unsigned (3 downto 0);
     RES : out unsigned (3 downto 0));
    attribute bram map: string;
    attribute bram_map of logic_bram_1: entity is "yes";
end logic_bram_1;
architecture beh of logic_bram_1 is
begin
    process (clk)
   begin
        if (clk'event and clk='1') then
            if (rst = '1') then
                RES <= "0000";
            else
               RES <= A + B + "0001";
            end if;
        end if;
    end process;
```

end beh;

\_ \_

8-Bit Adders With Constant in a Single Block Ram Primitive Verilog Coding Example

```
//
// The following example places 8-bit adders with
// constant in a single block RAM primitive
//
(* bram_map="yes" *)
```



```
module v_logic_bram_1 (clk, rst, A, B, RES);
input clk, rst;
input [3:0] A, B;
output [3:0] RES;
reg [3:0] RES;
always @(posedge clk)
begin
    if (rst)
        RES <= 4'b0000;
    else
        RES <= A + B + 8'b0001;
end
```

endmodule

Asynchronous Reset VHDL Coding Example

```
_ _
   -- In the following example, an asynchronous reset is used and
   -- so, the logic is not mapped onto block RAM
   _ _
   library ieee;
   use ieee.std_logic_1164.all;
   use ieee.numeric_std.all;
   entity logic_bram_2 is
   port (clk, rst : in std_logic;
         A,B
                  : in unsigned (3 downto 0);
         RES
                   : out unsigned (3 downto 0));
       attribute bram_map : string;
       attribute bram_map of logic_bram_2 : entity is "yes";
   end logic_bram_2;
   architecture beh of logic_bram_2 is
   begin
       process (clk, rst)
       begin
           if (rst='1') then
               RES <= "0000";
           elsif (clk'event and clk='1') then
               RES <= A + B + "0001";
           end if;
       end process;
   end beh;
Asynchronous Reset Verilog Coding Example
```

```
//
// In the following example, an asynchronous reset is used and
// so, the logic is not mapped onto block RAM
//
(* bram_map="yes" *)
```

```
module v_logic_bram_2 (clk, rst, A, B, RES);
input clk, rst;
input [3:0] A, B;
output [3:0] RES;
reg [3:0] RES;
always @(posedge clk or posedge rst)
begin
    if (rst)
        RES <= 4'b0000;
    else
        RES <= A + B + 8'b0001;
end
```

```
endmodule
```

# **Flip-Flop Retiming**

This section discusses Flip-Flop Retiming, and includes:

- "About Flip-Flop Retiming"
- "Limitations of Flip-Flop Retiming"
- "Controlling Flip-Flop Retiming"

## About Flip-Flop Retiming

Flip-flop retiming consists of moving flip-flops and latches across logic for the purpose of improving timing, thus increasing clock frequency.

Flip-flop retiming can be either forward or backward:

- Forward retiming moves a set of flip-flops that are the input of a LUT to a single flipflop at its output.
- Backward retiming moves a flip-flop that is at the output of a LUT to a set of flip-flops at its input.

Flip-flop retiming can:

- Significantly increase the number of flip-flops
- Remove some flip-flops

Nevertheless, the behavior of the designs remains the same. Only timing delays are modified.

Flip-flop retiming is part of global optimization. It respects the same constraints as all other optimization techniques. Since retiming is iterative, a flip-flop that is the result of a retiming can be moved again in the same direction (forward or backward) if it results in better timing. The only limit for the retiming occurs when the timing constraints are satisfied, or if no more improvements in timing can be obtained.

For each flip-flop moved, a message is printed specifying:

- The original and new flip-flop names
- Whether it is a forward or backward retiming.



## Limitations of Flip-Flop Retiming

Flip-flop retiming has the following limitations:

- Flip-flop retiming is not applied to flip-flops that have the IOB=TRUE property.
- Flip-flops are not moved forward if the flip-flop or the output signal has the "Keep (KEEP)" property.
- Flip-flops are not moved backward if the input signal has the "Keep (KEEP)" property.
- Instantiated flip-flops are moved only if the Optimize Instantiated Primitives constraint or command line option is set to **yes**.
- Flip-Flops are moved across instantiated primitives only if the Optimize Instantiated Primitives command line option or constraint is set to **yes**.
- Flip-flops with both a set and a reset are not moved.

## **Controlling Flip-Flop Retiming**

Use the following constraints to control flip-flop retiming:

- "Register Balancing (REGISTER\_BALANCING)"
- "Move First Stage (MOVE\_FIRST\_STAGE)"
- "Move Last Stage (MOVE\_LAST\_STAGE)"

# **Partitions**

XST supports Partitions in parallel with "Incremental Synthesis." Partitions are similar to Incremental Synthesis with one significant difference. Partitions not only rerun synthesis in an incremental fashion, but place and route runs also preserve unchanged sections of the design.

*Caution!* Do not use Incremental Synthesis and Partitions concurrently. XST rejects the design if, at the same time: (1) Incremental\_Synthesis and Resynthesize constraints are used in the design; and (2) Partitions are defined in the repository.

For more information on Partitions, see the ISE Help.

# **Incremental Synthesis**

This section discusses Incremental Synthesis, and includes:

- "About Incremental Synthesis"
- "Incremental Synthesis (INCREMENTAL\_SYNTHESIS)"
- "Grouping Through Incremental Synthesis Diagram"
- "Resynthesize (RESYNTHESIZE)"

## About Incremental Synthesis

Note: Incremental Synthesis affects synthesis only, not place and route.

Incremental Synthesis allows you to resynthesize only the modified portions of the design, rather than resynthesizing the entire design.

The two main categories of incremental synthesis are:

Block Level

In Block Level, the synthesis tool resynthesizes the entire block if at least one modification was made inside this block.

Gate or LUT Level

In Gate or LUT Level, the synthesis tool tries to identify the exact changes made in the design, and generates the final netlist with minimal changes.

XST supports block level incremental synthesis with some limitations.

Incremental Synthesis is implemented using two constraints:

- "Incremental Synthesis (INCREMENTAL\_SYNTHESIS)"
- "Resynthesize (RESYNTHESIZE)"

The introduction of "Partitions" changes some aspects of the existing Incremental Synthesis:

- The underscore (\_) hierarchy separator is not supported if the design is partitioned on several blocks using the "Incremental Synthesis (INCREMENTAL\_SYNTHESIS)" constraint. If the underscore (\_) hierarchy separator is specified, XST issues an error.
- The names of generated NGC files for each logic block are based on the instance names, even if the block is instantiated only once.

*Caution!* Do not use Incremental Synthesis and "Partitions" concurrently. XST will reject the design if, at the same time: (1) Incremental\_Synthesis and Resynthesize constraints are used in the design; and (2) Partitions are defined in the repository.

## Incremental Synthesis (INCREMENTAL\_SYNTHESIS)


Use "Incremental Synthesis (INCREMENTAL\_SYNTHESIS)" to control the decomposition of the design on several logic groups.


- If the "Incremental Synthesis (INCREMENTAL\_SYNTHESIS)" constraint is applied to a specific block, this block with all its descendents is considered as one logic group, until the next "Incremental Synthesis (INCREMENTAL\_SYNTHESIS)" constraint is found. During synthesis, XST generates a single NGC file for the logic group.
- You can apply the "Incremental Synthesis (INCREMENTAL\_SYNTHESIS)" constraint to a block that is instantiated more than once.
- If a single block is changed, then the entire logic group is resynthesized, and a new NGC file is generated.

Figure 3-1, "Grouping Through Incremental Synthesis," shows how blocks are grouped by the "Incremental Synthesis (INCREMENTAL\_SYNTHESIS)" constraint. Consider the following:

- LEVA, LEVA\_1, LEVA\_2, my\_add, my\_sub as one logic group
- LEVB, my\_and, my\_or and my\_sub as another logic group
- TOP is considered separately as a single logic group

# Grouping Through Incremental Synthesis Diagram





The name of the NGC file is based on the:

- Block name
- Full hierarchical instance name of the logic block

```
Table 3-3: NGC File Name Example
```

Logic Block	Full Hierarchical Instance Name	Corresponding NGC file	
My_Block	instA/instB/instC	instA_instB_instC#My _Block.ngc	

## Resynthesize (RESYNTHESIZE)

This section discusses "Resynthesize (RESYNTHESIZE)" and includes:

- "About Resynthesize (RESYNTHESIZE"
- "Resynthesize (RESYNTHESIZE) Examples"

#### About Resynthesize (RESYNTHESIZE

XST automatically recognizes which blocks were changed, and resynthesizes only those that were changed. This detection is done at the file level. If an HDL file contains two blocks, both blocks are considered modified. If these two blocks belong to the same logic group, there is no impact on the overall synthesis time. If the HDL file contains two blocks that belong to different logic groups, both logic groups are considered changed and are resynthesized. Xilinx recommends that you keep different blocks in a single HDL file only if they belong to the same logic group.

Use "Resynthesize (RESYNTHESIZE)" to force resynthesis of the blocks that were not changed.

XST runs HDL synthesis on the entire design. However, during low level optimization XST re-optimizes modified blocks only.

#### Resynthesize (RESYNTHESIZE) Examples

This section gives the following "Resynthesize (RESYNTHESIZE)" examples:

- "Resynthesize (RESYNTHESIZE) Example One (Three NGC Files)"
- "Resynthesize (RESYNTHESIZE) Example Two (Changes to Block LEVA\_1)"
- "Resynthesize (RESYNTHESIZE) Example Three (No Changes)"
- "RESYNTHESIZE Example Four (Change One Timing Constraint)"

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>.

Resynthesize (RESYNTHESIZE) Example One (Three NGC Files)

In this example, XST generates three NGC files as shown in the following log file segment.

```
...
*
*
*
Final Report
*

Final Results
Top Level Output File Name
Output File Name
Cutput File Name
Cu
```

Resynthesize (RESYNTHESIZE) Example Two (Changes to Block LEVA\_1)

If you made changes to block LEVA\_1, XST automatically resynthesizes the entire logic group, including LEVA, LEVA\_1, LEVA\_2 and my\_add, my\_sub as shown in the following log file segment.

```
*
*
*
Low Level Synthesis
*

Final Results
Incremental synthesis
Init <my_and> is up to date ...
Incremental synthesis
Init <my_and> is up to date ...
Optimizing unit <my_sub> ...
Optimizing unit <my_add> ...
```

www.xilinx.com



```
Optimizing unit <leva_1> ...
Optimizing unit <leva_2> ...
Optimizing unit <leva> ...
```

Resynthesize (RESYNTHESIZE) Example Three (No Changes)

If you made no changes to the design, during Low Level synthesis, XST reports that all blocks are up to date and the previously generated NGC files are kept unchanged, as shown in the following log file segment.

```
_____
*
*
                Low Level Synthesis
_____
Incremental synthesis: Unit <my_and> is up to date ...
Incremental synthesis: Unit <my_or> is up to date ...
Incremental synthesis: Unit <my_sub> is up to date ...
Incremental synthesis: Unit <my_add> is up to date ...
Incremental synthesis: Unit <levb> is up to date ...
Incremental synthesis: Unit <leva_1> is up to date ...
Incremental synthesis: Unit <leva_2> is up to date ...
Incremental synthesis: Unit <leva> is up to date ...
Incremental synthesis: Unit <top> is up to date ...
_____
. . .
```

#### RESYNTHESIZE Example Four (Change One Timing Constraint)

If you changed one timing constraint, XST cannot detect this modification. To force XST to resynthesize the required blocks, use the "Resynthesize (RESYNTHESIZE)" constraint. For example, if LEVA must be resynthesized, apply the "Resynthesize (RESYNTHESIZE)" constraint to this block. All blocks included in the <leva> logic group are re-optimized and new NGC files are generated as shown in the following log file segment.

```
. . .
_____
               Low Level Synthesis
*
_____
Incremental synthesis: Unit <my_and> is up to date ...
Incremental synthesis: Unit <my_or> is up to date ...
Incremental synthesis: Unit <levb> is up to date ...
Incremental synthesis: Unit <top> is up to date ...
. . .
Optimizing unit <my_sub> ...
Optimizing unit <my_add> ...
Optimizing unit <leva_1> ...
Optimizing unit <leva_2> ...
Optimizing unit <leva> ...
_____
```

. . .

If you have previously run XST in non-incremental mode and then switched to incremental mode, or the decomposition of the design has changed, you must delete all previously generated NGC files before continuing. Otherwise XST issues an error.

In the previous example, adding **incremental\_synthesis=true** to the block LEVA\_1, XST gives the following error:

```
ERROR:Xst:624 - Could not find instance <inst_leva_1> of cell <leva_1>
in <leva>
```

The problem probably occurred because the design was previously run in non-incremental synthesis mode. To fix the problem, remove the existing NGC files from the project directory.

If you modified the HDL in the top level block of the design, and at the same time changed the name of top level block, XST cannot detect design modifications and resynthesize the top-level block. Force resynthesis by using the "Resynthesize (RESYNTHESIZE)" constraint.

# **Speed Optimization Under Area Constraint**

This section discusses Speed Optimization Under Area Constraint, and includes:

- "About Speed Optimization Under Area Constraint"
- "Speed Optimization Under Area Constraint Examples"

#### About Speed Optimization Under Area Constraint

XST performs timing optimization under the area constraint. This option is named:

- LUT-FF Pairs Utilization Ratio (Virtex-5 devices)
- "Slice (LUT-FF Pairs) Utilization Ratio (SLICE\_UTILIZATION\_RATIO)" (all other FPGA devices)

This option is available from **Project Navigator** > **Process Properties** > **XST Synthesis Options**. By default this constraint is set to 100% of the selected device size.

This constraint has influence at low level synthesis only (it does not control inference). If this constraint is specified, XST makes an area estimation, and if the specified constraint is met, XST continues timing optimization trying not to exceed the constraint. If the size of the design is more than requested, then XST tries to reduce the area first and if the area constraint is met, then begins timing optimization.

## Speed Optimization Under Area Constraint Examples

This section gives the following Speed Optimization Under Area constraint examples:

- "Speed Optimization Under Area Constraint Example One (100%)"
- "Speed Optimization Under Area Constraint Example Two (70%)"
- "Speed Optimization Under Area Constraint Example Three (55%)"

#### Speed Optimization Under Area Constraint Example One (100%)

In the following example the area constraint was specified as 100% and initial estimation shows that in fact it occupies 102% of the selected device. XST begins optimization and reaches 95%.

www.xilinx.com



\*
\*
\*
Low Level Synthesis
\*
Found area constraint ratio of 100 (+ 5) on block tge,
actual ratio is 102.
Optimizing block <tge> to meet ratio 100 (+ 5) of 1536 slices :
Area constraint is met for block <tge>, final ratio is 95.
...

Speed Optimization Under Area Constraint Example Two (70%)

If the area constraint cannot be met, XST ignores it during timing optimization and runs low level synthesis to achieve the best frequency. In the following example, the target area constraint is set to 70%. Since XST was unable to satisfy the target area constraint, XST issues the following warning:

...
\*
\*
Low Level Synthesis
\*
Found area constraint ratio of 70 (+ 5) on block fpga\_hm, actual
ratio is 64.
Optimizing block <fpga\_hm> to meet ratio 70 (+ 5) of 1536 slices :
WARNING:Xst - Area constraint could not be met for block <tge>, final
ratio is 94
...

**Note:** "(+5)" stands for the max margin of the area constraint. If the area constraint is not met, but the difference between the requested area and obtained area during area optimization is less or equal then 5%, then XST runs timing optimization taking into account the achieved area, not exceeding it.

Speed Optimization Under Area Constraint Example Three (55%)

In the following example, the area was specified as 55%. XST achieved only 60%. But taking into account that the difference between requested and achieved area is not more than 5%, XST considers that the area constraint was met.

\*\*
\* Low Level Synthesis
\*
Found area constraint ratio of 55 (+ 5) on block fpga\_hm, actual
ratio is 64.
Optimizing block <fpga\_hm> to meet ratio 55 (+ 5) of 1536 slices :
Area constraint is met for block <fpga\_hm>, final ratio is 60.
...

In some situations, it is important to disable automatic resource management. To do so, specify **-1** as the value for SLICE\_UTILIZATION\_RATIO.

"Slice (LUT-FF Pairs) Utilization Ratio (SLICE\_UTILIZATION\_RATIO)" can be attached to a specific block of a design. You can specify an absolute number of slices (or FF-LUT pairs) as a percentage of the total number.

# **FPGA Optimization Log File**

The section discusses the FPGA Optimization Log File, and includes:

- "Design Optimization Report"
- "Cell Usage Report"
- "Timing Report"

## **Design Optimization Report**

During design optimization, XST reports:

Potential removal of equivalent flip-flops

Two flip-flops (latches) are equivalent when they have the same data and control pins.

Register replication

Register replication is performed either for timing performance improvement or for satisfying MAX\_FANOUT constraints. Register replication can be turned off using the "Register Duplication (REGISTER\_DUPLICATION)" constraint.

**Design Optimization Report Example** 

```
Starting low level synthesis ...
Optimizing unit <down4cnt> ...
Optimizing unit <doc_readwrite> ...
...
Optimizing unit <doc> ...
Building and optimizing final netlist ...
The FF/Latch <doc_readwrite/state_D2> in Unit <doc> is equivalent to
the following 2 FFs/Latches, which will be removed :
<doc_readwrite/state_P2> <doc_readwrite/state_M2>
Register doc_reset_I_reset_out has been replicated 2 time(s)
Register wr_l has been replicated 2 time(s)
```

## Cell Usage Report

The Cell Usage section of the Final Report gives the count of all the primitives used in the design. The primitives are classified in the following groups:

- "BELS Cell Usage"
- "Flip-Flops and Latches Cell Usage"
- "RAMS Cell Usage"
- "SHIFTERS Cell Usage"
- "Tristates Cell Usage"
- "Clock Buffers Cell Usage"
- "IO Buffers Cell Usage"



- "LOGICAL Cell Usage"
- "OTHER Cell Usage"

#### **BELS Cell Usage**

The BELS group in the Cell Usage section of the Final Report contains all the logical cells that are basic elements of the Virtex technology, for example:

- LUTs
- MUXCY
- MUXF5
- MUXF6
- MUXF7
- MUXF8

#### Flip-Flops and Latches Cell Usage

The Flip-Flops and Latches group in the Cell Usage section of the Final Report contains all the flip-flops and latches that are primitives of the Virtex technology, for example:

- FDR
- FDRE
- LD

#### RAMS Cell Usage

The RAMS group in the Cell Usage section of the Final Report contains all the RAMs.

#### SHIFTERS Cell Usage

The SHIFTERS group in the Cell Usage section of the Final Report contains all the shift registers that use the Virtex primitive:

- TSRL16
- SRL16\_1
- SRL16E
- SRL16E\_1
- SRLC

#### Tristates Cell Usage

The Tristates group in the Cell Usage section of the Final Report contains all the tristate primitives:

• BUFT

#### **Clock Buffers Cell Usage**

The Clock Buffers group in the Cell Usage section of the Final Report contains all the clock buffers:

- BUFG
- BUFGP
- BUFGDLL

#### IO Buffers Cell Usage

The IO Buffers group in the Cell Usage section of the Final Report contains all the standard I/O buffers (except the clock buffer):

- IBUF
- OBUF
- IOBUF
- OBUFT
- IBUF\_GTL ...

#### LOGICAL Cell Usage

The LOGICAL group in the Cell Usage section of the Final Report contains all the logical cells primitives that are not basic elements:

- AND2
- OR2 ...

#### OTHER Cell Usage

The OTHER group in the Cell Usage section of the Final Report contains all the cells that have not been classified in the previous groups.

#### Cell Usage Report Example

Following is an example of an XST report for cell usage:

Cell Usage :			
# BELS	: 70		
# LUT2	: 34		
# LUT3	: 3		
# LUT4	: 34		
# FlipFlops/Latches	: 9		
# FDC	: 8		
# FDP	: 1		
# Clock Buffers	: 1		
# BUFGP	: 1		
# IO Buffers	: 24		
# IBUF	: 16		
# OBUF	: 8		
	=========		

Where XST estimates the number of slices and gives, for example, the number of flip-flops, IOBs, and BRAMS. This report is very close to the one produced by MAP.

www.xilinx.com



A short table gives information about the number of clocks in the design, how each clock is buffered, and how many loads it has.

A short table gives information about the number of asynchronous set/reset signals in the design, how each signal is buffered, and how many loads it has.

## **Timing Report**

This section discusses the Timing Report, and includes:

- "About the Timing Report"
- "Timing Report Example"
- "Timing Report Timing Summary Section"
- "Timing Report Timing Detail Section"
- "Timing Report Schematic"
- "Timing Report Paths and Ports"

#### About the Timing Report

At the end of synthesis, XST reports the timing information for the design. The Timing Report shows the information for all four possible domains of a netlist:

- register to register
- input to register
- register to outpad
- inpad to outpad

#### **Timing Report Example**

Following is an example of a Timing Report section in the XST log file.

These timing numbers are only a synthesis estimate. For accurate timing information, see the trace report generated after place-and-route.

Clock Information:				
Clock Signal	++   Clock buffer(FF name)   Load			
CLK	BUFGP   11			
Asynchronous Control Signals Information:				
Control Signal	Buffer(FF name)	l	Load	
<pre>rstint(MACHINE/current_state_Out01:0) RESET sixty/msbclr(sixty/msbclr:0)</pre>			4   3   4	
Timing Summary:				

Speed Grade: -12

```
Minimum period: 2.644ns (Maximum Frequency: 378.165MHz)
  Minimum input arrival time before clock: 2.148ns
  Maximum output required time after clock: 4.803ns
  Maximum combinational path delay: 4.473ns
Timing Detail:
_____
All values displayed in nanoseconds (ns)
_____
Timing constraint: Default period analysis for Clock 'CLK'
 Clock period: 2.644ns (frequency: 378.165MHz)
 Total number of paths / destination ports: 77 / 11
_____
Delay:
                2.644ns (Levels of Logic = 3)
 Source: MACHINE/current_state_FFd3 (FF)
Destination: sixty/msbcount/qoutsig_3 (FF)
Source Clock: CLK rising
 Destination Clock: CLK rising
 Data Path: MACHINE/current_state_FFd3 to sixty/msbcount/qoutsig_3
                         Gate Net
   Cell:in->out fanout Delay Delay Logical Name (Net Name)
   _____
             8 0.272 0.642 MACHINE/current_state_FFd3
   FDC:C->Q
(MACHINE/current_state_FFd3)
   LUT3:I0->0 3 0.147 0.541 Ker81 (clkenable)
   LUT4_D:I1->0
LUT3:I2->0
                    1 0.147 0.451 sixty/msbce (sixty/msbce)
                    1 0.147 0.000 sixty/msbcount/qoutsig_3_rstpot (N43)
                        0.297
   FDC:D
                                     sixty/msbcount/qoutsig_3
   _____
                         2.644ns (1.010ns logic, 1.634ns route)
   Total
                                (38.2% logic, 61.8% route)
```

#### Timing Report Timing Summary Section

The Timing Summary section of the Timing Report summarizes the timing paths for all four domains:

• The path from any clock to any clock in the design:

Minimum period: 7.523ns (Maximum Frequency: 132.926MHz)

- The maximum path from all primary inputs to the sequential elements: Minimum input arrival time before clock: 8.945ns
- The maximum path from the sequential elements to all primary outputs: Maximum output required time before clock: 14.220ns
- The maximum path from inputs to outputs:

Maximum combinational path delay: 10.899ns

If there is no path in the domain, No path found is printed instead of the value.



#### **Timing Report Timing Detail Section**

The Timing Detail section of the Timing Report describes the most critical path in detail for each region:

- Start point of the path
- End point of the path
- Maximum delay of the path
- Slack

The start and end points can be:

- Clock (with the phase: rising/falling), or
- Port

```
Path from Clock 'sysclk' rising to Clock 'sysclk' rising : 7.523ns (Slack: -7.523ns)
```


The detailed path shows:

- Cell type
- Input and output of this gate
- Fanout at the output
- Gate delay
- Net delay estimate
- Name of the instance.

When entering a hierarchical block, **begin scope** is printed. When exiting a hierarchical block, **end scope** is printed.

#### **Timing Report Schematic**

The preceding report corresponds to the following schematic:.



#### Timing Report Paths and Ports

The Timing Report section shows the number of analyzed paths and ports. If XST is run with timing constraints, it also shows the number of failed paths and ports. The number of analyzed and failed paths shows how many timing problems there are in the design. The number of analyzed and failed ports may show how they are spread in the design. The

number of ports in a timing report represent the number of destination elements for a timing constraint.

For example, if you use the following timing constraints:

```
TIMESPEC "TSidentifier"=FROM "source_group" TO "dest_group" value
units;
```

then the number of ports corresponds to the number of elements in the destination group.

For a given timing constraint, XST may report that the number of failed paths is 100, but that the number of failed destination ports is only two flip-flops. In that case, it is sufficient to analyze the design description for these two flip-flops only in order to detect the changes necessary to meet timing.

## Implementation Constraints

XST writes all implementation constraints generated from HDL or constraint file attributes (LOC, ...) into the output NGC file.

"Keep (KEEP)" properties are generated during buffer insertion for maximum fanout control or for optimization.

# Virtex Primitive Support

This section discusses Virtex Primitive Support, and includes:

- "Instantiating Virtex Primitives"
- "Generating Primitives Through Attributes"
- "Primitives and Black Boxes"
- "VHDL and Verilog Virtex Libraries"
- "Virtex Primitives Log File"
- "Virtex Primitives Related Constraints"
- "Virtex Primitives Coding Examples"
- "Using the UNIMACRO Library"

#### Instantiating Virtex Primitives

XST enables you to instantiate Virtex primitives directly in your VHDL or Verilog code. Virtex primitives such as the following can be manually inserted in your HDL design through instantiation:

- MUXCY\_L
- LUT4\_L
- CLKDLL
- RAMB4\_S1\_S16
- IBUFG PCI33 5
- NAND3b2

All these primitives are compiled in the UNISIM library.

These primitives are not optimized by XST by default, and are available in the final NGC file. Use the Optimize Instantiated Primitives synthesis option to optimize instantiated

primitives and obtain better results. Timing information is available for most of the primitives, allowing XST to perform efficient timing-driven optimization.

In order to simplify instantiation of complex primitives as RAMs, XST supports an additional library called UNIMACRO. For more information, see the Xilinx *Libraries Guides* at <u>http://www.xilinx.com/support/software\_manuals.htm.</u>

## **Generating Primitives Through Attributes**

Some of these primitives can be generated through attributes:

- "Buffer Type (BUFFER\_TYPE)" can be assigned to the primary input or internal signal to force the use of BUFGDLL, IBUFG, BUFR or BUFGP. The same constraints can be used to disable buffer insertion.
- "I/O Standard (IOSTANDARD)" can be used to assign an I/O standard to an I/O primitive. For example, the following assigns PCI33\_5 I/O standard to the I/O port:

// synthesis attribute IOSTANDARD of in1 is PCI33\_5

## **Primitives and Black Boxes**

The primitive support is based on the concept of the black box. For information on the basics of black box support, see "Safe FSM Implementation."

There is a significant difference between black box and primitive support. Assume you have a design with a submodule called MUXF5. In general, the MUXF5 can be your own functional block or a Virtex primitive. To avoid confusion about how XST interprets this module, attach "BoxType (BOX\_TYPE)" to the component declaration of MUXF5.

If "BoxType (BOX\_TYPE)" is attached to the MUXF5 with a value of:

• primitive, or black\_box

XST tries to interpret this module as a Virtex primitive and use its parameters, for instance, in critical path estimation.

user\_black\_box

XST processes it as a regular user black box.

If the name of the user black box is the same as that of a Virtex primitive, XST renames it to a unique name and issues a warning. For example, MUX5 could be renamed to MUX51 as shown in the following log file example:

\* Low Level Synthesis \*
WARNING:Xst:79 - Model 'muxf5' has different characteristics in
destination library
WARNING:Xst:80 - Model name has been changed to 'muxf51'
...

If "BoxType (BOX\_TYPE)" is not attached to the MUXF5, XST processes this block as a user hierarchical block. If the name of the user black box is the same as that of a Virtex primitive, XST renames it to a unique name and issues a warning.

## VHDL and Verilog Virtex Libraries

This section discusses VHDL and Verilog Virtex Libraries, and includes:

- "About VHDL and Verilog Virtex Libraries"
- "VHDL Virtex Libraries"
- "Verilog Virtex Libraries"

#### About VHDL and Verilog Virtex Libraries

To simplify instantiation, XST includes VHDL and Verilog Virtex libraries. These libraries contain the complete set of Virtex primitives declarations with a "BoxType (BOX\_TYPE)" constraint attached to each component.

#### VHDL Virtex Libraries

In VHDL, declare library **unisim** with its package **vcomponents** in your source code:

```
library unisim;
use unisim.vcomponents.all;
```

The source code of this package can be found in the vhdl\src\ unisims\unisims\_vcomp.vhd file of the XST installation.

#### Verilog Virtex Libraries

In Verilog, the unisim library is precompiled. XST automatically links it with your design.

Use UPPERCASE for generic (VHDL) and parameter (Verilog) values when instantiating primitives.

For example the ODDR element has the following component declaration in UNISIM library:

```
component ODDR
generic
(DDR_CLK_EDGE : string := "OPPOSITE_EDGE";
INIT : bit := '0';
SRTYPE : string := "SYNC");
port(Q : out std_ulogic;
C : in std_ulogic;
CE : in std_ulogic;
D1 : in std_ulogic;
D2 : in std_ulogic;
R : in std_ulogic;
S : in std_ulogic;
```

end component;

When you instantiate this primitive in your code, the values of DDR\_CLK\_EDGE and SRTYPE generics must be in uppercase. If not, XST issues a warning stating that unknown values are used.

Some primitives, such as LUT1, enable you to use an INIT during instantiation. The two ways to pass an INIT to the final netlist are:

• Attach an INIT attribute to the instantiated primitive.

 Pass the INIT with the generics mechanism (VHDL), or the parameters mechanism (Verilog). Xilinx recommends this method, since it allows you to use the same code for synthesis and simulation.

#### Virtex Primitives Log File

XST does not issue any message concerning instantiation of Virtex primitives during HDL synthesis because the "BoxType (BOX\_TYPE)" attribute with its value, *primitive*, is attached to each primitive in the UNISIM library.

If you instantiate a block (non primitive) in your design and the block has no contents (no logic description) or the block has a logic description, but you attach a "BoxType (BOX\_TYPE)" constraint to it with a value of *user\_black\_box*, XST issues a warning as shown in the following log file example:

```
Analyzing Entity <black_b> (Architecture <archi>).
WARNING : (VHDL_0103). c:\jm\des.vhd (Line 23). Generating a Black Box
for component <my_block>.
Entity <black_b> analyzed. Unit <black_b> generated.
...
```

#### Virtex Primitives Related Constraints

- "BoxType (BOX\_TYPE)"
- The PAR constraints that can be passed from HDL to NGC without processing

### Virtex Primitives Coding Examples

This section gives the following Virtex Primitives coding examples:

- "Passing an INIT Value Via the INIT Constraint VHDL Coding Example"
- "Passing an INIT Value Via the INIT Constraint Verilog Coding Example"
- "Passing an INIT Value Via the Generics Mechanism VHDL Coding Example"
- "Passing an INIT Value Via the Parameters Mechanism Verilog Coding Example"
- "Passing an INIT Value Via the Defparam Mechanism Verilog Coding Example"

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>.

Passing an INIT Value Via the INIT Constraint VHDL Coding Example

```
architecture beh of primitive_1 is
    attribute INIT: string;
    attribute INIT of inst: label is "1";
```

begin

inst: LUT2 port map (I0=>I0,I1=>I1,O=>O);

end beh;

Passing an INIT Value Via the INIT Constraint Verilog Coding Example

```
//
// Passing an INIT value via the INIT constraint.
//
module v_primitive_1 (I0,I1,0);
    input I0,I1;
    output 0;
    (* INIT="1" *)
    LUT2 inst (.I0(I0), .I1(I1), .O(0));
```

```
endmodule
```

Passing an INIT Value Via the Generics Mechanism VHDL Coding Example

```
-- Passing an INIT value via the generics mechanism.
--
library ieee;
use ieee.std_logic_1164.all;
library unisim;
use unisim.vcomponents.all;
entity primitive_2 is
    port(I0,I1 : in std_logic;
        0 : out std_logic);
end primitive_2;
architecture beh of primitive_2 is
begin
    inst: LUT2 generic map (INIT=>"1")
        port map (I0=>I0,I1=>I1,O=>O);
end beh;
```

Passing an INIT Value Via the Parameters Mechanism Verilog Coding Example

```
//
// Passing an INIT value via the parameters mechanism.
//
module v_primitive_2 (I0,I1,0);
    input I0,I1;
    output 0;
```

LUT2 #(4'h1) inst (.IO(IO), .I1(I1), .O(O));

endmodule

Passing an INIT Value Via the Defparam Mechanism Verilog Coding Example

```
//
// Passing an INIT value via the defparam mechanism.
//
module v_primitive_3 (I0,I1,O);
    input I0,I1;
    output 0;
    LUT2 inst (.I0(I0), .I1(I1), .O(O));
    defparam inst.INIT = 4'h1;
```

endmodule

## Using the UNIMACRO Library

In order to simplify instantiation of complex primitives as RAMs, XST supports an additional library called UNIMACRO. For more information, see the Xilinx *Libraries Guides* at <a href="http://www.xilinx.com/support/software\_manuals.htm">http://www.xilinx.com/support/software\_manuals.htm</a>.

In VHDL, declare library **unimacro** with its package **vcomponents** in your source code:

```
library unimacro;
use unimacro.vcomponents.all;
```

The source code of this package can be found in the vhdl\src\ unisims\unisims\_vcomp.vhd file of the XST installation.

In Verilog, the UNIMACRO library is precompiled. XST automatically links it with your design.

# **Cores Processing**

This section discusses Cores Processing, and includes:

- "About Cores Processing"
- "Cores Processing VHDL Coding Example"
- "Read Cores Enabled or Disabled"

#### About Cores Processing

If a design contains cores represented by an Electronic Data Interchange Format (EDIF) or an NGC file, XST can automatically read them for timing estimation and area utilization control. Use **Project Navigator > Process Properties > Synthesis Options > Read Cores** to enable or disable this feature. Using the **read\_cores** option of the **run** command from the command line, you can also specify **optimize**. This enables cores processing, and allows XST to integrate the core netlist into the overall design. XST reads cores by default.

### Cores Processing VHDL Coding Example

In the following VHDL coding example, the block **my\_add** is an adder, which is represented as a black box in the design whose netlist was generated by CORE Generator<sup>TM</sup>.

```
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_signed.all;
entity read_cores is
 port(
    A, B : in std_logic_vector (7 downto 0);
    a1, b1 : in std_logic;
    SUM : out std_logic_vector (7 downto 0);
    res : out std_logic);
end read_cores;
architecture beh of read_cores is
 component my_add
 port (
   A, B : in std_logic_vector (7 downto 0);
    S : out std_logic_vector (7 downto 0));
  end component;
begin
 res <= a1 and b1;
 inst: my_add port map (A => A, B => B, S => SUM);
end beh;
```

### Read Cores Enabled or Disabled

If Read Cores is disabled, XST estimates Maximum Combinational Path Delay as 6.639ns (critical path goes through a simple AND function) and an area of one slice.

If Read Cores is enabled, XST issues the following messages during Low Level Synthesis:

```
...
*
*
Low Level Synthesis
*
Launcher: Executing edif2ngd -noa "my_add.edn" "my_add.ngo"
INF0:NgdBuild - Release 6.1i - edif2ngd G.21
INF0:NgdBuild - Copyright (c) 1995-2003 Xilinx, Inc. All rights
reserved.
Writing the design to "my_add.ngo"...
Loading core <my_add> for timing and area information for instance
<inst>.
```

• • •

Estimation of Maximum Combinational Path Delay is 8.281ns with an area of five slices.

By default, XST reads Electronic Data Interchange Format (EDIF) and NGC cores from the current (project) directory. If the cores are not in the project directory, specify the directory in which the cores are located with "Cores Search Directories (–sd)"

# **Specifying INIT and RLOC**

This section discusses Specifying INIT and "RLOC" and includes:

- "About Specifying INIT and RLOC"
- "Passing an INIT Value Via the LUT\_MAP Constraint Coding Examples"
- "Specifying INIT Value for a Flip-Flop Coding Examples"
- "Specifying INIT and RLOC Values for a Flip-Flop Coding Examples"

### About Specifying INIT and RLOC

Use the UNISIM library to directly instantiate LUT components in your HDL code. To specify a function that a particular LUT must execute, apply an INIT constraint to the instance of the LUT. To place an instantiated LUT or register in a particular slice of the chip, attach an "RLOC" constraint to the same instance.

It is not always convenient to calculate INIT functions and different methods that can be used to achieve this. Instead, you can describe the function that you want to map onto a single LUT in your VHDL or Verilog code in a separate block. Attaching a LUT\_MAP constraint to this block indicates to XST that this block must be mapped on a single LUT. XST automatically calculates the INIT value for the LUT and preserves this LUT during optimization. XST automatically recognizes the XC\_MAP constraint supported by Synplicity.

### Passing an INIT Value Via the LUT\_MAP Constraint Coding Examples

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>

The following coding examples show how to pass an INIT value using the LUT\_MAP constraint:

- "Passing an INIT Value Via the LUT\_MAP Constraint VHDL Coding Example"
- "Passing an INIT Value Via the LUT\_MAP Constraint Verilog Coding Example"

In these examples, the **top** block contains the instantiation of two AND gates, described in **and\_one** and **and\_two** blocks. XST generates two LUT2s and does not merge them. For more information, see "Map Entity on a Single LUT (LUT\_MAP)"

Passing an INIT Value Via the LUT\_MAP Constraint VHDL Coding Example

```
--
--
Mapping on LUTs via LUT_MAP constraint
--
library ieee;
use ieee.std_logic_1164.all;
entity and_one is
    port (A, B : in std_logic;
        REZ : out std_logic);
```

```
attribute LUT_MAP: string;
   attribute LUT_MAP of and_one: entity is "yes";
end and_one;
architecture beh of and_one is
begin
   REZ <= A and B;
end beh;
_____
library ieee;
use ieee.std_logic_1164.all;
entity and_two is
   port(A, B : in std_logic;
        REZ : out std_logic);
   attribute LUT_MAP: string;
   attribute LUT_MAP of and_two: entity is "yes";
end and_two;
architecture beh of and_two is
begin
   REZ <= A or B;
end beh;
-----
library ieee;
use ieee.std_logic_1164.all;
entity inits_rlocs_1 is
   port(A,B,C : in std_logic;
        REZ : out std_logic);
end inits_rlocs_1;
architecture beh of inits_rlocs_1 is
   component and_one
   port(A, B : in std_logic;
        REZ : out std_logic);
   end component;
   component and_two
   port(A, B : in std_logic;
        REZ : out std_logic);
   end component;
signal tmp: std_logic;
begin
   inst_and_one: and_one port map (A => A, B => B, REZ => tmp);
   inst_and_two: and_two port map (A => tmp, B => C, REZ => REZ);
end beh;
```

Passing an INIT Value Via the LUT\_MAP Constraint Verilog Coding Example

```
//
// Mapping on LUTs via LUT_MAP constraint
//
```



```
(* LUT_MAP="yes" *)
module v_and_one (A, B, REZ);
   input A, B;
   output REZ;
   and and_inst(REZ, A, B);
endmodule
// _____
(* LUT_MAP="yes" *)
module v_and_two (A, B, REZ);
   input A, B;
   output REZ;
   or or_inst(REZ, A, B);
endmodule
// ------
module v_inits_rlocs_1 (A, B, C, REZ);
   input A, B, C;
   output REZ;
   wire tmp;
   v_and_one inst_and_one (A, B, tmp);
   v_and_two inst_and_two (tmp, C, REZ);
endmodule
```

# Specifying INIT Value for a Flip-Flop Coding Examples

This section gives the following Specifying INIT Value for a Flip-Flop coding examples:

- ""
- "Specifying INIT Value for a Flip-Flop Verilog Coding Example"

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>

If a function cannot be mapped on a single LUT, XST issues an error message and interrupts synthesis. To define an INIT value for a flip-flop or a shift register, described at RTL level, assign its initial value in the signal declaration stage. This value is not ignored during synthesis and is propagated to the final netlist as an INIT constraint attached to the flip-flop or shift register.

In the following coding examples, a 4-bit register is inferred for signal tmp.

An INIT value equal **1011** is attached to the inferred register and propagated to the final netlist.

#### Specifying INIT Value for a Flip-Flop VHDL Coding Example

```
___
-- Specification on an INIT value for a flip-flop, described at RTL
level
_ _
library ieee;
use ieee.std_logic_1164.all;
entity inits_rlocs_2 is
    port (CLK : in std_logic;
          DI : in std_logic_vector(3 downto 0);
          DO : out std_logic_vector(3 downto 0));
end inits_rlocs_2;
architecture beh of inits_rlocs_2 is signal
    tmp: std_logic_vector(3 downto 0):="1011";
begin
    process (CLK)
    begin
        if (clk'event and clk='1') then
            tmp <= DI;</pre>
        end if;
    end process;
    DO <= tmp;
end beh;
```

Specifying INIT Value for a Flip-Flop Verilog Coding Example

```
11
// Specification on an INIT value for a flip-flop,
// described at RTL level
11
module v_inits_rlocs_2 (clk, di, do);
    input clk;
    input [3:0] di;
    output [3:0] do;
    reg
          [3:0] tmp;
    initial begin
        tmp = 4'b1011;
    end
    always @(posedge clk)
    begin
        tmp <= di;</pre>
    end
    assign do = tmp;
endmodule
```

# Specifying INIT and RLOC Values for a Flip-Flop Coding Examples

This section gives the following Specifying INIT and RLOC Values for a Flip-Flop coding examples:

- "Specifying INIT and RLOC Values for a Flip-Flop VHDL Coding Example"
- "Specifying INIT and RLOC Values for a Flip-Flop Verilog Coding Example"

The coding examples in this section are accurate as of the date of publication. Download updates from <u>ftp://ftp.xilinx.com/pub/documentation/misc/examples\_v9.zip</u>

To infer a register as shown in "" and "Specifying INIT Value for a Flip-Flop Verilog Coding Example," and place it in a specific location of a chip, attach an "RLOC" constraint to the tmp signal as shown in the following coding examples.

XST propagates it to the final netlist. This feature is supported for registers, and also for inferred block RAM if it can be implemented on a single block RAM primitive.

Specifying INIT and RLOC Values for a Flip-Flop VHDL Coding Example

```
-- Specification on an INIT and RLOC values for a flip-flop, described
   at RTL level
   _ _
   library ieee;
   use ieee.std_logic_1164.all;
   entity inits_rlocs_3 is
       port (CLK : in std_logic;
             DI : in std_logic_vector(3 downto 0);
             D0 : out std_logic_vector(3 downto 0));
   end inits_rlocs_3;
   architecture beh of inits_rlocs_3 is
       signal tmp: std_logic_vector(3 downto 0):="1011";
       attribute RLOC: string;
       attribute RLOC of tmp: signal is "X3Y0 X2Y0 X1Y0 X0Y0";
   begin
       process (CLK)
       begin
           if (clk'event and clk='1') then
               tmp <= DI;
           end if;
       end process;
       DO \ll tmp;
   end beh;
Specifying INIT and RLOC Values for a Flip-Flop Verilog Coding Example
   11
   // Specification on an INIT and RLOC values for a flip-flop,
   // described at RTL level
   11
```

module v\_inits\_rlocs\_3 (clk, di, do);

```
input clk;
input [3:0] di;
output [3:0] do;
(* RLOC="X3Y0 X2Y0 X1Y0 X0Y0" *)
reg [3:0] tmp;
initial begin
    tmp = 4'b1011;
end
always @(posedge clk)
begin
    tmp <= di;
end
assign do = tmp;
endmodule
```

# **Using PCI Flow With XST**

This section discusses Using PCI Flow With XST, and includes:

- "Satisfying Placement Constraints and Meeting Timing Requirements"
- "Preventing Logic and Flip-Flop Replication"
- "Disabling Read Cores"

### Satisfying Placement Constraints and Meeting Timing Requirements

To satisfy placement constraints and meet timing requirements when using PCI flow with XST:

- For VHDL, ensure that the names in the generated netlist are all in UPPER case.
   The default case is *lower*. Specify the case in **Project Navigator > Process Properties > Synthesis Options > Case**.
- For Verilog, ensure that Case is set to *maintain*.

The default case is *maintain*. Specify the case in **Project Navigator > Process Properties > Synthesis Options > Case**.

• Preserve the hierarchy of the design.

Specify the "Keep Hierarchy (KEEP\_HIERARCHY)" setting in **Project Navigator** > **Process Properties** > **Synthesis Options** > **Keep Hierarchy**.

• Preserve equivalent flip-flops.

XST removes equivalent flip-flops by default. Specify the "Equivalent Register Removal (EQUIVALENT\_REGISTER\_REMOVAL)" setting in Project Navigator > Process Properties > Xilinx Specific Options > Equivalent Register Removal.

# Preventing Logic and Flip-Flop Replication

To prevent logic and flip-flop replication caused by a high fanout flip-flop set/reset signal:

- Set a high maximum fanout value for the entire design in Project Navigator > Process Properties > Synthesis Options > Max Fanout, or
- Use "Max Fanout (MAX\_FANOUT)" to set a high maximum fanout value for the initialization signal connected to the RST port of PCI core (for example, max\_fanout=2048).

## **Disabling Read Cores**

Prevent XST from automatically reading PCI cores for timing and area estimation. In reading PCI cores, XST may perform logic optimization that does not allow the design to meet timing requirements, or which might lead to errors during MAP. To disable Read Cores, uncheck it in **Project Navigator > Process Properties > Synthesis Options > Read Cores**.

By default, XST reads cores for timing and area estimation.



# Chapter 4

# **XST CPLD Optimization**

This chapter (*XST CPLD Optimization*) discusses CPLD synthesis options and the implementation details for macro generation. This chapter includes:

- "CPLD Synthesis Options"
- "Implementation Details for Macro Generation"
- "CPLD Synthesis Log File Analysis"
- "CPLD Synthesis Constraints"
- "Improving Results in CPLD Synthesis"

# **CPLD Synthesis Options**

This section discusses CPLD Synthesis Options, and includes:

- "About CPLD Synthesis Options"
- "CPLD Synthesis Supported Devices"
- "Setting CPLD Synthesis Options"

### About CPLD Synthesis Options

XST performs device specific synthesis for:

- CoolRunner XPLA3
- CoolRunner-II
- XC9500
- XC9500XL<sup>TM</sup>
- XC9500V<sup>TM</sup>

XST generates an NGC file ready for the CPLD fitter.

The general flow of XST for CPLD synthesis is:

- 1. Hardware Description Language (HDL) synthesis of VHDL or Verilog designs
- 2. Macro inference
- 3. Module optimization
- 4. NGC file generation

This section describes supported CPLD families. It lists the XST options related *only* to CPLD synthesis that can be set from **Project Navigator** > **Process Properties**.



# **CPLD** Synthesis Supported Devices

XST supports CPLD synthesis for the following devices:

- CoolRunner XPLA3
- CoolRunner-II
- XC9500
- XC9500XL
- XC9500XV

The synthesis for CoolRunner, XC9500XL, and XC9500XV families includes clock enable processing. You can allow or invalidate the clock enable signal (when invalidating, it is replaced by equivalent logic). The selection of the macros that use the clock enable (counters, for instance) depends on the device type. A counter with clock enable is accepted for the CoolRunner, XC9500XL and XC9500XV families, but rejected (replaced by equivalent logic) for XC9500 devices.

## Setting CPLD Synthesis Options

Set the following CPLD synthesis options in **Project Navigator > Process Properties > Synthesis Options.** For more information, see "XST CPLD Constraints (Non-Timing)."

- "Keep Hierarchy (KEEP\_HIERARCHY)"
- "Macro Preserve (-pld\_mp)"
- "XOR Preserve (-pld\_xp)"
- "Equivalent Register Removal (EQUIVALENT\_REGISTER\_REMOVAL)"
- "Clock Enable (-pld\_ce)"
- "WYSIWYG (-wysiwyg)"
- "No Reduce (NOREDUCE)"

# **Implementation Details for Macro Generation**

XST processes the following macros:

- Adders
- Subtractors
- Add/sub
- Multipliers
- Comparators
- Multiplexers
- Counters
- Logical shifters
- Registers (flip-flops and latches)
- XORs

The macro generation is decided by the Macro Preserve command line option, which can take two values:

**yes** — macro generation is allowed.

```
no — macro generation is inhibited.
```

The general macro generation flow is:

- 1. Hardware Description Language (HDL) infers macros and submits them to the lowlevel synthesizer.
- 2. Low-level synthesizer accepts or rejects the macros depending on the resources required for the macro implementations.

An accepted macro is generated by an internal macro generator. A rejected macro is replaced by equivalent logic generated by the HDL synthesizer. A rejected macro may be decomposed by the HDL synthesizer into component blocks so that one component may be a new macro requiring fewer resources than the initial one, and another smaller macro may be accepted by XST. For instance, a flip-flop macro with clock enable (CE) cannot be accepted when mapping onto the XC9500. In this case the HDL synthesizer submits two new macros:

- A flip-flop macro without clock enable signal
- A MUX macro implementing the clock enable function

A generated macro is optimized separately and then merged with surrounded logic because optimization gives better results for larger components.

# **CPLD Synthesis Log File Analysis**

XST messages related to CPLD synthesis are located after the following message:

```
* Low Level Synthesis *
```

The XST log file contains:

Tracing of progressive unit optimizations:

Optimizing unit unit\_name ...

- Information, warnings or fatal messages related to unit optimization:
  - When equation shaping is applied (XC9500 devices only): Collapsing ...
  - Removing equivalent flip-flops:
    - Register ff1 equivalent to ff2 has been removed
  - User constraints fulfilled by XST:

implementation constraint: constraint\_name[=value]: signal\_name

• Final results statistics:

```
Final Results
Top Level Output file name : file_name
Output format : ngc
Optimization goal : {area | speed}
Target Technology : {9500 | 9500xl | 9500xv | xpla3 | xbr | cr2s}
Keep Hierarchy : {yes | soft | no}
```



```
Macro Preserve : {yes | no}
  XOR Preserve : {yes | no}
Design Statistics
  NGC Instances: nb_of_instances
  I/Os: nb_of_io_ports
Macro Statistics
  # FSMs: nb_of_FSMs
  # Registers: nb_of_registers
  # Tristates: nb_of_tristates
  # Comparators: nb_of_comparators
    n-bit comparator {equal | not equal | greater | less | greatequal
       lessequal}:
    nb_of_n_bit_comparators
  # Multiplexers: nb_of_multiplexers
    n-bit m-to-1 multiplexer :
    nb_of_n_bit_m_to_1_multiplexers
  # Adders/Subtractors: nb_of_adds_subs
    n-bit adder: nb_of_n_bit_adds
    n-bit subtractor: nb_of_n_bit_subs
  # Multipliers: nb_of_multipliers
  # Logic Shifters: nb_of_logic_shifters
  # Counters: nb_of_counters
  n-bit {up | down | updown} counter:
  nb_of_n_bit_counters
  # XORs: nb_of_xors
Cell Usage :
  # BELS: nb_of_bels
         AND...: nb_of_and...
  #
         OR...: nb_of_or...
  #
         INV: nb_of_inv
  #
  #
         XOR2: nb_of_xor2
         GND: nb_of_gnd
  #
  #
         VCC: nb_of_vcc
  # FlipFlops/Latches: nb_of_ff_latch
         FD...: nb_of_fd...
         LD...: nb_of_ld...
  #
  # Tri-States: nb_of_tristates
         BUFE: nb_of_bufe
  #
         BUFT: nb_of_buft
  # IO Buffers: nb_of_iobuffers
         IBUF: nb_of_ibuf
  #
  #
         OBUF: nb_of_obuf
         IOBUF: nb_of_iobuf
  #
```

- # OBUFE: nb\_of\_obufe
- # OBUFT: nb\_of\_obuft
- # Others: nb\_of\_others

# **CPLD Synthesis Constraints**

The constraints (attributes) specified in the Hardware Description Language (HDL) design or in the constraint files are written by XST into the NGC file as signal properties.

# **Improving Results in CPLD Synthesis**

This section discusses Improving Results in CPLD Synthesis, and includes:

- "About Improving Results in CPLD Synthesis"
- "Obtaining Better Frequency"
- "Fitting a Large Design"

# About Improving Results in CPLD Synthesis

XST produces optimized netlists for the CPLD fitter, which fits them in specified devices and creates the download programmable files. The CPLD low-level optimization of XST consists of logic minimization, subfunction collapsing, logic factorization, and logic decomposition. The result of optimization is an NGC netlist corresponding to Boolean equations, which are reassembled by the CPLD fitter to fit the best of the macrocell capacities. A special XST optimization process, known as equation shaping, is applied for XC9500/XL/XV devices when the following options are selected:

- Keep Hierarchy: No
- Optimization Effort: 2 or High
- Macro Preserve: No

The equation shaping processing also includes a critical path optimization algorithm, which tries to reduce the number of levels of critical paths.

The CPLD fitter multi-level optimization is still recommended because of the special optimizations done by the fitter (D to T flip-flop conversion, De Morgan Boolean expression selection).

# **Obtaining Better Frequency**

The frequency depends on the number of logic levels (logic depth). To reduce the number of levels, Xilinx recommends the following options:

• Optimization Effort

Set Optimization Effort to **2** or **High.** This value implies the calling of the collapsing algorithm, which tries to reduce the number of levels without increasing the complexity beyond certain limits.

• Optimization Goal

Set Optimization Goal to **Speed**. The priority is the reduction of number of levels.

Obtaining the best frequency depends on the CPLD fitter optimization. Xilinx recommends running the multi-level optimization of the CPLD fitter with different values

for the **-pterms** options, beginning with 20 and finishing with 50 with a step of 5. Statistically the value 30 gives the best results for frequency.

The following tries, in this order, may give successively better results for frequency:

- "Obtaining Better Frequency Try 1"
- "Obtaining Better Frequency Try 2"
- "Obtaining Better Frequency Try 3"
- "Obtaining Better Frequency Try 4"

The CPU time increases from Try 1 to Try 4.

#### Obtaining Better Frequency Try 1

Select only optimization effort 2 and speed optimization. The other options have default values.

- Optimization effort: 2 or High
- Optimization Goal: Speed

#### Obtaining Better Frequency Try 2

Flatten the user hierarchy. In this case optimization has a global view of the design, and the depth reduction may be better.

- Optimization effort: 1/Normal or 2/High
- Optimization Goal: Speed
- Keep Hierarchy: **no**

Obtaining Better Frequency Try 3

Merge the macros with surrounded logic. The design flattening is increased.

- Optimization effort: 1 or Normal
- Optimization Goal: Speed
- Keep Hierarchy: **no**
- Macro Preserve **no**

Obtaining Better Frequency Try 4

Apply the equation shaping algorithm. Options to be selected:

- Optimization effort: 2 or High
- Macro Preserve: no
- Keep Hierarchy: no

### Fitting a Large Design

If a design does not fit in the selected device, exceeding the number of device macrocells or device P-Term capacity, you must select an area optimization for XST. Statistically, the best area results are obtained with the following options:

- Optimization effort: 1 (Normal) or 2 (High)
- Optimization Goal: Area
- Default values for other options

Another option is **-wysiwyg yes**. This option may be useful when the design cannot be simplified by optimization and the complexity (in number of P-Terms) is near the device capacity. It may be that optimization, trying to reduce the number of levels, creates larger equations, therefore increasing the number of P-Terms and so preventing the design from fitting. By validating this option, the number of P-Terms is not increased, and the design fitting may be successful.





# Chapter 5

# XST Design Constraints

This chapter (*XST Design Constraints*) provides information about XST design constraints. For general information about XST design constraints, see:

- "About Constraints"
- "List of XST Design Constraints"
- "Setting Global Constraints and Options"
- "VHDL Attribute Syntax"
- "Verilog-2001 Attributes"
- "XST Constraint File (XCF)"
- "Constraints Priority"
- "XST-Specific Non-Timing Options"
- "XST Command Line Only Options"

For information about specific XST design constraints, see:

- "XST General Constraints"
- "XST HDL Constraints"
- "XST FPGA Constraints (Non-Timing)"
- "XST CPLD Constraints (Non-Timing)"
- "XST Timing Constraints"
- "XST Implementation Constraints"
- "XST-Supported Third Party Constraints"

# About Constraints

Constraints help you meet your design goals and obtain the best implementation of your circuit. Constraints control various aspects of synthesis, as well as placement and routing. Synthesis algorithms and heuristics automatically provide optimal results in most situations. If synthesis fails to initially achieve optimal results, use available constraints to try other synthesis alternatives.

The following mechanisms are available to specify constraints:

- Options provide global control on most synthesis aspects. They can be set either from
   Project Navigator > Process Properties > Synthesis Options, or by
   the run command from the command line.
- VHDL attributes can be directly inserted into the VHDL code and attached to individual elements of the design to control both synthesis, and placement and routing.

- Constraints can be added as Verilog attributes (preferred) or Verilog meta comments.
- Constraints can be specified in a separate constraint file.

Global synthesis settings are typically defined in **Project Navigator > Process Properties > Synthesis Options**, or from the command line. VHDL and Verilog attributes and Verilog meta comments can be inserted in your source code to specify different choices for individual parts of the design.

The local specification of a constraint overrides its global setting. Similarly, if a constraint is set both on a node (or an instance) and on the enclosing design unit, the former takes precedence for the considered node (or instance).

Follow these general rules:

- Several constraints can be applied on signals. In this case, the constraint must be placed in the block where the signal is declared and used.
- If a constraint can be applied on an entity (VHDL), then it can also be applied on the component declaration. The ability to apply constraints on components is not explicitly stated for each individual constraint, since it is a general XST rule.
- Some third party synthesis tools allow you to apply constraints on architectures. XST allows constraints on architectures only for those third party constraints automatically supported by XST.

# List of XST Design Constraints

Following is a list of XST Design Constraints, organized by type:

- "XST General Constraints"
- "XST HDL Constraints"
- "XST FPGA Constraints (Non-Timing)"
- "XST CPLD Constraints (Non-Timing)"
- "XST Timing Constraints"
- "XST Implementation Constraints"
- "Third Party Constraints"

### XST General Constraints

The following constraints are found in "XST General Constraints."

- "Add I/O Buffers (-iobuf)"
- "BoxType (BOX\_TYPE)"
- "Bus Delimiter (-bus\_delimiter)"
- "Case (–case)"
- "Case Implementation Style (-vlgcase)"
- "Verilog Macros (-define)"
- "Duplication Suffix (-duplication\_suffix)"
- "Full Case (FULL\_CASE)"
- "Generate RTL Schematic (–rtlview)"
- "Generics (-generics)"
- "Hierarchy Separator (-hierarchy\_separator)"

- "I/O Standard (IOSTANDARD)"
- "Keep (KEEP)"
- "Keep Hierarchy (KEEP\_HIERARCHY)"
- "Library Search Order (-lso)"
- "LOC"
- "Netlist Hierarchy (-netlist\_hierarchy)"
- "Optimization Effort (OPT\_LEVEL)"
- "Optimization Goal (OPT\_MODE)"
- "Parallel Case (PARALLEL\_CASE)"
- "RLOC"
- "Save (S / SAVE)"
- "Synthesis Constraint File (-uc)"
- "Translate Off (TRANSLATE\_OFF) and Translate On (TRANSLATE\_ON)"
- "Use Synthesis Constraints File (-iuc)"
- "Verilog Include Directories (-vlgincdir)"
- "Verilog 2001 (-verilog2001)"
- "HDL Library Mapping File (-xsthdpini)"
- "Work Directory (-xsthdpdir)"

# **XST HDL Constraints**

The following Hardware Description Language (HDL) constraints are found in "XST HDL Constraints."

- "Automatic FSM Extraction (FSM\_EXTRACT)"
- "Enumerated Encoding (ENUM\_ENCODING)"
- "Equivalent Register Removal (EQUIVALENT\_REGISTER\_REMOVAL)"
- "FSM Encoding Algorithm (FSM\_ENCODING)"
- "Mux Extraction (MUX\_EXTRACT)"
- "Register Power Up (REGISTER\_POWERUP)"
- "Resource Sharing (RESOURCE\_SHARING)"
- "Safe Recovery State (SAFE\_RECOVERY\_STATE)"
- "Safe Implementation (SAFE\_IMPLEMENTATION)"
- "Signal Encoding (SIGNAL\_ENCODING)"

# XST FPGA Constraints (Non-Timing)

The following constraints are found in "XST FPGA Constraints (Non-Timing)."

- "Asynchronous to Synchronous (ASYNC\_TO\_SYNC)"
- "Automatic BRAM Packing (AUTO\_BRAM\_PACKING)"
- "BRAM Utilization Ratio (BRAM\_UTILIZATION\_RATIO)"
- "Buffer Type (BUFFER\_TYPE)"
- "Extract BUFGCE (BUFGCE)"



- "Cores Search Directories (-sd)"
- "Decoder Extraction (DECODER\_EXTRACT)"
- "DSP Utilization Ratio (DSP\_UTILIZATION\_RATIO)"
- "FSM Style (FSM\_STYLE)"
- "Power Reduction (POWER)"
- "Read Cores (READ\_CORES)"
- "Resynthesize (RESYNTHESIZE)"
- "Incremental Synthesis (INCREMENTAL\_SYNTHESIS)"
- "Logical Shifter Extraction (SHIFT\_EXTRACT)"
- "LUT Combining (LC)"
- "Map Logic on BRAM (BRAM\_MAP)"
- "Max Fanout (MAX\_FANOUT)"
- "Move First Stage (MOVE\_FIRST\_STAGE)"
- "Move Last Stage (MOVE\_LAST\_STAGE)"
- "Multiplier Style (MULT\_STYLE)"
- "Mux Style (MUX\_STYLE)"
- "Number of Global Clock Buffers (-bufg)"
- "Number of Regional Clock Buffers (-bufr)"
- "Optimize Instantiated Primitives (OPTIMIZE\_PRIMITIVES)"
- "Pack I/O Registers Into IOBs (IOB)"
- "Priority Encoder Extraction (PRIORITY\_EXTRACT)"
- "RAM Extraction (RAM\_EXTRACT)"
- "RAM Style (RAM\_STYLE)"
- "Reduce Control Sets (REDUCE\_CONTROL\_SETS)"
- "Register Balancing (REGISTER\_BALANCING)"
- "Register Duplication (REGISTER\_DUPLICATION)"
- "ROM Extraction (ROM\_EXTRACT)"
- "ROM Style (ROM\_STYLE)"
- "Shift Register Extraction (SHREG\_EXTRACT)"
- "Slice Packing (-slice\_packing)"
- "Use Low Skew Lines (USELOWSKEWLINES)"
- "XOR Collapsing (XOR\_COLLAPSE)"
- "Slice (LUT-FF Pairs) Utilization Ratio (SLICE\_UTILIZATION\_RATIO)"
- "Slice (LUT-FF Pairs) Utilization Ratio Delta (SLICE\_UTILIZATION\_RATIO\_MAXMARGIN)"
- "Map Entity on a Single LUT (LUT\_MAP)"
- "Use Carry Chain (USE\_CARRY\_CHAIN)"
- "Convert Tristates to Logic (TRISTATE2LOGIC)"
- "Use Clock Enable (USE\_CLOCK\_ENABLE)"
- "Use Synchronous Set (USE\_SYNC\_SET)"

- "Use Synchronous Reset (USE\_SYNC\_RESET)"
- "Use DSP48 (USE\_DSP48)"

# XST CPLD Constraints (Non-Timing)

The following constraints are found in "XST CPLD Constraints (Non-Timing)."

- "Clock Enable (–pld\_ce)"
- "Data Gate (DATA\_GATE)"
- "Macro Preserve (-pld\_mp)"
- "No Reduce (NOREDUCE)"
- "WYSIWYG (-wysiwyg)"
- "XOR Preserve (-pld\_xp)"

## XST Timing Constraints

The following constraints are found in "XST Timing Constraints."

- "Cross Clock Analysis (-cross\_clock\_analysis)"
- "Write Timing Constraints (-write\_timing\_constraints)"
- "Clock Signal (CLOCK\_SIGNAL)"
- "Global Optimization Goal (-glob\_opt)"
- "XCF Timing Constraint Support"
- "Period (PERIOD)"
- "Offset (OFFSET)"
- "From-To (FROM-TO)"
- "Timing Name (TNM)"
- "Timing Name on a Net (TNM\_NET)"
- "Timegroup (TIMEGRP)"
- "Timing Ignore (TIG)"

### **XST Implementation Constraints**

The following constraints are found in "XST Implementation Constraints."

- "RLOC"
- "NOREDUCE"
- "PWR\_MODE"

# Third Party Constraints

For a discussion of Third Party Constraints and their XST equivalents, see "XST-Supported Third Party Constraints."

XILINX<sup>®</sup>

# **Setting Global Constraints and Options**

This section discusses Setting Global Constraints and Options, and includes:

- "Setting Synthesis Options"
- "Setting HDL Options"
- "Setting Xilinx-Specific Options"
- "Setting Other XST Command Line Options"
- "Custom Compile File List"

This section explains how to set global constraints and options in **Project Navigator > Process Properties**.

For a description of each constraint that applies generally — that is, to FPGA devices, CPLD devices, VHDL, and Verilog — see the Xilinx<sup>®</sup> *Constraints Guide*.

Except for **Value** fields with check boxes, there is a pull-down arrow or browse button in each **Value** field. The arrow is not visible until you click in the **Value** field.

# Setting Synthesis Options

To set Hardware Description Language (HDL) synthesis options from Project Navigator:

- 1. Select a source file from the Source file window.
- 2. Right-click Synthesize XST in the Process window.
- 3. Select Properties.
- 4. Select Synthesis Options.
- 5. Depending on the device type you have selected (FPGA or CPLD devices), one of two dialog boxes opens.
- 6. Select any of the following synthesis options:
- "Optimization Goal (OPT\_MODE)"
- "Optimization Effort (OPT\_LEVEL)"
- "Use Synthesis Constraints File (-iuc)"
- "Synthesis Constraint File (-uc)"
- "Library Search Order (–lso)"
- "Global Optimization Goal (-glob\_opt)"
- "Generate RTL Schematic (-rtlview)"
- "Write Timing Constraints (-write\_timing\_constraints)"
- "Verilog 2001 (-verilog2001)"

# To view the following options, select Edit > Preferences > Processes > Property Display Level > Advanced:

- "Keep Hierarchy (KEEP\_HIERARCHY)"
- "Cores Search Directories (–sd)"
- "Cross Clock Analysis (-cross\_clock\_analysis)"
- "Hierarchy Separator (-hierarchy\_separator)"
- "Bus Delimiter (-bus\_delimiter)"
- "Case (–case)"

- "Work Directory (-xsthdpdir)"
- "HDL Library Mapping File (-xsthdpini)"
- "Verilog Include Directories (-vlgincdir)"
- "Slice (LUT-FF Pairs) Utilization Ratio (SLICE\_UTILIZATION\_RATIO)"
- "Custom Compile File List"
- "Setting Other XST Command Line Options"

## Setting HDL Options

This section discusses Hardware Description Language (HDL) Options, and includes:

- "Setting HDL Options for FPGA Devices"
- "Setting HDL Options for CPLD Devices"

### Setting HDL Options for FPGA Devices

To set Hardware Description Language (HDL) options for FPGA devices, select Project Navigator > Process Properties > Synthesize - XST > HDL Options.

The following HDL Options can be set for FPGA devices:

- "FSM Encoding Algorithm (FSM\_ENCODING)"
- "Safe Implementation (SAFE\_IMPLEMENTATION)"
- "Case Implementation Style (-vlgcase)"
- "FSM Style (FSM\_STYLE)"\*

To view FSM Style, select Edit > Preferences > Processes > Property Display Level > Advanced.

- "RAM Extraction (RAM\_EXTRACT)"
- "RAM Style (RAM\_STYLE)"
- "ROM Extraction (ROM\_EXTRACT)"
- "ROM Style (ROM\_STYLE)"
- "Mux Extraction (MUX\_EXTRACT)"
- "Mux Style (MUX\_STYLE)"
- "Decoder Extraction (DECODER\_EXTRACT)"
- "Priority Encoder Extraction (PRIORITY\_EXTRACT)"
- "Shift Register Extraction (SHREG\_EXTRACT)"
- "Logical Shifter Extraction (SHIFT\_EXTRACT)"
- "XOR Collapsing (XOR\_COLLAPSE)"
- "Resource Sharing (RESOURCE\_SHARING)"
- "Multiplier Style (MULT\_STYLE)"

For later devices, Multiplier Style is renamed as follows:

- ◆ Use DSP48 (Virtex<sup>TM</sup>-4 devices)
- Use DSP Block (Virtex-5 devices)
- "Use DSP48 (USE\_DSP48)"



### Setting HDL Options for CPLD Devices

To set Hardware Description Language (HDL) options for CPLD devices, select **Project Navigator > Process Properties > Synthesize - XST > Options**.

The following HDL Options can be set for CPLD devices:

- "FSM Encoding Algorithm (FSM\_ENCODING)"
- "Safe Implementation (SAFE\_IMPLEMENTATION)"
- "Case Implementation Style (-vlgcase)"
- "Mux Extraction (MUX\_EXTRACT)"
- "Resource Sharing (RESOURCE\_SHARING)"

## Setting Xilinx-Specific Options

This section discusses Setting Xilinx-Specific Options, and includes:

- "Setting Xilinx-Specific Options for FPGA Devices"
- "Setting Xilinx-Specific Options for CPLD Devices"

### Setting Xilinx-Specific Options for FPGA Devices

To set Xilinx-specific options for FPGA devices, select **Project Navigator > Process Properties > Synthesis Options > Xilinx-Specific Options**.

The following Xilinx-specific options can be set for FPGA devices:

- "Add I/O Buffers (-iobuf)"
- "LUT Combining (LC)"
- "Max Fanout (MAX\_FANOUT)"
- "Register Duplication (REGISTER\_DUPLICATION)"
- "Reduce Control Sets (REDUCE\_CONTROL\_SETS)"
- "Equivalent Register Removal (EQUIVALENT\_REGISTER\_REMOVAL)"
- "Register Balancing (REGISTER\_BALANCING)"
- "Move First Stage (MOVE\_FIRST\_STAGE)"
- "Move Last Stage (MOVE\_LAST\_STAGE)"
- "Convert Tristates to Logic (TRISTATE2LOGIC)"

Convert Tristate to Logic appears only when working with devices with internal tristate resources.

- "Use Clock Enable (USE\_CLOCK\_ENABLE)"
- "Use Synchronous Set (USE\_SYNC\_SET)"
- "Use Synchronous Reset (USE\_SYNC\_RESET)"

To display the following options, select Edit > Preferences > Processes > Property Display Level > Advanced:

- "Number of Global Clock Buffers (-bufg)"
- "Number of Regional Clock Buffers (–bufr)"

### Setting Xilinx-Specific Options for CPLD Devices

To set Xilinx-specific options for CPLD devices, select **Project Navigator > Process Properties > Synthesis Options > Xilinx-Specific Options**.

The following Xilinx-specific options can be set for CPLD devices:

- "Add I/O Buffers (-iobuf)"
- "Equivalent Register Removal (EQUIVALENT\_REGISTER\_REMOVAL)"
- "Clock Enable (-pld\_ce)"
- "Macro Preserve (-pld\_mp)"
- "XOR Preserve (-pld\_xp)"
- "WYSIWYG (-wysiwyg)"

### Setting Other XST Command Line Options

Set other XST command line options in **Project Navigator > Process Properties > Other XST Command Line Options**. This is an advanced property. Use the syntax described in "XST Command Line Mode." Separate multiple options with a space.

While Other XST Command Line Options is intended for XST options not listed in **Process Properties**, if an option already listed is entered, precedence is given to that option. Illegal or unrecognized options cause XST to stop processing and generate a message such as:

ERROR:Xst:1363 - Option "-verilog2002" is not available for command run.

### **Custom Compile File List**

Use the Custom Compile File List property to change the order in which source files are processed by XST. With this property, you select a user-defined compile list file that XST uses to determine the order in which it processes libraries and design files. Otherwise, XST uses an automatically generated list.

List all design files and their libraries in the order in which they are to be compiled, from top to bottom. Type each file and library pair on its own line, with a semicolon separating the library from the file as follows:

```
library_name;file_name
[library_name;file_name]
...
```

Following is an example:

work;stopwatch.vhd work;statmach.vhd

Since this property is not connected to **Simulation Properties > Custom Compile File List**, a different compile list file is used for synthesis than for simulation.

• Set the "Full Case (FULL\_CASE)" and "Parallel Case (PARALLEL\_CASE)" synthesis constraints

# **VHDL Attribute Syntax**

You can describe constraints with VHDL attributes in the VHDL code. Before it can be used, an attribute must be declared with the following syntax:

```
attribute AttributeName : Type ;
```

VHDL Attribute Syntax Example One

attribute RLOC : string ;

The attribute type defines the type of the attribute value. The only allowed type for XST is **string**. An attribute can be declared in an entity or architecture. If declared in the entity, it is visible both in the entity and the architecture body. If the attribute is declared in the architecture, it cannot be used in the entity declaration. Once declared a VHDL attribute can be specified as follows:

attribute AttributeName of ObjectList : ObjectType is AttributeValue ;

VHDL Attribute Syntax Example Two

attribute RLOC of u123 : label is R11C1.S0 ; attribute bufg of my\_signal : signal is sr;

The object list is a comma separated list of identifiers. Accepted object types are entity, component, label, signal, variable and type.

Follow these general rules:

- If a constraint can be applied on an entity (VHDL), then it can also be applied on the component declaration. The ability to apply constraints on components is not explicitly stated for each individual constraint, since it is a general XST rule.
- Some third party synthesis tools allow you to apply constraints on architectures. XST allows constraints on architectures only for those third party constraints automatically supported by XST.

# Verilog-2001 Attributes

This section discusses Verilog-2001 Attributes, and includes:

- "About Verilog-2001 Attributes"
- "Verilog-2001 Attributes Syntax"
- "Verilog-2001 Limitations"
- "Verilog-2001 Meta Comments"

### About Verilog-2001 Attributes

XST supports Verilog-2001 attribute statements. Attributes are comments that pass specific information to software tools such as synthesis tools. Verilog-2001 attributes can be specified anywhere for operators or signals within module declarations and instantiations. Other attribute declarations may be supported by the compiler, but are ignored by XST.

Use attributes to:



# Verilog-2001 Attributes Syntax

Attributes are bounded by asterisks (\*), and use the following syntax:

```
(* attribute_name = attribute_value *)
```

where

- The *attribute* precedes the signal, module, or instance declaration to which it refers.
- The *attribute\_value* is a string. No integer or scalar values are allowed.
- The *attribute\_value* is between quotes.
- The default is 1. (\* attribute\_name \*) is the same as
   (\* attribute\_name = "1" \*).

Verilog-2001 Attributes Syntax Example One

(\* clock\_buffer = "IBUFG" \*) input CLK;

Verilog-2001 Attributes Syntax Example Two

(\* INIT = "0000" \*) reg [3:0] d\_out;

Verilog-2001 Attributes Syntax Example Three

```
always@(current_state or reset)
  begin (* parallel_case *) (* full_case *)
    case (current_state)
    ...
```

Verilog-2001 Attributes Syntax Example Four

(\* mult\_style = "pipe\_lut" \*) MULT my\_mult (a, b, c);

### Verilog-2001 Limitations

Verilog-2001 attributes are not supported for:

- Signal declarations
- Statements
- Port connections
- Expression operators

## Verilog-2001 Meta Comments

Constraints can also be specified in Verilog code using meta comments. The Verilog-2001 format is the preferred syntax, but the meta comment style is still supported. Use the following syntax:

```
// synthesis attribute AttributeName [of] ObjectName [is]
AttributeValue
```

#### Examples

- // synthesis attribute RLOC of u123 is R11C1.SO
- // synthesis attribute HU\_SET u1 MY\_SET
- // synthesis attribute bufg of my\_clock is "clk"

The following constraints use a different syntax:

- "Parallel Case (PARALLEL\_CASE)"
- "Full Case (FULL\_CASE)"
- "Translate Off (TRANSLATE\_OFF) and Translate On (TRANSLATE\_ON)"

For more information, see "Verilog Attributes and Meta Comments."

# XST Constraint File (XCF)

This section discusses the XST Constraint File (XCF), and includes:

- "Specifying the XST Constraint File (XCF)"
- "XCF Syntax and Utilization"
- "Native and Non-Native User Constraint File (UCF) Constraints Syntax"
- "XCF Syntax Limitations"

### Specifying the XST Constraint File (XCF)

XST constraints can be specified in the Xilinx Constraint File (XCF). The XCF has an extension of .xcf. For information on specifying the XCF in ISE, see the ISE Help.

To specify the XCF in command line mode, use "Synthesis Constraint File (–uc)" with the **run** command. For more information about the **run** command and running XST from the command line, see "XST Command Line Mode."

### XCF Syntax and Utilization

The XST Constraint File (XCF) syntax enables you to specify a specific constraint for:

- The entire device (globally), or
- Specific modules

The XCF syntax is basically the same as the User Constraint File (UCF) syntax for applying constraints to nets or instances, but with an extension to the syntax to allow constraints to be applied to specific levels of hierarchy. Use the keyword MODEL to define the entity or module to which the constraint is applied. If a constraint is applied to an entity or module, the constraint is applied to each instance of the entity or module.

Define constraints in **Project Navigator > Process Properties**, or the XST run script, if running on the command line. Specify exceptions in the XCF file. The constraints specified in the XCF file are applied ONLY to the module listed, and not to any submodules below it.

To apply a constraint to the entire entity or module use the following syntax:

**MODEL** entityname constraintname = constraintvalue;

#### Examples

```
MODEL top mux_extract = false;
MODEL my_design max_fanout = 256;
```

If the entity *my\_design* is instantiated several times in the design, the *max\_fanout=256* constraint is applied to each instance of *my\_design*.

To apply constraints to specific instances or signals within an entity or module, use the INST or NET keywords. XST does not support constraints that are applied to VHDL variables.

```
BEGIN MODEL entityname
INST instancename constraintname = constraintvalue;
NET signalname constraintname = constraintvalue;
```

END;

#### Examples

```
BEGIN MODEL crc32
INST stopwatch opt_mode = area ;
INST U2 ram_style = block ;
NET myclock clock_buffer = true ;
NET data_in iob = true ;
END;
```

For a complete list of XST synthesis constraints, see "XST-Specific Non-Timing Options."

# Native and Non-Native User Constraint File (UCF) Constraints Syntax

All constraints supported by XST can be divided into two groups:

- "Native User Constraint File (UCF) Constraints"
- "Non-Native User Constraint File (UCF) Constraints"

### Native User Constraint File (UCF) Constraints

Only Timing and Area Group constraints use native User Constraint File (UCF) syntax.

Use native UCF syntax, including wildcards and hierarchical names, for native UCF constraints such as:

- "Period (PERIOD)"
- "Offset (OFFSET)"
- "Timing Name on a Net (TNM\_NET)"
- "Timegroup (TIMEGRP)"
- "Timing Ignore (TIG)"
- "From-To (FROM-TO)"

Do not use these constraints inside the BEGIN MODEL... END construct. If you do, XST issues an error.

### Non-Native User Constraint File (UCF) Constraints

For all non-native User Constraint File (UCF) constraints, use the **MODEL** or **BEGIN MODEL... END**; constructs. This includes:

- Pure XST constraints such as:
  - "Automatic FSM Extraction (FSM\_EXTRACT)"
  - "RAM Style (RAM\_STYLE)"

- Implementation non-timing constraints such as:
  - ♦ "RLOC"
  - ♦ "Keep (KEEP)"

If you specify timing constraints in the XST Constraint File (XCF), Xilinx recommends that you use a forward slash (/) as a hierarchy separator instead of an underscore (\_). For more information, see "Hierarchy Separator (-hierarchy\_separator)"

# **XCF Syntax Limitations**

XST Constraint File (XCF) syntax has the following limitations:

- Nested model statements are not supported.
- Instance or signal names listed between the BEGIN MODEL statement and the END statement are only the ones visible inside the entity. Hierarchical instance or signal names are not supported.
- Wildcards in instance and signal names are not supported, except in timing constraints.
- Not all native User Constraint File (UCF) constraints are supported. For more information, see the Xilinx *Constraints Guide*.

# **Constraints Priority**

Constraints priority depends on the file in which the constraint appears. A constraint in a file accessed later in the design flow overrides a constraint in a file accessed earlier in the design flow. Priority is as follows, from highest to lowest:

- 1. Synthesis Constraint File
- 2. Hardware Description Language (HDL) file
- 3. **Project Navigator > Process Properties**, or the command line

# **XST-Specific Non-Timing Options**

Table 5-1, "XST-Specific Non-Timing Options," shows:

- Allowed values for each constraint
- Type of objects to which they can be applied
- Usage restrictions

In many cases, a particular constraint can be applied globally to an entire entity or model, or alternatively, it can be applied locally to individual signals, nets or instances.

Table 5-1:	XST-Specific	Non-Timing	Options
			••••••••

Constraint Name	Constraint Value	VHDL Target	Verilog Target	XCF Target	Command Line	Command Value
"BoxType (BOX_TYPE)"	primitive black_box user_black_box	entity inst	module inst	model inst (in model)	N/A	N/A
"Map Logic on BRAM (BRAM_MAP)"	yes no	entity	module	model	N/A	N/A

### Table 5-1: XST-Specific Non-Timing Options (Cont'd)

Constraint Name	Constraint Value	VHDL Target	Verilog Target	XCF Target	Command Line	Command Value
"Buffer Type (BUFFER_TYPE)"	bufgdll ibufg bufg bufgp ibuf bufr none	signal	signal	net (in model)	N/A	N/A
"Clock Signal (CLOCK_SIGNAL)"	yes no	primary clock signal	primary clock signal	net (in model)	-bufgce	yes no default: no
"Clock Signal (CLOCK_SIGNAL)"	yes no	clock signal	clock signal	clock signal net (in model)	N/A	N/A
"Decoder Extraction (DECODER_EXTRACT)"	yes no	entity signal	entity signal	model net (in model)	-decoder_extract	yes no default: yes
"Enumerated Encoding (ENUM_ENCODING)"	string containing space- separated binary codes	type	signal	net (in model)	N/A	N/A
"Equivalent Register Removal (EQUIVALENT_REGISTER_R EMOVAL)"	yes no	entity signal	module signal	model net (in model)	-equivalent_register_ removal	yes no default: yes
"FSM Encoding Algorithm (FSM_ENCODING)"	auto one-hot compact sequential gray johnson speed1 user	entity signal	module signal	model net (in model)	-fsm_encoding	auto one-hot compact sequential gray johnson speed1 user <b>default: auto</b>
"Automatic FSM Extraction (FSM_EXTRACT)"	yes no	entity signal	module signal	model net (in model)	-fsm_extract	yes no default: yes
"FSM Style (FSM_STYLE)"	lut bram	entity signal	module signal	model net (in model)	-fsm_style	lut bram default: lut
"Full Case (FULL_CASE)"	N/A	N/A	case statement	N/A	N/A	N/A
"Incremental Synthesis (INCREMENTAL_SYNTHESIS )"	yes no	entity	module	model	N/A	N/A
"Pack I/O Registers Into IOBs (IOB)"	true false auto	signal instance	signal instance	net (in model) inst (in model)	-iob	true false auto <b>default: auto</b>
"I/O Standard (IOSTANDARD)"	string For more information, see the Xilinx Constraints Guide.	signal instance	signal instance	net (in model) inst (in model)	N/A	N/A



### Table 5-1: XST-Specific Non-Timing Options (Cont'd)

Constraint Name	Constraint Value	VHDL Target	Verilog Target	XCF Target	Command Line	Command Value
"Keep (KEEP)"	true false	signal	signal	net (in model)	N/A	N/A
"Keep Hierarchy (KEEP_HIERARCHY)"	yes no soft	entity	module	model	-keep_hierarchy	yes no soft default (FPGA): no default (CPLD): yes
"LOC"	string	signal (primary IO) instance	signal (primary IO) instance	net (in model) inst (in model)	N/A	N/A
"Map Entity on a Single LUT (LUT_MAP)"	yes no	entity architecture	module	model	N/A	N/A
"Max Fanout (MAX_FANOUT)"	integer	entity signal	module signal	model net (in model)	-max_fanout	integer default: see detailed description
"Move First Stage (MOVE_FIRST_STAGE)"	yes no	entity primary clock signal	module primary clock signal	model primary clock signal net (in model)	-move_first_stage	yes no default: yes
"Move Last Stage (MOVE_LAST_STAGE)"	yes no	entity primary clock signal	module primary clock signal	model primary clock signal net (in model	-move_last_stage	yes no default: yes
"Multiplier Style (MULT_STYLE)"	auto block pipe_block kcm csd lut pipe_lut	entity signal	module signal	model net (in model)	-mult_style	auto block pipe_block kcm csd lut pipe_lut <b>default: auto</b>
"Mux Extraction (MUX_EXTRACT)"	yes no force	entity signal	module signal	model net (in model)	-mux_extract	yes no force default: yes
"Mux Style (MUX_STYLE)"	auto muxf muxcy	entity signal	module signal	model net (in model)	-mux_style	auto muxf muxcy default: auto
"No Reduce (NOREDUCE)"	yes no	signal	signal	net (in model)	N/A	N/A
"Optimization Effort (OPT_LEVEL)"	1 2	entity	module	model	-opt_level	1 2 default: 1
"Optimization Goal (OPT_MODE)"	speed area	entity	module	model	-opt_mode	speed area <b>default: speed</b>
"Optimize Instantiated Primitives (OPTIMIZE_PRIMITIVES)"	yes no	entity instance	module instance	model instance (in model)	-optimize_primitives	yes no default: no
"Parallel Case (PARALLEL_CASE)"	N/A	N/A	case statement	N/A	N/A	N/A

Table 5-1: XST-Specific Non-Timing Options (Cont'd)

Constraint Name	Constraint Value	VHDL Target	Verilog Target	XCF Target	Command Line	Command Value
"Power Reduction (POWER)"	yes no	entity	module	model	-power	yes no default: no
"Priority Encoder Extraction (PRIORITY_EXTRACT)"	yes no force	entity signal	module signal	model net (in model)	-priority_extract	yes no force <b>default: yes</b>
"RAM Extraction (RAM_EXTRACT)"	yes no	entity signal	module signal	model net (in model)	-ram_extract	yes no default: yes
"RAM Style (RAM_STYLE)"	auto block distributed pipe_distribute d block_power1 block_power2	entity signal	module signal	model net (in model)	-ram_style	auto block distributed <b>default: auto</b>
"Read Cores (READ_CORES)"	yes no optimize	entity component	module label	model inst (in model)	-read_cores	yes no optimize <b>default: yes</b>
"Register Balancing (REGISTER_BALANCING)"	yes no forward backward	entity signal FF instance name	module signal FF instance name primary clock signal	model net (in model) inst (in model)	-register_balancing	yes no forward backward <b>default: no</b>
"Register Duplication (REGISTER_DUPLICATION)"	yes no	entity signal	module	model net (in model)	-register_duplication	yes no <b>default: yes</b>
"Register Power Up (REGISTER_POWERUP)"	string	type	signal	net (in model)	N/A	N/A
"Resource Sharing (RESOURCE_SHARING)"	yes no	entity signal	module signal	model net (in model)	-resource_sharing	yes no default: yes
"Resynthesize (RESYNTHESIZE)"	yes no	entity	module	model	N/A	N/A
"ROM Extraction (ROM_EXTRACT)"	yes no	entity signal	module signal	model net (in model)	-rom_extract	yes no <b>default: yes</b>
"ROM Style (ROM_STYLE)"	auto block distributed	entity signal	module signal	model net (in model)	-rom_style	auto block distributed <b>default: auto</b>
"Save (S / SAVE)"	yes no	signal inst of primitive	signal inst of primitive	net (in model) inst of primitive (in model)	N/A	N/A
"Safe Implementation (SAFE_IMPLEMENTATION)"	yes no	entity signal	module signal	model net (in model)	-safe_implementation	yes no default: no



Table 5-1:	XST-Specific Non-Timing Options (Cont'd)	
------------	--	--

Constraint Name	Constraint Value	VHDL Target	Verilog Target	XCF Target	Command Line	Command Value
"Safe Recovery State (SAFE_RECOVERY_STATE)"	string	signal	signal	net (in model)	N/A	N/A
"Logical Shifter Extraction (SHIFT_EXTRACT)"	yes no	entity signal	module signal	model net (in model)	-shift_extract	yes no <b>default: yes</b>
"Shift Register Extraction (SHREG_EXTRACT)"	yes no	entity signal	module signal	model net (in model)	_shreg_extract	yes no <b>default: yes</b>
"Signal Encoding (SIGNAL_ENCODING)"	auto one-hot user	entity signal	module signal	model net (in model)	-signal_encoding	auto one-hot user <b>default: auto</b>
"Slice (LUT-FF Pairs) Utilization Ratio (SLICE_UTILIZATION_RATI O)"	integer (range - 1 to 100) integer% (range -1 to 100) integer#	entity	module	model	-slice_utilization_ratio	integer (range -1 to 100) integer% (range -1 to 100) integer# default: 100
"Slice (LUT-FF Pairs) Utilization Ratio Delta (SLICE_UTILIZATION_RATI O_MAXMARGIN)"	integer (range 0 to 100) integer% (range 0 to 100) integer#	entity	module	model	-slice_utilization_ ratio_maxmargin	integer (range 0 to 100) integer% (range 0 to 100) integer# default: 0
"Translate Off (TRANSLATE_OFF) and Translate On (TRANSLATE_ON)"	N/A	local no target	local no target	N/A	N/A	N/A
"Convert Tristates to Logic (TRISTATE2LOGIC)"	yes no	entity signal	module signal	model net (in model)	-tristate2logic	yes no default: yes
"Use Carry Chain (USE_CARRY_CHAIN)"	yes no	entity signal	module signal	model net (in model)	-use_carry_chain	yes no default: yes
"Use Clock Enable (USE_CLOCK_ENABLE)"	auto yes no	entity signal FF instance name	module signal FF instance name	model net (in model) inst (in model)	-use_clock_enable	auto yes no default: auto
"Use DSP48 (USE_DSP48)"	auto yes no	entity signal	module signal	model net (in model)	-use_dsp48	auto yes no <b>default: auto</b>
"Use Synchronous Reset (USE_SYNC_RESET)"	auto yes no	entity signal FF instance name	module signal FF instance name	model net (in model) inst (in model)	-use_sync_reset	auto yes no <b>default: auto</b>
"Use Synchronous Set (USE_SYNC_SET)"	auto yes no	entity signal FF instance name	module signal FF instance name	model net (in model) inst (in model)	-use_sync_set	auto yes no default: auto

### Table 5-1: XST-Specific Non-Timing Options (Cont'd)

Constraint Name	Constraint Value	VHDL Target	Verilog Target	XCF Target	Command Line	Command Value
"Use Low Skew Lines (USELOWSKEWLINES)"	yes no	signal	signal	net (in model)	N/A	N/A
"XOR Collapsing (XOR_COLLAPSE)"	yes no	entity signal	module signal	model net (in model)	-xor_collapse	yes no default: yes



# **XST Command Line Only Options**

Table 5-2: XST-Specific Non-Timing Options: XST Command Line Only

Constraint Name	Command Line	Command Value
VHDL Top Level Architecture	-arch	architecture_name default: N/A
Asynchronous to Synchronous	-async_to_sync	yes no <b>default: no</b>
Automatic BRAM Packing	-auto_bram_packing	yes no <b>default: no</b>
BRAM Utilization Ratio (BRAM_UTILIZATION_RATIO)	-bram_utilization_ ratio	integer (range -1 to 100) integer% (range -1 to 100) integer# default: 100
Maximum Global Clock Buffers	-bufg	Integer default: max number of buffers in target device
Maximum Regional Clock Buffers	-bufr	Integer default: max number of buffers in target device
Bus Delimiter	-bus_delimiter	< > [] {} () default: <>
Case	-case	upper lower maintain <b>default: maintain</b>
Verilog Macros	-define	{name = value} default: N/A

	Table 5-2: XST-Specific Non-Timing Options: XST Command Line Only (Cont'd)			
DSP Utilization Ratio (DSP_UTILIZATION_RATIO)	-dsp_utilization_ratio	integer (range -1 to 100) integer% (range -1 to 100) integer# default: 100		
Duplication suffix	-duplication_suffix	string%dstring default: _%d		
VHDL Top-Level block (Valid only when old VHDL project format is used (-ifmt VHDL). Use project format (-ifmt mixed) and - top option to specify which top level block to synthesize.)	-ent	entity_name default: N/A		
Generics	-generics	{name = value} default: N/A		
HDL File Compilation Order	-hdl_compilation_order	auto user <b>default: auto</b>		
Hierarchy Separator	-hierarchy_separator	– / default: /		
Input Format	-ifmt	mixed vhdl verilog <b>default: mixed</b>		
Input/Project File Name	-ifn	file_name default: N/A		
Add I/O Buffers	-iobuf	yes no <b>default: yes</b>		
Ignore User Constraints	-iuc	yes no <b>default: no</b>		
Library Search Order	-lso	file_name.lso default: N/A		

Table 5-2: XST-Specific Non-Timing Options: XST Command Line Only (Cont'd)

Table 5-2: XST-Specific Non-Timing Options: XST Command Line Only (Cont'd)	Table 5-2:	XST-Specific Non-Timing	Options: XST	Command Line Only (Cont'd)
--	------------	-------------------------	--------------	----------------------------

LUT Combining	-lc	auto
8		area
		off
		default: off
		default: off
Netlist Hierarchy	-netlist_hierarchy	as_optimized
		rebuilt
		default: as_optimized
Output File Format	-ofmt	ngc
		default: ngc
Output File Name	-ofn	file_name
		default: N/A
Target Device	-р	part-package-speed (For example: xcv50-fg456-5: xcv50-fg456-6)
		default: N/A
Clock Enable	-pld_ce	yes
		no
		default: yes
Macro Preserve	-pld_mp	yes
		no
		default: yes
XOR Preserve	-pld_xp	yes
		no
		default: yes
Reduce Control Sets	-reduce_control_sets	auto
		no
		default: no
Generate RTL Schematic	-rtlview	yes
		no
		only
		default: no
Cores Search Directories		directorics
Cores Search Directories	-sd	directories
		default: N/A

Slice Packing	-slice_packing	yes no <b>default: yes</b>
Top Level Block	-top	block_name default: N/A
Synthesis Constraints File	-uc	file_name.xcf default: N/A
Verilog 2001	-verilog2001	yes no <b>default: yes</b>
Case Implementation Style	-vlgcase	full parallel full-parallel <b>default: N/A</b>
Verilog Include Directories	-vlgincdir	directories default: N/A
Work Library	-work_lib	directory default: work
wysiwyg	-wysiwyg	yes no <b>default: no</b>
Work Directory	-xsthdpdir	Directory default: ./xst
HDL Library Mapping File	-xsthdpini	file_name.ini default: N/A

# Table 5-2: XST-Specific Non-Timing Options: XST Command Line Only (Cont'd)

# XST Timing Options

This section discusses XST Timing Options, and includes:

- "XST Timing Options: Project Navigator > Process Properties or Command Line"
- "XST Timing Options: Xilinx Constraint File (XCF)"

# XST Timing Options: Project Navigator > Process Properties or Command Line

Table 5-3, "XST Timing Constraints Supported Only in Project Navigator > Process Properties, or Command Line," shows the XST timing constraints that you can invoke only from **Project Navigator > Process Properties**, or from the command line.

The table applies to the following architectures:

- Virtex, Virtex-E
- Virtex-II, Virtex-II Pro
- Virtex-4, Virtex-5
- Spartan-II, Spartan-IIE
- Spartan-3, Spartan-3E, Spartan3-A

*Table 5-3:* XST Timing Constraints Supported Only in Project Navigator > Process Properties, or Command Line

Option	Process Property (Project Navigator)	Values
glob_opt	Global Optimization Goal	allclocknets inpad_to_outpad offset_in_before offset_out_after max_delay <b>default: allclocknets</b>
cross_clock_analysis	Cross Clock Analysis	yes no <b>default: no</b>
write_timing_constraints	Write Timing Constraints	yes no <b>default: no</b>

# XST Timing Options: Xilinx Constraint File (XCF)

The following XST timing constraints can be applied for synthesis only through the Xilinx Constraint File (XCF):

- "Period (PERIOD)"
- "Offset (OFFSET)"
- "From-To (FROM-TO)"
- "Timing Name (TNM)"
- "Timing Name on a Net (TNM\_NET)"

- "Timegroup (TIMEGRP)"
- "Timing Ignore (TIG)"
- TIMESPEC
- TSIDENTIFIER

These timing constraints influence synthesis optimization, and can be passed on to place and route by selecting the Write Timing Constraints command line option.

These timing constraints are supported by the following architectures:

- Spartan-II, Spartan-IIE
- Spartan-3, Spartan-3E
- Spartan-3A, Spartan-3A D
- Virtex, Virtex-E
- Virtex-II, Virtex-II Pro
- Virtex-4, Virtex-5

For more information as to the Value and Target of each constraint, see the Xilinx *Constraints Guide*.

# **XST General Constraints**

This section lists general constraints for use with XST. These constraints apply to FPGA devices, CPLD devices, VHDL, and Verilog. You can set some of these options in **Project Navigator > Process Properties > Synthesis Options**. This section discusses the following constraints:

- "Add I/O Buffers (-iobuf)"
- "BoxType (BOX\_TYPE)"
- "Bus Delimiter (-bus\_delimiter)"
- "Case (-case)"
- "Case Implementation Style (-vlgcase)"
- "Verilog Macros (-define)"
- "Duplication Suffix (-duplication\_suffix)"
- "Full Case (FULL\_CASE)"
- "Generate RTL Schematic (-rtlview)"
- "Generics (-generics)"
- "Hierarchy Separator (-hierarchy\_separator)"
- "I/O Standard (IOSTANDARD)"
- "Keep (KEEP)"
- "Keep Hierarchy (KEEP\_HIERARCHY)"
- "Library Search Order (–lso)"
- "LOC"
- "Netlist Hierarchy (-netlist\_hierarchy)"
- "Optimization Effort (OPT\_LEVEL)"
- "Optimization Goal (OPT\_MODE)"
- "Parallel Case (PARALLEL\_CASE)"

- "RLOC"
- "Save (S / SAVE)"
- "Synthesis Constraint File (-uc)"
- "Translate Off (TRANSLATE\_OFF) and Translate On (TRANSLATE\_ON)"
- "Use Synthesis Constraints File (-iuc)"
- "Verilog Include Directories (-vlgincdir)"
- "Verilog 2001 (-verilog2001)"
- "HDL Library Mapping File (-xsthdpini)"
- "Work Directory (-xsthdpdir)"

# Add I/O Buffers (-iobuf)

Add I/O Buffers (-iobuf) enables or disables I/O buffer insertion. XST automatically inserts Input/Output Buffers into the design. If you manually instantiate I/O Buffers for some or all the I/Os, XST inserts I/O Buffers only for the remaining I/Os. If you do not want XST to insert any I/O Buffers, set -iobuf to no. Add I/O Buffers is useful to synthesize a part of a design to be instantiated later on.

Add I/O Buffers values are:

- yes (default)
- no

When **yes** is selected, IBUF and IOBUF primitives are generated. IBUF and OBUF primitives are connected to I/O ports of the top-level module. When XST is called to synthesize an internal module that is instantiated later in a larger design, you must select the **no** option. If I/O buffers are added to a design, this design cannot be used as a submodule of another design.

# Add I/O Buffers Architecture Support

Add I/O Buffers is architecture independent.

# Add I/O Buffers Applicable Elements

Add I/O Buffers applies globally.

# Add I/O Buffer Propagation Rules

Add I/O Buffers applies to design primary IOs.

# Add I/O Buffers Syntax Examples

Following are syntax examples using Add I/O Buffers with particular tools or methods. If a tool or method is not listed, Add I/O Buffers not be used with it.

Add I/O Buffers XST Command Line Syntax Example

Define Add I/O Buffers globally with the **-iobuf** command line option of the **run** command:

```
-iobuf {yes no true false soft}
```

The default is **yes**.

Add I/O Buffers Project Navigator Syntax Example

Define Add I/O Buffers globally in **Project Navigator > Process Properties > Xilinx-Specific Options > Add I/O Buffers**.

# BoxType (BOX\_TYPE)

Box Type (BOX\_TYPE) is a synthesis constraint.

Box Type values are:

- primitive
- black\_box
- user\_black\_box

These values instruct XST not to synthesize the behavior of a module.

The **black\_box** value is equivalent to **primitive**. It will eventually become obsolete.

If **user\_black\_box** is specified, XST reports inference of a black box in the log file. It does not do so if **primitive** is specified.

If Box Type is applied to at least a single instance of a block of a design, Box Type is propagated to all other instances of the entire design. This feature was implemented for Verilog and XST Constraint File (XCF) in order to have a VHDL-like support, where Box Type can be applied to a component.

## Box Type Architecture Support

Box Type is architecture independent.

#### Box Type Applicable Elements

Box Type applies to the following design elements:

• VHDL

component, entity

- Verilog module, instance
- XCF model, instance

# Box Type Propagation Rules

Box Type applies to the design element to which it is attached.

#### Box Type Syntax Examples

Following are syntax examples using Box Type with particular tools or methods. If a tool or method is not listed, Box Type may not be used with it.

Box Type VHDL Syntax Example

Before using Box Type, declare it with the following syntax:

```
attribute box_type: string;
```



After declaring Box Type, specify the VHDL constraint:

```
attribute box_type of {component_name|entity_name}: {component|entity}
is "{primitive|black_box|user_black_box}";
```

Box Type Verilog Syntax Example

Place this attribute immediately before the black box instantiation:

(\* box\_type = "{primitive|black\_box|user\_black\_box}" \*)

Box Type XCF Syntax Example One

**MODEL** "entity\_name" **box\_type=**"{primitive black\_box|user\_black\_box}";

Box Type XCF Syntax Example Two

```
BEGIN MODEL "entity_name"
INST "instance_name"
box_type="{primitive|black_box|user_black_box}";
END;
```

# Bus Delimiter (-bus\_delimiter)

The Bus Delimiter (**-bus\_delimiter**) command line option defines the format used to write the signal vectors in the result netlist. The available possibilities are:

- <> (default)
- []
- {}
- ()

#### Bus Delimiter Architecture Support

Bus Delimiter is architecture independent.

#### Bus Delimiter Applicable Elements

Bus Delimiter applies to syntax.

#### Bus Delimiter Propagation Rules

Not applicable

#### Bus Delimiter Syntax Examples

Following are syntax examples using Bus Delimiter with particular tools or methods. If a tool or method is not listed, Bus Delimiter not be used with it.

Bus Delimiter XST Command Line Syntax Example

Define Bus Delimiter globally with the **-bus\_delimiter** command line option of the **run** command:

```
-bus_delimiter { <> | [] | { } | () }
```

The default is <>.

Bus Delimiter Project Navigator Syntax Example

Define Bus Delimiter globally in **Project Navigator > Process Properties >** Synthesis Options > Bus Delimiter.

# Case (-case)

The Case (**-case**) command line option determines if instance and net names are written in the final netlist using all lower or upper case letters, or if the case is maintained from the source. The case can be maintained for either Verilog or VHDL synthesis flow.

## Case Architecture Support

Case is architecture independent.

#### **Case Applicable Elements**

Case applies to syntax.

#### Case Propagation Rules

Not applicable

## Case Syntax Examples

Following are syntax examples using Case with particular tools or methods. If a tool or method is not listed, Case may not be used with it.

Case XST Command Line Syntax Example

Define Case globally with the **-case** command line option of the **run** command:

-case {upper/lower/maintain}

The default is **maintain**.

Case Project Navigator Syntax Example

Define Case globally in **Project Navigator > Process Properties > Synthesis Options > Case**.

# Case Implementation Style (-vlgcase)

Case Implementation Style (-vlgcase) is valid for Verilog designs only.

Case Implementation Style instructs XST how to interpret Verilog Case statements. It has three possible values: **full**, **parallel** and **full-parallel**.

- If the option is not specified, XST implements the exact behavior of the case statements.
- If **full** is used, XST assumes that the case statements are complete, and avoids latch creation.
- If **parallel** is used, XST assumes that the branches cannot occur in parallel, and does not use a priority encoder.
- If **full-parallel** is used, XST assumes that the case statements are complete, and that the branches cannot occur in parallel, therefore saving latches and priority encoders.

For more information, see "Multiplexers HDL Coding Techniques," "Full Case (FULL\_CASE)," and "Parallel Case (PARALLEL\_CASE)."

## Case Implementation Style Architecture Support

Case Implementation Style is architecture independent.

#### Case Implementation Style Applicable Elements

Case Implementation Style applies globally.

#### Case Implementation Style Propagation Rules

Not applicable

#### Case Implementation Style Syntax Examples

Following are syntax examples using Case Implementation Style with particular tools or methods. If a tool or method is not listed, Case Implementation Style may not be used with it.

Case Implementation Style XST Command Line Syntax Example

Define Case Implementation Style globally with the **-vlgcase** command line option of the **run** command:

```
-vlgcase {full|parallel|full-parallel}
```

By default, there is no value.

Case Implementation Style Project Navigator Syntax Example

Define Case Implementation Style globally in **Project Navigator > Process Properties > HDL Options > Case Implementation Style**.

Case Implementation Style values are:

- Full
- Parallel
- Full-Parallel

By default, the value is blank.

# Verilog Macros (-define)

Verilog Macros (-define) is valid for Verilog designs only. Verilog Macros allows you to define (or redefine) Verilog macros. This allows you to easily modify the design configuration without any Hardware Description Language (HDL) source modifications, such as for IP core generation and testing flows. If the defined macro is not used in the design, no message is given.

#### Verilog Macros Architecture Support

Verilog Macros is architecture independent.

#### Verilog Macros Applicable Elements

Verilog Macros applies to the entire design.

# Verilog Macros Propagation Rules

Not applicable

# Verilog Macros Syntax Examples

Following are syntax examples using Verilog Macros with particular tools or methods. If a tool or method is not listed, Verilog Macros may not be used with it.

Verilog Macros XST Command Line Syntax Example

Define Verilog Macros globally with the **-define** command line option of the **run** command:

```
-define {name[=value] name[=value] -}
```

where

name is a macro name

value is a macro text

The default is an empty definition:

-define {}

#### Note:

- Values for macros are not mandatory.
- Place the values inside curly braces ({ . . . }).
- Separate the values with spaces.
- Macro text can be specified between quotation marks ("..."), or without them. If the macro text contains spaces, you must use quotation marks ("...").

-define {macro1=Xilinx macro2="Xilinx Virtex4"}

Verilog Macros Project Navigator Syntax Example

Define Verilog Macros globally in **Project Navigator > Process Properties >** Synthesis Options > Verilog Macros.

Do not use curly braces ({...}) when specifying values in Project Navigator.

acro1=Xilinx macro2="Xilinx Virtex4"

# Duplication Suffix (-duplication\_suffix)

Duplication Suffix (**-duplication\_suffix**) controls how XST names replicated flipflops. By default, when XST replicates a flip-flop, it creates a name for the new flip-flop by taking the name of the original flip-flop and adding \_*n* to the end of it, where *n* is an index number.

For example, if the original flip-flop name is **my\_ff**, and this flip-flop was replicated three times, XST generates flip-flops with the following names:

- my\_ff\_1
- my\_ff\_2
- my\_ff\_3

Use Duplication Suffix to specify a text string to append to the end of the default name. Use the **%d** escape character to specify where in the name the index number appears.



For example, for the flip-flop named **my\_ff**, if you **specify \_dupreg\_%d** with the Duplication Suffix option, XST generates the following names:

- my\_ff\_dupreg\_1
- my\_ff\_dupreg\_2
- my\_ff\_dupreg\_3

The **%d** escape character can be placed anywhere in the suffix definition.

For example, if the Duplication Suffix value is specified as **\_dup\_%d\_reg**, XST generates the following names:

- my\_ff\_dup\_1\_reg
- my\_ff\_dup\_2\_reg
- my\_ff\_dup\_3\_reg

#### Duplication Suffix Architecture Support

Duplication Suffix is architecture independent.

#### **Duplication Suffix Applicable Elements**

Duplication Suffix applies to files.

## **Duplication Suffix Propagation Rules**

Not applicable

#### **Duplication Suffix Syntax Examples**

Following are syntax examples using Duplication Suffix with particular tools or methods. If a tool or method is not listed, Duplication Suffix may not be used with it.

Duplication Suffix XST Command Line Syntax Example

Define Duplication Suffix globally with the **-duplication\_suffix** command line option of the **run** command:

-duplication\_suffix string%dstring

The default is **\_%d**.

Duplication Suffix Project Navigator Syntax Example

Define Duplication Suffix globally in **Project Navigator > Process Properties** > Synthesis Options > Other.

For more information about coding details, see "Duplication Suffix XST Command Line Syntax Example."

# Full Case (FULL\_CASE)

Full Case (FULL\_CASE) is valid for Verilog designs only. Full Case indicates that all possible selector values have been expressed in a **case**, **casex** or **casez** statement. The

Full Case directive prevents XST from creating additional hardware for those conditions not expressed. For more information, see "Multiplexers HDL Coding Techniques."

# Full Case Architecture Support

Full Case is architecture independent.

## Full Case Applicable Elements

Full Case applies to case statements in Verilog meta comments.

## **Full Case Propagation Rules**

Not applicable

### Full Case Syntax Examples

Following are syntax examples using Full Case with particular tools or methods. If a tool or method is not listed, Full Case may not be used with it.

#### Full Case Verilog Syntax Example

The Verilog 2001 syntax is as follows:

```
(* full_case *)
```

Since Full Case does not contain a target reference, the attribute immediately precedes the selector:

```
(* full_case *)
casex select
   4'blxxx: res = data1;
   4'bx1xx: res = data2;
   4'bxx1x: res = data3;
   4'bxxx1: res = data4;
endcase
```

Full Case is also available as a meta comment in the Verilog code. The syntax differs from the standard meta comment syntax as shown in the following:

// synthesis full\_case

Since Full Case does not contain a target reference, the meta comment immediately follows the selector:

```
casex select // synthesis full_case
 4'blxxx: res = data1;
 4'bx1xx: res = data2;
 4'bxx1x: res = data3;
 4'bxxx1: res = data4;
endcase
```

Full Case XST Command Line Syntax Example

Define Full Case globally with the **-vlgcase** command line option of the **run** command:

```
-vlgcase {full|parallel|full-parallel}
```



Full Case Project Navigator Syntax Example

For Verilog files only, define Full Case globally in **Project Navigator > Process Properties > Synthesis Options > Full Case**.

For Case Implementation Style, select Full as a Value.

# Generate RTL Schematic (-rtlview)

Generate RTL Schematic (**-rtlview**) enables XST to generate a netlist file, representing an RTL structure of the design. This netlist can be viewed by the RTL and Technology Viewers. Generate RTL Schematic has three possible values:

- yes
- no
- only

When **only** is specified, XST stops synthesis just after the RTL view is generated. The file containing the RTL view has an NGR file extension.

#### Generate RTL Schematic Architecture Support

Generate RTL Schematic is architecture independent.

#### Generate RTL Schematic Applicable Elements

Generate RTL Schematic applies to files.

#### Generate RTL Schematic Propagation Rules

Not applicable

#### Generate RTL Schematic Syntax Examples

Following are syntax examples using Generate RTL Schematic with particular tools or methods. If a tool or method is not listed, Generate RTL Schematic may not be used with it.

Generate RTL Schematic XST Command Line Syntax Example

Define Generate RTL Schematic globally with the **-rtlview** command line option of the **run** command:

-rtlview {yes | no | only}

The default is **no**.

Generate RTL Schematic Project Navigator Syntax Example

Define Generate RTL Schematic globally in **Project Navigator > Process Properties > Synthesis Options > Generate RTL Schematic**.

The default is **yes**.

# **Generics** (-generics)

Generics (**-generics**) allows you to to redefine generics (VHDL) or parameters (Verilog) values defined in the top-level design block. This allows you to easily modify the design configuration without any Hardware Description Language (HDL) source modifications, such as for IP core generation and testing flows. If the defined value does not correspond

to the data type defined in the VHDL or Verilog code, then XST tries to detect the situation and issues a warning, ignoring the command line definition.

In some situations, XST may fail to detect a type mismatch. In that case, XST attempts to apply this value by adopting it to the type defined in the VHDL or Verilog file without any warning. Be sure that the value you specified corresponds to the type defined in the VHDL or Verilog code. If a defined generic or parameter name does not exist in the design, no message is given, and the definition is ignored.

# **Generics Architecture Support**

Generics is architecture independent.

## **Generics Applicable Elements**

Generics applies to the entire design.

#### Generics Propagation Rules

Not applicable

#### **Generics Syntax Examples**

Following are syntax examples using Generics with particular tools or methods. If a tool or method is not listed, Generics may not be used with it.

Generics XST Command Line Syntax Example

Define Generics globally with the -generics command line option of the run command:

```
-generics {name=value name=value .}
```

where

name

is the name of a generic or parameter of the top level design block, and

#### value

is the value of a generic or parameter of the top level design block.

The default is an empty definition:

#### -generics {}

Follow these rules:

- Place the values inside curly braces ({ . . . }).
- Separate the values with spaces.
- XST can accept as values only constants of scalar types. Composite data types (arrays or records) are supported only in the following situations:
  - string
  - std\_logic\_vector
  - std\_ulogic\_vector
  - signed, unsigned
  - bit\_vector



• There are no spaces between the prefix and the corresponding value:

-generics {company="Xilinx" width=5 init\_vector=b100101}

Generics Project Navigator Syntax Example

Define Generics globally in **Project Navigator > Process Properties >** Synthesis Options > Generics, Parameters.

Do not use curly braces ({...}) when specifying values in Project Navigator:

company="Xilinx" width=5 init\_vector=b100101

# Hierarchy Separator (-hierarchy\_separator)

Hierarchy Separator (**-hierarchy\_separator**) defines the hierarchy separator character that is used in name generation when the design hierarchy is flattened.

The two supported characters are:

- \_(underscore)
- / (forward slash)

The default is / (forward slash) for newly created projects.

If a design contains a sub-block with instance INST1, and this sub-block contains a net called TMP\_NET, then the hierarchy is flattened and the hierarchy separator character is / (forward slash). The name TMP\_NET becomes INST1\_TMP\_NET. If the hierarchy separator character is / (forward slash), the net name is NST1/TMP\_NET.

Using / (forward slash) as a hierarchy separator is useful in design debugging because the / (forward slash) separator makes it much easier to identify a name if it is hierarchical.

# Hierarchy Separator Architecture Support

Hierarchy Separator is architecture independent.

#### Hierarchy Separator Applicable Elements

Hierarchy Separator applies to files.

#### Hierarchy Separator Propagation Rules

Not applicable

#### **Hierarchy Separator Syntax Examples**

Following are syntax examples using Hierarchy Separator with particular tools or methods. If a tool or method is not listed, Hierarchy Separator may not be used with it.

Hierarchy Separator XST Command Line Syntax Example

Define Hierarchy Separator globally with the **-hierarchy\_separator** command line option of the **run** command:

-hierarchy\_separator { \_ / }

The default is / (forward slash) for newly created projects.

Hierarchy Separator Project Navigator Syntax Example

Define Hierarchy Separator globally in **Project Navigator** > **Process Properties** > **Synthesis Options** > **Hierarchy Separator**.

The default is / (forward slash).

# I/O Standard (IOSTANDARD)

Use I/O Standard (IOSTANDARD) to assign an I/O standard to an I/O primitive. For more information, see "IOSTANDARD" in the Xilinx *Constraints Guide*.

# Keep (KEEP)

Keep (KEEP) is an advanced mapping constraint. When a design is mapped, some nets may be absorbed into logic blocks. When a net is absorbed into a block, it can no longer be seen in the physical design database. This may happen, for example, if the components connected to each side of a net are mapped into the same logic block. The net may then be absorbed into the block containing the components. KEEP prevents this from happening.

KEEP preserves the existence of the signal in the final netlist, but not its structure. For example, if your design has a 2-bit multiplexer selector and you attach KEEP to it, this signal is preserved in the final netlist. But the multiplexer could be automatically reencoded by XST using one-hot encoding. As a consequence, this signal in the final netlist is four bits wide instead of the original two. To preserve the structure of the signal, in addition to KEEP, you must also use "Enumerated Encoding (ENUM\_ENCODING)"

For more information, see "KEEP" in the Xilinx Constraints Guide.

# Keep Hierarchy (KEEP\_HIERARCHY)

Keep Hierarchy (KEEP\_HIERARCHY) is a synthesis and implementation constraint. If hierarchy is maintained during synthesis, the implementation tools use Keep Hierarchy to preserve the hierarchy throughout implementation, and allow a simulation netlist to be created with the desired hierarchy.

XST can flatten the design to obtain better results by optimizing entity or module boundaries. You can set Keep Hierarchy to **true** so that the generated netlist is hierarchical and respects the hierarchy and interface of any entity or module in your design.

Keep Hierarchy is related to the hierarchical blocks (VHDL entities, Verilog modules) specified in the Hardware Description Language (HDL) design, and does not concern the macros inferred by the HDL synthesizer.

# **Keep Hierarchy Values**

Keep Hierarchy values are:

true

Allows the preservation of the design hierarchy, as described in the HDL project. If this value is applied to synthesis, it is also propagated to implementation. For CPLD devices, the default is **true**.

false

Hierarchical blocks are merged in the top level module. For FPGA devices, the default is **false**.



#### soft


Allows the preservation of the design hierarchy in synthesis, but KEEP\_HIERARCHY is not propagated to implementation.

## Preserving the Hierarchy

In general, a Hardware Description Language (HDL) design is a collection of hierarchical blocks. Preserving the hierarchy gives the advantage of fast processing because the optimization is done on separate pieces of reduced complexity. Nevertheless, very often, merging the hierarchy blocks improves the fitting results (fewer PTerms and device macrocells, better frequency) because the optimization processes (collapsing, factorization) are applied globally on the entire logic.

## Keep Hierarchy Diagram

In Figure 5-1, "Keep Hierarchy Diagram," if Keep Hierarchy is set to the entity or module I2, the hierarchy of I2 is in the final netlist, but its contents I4, I5 are flattened inside I2. I1, I3, I6, and I7 are also flattened.



X9542

Figure 5-1: Keep Hierarchy Diagram

# Keep Hierarchy Architecture Support

Keep Hierarchy is architecture independent.

#### Keep Hierarchy Applicable Elements

Keep Hierarchy applies to logical blocks, including blocks of hierarchy or symbols.

#### Keep Hierarchy Propagation Rules

Keep Hierarchy applies to the entity or module to which it is attached.

# Keep Hierarchy Syntax Examples

Following are syntax examples using Keep Hierarchy with particular tools or methods. If a tool or method is not listed, Keep Hierarchy may not be used with it.

Keep Hierarchy Schematic Syntax Example

- Attach to the entity or module symbol.
- Attribute Name: KEEP\_HIERARCHY
- Attribute Values: YES, NO

Keep Hierarchy VHDL Syntax Example

Before using Keep Hierarchy, declare it with the following syntax:

attribute keep\_hierarchy : string;

After declaring Keep Hierarchy, specify the VHDL constraint:

attribute keep\_hierarchy of architecture\_name: architecture is
"{yes|no|true|false|soft}";

The default is **no** for FPGA devices and **yes** for CPLD devices.

Keep Hierarchy Verilog Syntax Example

Place this attribute immediately before the module declaration or instantiation:

```
(* keep_hierarchy = "{yes no true false soft}" *)
```

Keep Hierarchy XCF Syntax Example

**MODEL** "entity\_name" keep\_hierarchy={yes|no|true|false|soft};

Keep Hierarchy XST Command Line Syntax Example

Define Keep Hierarchy globally with the **-keep\_hierarchy** command line option of the **run** command:

-keep\_hierarchy  $\{yes \mid no \mid soft\}$ 

The default is **no** for FPGA devices and **yes** for CPLD devices.

For more information, see "XST Command Line Mode."

Keep Hierarchy Project Navigator Syntax Example

Define Keep Hierarchy globally in **Project Navigator > Process Properties >** Synthesis Options > Keep Hierarchy.

# Library Search Order (–Iso)

Use Library Search Order (**-1so**) to specify the order in which library files are used. To invoke Library Search Order:

- Specify the search order file in Project Navigator > Process Properties > Synthesis Options > Library Search, or
- Use the -lso command line option

Library Search Order Architecture Support

Library Search Order is architecture independent.



# Library Search Order Applicable Elements

Library Search Order applies to files.

# Library Search Order Propagation Rules

Not applicable

## Library Search Order Syntax Examples

Following are syntax examples using Library Search Order with particular tools or methods. If a tool or method is not listed, Library Search Order may not be used with it.

Library Search Order XST Command Line Syntax Example

Define Library Search Order globally with the **-1so** command line option of the **run** command:

-1so file\_name.lso

There is no default file name. If not specified, XST uses the default search order.

For more information, see the "Library Search Order (LSO) Files in Mixed Language Projects."

Library Search Order Project Navigator Syntax Example

Define Library Search Order globally in **Project Navigator > Process Properties > Synthesis Options > Library Search Order**.

For more information, see "Library Search Order (LSO) Files in Mixed Language Projects."

# LOC

The LOC constraint defines where a design element can be placed within an FPGA or CPLD device. For more information, see "LOC" in the Xilinx *Constraints Guide*.

# Netlist Hierarchy (-netlist\_hierarchy)

Use Netlist Hierarchy (**-netlist\_hierarchy**) to control the form in which the final NGC netlist is generated. Netlist Hierarchy allows you to write the hierarchical netlist even if the optimization was done on a partially or fully flattened design.

If the value of Netlist Hierarchy is:

as\_optimized

XST takes into account the "Keep Hierarchy (KEEP\_HIERARCHY)" constraint, and generates the NGC netlist in the form in which it was optimized. In this mode, some hierarchical blocks can be flattened, and some can maintain hierarchy boundaries.

rebuilt

XST writes a hierarchical NGC netlist, regardless of the "Keep Hierarchy (KEEP\_HIERARCHY)" constraint.

#### Netlist Hierarchy Architecture Support

Netlist Hierarchy is architecture independent.

# Netlist Hierarchy Applicable Elements

Netlist Hierarchy applies globally.

## **Netlist Hierarchy Propagation Rules**

Not applicable

#### Netlist Hierarchy Syntax Examples

Following are syntax examples using Netlist Hierarchy with particular tools or methods. If a tool or method is not listed, Netlist Hierarchy may not be used with it.

Netlist Hierarchy XST Command Line Syntax Example

Define Netlist Hierarchy globally with the **- netlist**\_hierarchy command line option of the **run** command:

- netlist\_hierarchy { as\_optimized | rebuilt }

The default is **as\_optimized**.

# **Optimization Effort (OPT\_LEVEL)**

Optimization Effort (OPT\_LEVEL) defines the synthesis optimization effort level.

Allowed Optimization Effort values are:

• **1** (normal optimization)

Use 1 (normal optimization) for very fast processing, especially for hierarchical designs. In speed optimization mode, Xilinx recommends using **1** (normal optimization) for the majority of designs. 1 (normal optimization) is the default.

• **2** (higher optimization)

While 2 (higher optimization) is more time consuming, it sometimes gives better results in the number of slices/macrocells or maximum frequency. Selecting 2 (higher optimization) usually results in increased synthesis run times, and does not always bring optimization gain.

#### **Optimization Effort Architecture Support**

Optimization Effort is architecture independent.

#### **Optimization Effort Applicable Elements**

Optimization Effort applies globally, or to an entity or module.

#### Optimization Effort Propagation Rules

Optimization Effort applies to the entity or module to which it is attached.

#### Optimization Effort Syntax Examples

Following are syntax examples using Optimization Effort with particular tools or methods. If a tool or method is not listed, Optimization Effort may not be used with it.



**Optimization Effort VHDL Syntax Example** 

Before using Optimization Effort, declare it with the following syntax:

attribute opt\_level: string;

After declaring Optimization Effort, specify the VHDL constraint:

attribute opt\_level of entity\_name: entity is "{1|2}";

**Optimization Effort Verilog Syntax Example** 

Place this attribute immediately before the module declaration or instantiation:

(\* opt\_level = "{1|2}" \*)

Optimization Effort XCF Syntax Example

MODEL "entity\_name" opt\_level={1|2};

Optimization Effort XST Command Line Syntax Example

Define Optimization Effort globally with the **-opt\_level** command line option:

-opt\_level {1|2}

The default is **1**.

Optimization Effort Project Navigator Syntax Example

Define Optimization Effort globally in **Project Navigator > Process Properties** > Synthesis Options > Optimization Effort.

# **Optimization Goal (OPT\_MODE)**

Optimization Goal (OPT\_MODE defines the synthesis optimization strategy.

Available Optimization Goal values are:

speed

The priority of **speed** is to reduce the number of logic levels and therefore to increase frequency. **speed** is the default.

• area

The priority of **area** is to reduce the total amount of logic used for design implementation and therefore improve design fitting.

#### Optimization Goal Architecture Support

Optimization Goal is architecture independent.

#### Optimization Goal Applicable Elements

Optimization Goal applies globally, or to an entity or module.

## **Optimization Goal Propagation Rules**

Optimization Goal applies to the entity or module to which it is attached.

# **Optimization Goal Syntax Examples**

Following are syntax examples using Optimization Goal with particular tools or methods. If a tool or method is not listed, Optimization Goal may not be used with it.

**Optimization Goal VHDL Syntax Example** 

Before using Optimization Goal, declare it with the following syntax:

attribute opt\_mode: string;

After declaring Optimization Goal, specify the VHDL constraint:

```
attribute opt_mode of entity_name: entity is "{speed | area}";
```

**Optimization Goal Verilog Syntax Example** 

Place this attribute immediately before the module declaration or instantiation:

(\* opt\_mode = "{speed|area}" \*)

Optimization Goal XCF Syntax Example

MODEL "entity\_name" opt\_mode={speed|area};

Optimization Goal XST Command Line Syntax Example

Define Optimization Goal globally with the **-opt\_mode** command line option of the **run** command:

-opt\_mode {area|speed}

The default is **speed**.

Optimization Goal Project Navigator Syntax Example

Define Optimization Goal globally in **Project Navigator > Process Properties** > Synthesis Options > Optimization Goal.

The default is **speed**.

# Parallel Case (PARALLEL\_CASE)

Parallel Case (PARALLEL\_CASE) is valid for Verilog designs only. Parallel Case forces a case statement to be synthesized as a parallel multiplexer and prevents the case statement from being transformed into a prioritized **if...elsif** cascade. For more information, see "Multiplexers HDL Coding Techniques."

#### Parallel Case Architecture Support

Parallel Case is architecture independent.

#### Parallel Case Applicable Elements

Parallel Case applies to case statements in Verilog meta comments only.

#### Parallel Case Propagation Rules

Not applicable



# Parallel Case Syntax Examples

Following are syntax examples using Parallel Case with particular tools or methods. If a tool or method is not listed, Parallel Case may not be used with it.

Parallel Case Verilog Syntax Examples

The Parallel Case Verilog 2001 syntax is:

(\* parallel\_case \*)

Since Parallel Case does not contain a target reference, the attribute immediately precedes the selector.

```
(* parallel_case *)
casex select
  4'blxxx: res = data1;
  4'bxlxx: res = data2;
  4'bxxlx: res = data3;
  4'bxxxl: res = data4;
endcase
```

Parallel Case is also available as a meta comment in the Verilog code. The syntax differs from the standard meta comment syntax as shown in the following:

```
// synthesis parallel_case
```

Since Parallel Case does not contain a target reference, the meta comment immediately follows the selector:

```
casex select // synthesis parallel_case
4'blxxx: res = data1;
4'bx1xx: res = data2;
4'bxx1x: res = data3;
4'bxxx1: res = data4;
endcase
```

Parallel Case XST Command Line Syntax Example

Define Parallel Case globally with the **-vlgcase** command line option of the **run** command:

-vlgcase {full|parallel|full-parallel}

# **RLOC**

RLOC is a basic mapping and placement constraint. RLOC groups logic elements into discrete sets and allows you to define the location of any element within the set relative to other elements in the set, regardless of eventual placement in the overall design. For more information, see "RLOC" in the Xilinx *Constraints Guide*.

# Save (S / SAVE)

Save (S or its alias SAVE) is an advanced mapping constraint. When the design is mapped, some nets may be absorbed into logic blocks, and some elements such as LUTs can be optimized away. When a net is absorbed into a block, or a block is optimized away, it can no longer be seen in the physical design database. The S (SAVE) constraint prevents this from happening. Several optimization techniques such as nets or blocks replication and register balancing are also disabled by the S (SAVE) constraint.

If the S (SAVE) constraint is applied to a net, XST preserves the net with all elements directly connected to it in the final netlist. This includes nets connected to these elements.

If the S (SAVE) constraint is applied to a block such as a LUT, XST preserves the LUT with all signals connected to it.

For more information, see the Xilinx Constraints Guide.

# Synthesis Constraint File (-uc)

Synthesis Constraint File (-uc) specifies a synthesis constraint file for XST to use. The XST Constraint File (XCF) has an extension of .xcf. If the extension is not .xcf, XST errors out and stops processing. For more information, see "XST Constraint File (XCF)."

# Synthesis Constraint File Architecture Support

Synthesis Constraint File is architecture independent.

# Synthesis Constraint File Applicable Elements

Synthesis Constraint File applies to files.

# Synthesis Constraint File Propagation Rules

Not applicable

# Synthesis Constraint File Syntax Examples

Following are syntax examples using Synthesis Constraint File with particular tools or methods. If a tool or method is not listed, Synthesis Constraint File may not be used with it.

Synthesis Constraint File XST Command Line Syntax Example

Specify a file name with the **-uc** command line option of the **run** command:

-uc filename

Synthesis Constraint File Project Navigator Syntax Example

Define Synthesis Constraint File globally in **Project Navigator > Process Properties > Synthesis Options > Use Synthesis Constraints File**.

# Translate Off (TRANSLATE\_OFF) and Translate On (TRANSLATE\_ON)

Translate Off (TRANSLATE\_OFF) and Translate On (TRANSLATE\_ON) instruct XST to ignore portions of your VHDL or Verilog code that are not relevant for synthesis, such as simulation code.

- TRANSLATE\_OFF marks the beginning of the section to be ignored.
- TRANSLATE\_ON instructs XST to resume synthesis from that point.

Translate Off and Translate On are also Synplicity and Synopsys directives that that XST supports in Verilog. Automatic conversion is also available in VHDL and Verilog.



Translate Off and Translate On can be used with the following words:

- synthesis
- synopsys
- pragma

#### Translate Off and Translate On Architecture Support

Translate Off and Translate On are architecture independent.

#### Translate Off and Translate On Applicable Elements

Translate Off and Translate On apply locally.

#### Translate Off and Translate On Propagation Rules

Instructs the synthesis tool to enable or disable portions of code

#### Translate Off and Translate On Syntax Examples

Following are syntax examples using Translate Off and Translate On with particular tools or methods. If a tool or method is not listed, Translate Off and Translate On may not be used with it.

#### Translate Off and Translate On VHDL Syntax Example

In VHDL, write Translate Off and Translate On as follows:

-- synthesis translate\_off
...code not synthesized...
-- synthesis translate\_on

-- Synchesis clanslace\_on

Translate Off and Translate On Verilog Syntax Example

Translate Off and Translate On are available as VHDL or Verilog meta comments. The Verilog syntax differs from the standard meta comment syntax presented earlier, as shown in the following coding example:

// synthesis translate\_off
...code not synthesized...
// synthesis translate\_on

# Use Synthesis Constraints File (–iuc)

Use Synthesis Constraints File (**-iuc**) allows you to ignore the constraint file during synthesis.

#### Use Synthesis Constraints File Architecture Support

Use Synthesis Constraints File is architecture independent.

#### Use Synthesis Constraints File Applicable Elements

Use Synthesis Constraints File applies to files.

#### Use Synthesis Constraints File Propagation Rules

Not applicable

# Use Synthesis Constraints File Syntax Examples

Following are syntax examples using Use Synthesis Constraints File with particular tools or methods. If a tool or method is not listed, Use Synthesis Constraints File may not be used with it.

Use Synthesis Constraints File XST Command Line Syntax Example

Define Use Synthesis Constraints File globally with the **-iuc** command line option of the **run** command:

-iuc {yes|no}

The default is **no**.

Use Synthesis Constraints File Project Navigator Syntax Example

Define Use Synthesis Constraints File globally in **Project Navigator > Process Properties > Synthesis Options > Use Synthesis Constraints File**.

# Verilog Include Directories (–vlgincdir)

The Verilog Include Directories (**-vlgincdir**) switch is used to help the parser find files referenced by `include statements. When an `include statement references a file, XST looks in different areas in this order:

- Relative to the current directory.
- Relative to the inc directories.
- Relative to the current file.

*Note:* -vlgincdir should be used in conjunction with `include.

#### Verilog Include Directories Architecture Support

Verilog Include Directories is architecture independent.

#### Verilog Include Directories Applicable Elements

Verilog Include Directories applies to directories.

#### Verilog Include Directories Propagation Rules

Not applicable

#### Verilog Include Directories Syntax Examples

Following are syntax examples using Verilog Include Directories with particular tools or methods. If a tool or method is not listed, Verilog Include Directories may not be used with it.

Verilog Include Directories XST Command Line Syntax Example

Define Verilog Include Directories globally with the **-vlgincdir** command line option of the **run** command: Allowed values are names of directories. For more information, see "Names With Spaces in Command Line Mode."

```
-vlgincdir {directory_path [directory_path]}
```

There is no default.



Verilog Include Directories Project Navigator Syntax Example

Define Verilog Include Directories globally in **Project Navigator > Process Properties > Synthesis Options > Verilog Include Directories**.

Allowed values are names of directories. There is no default.

To view Verilog Include Directories, select Edit > Preferences > Processes > Property Display Level > Advanced.

# Verilog 2001 (-verilog2001)

Verilog 2001 (**-verilog2001**) enables or disables interpreted Verilog source code as the Verilog 2001 standard. By default Verilog source code is interpreted as the Verilog 2001 standard.

#### Verilog 2001 Architecture Support

Verilog 2001 (-verilog2001) is architecture independent.

#### Verilog 2001 Applicable Elements

Verilog 2001 applies to syntax.

#### Verilog 2001 Propagation Rules

Not applicable

#### Verilog 2001 Syntax Examples

Following are syntax examples using Verilog 2001 with particular tools or methods. If a tool or method is not listed, Verilog 2001may not be used with it.

#### Verilog 2001 XST Command Line Syntax Example

Define Verilog 2001 globally with the **-verilog2001** command line option of the **run** command:

-verilog2001 {yes no}

The default is **yes**.

Verilog 2001 Project Navigator Syntax Example

Define Verilog 2001 globally in **Project Navigator** > **Process Properties** > **Synthesis Options** > **Verilog 2001**.

# HDL Library Mapping File (–xsthdpini)

Use HDL Library Mapping File (**-xsthdpini**) to define the library mapping.

The library mapping file has two associated parameters:

- XSTHDPINI
- XSTHDPDIR

The library mapping file contains:

- The library name
- The directory in which the library is compiled

XST maintains two library mapping files:

- The pre-installed file, which is installed during the Xilinx software installation
- The user file, which you may define for your own projects

The pre-installed (default) INI file is named xhdp.ini, and is located in %XILINX%\vhdl\xst. These files contain information about the locations of the standard VHDL and UNISIM libraries. These should not be modified, but the syntax can be used for user library mapping. This file appears as follows:

```
-- Default lib mapping for XST
std=$XILINX/vhdl/xst/std
ieee=$XILINX/vhdl/xst/unisim
unisim=$XILINX/vhdl/xst/unisim
aim=$XILINX/vhdl/xst/aim
pls=$XILINX/vhdl/xst/pls
```

Use this file format to define where each of your own libraries must be placed. By default, all compiled VHDL flies are stored in the xst sub-directory of the ISE<sup>TM</sup> project directory.

To place your custom INI file anywhere on a disk:

- Select the VHDL INI file in Project Navigator > Process Properties > Synthesis Options, or
- Set up the **-xsthdpini** parameter, using the following command in stand-alone mode:

set -xsthdpini file\_name

You can give this library mapping file any name you wish, but it is best to keep the .ini classification. The format is:

library\_name=path\_to\_compiled\_directory

Use double dash (--) for comments.

#### **MY.INI Example Text**

work1=H:\Users\conf\my\_lib\work1
work2=C:\mylib\work2

#### HDL Library Mapping File Architecture Support

HDL Library Mapping File is architecture independent.

#### HDL Library Mapping File Applicable Elements

HDL Library Mapping File applies to files.

#### HDL Library Mapping File Propagation Rules

Not applicable

#### HDL Library Mapping File Syntax Examples

Following are syntax examples using HDL Library Mapping File with particular tools or methods. If a tool or method is not listed, HDL Library Mapping File may not be used with it.



HDL Library Mapping File XST Command Line Syntax Example

Define HDL Library Mapping File globally with the **set -xsthdpini** command line option before running the **run** command:

set -xsthdpini file\_name

The command can accept a single file only.

HDL Library Mapping File Project Navigator Syntax Example

Define HDL Library Mapping File globally in **Project Navigator > Process Properties > Synthesis Options > VHDL INI File**.

To view HDL Library Mapping File, select Edit > Preferences > Processes > Property Display Level > Advanced.

# Work Directory (–xsthdpdir)

Work Directory (**-xsthdpdir**) defines the location in which VHDL-compiled files must be placed if the location is not defined by library mapping files. To access Work Directory:

- Select Project Navigator > Process Properties > Synthesis Options
   > VHDL Working Directory, or
- Use the following command in stand-alone mode:

set -xsthdpdir directory

#### Work Directory Example

Assume the following for purposes of this example:

- Three different users are working on the same project.
- They share one standard, pre-compiled library, shlib.
- This library contains specific macro blocks for their project.
- Each user also maintains a local work library.
- User 3 places her local work library outside the project directory (for example, in c:\temp).
- Users 1 and 2 share another library (lib12) between them, but not with User 3.

The settings required for the three users are as follows:

#### Work Directory Example User One

```
Mapping file:
schlib=z:\sharedlibs\shlib
lib12=z:\userlibs\lib12
```

#### Work Directory Example User Two

Mapping file: schlib=z:\sharedlibs\shlib lib12=z:\userlibs\lib12

#### Work Directory Example User Three

```
Mapping file:
schlib=z:\sharedlibs\shlib
```

User Three will also set:

XSTHDPDIR = c:\temp

# Work Directory Architecture Support

Work Directory is architecture independent.

## Work Directory Applicable Elements

Work Directory applies to directories.

# Work Directory Propagation Rules

Not applicable

## Work Directory Syntax Examples

Following are syntax examples using Work Directory with particular tools or methods. If a tool or method is not listed, Work Directory may not be used with it.

Work Directory XST Command Line Syntax Example

Define Work Directory globally with the **set** –**xsthdpdir** command line option before running the **run** command:

set -xsthdpdir directory

Work Directory can accept a single path only. You must specify the directory. There is no default.

Work Directory Project Navigator Syntax Example

Define Work Directory globally in **Project Navigator > Process Properties >** Synthesis Options > VHDL Work Directory.

```
To view Work Directory, select Edit > Preferences > Processes > Property Display Level > Advanced.
```

# **XST HDL Constraints**

This section describes Hardware Description Language (HDL) design constraints that can be used with XST. This section discusses the following constraints:

- "Automatic FSM Extraction (FSM\_EXTRACT)"
- "Enumerated Encoding (ENUM\_ENCODING)"
- "Equivalent Register Removal (EQUIVALENT\_REGISTER\_REMOVAL)"
- "FSM Encoding Algorithm (FSM\_ENCODING)"
- "Mux Extraction (MUX\_EXTRACT)"
- "Register Power Up (REGISTER\_POWERUP)"
- "Resource Sharing (RESOURCE\_SHARING)"
- "Safe Recovery State (SAFE\_RECOVERY\_STATE)"
- "Safe Implementation (SAFE\_IMPLEMENTATION)"
- "Signal Encoding (SIGNAL\_ENCODING)"

# About XST HDL Constraints

The constraints described in this section apply to FPGA devices, CPLD devices, VHDL, and Verilog. Most of the constraints can be set globally in **Project Navigator > Process Properties > HDL Options**. The only constraints that cannot be set in Process Properties are:

- "Enumerated Encoding (ENUM\_ENCODING)"
- "Safe Recovery State (SAFE\_RECOVERY\_STATE)"
- "Signal Encoding (SIGNAL\_ENCODING)"

# Automatic FSM Extraction (FSM\_EXTRACT)

Automatic FSM Extraction (FSM\_EXTRACT) enables or disables finite state machine extraction and specific synthesis optimizations. In order to set values for the FSM Encoding Algorithm and FSM Flip-Flop Type, Automatic FSM Extraction must be enabled.

# Automatic FSM Extraction Architecture Support

Automatic FSM Extraction is architecture independent.

#### Automatic FSM Extraction Applicable Elements

Automatic FSM Extraction applies globally, or to a VHDL entity, Verilog module, or signal

# Automatic FSM Extraction Propagation Rules

Automatic FSM Extraction applies to the entity, module, or signal to which it is attached.

# Automatic FSM Extraction Syntax Examples

Following are syntax examples using Automatic FSM Extraction with particular tools or methods. If a tool or method is not listed, Automatic FSM Extraction may not be used with it.

Automatic FSM Extraction VHDL Syntax Example

Before using Automatic FSM Extraction, declare it with the following syntax:

attribute fsm\_extract: string;

After declaring Automatic FSM Extraction, specify the VHDL constraint:

attribute fsm\_extract of {entity\_name|signal\_name}: {entity|signal} is
"{yes|no}";

Automatic FSM Extraction Verilog Syntax Example

Place Automatic FSM Extraction immediately before the module or signal declaration:

(\* fsm\_extract = "{yes | no}" \*)

Automatic FSM Extraction XCF Syntax Example One

**MODEL** "entity\_name" **fsm\_extract=**{**yes** | **no** | **true** | **false**};

Automatic FSM Extraction XCF Syntax Example Two

```
BEGIN MODEL "entity_name"
NET "signal_name" fsm_extract={yes|no|true|false};
END;
```

Automatic FSM Extraction XST Command Line Syntax Example

Define Automatic FSM Extraction globally with the **-fsm\_extract** command line option of the **run** command:

-fsm\_extract {yes | no}

The default is **yes**.

Automatic FSM Extraction Project Navigator Syntax Example

Set Automatic FSM Extraction (-fsm\_extract) and FSM Encoding (-fsm\_encoding) options in Project Navigator > Process Properties > HDL Options > FSM Encoding Algorithm. These options are:

- If FSM Encoding Algorithm is set to None, and -fsm\_extract is set to no, fsm\_encoding does not influence synthesis.
- In all other cases, -fsm\_extract is set to yes, and -fsm\_encoding is set to the selected value. For more information about -fsm\_encoding, see "FSM Encoding Algorithm (FSM\_ENCODING)."

# Enumerated Encoding (ENUM\_ENCODING)

Enumerated Encoding (ENUM\_ENCODING) applies a specific encoding to a VHDL enumerated type. The value is a string containing space-separated binary codes. You can specify Enumerated Encoding only as a VHDL constraint on the considered enumerated type.

When describing a Finite State Machine (FSM) using an enumerated type for the state register, you may specify a particular encoding scheme with Enumerated Encoding. In order for this encoding to be used by XST, set "FSM Encoding Algorithm (FSM\_ENCODING)" to **user** for the considered state register.

#### Enumerated Encoding Architecture Support

Enumerated Encoding is architecture independent.

#### Enumerated Encoding Applicable Elements

Enumerated Encoding applies to a type or signal.

Because Enumerated Encoding must preserve the external design interface, XST ignores Enumerated Encoding when it is used on a port.

#### Enumerated Encoding Propagation Rules

Enumerated Encoding applies to the type or signal to which it is attached.

#### Enumerated Encoding Syntax Examples

Following are syntax examples using Enumerated Encoding with particular tools or methods. If a tool or method is not listed, Enumerated Encoding may not be used with it.

Enumerated Encoding VHDL Syntax Example

Specify Enumerated Encoding as a VHDL constraint on the considered enumerated type:

```
...
architecture behavior of example is
type statetype is (ST0, ST1, ST2, ST3);
attribute enum_encoding of statetype : type is "001 010 100 111";
signal state1 : statetype;
signal state2 : statetype;
begin
...
```

Enumerated Encoding XCF Syntax Example

```
BEGIN MODEL "entity_name"
NET "signal_name" enum_encoding="string";
END;
```

# Equivalent Register Removal (EQUIVALENT\_REGISTER\_REMOVAL)

Equivalent Register Removal (EQUIVALENT\_REGISTER\_REMOVAL) enables or disables removal of equivalent registers described at the RTL Level. By default, XST does not remove equivalent flip-flops if they are instantiated from a Xilinx<sup>®</sup> primitive library. Flip-flop optimization includes removing:

- Equivalent flip-flops for FPGA and CPLD devices
- Flip-flops with constant inputs for CPLD devices

This processing increases the fitting success as a result of the logic simplification implied by the flip-flops elimination.

Equivalent Register Removal values are:

• **yes** (default)

Flip-flop optimization is allowed.

• no

Flip-flop optimization is inhibited. The flip-flop optimization algorithm is time consuming. For fast processing, use **no**.

- true (XCF only)
- false (XCF only)

#### Equivalent Register Removal Architecture Support

Equivalent Register Removal is architecture independent.

#### Equivalent Register Removal Applicable Elements

Equivalent Register Removal applies globally, or to an entity, module, or signal.

#### Equivalent Register Removal Propagation Rules

Equivalent Register Removal removes equivalent flip-flops and flip-flops with constant inputs.

## Equivalent Register Removal Syntax Examples

Following are syntax examples using Equivalent Register Removal with particular tools or methods. If a tool or method is not listed, Equivalent Register Removal may not be used with it.

Equivalent Register Removal VHDL Syntax Example

Before using Equivalent Register Removal, declare it with the following syntax:

attribute equivalent\_register\_removal: string;

After declaring Equivalent Register Removal, specify the VHDL constraint:

```
attribute equivalent_register_removal of {entity_name|signal_name}:
{signal|entity} is "{yes|no}";
```

Equivalent Register Removal Verilog Syntax Example

Place Equivalent Register Removal immediately before the module or signal declaration:

(\* equivalent\_register\_removal = "{yes | no}" \*)

Equivalent Register Removal XCF Syntax Example One

```
MODEL "entity_name" equivalent_register_removal={yes|no|true|false};
```

Equivalent Register Removal XCF Syntax Example Two

**BEGIN MODEL** "entity\_name"

**NET** "signal\_name" equivalent\_register\_removal={yes|no|true|false};

END;

Equivalent Register Removal XST Command Line Syntax Example

Define Equivalent Register Removal globally with the – equivalent\_register\_removal command line option of the run command:

-equivalent\_register\_removal {yes | no}

The default is **yes**.

Equivalent Register Removal Project Navigator Syntax Example

Define Equivalent Register Removal globally in **Project Navigator > Process Properties > Xilinx-Specific Options > Equivalent Register Removal**.

# FSM Encoding Algorithm (FSM\_ENCODING)

FSM Encoding Algorithm (FSM\_ENCODING) selects the finite state machine coding technique. In order to select a value for the FSM Encoding Algorithm, Automatic FSM Extraction must be enabled.

FSM Encoding Algorithm values are:

- Auto
- One-Hot
- Compact
- Sequential
- Gray
- Johnson



- Speed1
- User

FSM Encoding Algorithm defaults to **auto**. The best coding technique is automatically selected for each individual state machine.

## FSM Encoding Algorithm Architecture Support

FSM Encoding Algorithm is architecture independent.

## FSM Encoding Algorithm Applicable Elements

FSM Encoding Algorithm applies globally, or to a VHDL entity, Verilog module, or signal.

#### FSM Encoding Algorithm Propagation Rules

FSM Encoding Algorithm applies to the entity, module, or signal to which it is attached.

# FSM Encoding Algorithm Syntax Examples

Following are syntax examples using FSM Encoding Algorithm with particular tools or methods. If a tool or method is not listed, FSM Encoding Algorithm may not be used with it.

FSM Encoding Algorithm VHDL Syntax Example

Before using FSM Encoding Algorithm, declare it with the following syntax:

attribute fsm\_encoding: string;

After declaring FSM Encoding Algorithm, specify the VHDL constraint:

```
attribute fsm_encoding of {entity_name|signal_name}: {entity|signal} is
    "{auto|one-hot
    |compact|sequential|gray|johnson|speed1|user}";
```

The default is **auto**.

FSM Encoding Algorithm Verilog Syntax Example

Place FSM Encoding Algorithm immediately before the module or signal declaration:

The default is **auto**.

FSM Encoding Algorithm XCF Syntax Example One

FSM Encoding Algorithm XCF Syntax Example Two

BEGIN MODEL "entity\_name"

```
NET "signal_name" fsm_encoding={auto|one-hot
|compact|sequential|gray|johnson|speed1|user};
```

END;

FSM Encoding Algorithm XST Command Line Syntax Example

Define FSM Encoding Algorithm globally with the **-fsm\_encoding** command line option of the **run** command:

```
-fsm_encoding {auto|one-hot
|compact|sequential|gray|johnson|speed1|user}
```

The default is **auto**.

FSM Encoding Algorithm Project Navigator Syntax Example

Set FSM Encoding (-fsm\_encoding) and Automatic FSM Extraction (-fsm\_extract) options in Project Navigator > Process Properties > HDL Options > FSM Encoding Algorithm.

These options are:

- If the FSM Encoding Algorithm menu is set to None, and -fsm\_extract is set to no, -fsm\_encoding has no influence on the synthesis.
- In all other cases, -fsm\_extract is set to yes and -fsm\_encoding is set to the value selected in the menu. For more information, see "Automatic FSM Extraction (FSM\_EXTRACT)"

## Mux Extraction (MUX\_EXTRACT)

Mux Extraction (MUX\_EXTRACT) enables or disables multiplexer macro inference.

Mux Extraction values are:

- yes
- no
- force
- true (XCF only)
- **false** (XCF only)

By default, multiplexer inference is enabled (**yes**). For each identified multiplexer description, based on some internal decision rules, XST actually creates a macro or optimizes it with the rest of the logic. The **force** value overrides those decision rules, and forces XST to create the MUX macro.

#### Mux Extraction Architecture Support

Mux Extraction is architecture independent.

## Mux Extraction Applicable Elements

Mux Extraction applies globally, or to a VHDL entity, a Verilog module, or signal.

#### Mux Extraction Propagation Rules

Mux Extraction applies to the entity, module, or signal to which it is attached.

#### Mux Extraction Syntax Examples

Following are syntax examples using Mux Extraction with particular tools or methods. If a tool or method is not listed, Mux Extraction may not be used with it.



Mux Extraction VHDL Syntax Example

Before using Mux Extraction, declare it with the following syntax:

```
attribute mux_extract: string;
```

After declaring Mux Extraction, specify the VHDL constraint:

```
attribute mux_extract of {signal_name|entity_name}: {entity|signal} is
  "{yes|no|force}";
```

The default is **yes**.

Mux Extraction Verilog Syntax Example

Place Mux Extraction immediately before the module or signal declaration:

(\* mux\_extract = "{yes | no | force}" \*)

The default is **yes**.

Mux Extraction XCF Syntax Example One

**MODEL** "entity\_name" mux\_extract={yes | no | true | false | force};

Mux Extraction XCF Syntax Example Two

**BEGIN MODEL** "entity\_name"

```
NET "signal_name" mux_extract={yes|no|true|false|force};
```

END;

Mux Extraction XST Command Line Syntax Example

Define Mux Extraction globally with the **-mux\_extract** command line option of the **run** command:

-mux\_extract {yes | no | force}

The default is **yes**.

Mux Extraction Project Navigator Syntax Example

Define Mux Extraction globally in **Project Navigator > Process Properties > HDL Options**.

## Register Power Up (REGISTER\_POWERUP)

XST does not automatically calculate and enforce register power-up values. You must explicitly specify them if needed using Register Power Up (REGISTER\_POWERUP). This XST synthesis constraint can be assigned to a VHDL enumerated type, or it may be directly attached to a VHDL signal or a Verilog register node through a VHDL attribute or Verilog meta comment. The value may be a binary string or a symbolic code value.

#### Register Power Up Architecture Support

Register Power Up applies to the following devices only:

- All CPLD devices
- Spartan-3A

## Register Power Up Applicable Elements

Register Power Up applies to signals and types.

## **Register Power Up Propagation Rules**

Register Power Up applies to the signal or type to which it is attached.

## Register Power Up Syntax Examples

Following are syntax examples using Register Power Up with particular tools or methods. If a tool or method is not listed, Register Power Up may not be used with it.

#### Register Power Up VHDL Syntax Example One

The register is defined with a predefined VHDL type such as **std\_logic\_vector**. The Register Power Up value is necessarily a binary code.

```
signal myreg : std_logic_vector (3 downto 0);
attribute register_powerup of myreg : signal is "0001";
```

Register Power Up VHDL Syntax Example Two

The register is defined with an enumerated type (symbolic state machine). Register Power Up is attached to the signal and its value is one of the symbolic states defined. Actual power-up code differs depending on how the state machine is encoded.

```
type state_type is (s1, s2, s3, s4, s5);
signal state1 : state_type;
```

Register Power Up VHDL Syntax Example Three

Register Power Up is attached to an enumerated type. All registers defined with that type inherit the constraint.

```
type state_type is (s1, s2, s3, s4, s5);
attribute register_powerup of state_type : type is "s1";
signal state1, state2 : state_type;
```

Register Power Up VHDL Syntax Example Four

For enumerated type objects, the power-up value may also be defined as a binary code. However, if automatic encoding is enabled and leads to a different encoding scheme (in particular a different code width), the power-up value is ignored.

```
type state_type is (s1, s2, s3, s4, s5);
attribute enum_encoding of state_type : type is "001 011 010 100 111";
attribute register_powerup of state_type : type is "100";
signal state1 : state_type;
```

Register Power Up Verilog Syntax Example

Place Register Power Up immediately before the signal declaration:

```
(* register_powerup = "<value>" *)
```

Register Power Up XCF Syntax Example

```
BEGIN MODEL "entity_name"
NET "signal_name" register_powerup="string";
```

END;



## **Resource Sharing (RESOURCE\_SHARING)**

Resource Sharing (RESOURCE\_SHARING) enables or disables resource sharing of arithmetic operators.

Resource Sharing values are:

- **yes** (default)
- no
- force
- true (XCF only)
- false (XCF only)

### **Resource Sharing Architecture Support**

Resource Sharing is architecture independent.

## **Resource Sharing Applicable Elements**

Resource Sharing applies globally, or to design elements.

### **Resource Sharing Propagation Rules**

Resource Sharing applies to the entity or module to which it is attached.

## **Resource Sharing Syntax Examples**

Following are syntax examples using Resource Sharing with particular tools or methods. If a tool or method is not listed, Resource Sharing may not be used with it.

Resource Sharing VHDL Syntax Example

Before using Resource Sharing declare it with the following syntax:

attribute resource\_sharing: string;

After declaring Resource Sharing, specify the VHDL constraint:

```
attribute resource_sharing of entity_name: entity is "{yes | no}";
```

**Resource Sharing Verilog Syntax Example** 

Place Resource Sharing immediately before the module declaration or instantiation:

```
(* resource_sharing = "{yes | no}" *)
```

Resource Sharing XCF Syntax Example One

**MODEL** "entity\_name" resource\_sharing={yes | no | true | false};

Resource Sharing XCF Syntax Example Two

**BEGIN MODEL** "entity\_name"

```
NET "signal_name" resource_sharing={yes|no|true|false};
END;
```

Resource Sharing XST Command Line Syntax Example

Define Resource Sharing globally with the **-resource\_sharing** command line option of the **run** command:

-resource\_sharing {yes | no}

The default is **yes**.

Resource Sharing Project Navigator Syntax Example

Define Resource Sharing globally in **Project Navigator > HDL Options > Resource Sharing**.

# Safe Recovery State (SAFE\_RECOVERY\_STATE)

Safe Recovery State (SAFE\_RECOVERY\_STATE) defines a recovery state for use when a finite state machine (FSM) is implemented in Safe Implementation mode. If the FSM enters an invalid state, XST uses additional logic to force the FSM to a valid recovery state. By implementing FSM in safe mode, XST collects all code not participating in the normal FSM behavior and treats it as illegal.

XST uses logic that returns the FSM synchronously to the:

- Known state
- Reset state
- Power up state
- State you specified using SAFE\_RECOVERY\_STATE

For more information, see "Safe Implementation (SAFE\_IMPLEMENTATION)."

### Safe Recovery State Architecture Support

Safe Recovery State is architecture independent.

#### Safe Recovery State Applicable Elements

Safe Recovery State applies to a signal representing a state register.

#### Safe Recovery State Propagation Rules

Safe Recovery State applies to a signal to which it is attached.

#### Safe Recovery State Syntax Examples

Following are syntax examples using Safe Recovery State with particular tools or methods. If a tool or method is not listed, Safe Recovery State may not be used with it.

#### Safe Recovery State VHDL Syntax Example

Before using Safe Recovery State, declare it with the following syntax:

attribute safe\_recovery\_state: string;

After declaring Safe Recovery State, specify the VHDL constraint:

attribute safe\_recovery\_state of {signal\_name}:{signal} is "<value>";



Safe Recovery State Verilog Syntax Example

Place Safe Recovery State immediately before the signal declaration:

```
(* safe_recovery_state = "<value>" *)
```

Safe Recovery State XCF Syntax Example

```
BEGIN MODEL "entity_name"
NET "signal_name" safe_recovery_state="<value>";
END;
```

## Safe Implementation (SAFE\_IMPLEMENTATION)

Safe Implementation (SAFE\_IMPLEMENTATION) implements finite state machines (FSMs) in Safe Implementation mode. In Safe Implementation mode, XST generates additional logic that forces an FSM to a valid state (recovery state) if the FSM enters an invalid state. By default, XST automatically selects **reset** as the recovery state. If the FSM does not have an initialization signal, XST selects **power-up** as the recovery state.

Define the recovery state manually with "Safe Recovery State (SAFE\_RECOVERY\_STATE)."

To activate Safe Implementation in:

Project Navigator

Select Project Navigator > Process Properties > HDL Options > Safe Implementation.

• HDL

Apply Safe Implementation (SAFE\_IMPLEMENTATION) to the hierarchical block or signal that represents the state register in the FSM.

### Safe Implementation Architecture Support

Safe Implementation is architecture independent.

#### Safe Implementation Applicable Elements

Safe Implementation applies to an entire design through the XST command line, to a particular block (entity, architecture, component), or to a signal.

#### Safe Implementation Propagation Rules

Safe Implementation applies to an entity, component, module, or signal to which it is attached.

#### Safe Implementation Syntax Examples

Following are syntax examples using Safe Implementation with particular tools or methods. If a tool or method is not listed, Safe Implementation, may not be used with it.

Safe Implementation VHDL Syntax Example

Before using Safe Implementation, declare it with the following syntax:

attribute safe\_implementation: string;

After declaring Safe Implementation, specify the VHDL constraint:

```
attribute safe_implementation of
{entity_name|component_name|signal_name}: {entity|component|signal} is
"{yes|no}";
```

Safe Implementation Verilog Syntax Example

Place Safe Implementation immediately before the module or signal declaration:

(\* safe\_implementation = "{yes | no}" \*)

Safe Implementation XCF Syntax Example One

```
MODEL "entity_name" safe_implementation={yes|no|true|false};
```

Safe Implementation XCF Syntax Example Two

```
BEGIN MODEL "entity_name"
NET "signal_name" safe_implementation={yes|no|true|false};
```

END;

Safe Implementation XST Command Line Syntax Example

Define Safe Implementation globally with the **-safe\_implementation** command line option of the **run** command:

-safe\_implementation {yes | no}

The default is **no**.

Safe Implementation Project Navigator Syntax Example

Define Safe Implementation globally in **Project Navigator > HDL Options >Safe Implementation**.

## Signal Encoding (SIGNAL\_ENCODING)

Signal Encoding (SIGNAL\_ENCODING) selects the coding technique to use for internal signals.

Signal Encoding values are:

auto

The default. The best coding technique is automatically selected for each individual signal.

one-hot

Forces the encoding to a one-hot encoding

user

Forces XST to keep your encoding

#### Signal Encoding Architecture Support

Signal Encoding is architecture independent.

#### Signal Encoding Applicable Elements

Signal Encoding applies globally, or to a VHDL entity, Verilog module, or signal.



## Signal Encoding Propagation Rules

Signal Encoding applies to the entity, module, or signal to which it is attached.

## Signal Encoding Syntax Examples

Following are syntax examples using Signal Encoding with particular tools or methods. If a tool or method is not listed, Signal Encoding may not be used with it.

Signal Encoding VHDL Syntax Example

Before using Signal Encoding, declare it with the following syntax:

```
attribute signal_encoding: string;
```

After declaring Signal Encoding, specify the VHDL constraint:

```
attribute signal_encoding of
{component_name|signal_name|entity_name|label_name}:
{component|signal|entity|label} is "{auto|one-hot|user}";
```

The default is **auto**.

Signal Encoding Verilog Syntax Example

Place Signal Encoding immediately before the signal declaration:

(\* signal\_encoding = "{auto|one-hot|user}" \*)

The default is **auto**.

Signal Encoding XCF Syntax Example One

**MODEL** "entity\_name" signal\_encoding = {auto one-hot user};

Signal Encoding XCF Syntax Example Two

```
BEGIN MODEL "entity_name"
NET "signal_name" signal_encoding = {auto|one-hot|user};
END;
```

Signal Encoding XST Command Line Syntax Example

Define Signal Encoding globally with the **-signal\_encoding** command line option of the **run** command:

-signal\_encoding {auto|one-hot|user}

The default is **auto**.

# XST FPGA Constraints (Non-Timing)

This section describes FPGA Hardware Description Language (HDL) options. These options apply *only* to FPGA devices. These options do *not* apply to CPLD devices.

In many cases, a particular constraint can be applied globally to an entire entity or model, or alternatively, it can be applied locally to individual signals, nets or instances. See Table 5-1, "XST-Specific Non-Timing Options," and Table 5-2, "XST-Specific Non-Timing Options: XST Command Line Only," for valid constraint targets.

Automatic Incremental Synthesis (**-automatic\_incremental\_synthesis**) instructs XST to automatically run in incremental synthesis mode. In this mode, XST recompiles

only the modules that have changed since the last compile. Use the **no** value to recompile the entire design.

Define Automatic Incremental Synthesis globally with the – automatic\_incremental\_synthesis option of the run command. Following is the basic syntax:

-automatic\_incremental\_synthesis {yes | no}

The default is **yes**.

Set Automatic Incremental Synthesis globally in **Project Navigator > Process Properties > Synthesis Options > Automatic Incremental Synthesis**.

This section discusses the following constraints:

- "Asynchronous to Synchronous (ASYNC\_TO\_SYNC)"
- "Automatic BRAM Packing (AUTO\_BRAM\_PACKING)"
- "BRAM Utilization Ratio (BRAM\_UTILIZATION\_RATIO)"
- "Buffer Type (BUFFER\_TYPE)"
- "Extract BUFGCE (BUFGCE)"
- "Cores Search Directories (-sd)"
- "Decoder Extraction (DECODER\_EXTRACT)"
- "DSP Utilization Ratio (DSP\_UTILIZATION\_RATIO)"
- "FSM Style (FSM\_STYLE)"
- "Power Reduction (POWER)"
- "Read Cores (READ\_CORES)"
- "Resynthesize (RESYNTHESIZE)"
- "Incremental Synthesis (INCREMENTAL\_SYNTHESIS)"
- "Logical Shifter Extraction (SHIFT\_EXTRACT)"
- "LUT Combining (LC)"
- "Map Logic on BRAM (BRAM\_MAP)"
- "Max Fanout (MAX\_FANOUT)"
- "Move First Stage (MOVE\_FIRST\_STAGE)"
- "Move Last Stage (MOVE\_LAST\_STAGE)"
- "Multiplier Style (MULT\_STYLE)"
- "Mux Style (MUX\_STYLE)"
- "Number of Global Clock Buffers (-bufg)"
- "Number of Regional Clock Buffers (-bufr)"
- "Optimize Instantiated Primitives (OPTIMIZE\_PRIMITIVES)"
- "Pack I/O Registers Into IOBs (IOB)"
- "Priority Encoder Extraction (PRIORITY\_EXTRACT)"
- "RAM Extraction (RAM\_EXTRACT)"
- "RAM Style (RAM\_STYLE)"
- "Reduce Control Sets (REDUCE\_CONTROL\_SETS)"
- "Register Balancing (REGISTER\_BALANCING)"
- "Register Duplication (REGISTER\_DUPLICATION)"

- "ROM Extraction (ROM\_EXTRACT)"
- "ROM Style (ROM\_STYLE)"
- "Shift Register Extraction (SHREG\_EXTRACT)"
- "Slice Packing (-slice\_packing)"
- "Use Low Skew Lines (USELOWSKEWLINES)"
- "XOR Collapsing (XOR\_COLLAPSE)"
- "Slice (LUT-FF Pairs) Utilization Ratio (SLICE\_UTILIZATION\_RATIO)"
- "Slice (LUT-FF Pairs) Utilization Ratio Delta (SLICE\_UTILIZATION\_RATIO\_MAXMARGIN)"
- "Map Entity on a Single LUT (LUT\_MAP)"
- "Use Carry Chain (USE\_CARRY\_CHAIN)"
- "Convert Tristates to Logic (TRISTATE2LOGIC)"
- "Use Clock Enable (USE\_CLOCK\_ENABLE)"
- "Use Synchronous Set (USE\_SYNC\_SET)"
- "Use Synchronous Reset (USE\_SYNC\_RESET)"
- "Use DSP48 (USE\_DSP48)"

## Asynchronous to Synchronous (ASYNC\_TO\_SYNC)

Asynchronous to Synchronous (ASYNC\_TO\_SYNC) allows you to replace Asynchronous Set/Reset signals with Synchronous signals throughout the entire design. This allows absorption of registers by DSP48 and BRAMs, thereby improving quality of results. In addition, this feature may have a positive impact on power optimization.

Although XST can place FSMs on BRAMs, in most cases an FSM has an Asynchronous Set/Reset signal, which does not allow FSM implementation on BRAMs. ASYNC\_TO\_SYNC allows you to more easily place FSMs on BRAMs, by eliminating the need to manually change the design.

Replacing Asynchronous Set/Reset signals by Synchronous signals makes the generated NGC netlist NOT equivalent to the initial RTL description. You must ensure that the synthesized design satisfies the initial specification. XST issues the following warning:

WARNING: You have requested that asynchronous control signals of sequential elements be treated as if they were synchronous. If you haven't done so yet, please carefully review the related documentation material. If you have opted to asynchronously control flip-flop initialization, this feature allows you to better explore the possibilities offered by the Xilinx solution without having to go through a painful rewriting effort. However, be well aware that the synthesis result, while providing you with a good way to assess final device usage and design performance, is not functionally equivalent to your HDL description. As a result, you will not be able to validate your design by comparison of pre-synthesis and post-synthesis simulation results. Please also note that in general we strongly recommend synchronous flip-flop initialization.

## Asynchronous to Synchronous Architecture Support

Asynchronous to Synchronous applies to all FPGA devices. Asynchronous to Synchronous does not apply to CPLD devices.

## Asynchronous to Synchronous Applicable Elements

Asynchronous to Synchronous applies to the entire design.

## Asynchronous to Synchronous Propagation Rules

Not applicable

## Asynchronous to Synchronous Syntax Examples

Following are syntax examples using Asynchronous to Synchronous with particular tools or methods. If a tool or method is not listed, Asynchronous to Synchronous may not be used with it.

#### Asynchronous to Synchronous XST Command Line Syntax Example

Define Asynchronous to Synchronous globally with the **-async\_to\_sync** command line option of the **run** command:

-async\_to\_sync {yes no}

The default is **no**.

Asynchronous to Synchronous Project Navigator Syntax Example

Define Asynchronous to Synchronous globally with **Project Navigator > Process Properties > HDL Options > Asynchronous to Synchronous.** 

## Automatic BRAM Packing (AUTO\_BRAM\_PACKING)

Automatic BRAM Packing (AUTO\_BRAM\_PACKING) allows you to pack two small BRAMs in a single BRAM primitive as dual-port BRAM. XST packs BRAMs together only if they are situated in the same hierarchical level.

### Automatic BRAM Packing Architecture Support

Automatic BRAM Packing applies to all FPGA devices. Automatic BRAM Packing does not apply to CPLD devices.

### Automatic BRAM Packing Applicable Elements

Automatic BRAM Packing applies to the entire design.

#### Automatic BRAM Packing Propagation Rules

Not applicable

### Automatic BRAM Packing Syntax Examples

Following are syntax examples using Automatic BRAM Packing with particular tools or methods. If a tool or method is not listed, Automatic BRAM Packing may not be used with it.

#### Automatic BRAM Packing XST Command Line Syntax Example

Define Automatic BRAM Packing globally with the **-auto\_bram\_packing** command line option of the **run** command:

-auto\_bram\_packing {yes | no}



The default is **no**.

Automatic BRAM Packing Project Navigator Syntax Example

Define Automatic BRAM Packing globally with **Project Navigator** > **Process Properties** > **Automatic BRAM Packing**.

# BRAM Utilization Ratio (BRAM\_UTILIZATION\_RATIO)

BRAM Utilization Ratio (BRAM\_UTILIZATION\_RATIO) defines the number of BRAM blocks that XST must not exceed during synthesis. BRAMs in the design may come not only from BRAM inference processes, but from instantiation and BRAM mapping optimizations. You may isolate an RTL description of logic in a separate block, and then ask XST to map this logic to BRAM. For more information, see "Mapping Logic Onto Block RAM."

Instantiated BRAMs are the primary candidates for available BRAM resources. The inferred RAMs are placed on the remaining BRAM resources. However, if the number of instantiated BRAMs exceeds the number of available resources, XST does not modify the instantiations and implement them as block RAMs. The same behavior occurs if you force specific RAMs to be implemented as BRAMs. If there are no resources, XST respects user constraints, even if the number of BRAM resources is exceeded.

If the number of user-specified BRAMs exceeds the number of available BRAM resources on the target FPGA device, XST issues a warning, and uses only available BRAM resources on the chip for synthesis. However, you may disable automatic BRAM resource management by using value **-1**. This can be used to see the number of BRAMs XST can potentially infer for a specific design.

You may experience significant synthesis time if the number of BRAMs in the design significantly exceeds the number of available BRAMs on the target FPGA device (hundreds of BRAMs). This may happen due to a significant increase in design complexity when all non-fittable BRAMs are converted to distributed RAMs.

### **BRAM Utilization Ratio Architecture Support**

BRAM Utilization Ratio applies to all FPGA devices. BRAM Utilization Ratio does not apply to CPLD devices.

#### **BRAM Utilization Ratio Applicable Elements**

BRAM Utilization Ratio applies to the entire design.

#### BRAM Utilization Ratio Propagation Rules

Not applicable

### BRAM Utilization Ratio Syntax Examples

Following are syntax examples using BRAM Utilization Ratio with particular tools or methods. If a tool or method is not listed, BRAM Utilization Ratio may not be used with it.

BRAM Utilization Ratio XST Command Line Syntax Examples

Define BRAM Utilization Ratio globally with the **-bram\_utilization\_ratio** command line option of the **run** command:

```
-bram_utilization_ratio <integer>[%][#]
```

where

<integer> range is [-1 to 100] when % is used or both % and # are omitted

The default is **100**.

BRAM Utilization Ratio XST Command Line Syntax Example One

-bram\_utilization\_ratio 50

means 50% of BRAMs blocks in the target device

BRAM Utilization Ratio XST Command Line Syntax Example Two

-bram\_utilization\_ratio 50%

means 50% of BRAMs blocks in the target device

BRAM Utilization Ratio XST Command Line Syntax Example Three

-bram\_utilization\_ratio 50#

means 50 BRAMs blocks

There must be no space between the integer value and the percent (%) or pound (#) characters.

In some situations, you can disable automatic BRAM resource management (for example, to see how many BRAMs XST can potentially infer for a specific design). To disable automatic resource management, specify **-1** (or any negative value) as a constraint value.

BRAM Utilization Ratio Project Navigator Syntax Example

Define globally in **Project Navigator > Process Properties > Synthesis Options > BRAM Utilization Ratio**.

In Project Navigator, you can define the value of BRAM Utilization Ratio only as a percentage. The definition of the value in the form of absolute number of BlockRAMs is not supported.

## Buffer Type (BUFFER\_TYPE)

Buffer Type (BUFFER\_TYPE) is a new name for CLOCK\_BUFFER. Since CLOCK\_BUFFER will become obsolete in future releases, Xilinx recommends that you use this new name. BUFFER\_TYPE selects the type of buffer to be inserted on the input port or internal net. The **bufr** value is supported for Virtex-4 and Virtex-5 devices only.

#### Buffer Type Architecture Support

Buffer Type applies to all FPGA devices. Buffer Type does not apply to CPLD devices.

#### Buffer Type Applicable Elements

Buffer Type applies to signals.



## **Buffer Type Propagation Rules**

Buffer Type applies to the signal to which it is attached.

## Buffer Type Syntax Examples

Following are syntax examples using Buffer Type with particular tools or methods. If a tool or method is not listed, Buffer Type may not be used with it.

Buffer Type VHDL Syntax Example

Before using Buffer Type, declare it with the following syntax:

attribute buffer\_type: string;

After declaring Buffer Type, specify the VHDL constraint:

attribute buffer\_type of signal\_name: signal is
"{bufgdll|ibufg|bufgp|ibuf|bufr|none}";

Buffer Type Verilog Syntax Example

Place Buffer Type immediately before the signal declaration:

```
(* buffer_type = "{bufgdll|ibufg|bufgp|ibuf|bufr|none}" *)
```

Buffer Type XCF Syntax Example

```
BEGIN MODEL "entity_name"
NET "signal_name"
buffer_type={bufgdll|ibufg|bufgp|ibuf|bufr|none};
END;
```

# **Extract BUFGCE (BUFGCE)**

Extract BUFGCE (BUFGCE) implements BUFGMUX functionality by inferring a BUFGMUX primitive. This operation reduces the wiring. Clock and clock enable signals are driven to *n* sequential components by a single wire.

Extract BUFGCE must be attached to the primary clock signal.

Extract BUFGCE values are:

- yes
- no

Extract BUFGCE is accessible through Hardware Description Language (HDL) code. If **bufgce=yes**, XST implements BUFGMUX functionality if possible. All flip-flops must have the same clock enable signal.

#### Extract BUFGCE Architecture Support

Extract BUFGCE applies to the following FPGA devices only:

- Spartan-3
- Spartan-3E
- Spartan-3A
- Spartan-3A D
- Virtex-II

- Virtex-II Pro
- Virtex-4
- Virtex-5

Extract BUFGCE does not apply to CPLD devices.

## **Extract BUFGCE Applicable Elements**

Extract BUFGCE applies to clock signals.

## **Extract BUFGCE Propagation Rules**

Extract BUFGCE applies to the signal to which it is attached.

## Extract BUFGCE Syntax Examples

Following are syntax examples using Extract BUFGCE with particular tools or methods. If a tool or method is not listed, Extract BUFGCE may not be used with it.

Extract BUFGCE VHDL Syntax Example

Before using Extract BUFGCE, declare it with the following syntax:

attribute bufgce : string;

After declaring Extract BUFGCE, specify the VHDL constraint:

attribute bufgce of signal\_name: signal is "{yes|no}";

Extract BUFGCE Verilog Syntax Example

Place Extract BUFGCE immediately before the signal declaration:

(\* bufgce = "{yes | no}" \*)

Extract BUFGCE XCF Syntax Example

```
BEGIN MODEL "entity_name"
NET "primary_clock_signal" bufgce={yes | no | true | false};
```

END;

## **Cores Search Directories (-sd)**

Cores Search Directories (-sd) tells XST to look for cores in directories other than the default. By default XST searches for cores in the directory specified in the -ifn option.

## Cores Search Directories Architecture Support

Cores Search Directories applies to all FPGA devices. Cores Search Directories does not apply to CPLD devices.

### Cores Search Directories Applicable Elements

Cores Search Directories applies globally.

### **Cores Search Directories Propagation Rules**

Not applicable



## Cores Search Directories Syntax Examples

Following are syntax examples using Cores Search Directories with particular tools or methods. If a tool or method is not listed, Cores Search Directories may not be used with it.

#### Cores Search Directories XST Command Line Syntax Example

Define Cores Search Directories globally with the **-sd** command line option of the **run** command. Allowed values are names of directories. For more information, see "Names With Spaces in Command Line Mode."

-sd {directory\_path [directory\_path]}

There is no default.

Cores Search Directories Project Navigator Syntax Example

Define Cores Search Directories globally in **Project Navigator > Process Properties > Synthesis Options > Cores Search Directory**.

## **Decoder Extraction (DECODER\_EXTRACT)**

Decoder Extraction (DECODER\_EXTRACT) enables or disables decoder macro inference.

#### Decoder Extraction Architecture Support

Decoder Extraction applies to all FPGA devices. Decoder Extraction does not apply to CPLD devices.

#### Decoder Extraction Applicable Elements

Decoder Extraction applies globally or to an entity, module or signal.

#### Decoder Extraction Propagation Rules

When attached to a net or signal, Decoder Extraction applies to the attached signal.

When attached to an entity or module, Decoder Extraction is propagated to all applicable elements in the hierarchy within the entity or module.

#### Decoder Extraction Syntax Examples

Following are syntax examples using Decoder Extraction with particular tools or methods. If a tool or method is not listed, Decoder Extraction may not be used with it.

Decoder Extraction VHDL Syntax Example

Before using Decoder Extraction, declare it with the following syntax:

attribute decoder\_extract: string;

After declaring Decoder Extraction, specify the VHDL constraint:

```
attribute decoder_extract of {entity_name|signal_name}:
{entity|signal} is "{yes|no}";
```

Decoder Extraction Verilog Syntax Example

Place Decoder Extraction immediately before the module or signal declaration:

```
(* decoder_extract "{yes | no}" *)
```

Decoder Extraction XCF Syntax Example One

**MODEL** "entity\_name" decoder\_extract={yes | no | true | false};

Decoder Extraction XCF Syntax Example Two

```
BEGIN MODEL "entity_name"
```

**NET** "signal\_name" decoder\_extract={yes | no | true | false};

END;

Decoder Extraction XST Command Line Syntax Example

Define Decoder Extraction globally with the **-decoder\_extract** command line option of the **run** command:

-decoder\_extract {yes no}

The default is **yes**.

Decoder Extraction Project Navigator Syntax Example

Define Decoder Extraction globally in **Project Navigator > Process Properties > HDL Options > Decoder Extraction**.

Decoder Extraction values are:

- yes (default)
- **no** (check box in not checked)

## DSP Utilization Ratio (DSP\_UTILIZATION\_RATIO)

DSP Utilization Ratio (DSP\_UTILIZATION\_RATIO) defines the number of DSP slices (in absolute number or percent of slices) that XST must not exceed during synthesis optimization. The default is 100% of the target device.

DSP slices in the design may come not only from DSP inference processes, but also from instantiation. Instantiated DSP slices are the primary candidates for available DSP resources. The inferred DSPs are placed on the remaining DSP resources. If the number of instantiated DSPs exceeds the number of available resources, XST does not modify the instantiations and implement them as block DSP slices. The same behavior occurs if you force specific macro implementation to be implemented as DSP slices by using the "Use DSP48 (USE\_DSP48)" constraint. If there are no resources, XST respects user constraints even if the number of DSP slices is exceeded.

If the number of user-specified DSP slices exceeds the number of available DSP resources on the target FPGA device, XST issues a warning, and uses only available DSP resources on the chip for synthesis.

You can disable automatic DSP resource management (for example, to see how many DSPs XST can potentially infer for a specific design) by specifying **-1** (or any negative value) as a constraint value.



## DSP Utilization Ratio Architecture Support

DSP Utilization Ratio applies to the following FPGA devices only:

- Spartan-3A D
- Virtex-4
- Virtex-5

DSP Utilization Ratio does not apply to CPLD devices.

## DSP Utilization Ratio Applicable Elements

DSP Utilization Ratio applies globally.

## DSP Utilization Ratio Propagation Rules

Not applicable

## DSP Utilization Ratio Syntax Examples

Following are syntax examples using DSP Utilization Ratio with particular tools or methods. If a tool or method is not listed, DSP Utilization Ratio may not be used with it.

DSP Utilization Ratio XST Command Line Syntax Example

Define DSP Utilization Ratio globally with the **-dsp\_utilization\_ratio** command line option of the **run** command:

```
-dsp_utilization_ratio number[% | #]
```

where

<integer> range is [-1 to 100] when % is used or the both % and # are omitted.

To specify a percent of total slices use %. To specify an absolute number of slices use **#**. The default is %. For example:

- To specify 50% of DSP blocks of the target device enter the following: -dsp\_utilization\_ratio 50
- To specify 50% of DSP blocks of the target device enter the following: -dsp\_utilization\_ratio 50%
- To specify 50 DSP blocks enter the following:

-dsp\_utilization\_ratio 50#

There must be no space between the integer value and the percent (%) or pound (#) characters.

DSP Utilization Ratio Project Navigator Syntax Example

Define DSP Utilization Ratio globally in **Project Navigator** > **Process Properties** > **Synthesis Options** > **DSP Utilization Ratio**.

In Project Navigator, you can define the value of DSP Utilization Ratio only as a percentage. You can not define the value as an absolute number of slices.

# FSM Style (FSM\_STYLE)

FSM Style (FSM\_STYLE) can make large FSMs more compact and faster by implementing them in the block RAM resources provided in Virtex<sup>™</sup> and later technologies. Use FSM\_STYLE to direct XST to use block RAM resources rather than LUTs (default) to implement FSMs. FSM\_STYLE is both a global and a local constraint.

## FSM Style Architecture Support

FSM Style applies to all FPGA devices. FSM Style does not apply to CPLD devices.

### FSM Style Applicable Elements

FSM Style applies globally, or to a VHDL entity, Verilog module, or signal.

#### FSM Style Propagation Rules

FSM Style applies to the entity, module, or signal to which it is attached.

#### FSM Style Syntax Examples

Following are syntax examples using FSM Style with particular tools or methods. If a tool or method is not listed, FSM Style may not be used with it.

FSM Style VHDL Syntax Example

Before using FSM\_STYLE, declare it with the following syntax:

attribute fsm\_style: string;

After declaring FSM\_STYLE, specify the VHDL constraint:

```
attribute fsm_style of {entity_name|signal_name}: {entity|signal} is
"{lut|bram}";
```

The default is **lut**.

FSM Style Verilog Syntax Example

Place FSM\_STYLE immediately before the instance, module, or signal declaration:

(\* fsm\_style = "{lut | bram}" \*)

FSM Style XCF Syntax Example One

MODEL "entity\_name" fsm\_style = {lut|bram};

FSM Style XCF Syntax Example Two

```
BEGIN MODEL "entity_name"
```

```
NET "signal_name" fsm_style = {lut|bram};
```

END;

FSM Style XCF Syntax Example Three

```
BEGIN MODEL "entity_name"
```

```
INST "instance_name" fsm_style = {lut|bram};
```

END;



FSM Style Project Navigator Syntax Example

Define FSM Style globally in **Project Navigator** > **Process Properties** > **Synthesis Options** > **FSM Style**.

## Power Reduction (POWER)

Power Reduction (POWER) instructs XST to optimize the design to consume as little power as possible. Macro processing decisions are made to implement functions in a manner than uses minimal power. Although Power Reduction is allowed in both AREA and SPEED modes, it may negatively impact the final overall area and speed of the design.

In the current release, power optimization done by XST is dedicated to DSP48 and BRAM blocks.

XST supports two BRAM optimization methods :

- Method One does not significantly impact area and speed. Method One is used by default when power optimization is enabled.
- Method Two saves more power, but may significantly impact area and speed.

Both methods can be controlled by using the "RAM Style (RAM\_STYLE)" constraint with **block\_power1** for Method One and **block\_power2** for Method Two.

In some situations, XST may issue an HDL Advisor message giving you tips on how to improve your design. For example, if XST detects that Read First mode is used for BRAM, XST recommends that you use Write First or No Change modes.

#### Power Reduction Architecture Support

Power Reduction applies to Virtex-4 and Virtex-5 devices only. Power Reduction does not apply to CPLD devices.

#### Power Reduction Applicable Elements

Apply Power Reduction to:

- A component or entity (VHDL)
- A model or label (instance) (Verilog)
- A model or INST (in model) (XCF)
- The entire design (XST command line)

#### Power Reduction Propagation Rules

Power Reduction applies to the entity, module, or signal to which it is attached.

#### Power Reduction Syntax Examples

Following are syntax examples using Power Reduction with particular tools or methods. If a tool or method is not listed, Power Reduction may not be used with it.

Power Reduction VHDL Syntax Example

Before using Power Reduction, declare it with the following syntax:

attribute power: string;

After declaring Power Reduction, specify the VHDL constraint:

```
attribute power of {component name | entity_name} : {component | entity} is
"{yes | no}";
```

The default is **no**.

Power Reduction Verilog Syntax Example

Place Power Reduction immediately before the module declaration or instantiation:

(\* power = "{yes | no}" \*)

The default is **no**.

Power Reduction XCF Syntax Example

```
MODEL "entity_name" power = {yes|no|true|false};
```

The default is **false**.

Power Reduction XST Command Line Syntax Example

Define Power Reduction globally with the **-power** command line option of the **run** command:

-power {yes no}

The default is **no**.

Power Reduction Project Navigator Syntax Example

Specify Power Reduction globally in **Project Navigator > Process Properties >** Synthesis Options > Power Reduction.

## Read Cores (READ\_CORES)

Use Read Cores (READ\_CORES) to enable or disable the ability of XST to read Electronic Data Interchange Format (EDIF) or NGC core files for timing estimation and device utilization control. By reading a specific core, XST is better able to optimize logic around the core, since it sees how the logic is connected. However, in some cases the Read Cores operation must be disabled in XST in order to obtain the desired results. For example, the PCI core must not be visible to XST, since the logic directly connected to the PCI core must be optimized differently as compared to other cores. Read Cores allows you to enable or disable read operations on a core by core basis.

For more information, see "Cores Processing."

Read Cores has three possible values:

no (false)

Disables cores processing

yes (true)

Enables cores processing, but maintains the core as a black box and does not further incorporate the core into the design

optimize

Enables cores processing, and merges the core's netlist into the overall design. This value is available through the XST command line mode only.



## **Read Cores Architecture Support**

Read Cores applies to all FPGA devices. Read Cores does not apply to CPLD devices.

### **Read Cores Applicable Elements**

Since Read Cores can be used with "BoxType (BOX\_TYPE)" the set of objects on which the both constraints can be applied must be the same.

Apply Read Cores to:

- A component or entity (VHDL)
- A model or label (instance) (Verilog)
- A model or INST (in model) (XCF)
- The entire design (XST command line)

If Read Cores is applied to at least a single instance of a block, then Read Cores is applied to all other instances of this block for the entire design.

#### Read Cores Propagation Rules

Not applicable

#### Read Cores Syntax Examples

Following are syntax examples using Read Cores with particular tools or methods. If a tool or method is not listed, Read Cores may not be used with it.

Read Cores VHDL Syntax Example

Before using Read Cores, declare it with the following syntax:

attribute read\_cores: string;

After declaring Read Cores, specify the VHDL constraint:

```
attribute read_cores of {component_name| entity_name} :
{component|entity} is "{yes |no|optimize}";
```

The default is **yes**.

Read Cores Verilog Syntax Example

Place Read Cores immediately before the module declaration or instantiation:

(\* read\_cores = "{yes no optimize}" \*)

The default is **yes**.

Read Cores XCF Syntax Example One

**MODEL** "entity\_name" read\_cores = {yes | no | true | false | optimize };

Read Cores XCF Syntax Example Two

**BEGIN MODEL** "entity\_name"

```
INST "instance_name" read_cores = {yes |no|true|false|optimize};
```

END;

The default is **yes**.

Read Cores XST Command Line Syntax Example

-read\_cores {yes|no|optimize}

Read Cores Project Navigator Syntax Example

Define Read Cores globally in **Project Navigator** > **Process Properties** > **Synthesis Options** > **Read Cores**.

The **optimize** option is not available in Project Navigator.

## **Resynthesize (RESYNTHESIZE)**

Resynthesize (RESYNTHESIZE) forces or prevents resynthesis of groups created by the "Incremental Synthesis (INCREMENTAL\_SYNTHESIS)" constraint.

Resynthesize values are:

- yes
- no
- true (XCF only)
- false (XCF only)

There is no global option.

#### Resynthesize Architecture Support

Resynthesize applies to all FPGA devices. Resynthesize does not apply to CPLD devices.

#### Resynthesize Applicable Elements

Resynthesize applies to design elements only.

#### Resynthesize Propagation Rules

Resynthesize applies to the entity or module to which it is attached.

#### Resynthesize Syntax Examples

Following are syntax examples using Resynthesize with particular tools or methods. If a tool or method is not listed, Resynthesize may not be used with it.

Resynthesize VHDL Syntax Example

Before using Resynthesize declare it with the following syntax:

attribute resynthesize: string;

After declaring Resynthesize, specify the VHDL constraint:

```
attribute resynthesize of entity_name: entity is "{yes no}";
```

Resynthesize Verilog Syntax Example

Place Resynthesize immediately before the module declaration or instantiation:

(\* resynthesize = "{yes no}" \*)

Resynthesize XCF Syntax Example

```
MODEL "entity_name" resynthesize={yes | no};
```

# Incremental Synthesis (INCREMENTAL\_SYNTHESIS)

Incremental Synthesis (INCREMENTAL\_SYNTHESIS) controls the decomposition of a design into several subgroups. This can be applied on a VHDL entity or Verilog module so that XST generates a single and separate NGC file for it and its descendents. For more information, see "Partitions."

Incremental Synthesis is not accessible from **Synthesize** > **XST Process Properties**. Incremental Synthesist is available only through:

- VHDL attributes
- Verilog meta comments
- XST constraint file

## Incremental Synthesis Architecture Support

Incremental Synthesis applies to all FPGA devices. Incremental Synthesis does not apply to CPLD devices.

### Incremental Synthesis Applicable Elements

Incremental Synthesis applies to a VHDL entity or Verilog module.

## Incremental Synthesis Propagation Rules

Incremental Synthesis applies to the entity or module to which it is attached.

## Incremental Synthesis Syntax Examples

Following are syntax examples using Incremental Synthesis with particular tools or methods. If a tool or method is not listed, Incremental Synthesis may not be used with it.

Incremental Synthesis VHDL Syntax Example

Before using Incremental Synthesis declare it with the following syntax:

attribute incremental\_synthesis: string;

After declaring Incremental Synthesis, specify the VHDL constraint:

```
attribute incremental_synthesis of entity_name: entity is "{yes | no}";
```

Incremental Synthesis Verilog Syntax Example

Place Incremental Synthesis immediately before the module declaration or instantiation:

(\* incremental\_synthesis = "{yes|no}" \*)

Incremental Synthesis XCF Syntax Example

**MODEL** "entity\_name" incremental\_synthesis={yes | no};

# Logical Shifter Extraction (SHIFT\_EXTRACT)

Logical Shifter Extraction (SHIFT\_EXTRACT) enables or disables logical shifter macro inference.

Logical Shifter Extraction values are:

- **yes** (default)
- no
- true (XCF only)
- false (XCF only)

## Logical Shifter Extraction Architecture Support

Logical Shifter Extraction applies to all FPGA devices. Logical Shifter Extraction does not apply to CPLD devices.

### Logical Shifter Extraction Applicable Elements

Logical Shifter Extraction applies globally, or to design elements and nets.

### Logical Shifter Extraction Propagation Rules

Logical Shifter Extraction applies to the entity, module, or signal to which it is attached.

### Logical Shifter Extraction Syntax Examples

Following are syntax examples using Logical Shifter Extraction with particular tools or methods. If a tool or method is not listed, Logical Shifter Extraction may not be used with it.

Logical Shifter Extraction VHDL Syntax Example

Before using Logical Shifter Extraction declare it with the following syntax:

attribute shift\_extract: string;

After declaring Logical Shifter Extraction, specify the VHDL constraint:

```
attribute shift_extract of {entity_name|signal_name}: {signal|entity}
is "{yes|no}";
```

Logical Shifter Extraction Verilog Syntax Example

Place Logical Shifter Extraction immediately before the module or signal declaration:

```
(* shift_extract = "{yes | no}" *)
```

Logical Shifter Extraction XCF Syntax Example One

**MODEL** "entity\_name" shift\_extract={yes|no|true|false};

Logical Shifter Extraction XCF Syntax Example Two

```
BEGIN MODEL "entity_name"
```

```
NET "signal_name" shift_extract={yes | no | true | false};
```

END;



Logical Shifter Extraction XST Command Line Syntax Example

Define Logical Shifter Extraction globally with the **-shift\_extract** command line option of the **run** command:

-shift\_extract {yes | no}

The default is **yes**.

Logical Shifter Extraction Project Navigator Syntax Example

Define Logical Shifter Extraction globally **Project Navigator > Process Properties > HDL Options > Logical Shifter Extraction**.

## LUT Combining (LC)

LUT Combining (LC) enables the merging of LUT pairs with common inputs into single dual-output LUT6s in order to improve design area. This optimization process may reduce design speed.

LUT Combining supports three values:

auto

XST tries to make a tradeoff between area and speed.

• area

XST performs maximum LUT combining to provide as small an implementation as possible.

• off

Disables LUT combining.

#### LUT Combining Architecture Support

LUT Combining applies to FPGA Virtex-5 devices only. LUT Combining does not apply to CPLD devices.

#### LUT Combining Applicable Elements

LUT Combining applies globally.

#### LUT Combining Propagation Rules

Not applicable

#### LUT Combining Syntax Examples

Following are syntax examples using LUT Combining with particular tools or methods. If a tool or method is not listed, LUT Combining may not be used with it.

#### LUT Combining XST Command Line Syntax Example

Define LUT Combining globally with the -lc command line option of the run command:

-lc {auto|area|off}

The default is off.

LUT Combining Project Navigator Syntax Example

Define LUT Combining globally in Project Navigator > Process Properties > Xilinx-

Specific Options > LUT Combining.

## Map Logic on BRAM (BRAM\_MAP)

Map Logic on BRAM (BRAM\_MAP) is used to map an entire hierarchical block on the block RAM resources available in Virtex and later technologies.

Map Logic on BRAM values are:

- yes
- no (default)

Map Logic on BRAM is both a global and a local constraint. For more information, see "Mapping Logic Onto Block RAM."

#### Map Logic on BRAM Architecture Support

Map Logic on BRAM applies to all FPGA devices. Map Logic on BRAM does not apply to CPLD devices.

#### Map Logic on BRAM Applicable Elements

Map Logic on BRAM applies to BRAMs.

#### Map Logic on BRAM Propagation Rules

Isolate the logic (including output register) to be mapped on RAM in a separate hierarchical level. Logic that does not fit on a single block RAM is not mapped. Ensure that the whole entity fits, not just part of it.

The attribute BRAM\_MAP is set on the instance or entity. If no block RAM can be inferred, the logic is passed to Global Optimization, where it is optimized. The macros *are not* inferred. Be sure that XST has mapped the logic.

#### Map Logic on BRAM Syntax Examples

Following are syntax examples using Map Logic on BRAM with particular tools or methods. If a tool or method is not listed, Map Logic on BRAM may not be used with it.

Map Logic on BRAM VHDL Syntax Example

Before using Map Logic on BRAM, declare it with the following syntax:

attribute bram\_map: string;

After declaring Map Logic on BRAM, specify the VHDL constraint:

attribute bram\_map of component\_name: component is "{yes|no}";

Map Logic on BRAM Verilog Syntax Example

Place Map Logic on BRAM immediately before the module declaration or instantiation:

(\* bram\_map = "{yes | no}" \*)

Map Logic on BRAM XCF Syntax Example One

```
MODEL "entity_name" bram_map = {yes | no | true | false};
```



Map Logic on BRAM XCF Syntax Example Two

```
BEGIN MODEL "entity_name"
INST "instance_name" bram_map = {yes|no|true|false};
END;
```

## Max Fanout (MAX\_FANOUT)

Max Fanout (MAX\_FANOUT) limits the fanout of nets or signals. The value is an integer. Default values are shown in Table 5-4, "Max Fanout Default Values." Max Fanout is both a global and a local constraint.

Table 5-4: Max Fanout Default Values

Devices	Default Value
Virtex, Virtex-E	100
Spartan-II, Spartan-IIE	100
Spartan-3, Spartan-3E, Spartan-3A, Spartan-3A D	500
Virtex-II, Virtex-II Pro	500
Virtex-4	500
Virtex-5	100000 (One Hundred Thousand)

Large fanouts can cause routability problems. XST tries to limit fanout by duplicating gates or by inserting buffers. This limit is not a technology limit but a guide to XST. It may happen that this limit is not exactly respected, especially when this limit is small (less than 30).

In most cases, fanout control is performed by duplicating the gate driving the net with a large fanout. If the duplication cannot be performed, buffers are inserted. These buffers are protected against logic trimming at the implementation level by defining a "Keep (KEEP)" attribute in the NGC file.

If the register replication option is set to **no**, only buffers are used to control fanout of flipflops and latches.

Max Fanout is global for the design, but you can control maximum fanout independently for each entity or module or for given individual signals by using constraints.

If the actual net fanout is less than the Max Fanout value, XST behavior depends on how Max Fanout is specified.

- If the value of Max Fanout is set in Project Navigator, in the command line, or is attached to a specific hierarchical block, XST interprets its value as a guidance.
- If Max Fanout is attached to a specific net, XST does not perform logic replication. Putting Max Fanout on the net may prevent XST from having better timing optimization.

For example, suppose that the critical path goes through the net, which actual fanout is 80 and set Max Fanout value to 100. If Max Fanout is specified in Project Navigator, XST may replicate it, trying to improve timing. If Max Fanout is attached to the net itself, XST does not perform logic replication.

## Max Fanout Architecture Support

Max Fanout applies to all FPGA devices. Max Fanout does not apply to CPLD devices.

## Max Fanout Applicable Elements

Max Fanout applies globally, or to a VHDL entity, a Verilog module, or signal.

### Max Fanout Propagation Rules

Max Fanout applies to the entity, module, or signal to which it is attached.

#### Max Fanout Syntax Examples

Following are syntax examples using Max Fanout with particular tools or methods. If a tool or method is not listed, Max Fanout may not be used with it.

Max Fanout VHDL Syntax Example

Before using Max Fanout, declare it with the following syntax:

attribute max\_fanout: string;

After declaring Max Fanout, specify the VHDL constraint:

attribute max\_fanout of {signal\_name|entity\_name}: {signal|entity} is
"integer";

Max Fanout Verilog Syntax Example

Place Max Fanout immediately before the module or signal declaration:

(\* max\_fanout = "integer" \*)

Max Fanout XCF Syntax Example One

MODEL "entity\_name" max\_fanout=integer;

Max Fanout XCF Syntax Example Two

BEGIN MODEL "entity\_name"
 NET "signal\_name" max\_fanout=integer;

END;

Max Fanout XST Command Line Syntax Example

Define Max Fanout globally with the **-max\_fanout** command line option of the **run** command:

-max\_fanout integer

Max Fanout Project Navigator Syntax Example

Define globally in **Project Navigator** > **Process Properties** > **Xilinx-Specific Options** > **Max Fanout**.

## Move First Stage (MOVE\_FIRST\_STAGE)

Move First Stage (MOVE\_FIRST\_STAGE) controls the retiming of registers with paths coming from primary inputs. Both Move First Stage constraint and "Move Last Stage (MOVE\_LAST\_STAGE)" relate to Register Balancing.

www.xilinx.com



#### Note:

- A flip-flop (FF in the diagram) belongs to the First Stage if it is on the paths coming from primary inputs.
- A flip-flop belongs to the Last Stage if it is on the paths going to primary outputs.




Figure 5-2: Move First Stage

During register balancing:

- First Stage flip-flops are moved forward
- Last Stage flip-flops are moved backward.

This process can dramatically increase input-to-clock and clock-to-output timing, which is not desirable. To prevent this, you may use OFFSET\_IN\_BEFORE and OFFSET\_IN\_AFTER constraints.

In the case:

- The design does not have a strong requirements, or
- You want to see the first results without touching the first and last flip-flop stages.

Two additional constraints can be used: MOVE\_FIRST\_STAGE and MOVE\_LAST\_STAGE. Both constraints may have two values: **yes** and **no**.

- MOVE\_FIRST\_STAGE=no prevents the first flip-flop stage from moving
- MOVE\_LAST\_STAGE=no prevents the last flip-flop stage from moving

Several constraints influence register balancing. For more information, see "Register Balancing (REGISTER\_BALANCING)."

### Move First Stage Architecture Support

Move First Stage applies to all FPGA devices. Move First Stage does not apply to CPLD devices.

## Move First Stage Applicable Elements

Move First Stage applies to the following only:

- Entire design
- Single modules or entities
- Primary clock signal

## Move First Stage Propagation Rules

For Move First Stage propagation rules, see "Move First Stage (MOVE\_FIRST\_STAGE)."

## Move First Stage Syntax Examples

Following are syntax examples using Move First Stage with particular tools or methods. If a tool or method is not listed, Move First Stage may not be used with it.

Move First Stage VHDL Syntax Example

Before using Move First Stage, declare it with the following syntax:

attribute move\_first\_stage : string;

After declaring Move First Stage, specify the VHDL constraint:

```
attribute move_first_stage of {entity_name|signal_name}:
{signal|entity} is "{yes|no}";
```

Move First Stage Verilog Syntax Example

Place Move First Stage immediately before the module or signal declaration:

```
(* move_first_stage = "{yes no}" *)
```

Move First Stage XCF Syntax Example One

```
MODEL "entity_name" move_first_stage={yes | no | true | false};
```

Move First Stage XCF Syntax Example Two

BEGIN MODEL "entity\_name"
NET "primary\_clock\_signal" move\_first\_stage={yes|no|true|false};
END;

Move First Stage XST Command Line Syntax Example

Define Move First Stage globally with the **-move\_first\_stage** command line option of the **run** command:

-move\_first\_stage {yes | no}

The default is **yes**.

Move First Stage Project Navigator Syntax Example

Define Move First Stage globally in **Project Navigator > Process Properties >** Xilinx-Specific Options > Move First Flip-Flop Stage.

## Move Last Stage (MOVE\_LAST\_STAGE)

Move Last Stage (MOVE\_LAST\_STAGE) controls the retiming of registers with paths going to primary outputs. Both Move Last Stage and "Move First Stage (MOVE\_FIRST\_STAGE)" relate to Register Balancing.

## Move Last Stage Architecture Support

Move Last Stage applies to all FPGA devices. Move Last Stage does not apply to CPLD devices.

### Move Last Stage Applicable Elements

Move Last Stage applies to the following only:

- Entire design
- Single modules or entities
- Primary clock signal

#### Move Last Stage Propagation Rules

For Move Last Stage propagation rules, see "Move First Stage (MOVE\_FIRST\_STAGE)."

## Move Last Stage Syntax Examples

Following are syntax examples using Move Last Stage with particular tools or methods. If a tool or method is not listed, Move Last Stage may not be used with it.

Move Last Stage Syntax Example

Before using Move Last Stage, declare it with the following syntax:

attribute move\_last\_stage : string;

After declaring Move Last Stage, specify the VHDL constraint:

```
attribute move_last_stage of {entity_name|signal_name}:
{signal|entity} is "{yes|no}";
```

Move Last Stage Verilog Syntax Example

Place Move Last Stage immediately before the module or signal declaration:

```
(* move_last_stage = "{yes | no}" *)
```

Move Last Stage XCF Syntax Example One

**MODEL** "entity\_name" move\_last\_stage={yes | no | true | false};

Move Last Stage XCF Syntax Example Two

**BEGIN MODEL** "entity\_name"

```
NET "primary_clock_signal" move_last_stage={yes | no | true | false};
```

END;

Move Last Stage XST Command Line Syntax Example

Define Move Last Stage globally with the **-move\_last\_stage** command line option of the **run** command:

```
-move_last_stage {yes|no}
```

The default is **yes**.

Move Last Stage Project Navigator Syntax Example

Define Move Last Stage globally in **Project Navigator > Process Properties >** Xilinx-Specific Options > Move Last Stage.

# Multiplier Style (MULT\_STYLE)

Multiplier Style (MULT\_STYLE) controls the way the macrogenerator implements the multiplier macros.

Multiplier Style values are:

auto

For Virtex-II, Virtex-II Pro, Virtex-4, and Virtex-5 devices, the default is **auto**. XST looks for the best implementation for each considered macro.

- block
- pipe\_block

The **pipe\_block** option is used to pipeline DSP48 based multipliers. It is available for Virtex-4 and Virtex-5 devices only

- kcm
- csd
- lut
- pipe\_lut

The **pipe\_lut** option is for pipeline slice-based multipliers. The implementation style can be manually forced to use block multiplier or LUT resources in the following devices:

- Virtex-II, Virtex-II Pro
- Virtex-4, Virtex-5 devies

### Multiplier Style Architecture Support

Multiplier Style applies to the following FPGA devices only:

- Spartan-3, Spartan-3E, Spartan-3A, Spartan-3A D
- Virtex-II, Virtex-II Pro
- Virtex-4, Virtex-5

Multiplier Style does not apply to CPLD devices.

#### Multiplier Style Applicable Elements

Multiplier Style applies globally, or to a VHDL entity, a Verilog module, or signal.

### Multiplier Style Propagation Rules

Multiplier Style applies to the entity, module, or signal to which it is attached.



## Multiplier Style Syntax Examples

Following are syntax examples using Multiplier Style with particular tools or methods. If a tool or method is not listed, Multiplier Style may not be used with it.

Multiplier Style VHDL Syntax Example

Before using Multiplier Style, declare it with the following syntax:

attribute mult\_style: string;

After declaring Multiplier Style, specify the VHDL constraint:

```
attribute mult_style of {signal_name|entity_name}: {signal|entity} is
"{auto|block|pipe_block|kcm|csd|lut|pipe_lut}";
```

For the following devices, the default is **lut**:

- Virtex, Virtex-E
- Spartan-II, Spartan-IIE

For the following devices, the default is **auto**:

- Spartan-3, Spartan-3E, Spartan-3A, Spartan-3A D
- Virtex-II, Virtex-II Pro
- Virtex-4, Virtex-5

Multiplier Style Verilog Syntax Example

Place Multiplier Style immediately before the module or signal declaration:

```
(* mult_style = "{auto|block|pipe_block|kcm|csd|lut|pipe_lut}" *)
```

For the following devices, the default is **lut**:

- Virtex, Virtex-E
- Spartan-II, Spartan-IIE

For the following devices, the default is **auto**:

- Spartan-3, Spartan-3E, Spartan-3A, Spartan-3A D
- Virtex-II, Virtex-II Pro
- Virtex-4, Virtex-5

Multiplier Style XCF Syntax Example One

```
MODEL "entity_name"
mult_style={auto|block|pipe_block|kcm|csd|lut|pipe_lut};
```

Multiplier Style XCF Syntax Example Two

```
BEGIN MODEL "entity_name"
```

```
NET "signal_name"
mult_style={auto|block|pipe_block|kcm|csd|lut|pipe_lut};
```

END;

Multiplier Style XST Command Line Syntax Example

Define Multiplier Style globally with the **-mult\_style** command line option of the **run** command:

```
-mult_style {auto|block|pipe_block|kcm|csd|lut|pipe_lut}
```

For the following devices, the default is **lut**:

- Virtex, Virtex-E
- Spartan-II, Spartan-IIE

For the following devices, the default is **auto**:

- Spartan-3, Spartan-3E, Spartan-3A, Spartan-3A D
- Virtex-II, Virtex-II Pro
- Virtex-4, Virtex-5

The **-mult\_style** command line option is not supported for Virtex-4 or Virtex-5 devices. For those devices, use **-use\_dsp48**.

Multiplier Style Project Navigator Syntax Example

Define Multiplier Style globally in **Project Navigator > Process Properties > HDL Options > Multiplier Style**.

# Mux Style (MUX\_STYLE)

Mux Style (MUX\_STYLE) controls the way the macrogenerator implements the multiplexer macros.

Mux Style values are:

- auto (default)
- muxf
- muxcy

The default is **auto**. XST looks for the best implementation for each considered macro.

#### Table 5-5: Available Mux Style Implementation Styles

Devices	Resources
• Virtex	• MUXF
• Virtex-E	• MUXF6
• Spartan-II	• MUXCY
• Spartan-IIE	
• Spartan-3	• MUXF
• Spartan3-E	• MUXF6
• Spartan-3A	• MUXCY
• Spartan-3A D	• MUXF7
Virtex-II	• MUXF8
Virtex-II Pro	
• Virtex-4	
• Virtex-5	

## Mux Style Architecture Support

Mux Style applies to all FPGA devices. Mux Style does not apply to CPLD devices.



## Mux Style Applicable Elements

Mux Style applies globally, or to a VHDL entity, a Verilog module, or signal.

## Mux Style Propagation Rules

Mux Style applies to the entity, module, or signal to which it is attached.

## Mux Style Syntax Examples

Following are syntax examples using Mux Style with particular tools or methods. If a tool or method is not listed, Mux Style may not be used with it.

Mux Style VHDL Syntax Example

Before using Mux Style, declare it with the following syntax:

attribute mux\_style: string;

After declaring Mux Style, specify the VHDL constraint:

```
attribute mux_style of {signal_name|entity_name}: {signal|entity} is
"{auto|muxf|muxcy}";
```

The default is **auto**.

Mux Style Verilog Syntax Example

Place Mux Style immediately before the module or signal declaration:

(\* mux\_style = "{auto|muxf|muxcy}" \*)

The default is **auto**.

Mux Style XCF Syntax Example One

MODEL "entity\_name" mux\_style={auto | muxf | muxcy};

Mux Style XCF Syntax Example Two

**BEGIN MODEL** "entity\_name"

**NET** "signal\_name" **mux\_style**={**auto** | **muxf** | **muxcy**};

END;

Mux Style XST Command Line Syntax Example

Define Mux Style globally with the **-mux\_style** command line option of the **run** command:

-mux\_style {auto|muxf|muxcy}

The default is **auto**.

Mux Style Project Navigator Syntax Example

Define Mux Style globally in **Project Navigator > Process Properties > HDL** Options > Mux Style.

## Number of Global Clock Buffers (-bufg)

Number of Global Clock Buffers (**-bufg**) controls the maximum number of BUFGs created by XST. The value is an integer. The default value depends on the target device, and is equal to the maximum number of available BUFGs.

# Number of Global Clock Buffers Architecture Support

Number of Global Clock Buffers applies to all FPGA devices. Number of Global Clock Buffers does not apply to CPLD devices.

# Number of Global Clock Buffers Applicable Elements

Number of Global Clock Buffers applies globally.

## Number of Global Clock Buffers Propagation Rules

Not applicable

## Number of Global Clock Buffers Syntax Examples

Following are syntax examples using Number of Global Clock Buffers with particular tools or methods. If a tool or method is not listed, Number of Global Clock Buffers may not be used with it.

#### Number of Global Clock Buffers XST Command Line Syntax Example

Define Number of Global Clock Buffers globally with the **-bufg** command line option of the **run** command:

-bufg integer

The value is an integer. The default values are different for different architectures. The defaults for selected architectures are shown in Table 5-6, "Default Values of Number of Global Clock Buffers." The number of BUFGs cannot exceed the maximum number of BUFGs for the target device.

#### *Table 5-6:* Default Values of Number of Global Clock Buffers

Devices	Default Value
<ul><li>Virtex</li><li>Virtex-E</li></ul>	4
<ul><li>Virtex-II</li><li>Virtex-II Pro</li></ul>	16
<ul><li>Virtex-4</li><li>Virtex-5</li></ul>	32
<ul><li>Spartan-II</li><li>Spartan-IIE</li></ul>	4
• Spartan-3	8
<ul><li>Spartan-3E</li><li>Spartan-3A</li><li>Spartan-3A D</li></ul>	24

Number of Global Clock Buffers Project Navigator Syntax Example

Define Number of Global Clock Buffers globally in **Project Navigator > Process Properties > Xilinx-Specific Options > Number of Clock Buffers**.



# Number of Regional Clock Buffers (-bufr)

Number of Regional Clock Buffers (**-bufr**) controls the maximum number of BUFRs created by XST. The value is an integer. The default value depends on the target device, and is equal to the maximum number of available BUFRs.

## Number of Regional Clock Buffers Architecture Support

Number of Regional Clock Buffers:

- May be used with Virtex-4 devices only.
- May NOT be used with Virtex-5 devices.
- Does not apply to CPLD devices.

#### Number of Regional Clock Buffers Applicable Elements

Number of Regional Clock Buffers applies globally.

#### Number of Regional Clock Buffers Propagation Rules

Not applicable

#### Number of Regional Clock Buffers Syntax Examples

Following are syntax examples using Number of Regional Clock Buffers with particular tools or methods. If a tool or method is not listed, Number of Regional Clock Buffers may not be used with it.

#### Number of Regional Clock Buffers XST Command Line Syntax Example

Define Number of Regional Clock Buffers globally with the **-bufr** command line option of the **run** command:

-bufr integer

The value is an integer.

The number of BUFRs cannot exceed the maximum number of BUFRs for the target device.

Number of Regional Clock Buffers Project Navigator Syntax Example

Define Number of Regional Clock Buffers globally in **Project Navigator > Process Properties > Xilinx-Specific Options > Number of Regional Clock Buffers**.

# **Optimize Instantiated Primitives (OPTIMIZE\_PRIMITIVES)**

By default, XST does not optimize instantiated primitives in Hardware Description Languages (HDLs). Use Optimize Instantiated Primitives (OPTIMIZE\_PRIMITIVES) to deactivate the default. Optimize Instantiated Primitives allows XST to optimize Xilinx library primitives that have been instantiated in an HDL.

Optimization of instantiated primitives is limited by the following factors:

If an instantiated primitive has specific constraints such as "RLOC" attached, XST preserves it as is.

 Not all primitives are considered by XST for optimization. Such hardware elements as MULT18x18, BRAMs, and DSP48 are not optimized (modified) even if optimization of instantiated primitives is enabled.

## **Optimize Instantiated Primitives Architecture Support**

Optimize Instantiated Primitives applies to all FPGA devices. Optimize Instantiated Primitives does not apply to CPLD devices.

## **Optimize Instantiated Primitives Applicable Elements**

Optimize Instantiated Primitives applies to hierarchical blocks, components, and instances.

#### **Optimize Instantiated Primitives Propagation Rules**

Optimize Instantiated Primitives applies to the component or instance to which it is attached.

#### Optimize Instantiated Primitives Syntax Examples

Following are syntax examples using Optimize Instantiated Primitives with particular tools or methods. If a tool or method is not listed, Optimize Instantiated Primitives may not be used with it.

Optimize Instantiated Primitives Schematic Syntax Examples

- Attach to a valid instance
- Attribute Name
   OPTIMIZE PRIMITIVES
- Attribute Values
  - yes
  - no (default)

Optimize Instantiated Primitives VHDL Syntax Example

Before using Optimize Instantiated Primitives, declare it with the following syntax:

attribute optimize\_primitives: string;

After declaring Optimize Instantiated Primitives, specify the VHDL constraint:

```
attribute optimize_primitives of
{component_name|entity_name|label_name}: {component|entity|label} is
"{yes|no}";
```

Optimize Instantiated Primitives Verilog Syntax Example

Place Optimize Instantiated Primitives immediately before the instance, module or signal declaration:

(\* optimize\_primitives = "{yes | no}" \*)

Optimize Instantiated Primitives XCF Syntax Example

```
MODEL "entity_name" optimize_primitives = {yes|no|true|false};
```



Optimize Instantiated Primitives Project Navigator Syntax Example

Define Optimize Instantiated Primitives globally in **Project Navigator > Process Properties > Xilinx-Specific Options > Optimize Instantiated Primitives**.

# Pack I/O Registers Into IOBs (IOB)

Pack I/O Registers Into IOBs (IOB) packs flip-flops in the I/Os to improve input/output path timing.

When IOB is set to **auto**, the action XST takes depends on the Optimization setting:

- If Optimization is set to area, XST packs registers as tightly as possible to the IOBs in order to reduce the number of slices occupied by the design.
- If Optimization is set to **speed**, XST packs registers to the IOBs provided they are not covered by timing constraints (in other words, they are not taken into account by timing optimization). For example, if you specify a period constraint, XST packs a register to the IOB if it is not covered by the period constraint. If a register is covered by timing optimization, but you do want to pack it to an IOB, you must apply the IOB constraint locally to the register.

For more information, see "IOB" in the Xilinx Constraints Guide.

# Priority Encoder Extraction (PRIORITY\_EXTRACT)

Priority Encoder Extraction (PRIORITY\_EXTRACT) enables or disables priority encoder macro inference.

Priority Encoder Extraction values are:

- yes (default)
- no
- true (XCF only)
- force (XCF only)

For each identified priority encoder description, based on some internal decision rules, XST actually creates a macro or optimize it with the rest of the logic. The **force** value allows you to override those decision rules, and force XST to extract the macro.

#### Priority Encoder Extraction Architecture Support

Priority Encoder Extraction applies to all FPGA devices. Priority Encoder Extraction does not apply to CPLD devices.

#### Priority Encoder Extraction Applicable Elements

Priority Encoder Extraction applies globally or to an entity, module, or signal.

#### Priority Encoder Extraction Propagation Rules

Priority Encoder Extraction applies to the entity, module, or signal to which it is attached.

## Priority Encoder Extraction Syntax Examples

Following are syntax examples using Priority Encoder Extraction with particular tools or methods. If a tool or method is not listed, Priority Encoder Extraction may not be used with it.

Priority Encoder Extraction VHDL Syntax Example

Before using Priority Encoder Extraction, declare it with the following syntax:

```
attribute priority_extract: string;
```

After declaring Priority Encoder Extraction, specify the VHDL constraint:

```
attribute priority_extract of {signal_name|entity_name}:
{signal|entity} is "{yes|no|force}";
```

The default is **yes**.

Priority Encoder Extraction Verilog Syntax Example

Place Priority Encoder Extraction immediately before the module or signal declaration:

Priority Encoder Extraction XCF Syntax Example One

```
MODEL "entity_name" priority_extract={yes | no | true | false | force};
```

Priority Encoder Extraction XCF Syntax Example Two

**BEGIN MODEL** "entity\_name"

**NET** "signal\_name" priority\_extract={yes | no | true | false | force};

END;

Priority Encoder Extraction XST Command Line Syntax Example

Define Priority Encoder Extraction globally with the **-priority\_extract** command line option of the **run** command:

-priority\_extract {yes|no|force}

The default is **yes**.

Priority Encoder Extraction Project Navigator Syntax Example

Define Priority Encoder Extraction globally in **Project Navigator > Process Properties > HDL Options > Priority Encoder Extraction**.

# **RAM Extraction (RAM\_EXTRACT)**

RAM Extraction (RAM\_EXTRACT) enable or disables RAM macro inference.

RAM Extraction values are:

- **yes** (default)
- no
- true (XCF only)
- false (XCF only)

#### RAM Extraction Architecture Support

RAM Extraction applies to all FPGA devices. RAM Extraction does not apply to CPLD devices.



# **RAM Extraction Applicable Elements**

RAM Extraction applies globally, or to an entity, module, or signal.

## **RAM Extraction Propagation Rules**

RAM Extraction applies to the entity, module, or signal to which it is attached.

#### RAM Extraction Syntax Examples

Following are syntax examples using RAM Extraction with particular tools or methods. If a tool or method is not listed, RAM Extraction, may not be used with it.

RAM Extraction VHDL Syntax Example

Before using RAM Extraction, declare it with the following syntax:

attribute ram\_extract: string;

After declaring RAM Extraction, specify the VHDL constraint:

```
attribute ram_extract of {signal_name|entity_name}: {signal|entity} is
"{yes|no}";
```

RAM Extraction Verilog Syntax Example

Place RAM Extraction immediately before the module or signal declaration:

(\* ram\_extract = "{yes | no}" \*)

RAM Extraction XCF Syntax Example One

RAM Extraction Syntax MODEL "entity\_name"
ram\_extract={yes|no|true|false};

RAM Extraction XCF Syntax Example Two

BEGIN MODEL "entity\_name"

```
NET "signal_name" ram_extract={yes|no|true|false};
```

END;

RAM Extraction XST Command Line Syntax Example

Define RAM Extraction globally with the **-ram\_extract** command line option of the **run** command:

-ram\_extract {yes | no}

The default is **yes**.

RAM Extraction Project Navigator Syntax Example

Define RAM Extraction globally in **Project Navigator** > **Process Properties** > **HDL Options** > **RAM Extraction**.

# **RAM Style (RAM\_STYLE)**

RAM Style (RAM\_STYLE) controls the way the macrogenerator implements the inferred RAM macros.

RAM Style values are:

- **auto** (default)
- block
- distributed
- pipe\_distributed
- block\_power1
- block\_power2

The default is **auto**. XST looks for the best implementation for each inferred RAM.

You must use **block\_power1** and **block\_power2** in order to achieve power-oriented BRAM optimization. For more information, see "Power Reduction (POWER)."

The implementation style can be manually forced to use block RAM or distributed RAM resources.

You can specify **pipe\_distributed**, **block\_power1**, and **block\_power2** only through VHDL or Verilog or XCF constraints.

#### RAM Style Architecture Support

RAM Style applies to all FPGA devices. RAM Style does not apply to CPLD devices. **Block\_power1** and **block\_power2** are supported for Virtex-4 and Virtex-5 devices only.

#### RAM Style Applicable Elements

RAM Style applies globally or to an entity, module, or signal.

#### RAM Style Propagation Rules

RAM Style applies to the entity, module, or signal to which it is attached.

#### RAM Style Syntax Examples

Following are syntax examples using RAM Style with particular tools or methods. If a tool or method is not listed, RAM Style may not be used with it.

#### RAM Style VHDL Syntax Example

Before using RAM Style, declare it with the following syntax:

attribute ram\_style: string;

After declaring RAM Style, specify the VHDL constraint:

```
attribute ram_style of {signal_name|entity_name}: {signal|entity} is
"{auto|block|distributed|pipe_distributed|block_power1|block_power2}";
```

The default is **auto**.

RAM Style Verilog Syntax Example

Place RAM Style immediately before the module or signal declaration:



```
(* ram_style =
"{auto|block|distributed|pipe_distributed|block_power1|block_power2}"
*)
```

The default is **auto**.

RAM Style XCF Syntax Example One

```
MODEL "entity_name"
ram_style={auto|block|distributed|pipe_distributed|block_power1|block_
power2};
```

RAM Style XCF Syntax Example Two

**BEGIN MODEL** "entity\_name"

```
NET "signal_name"
ram_style={auto|block|distributed|pipe_distributed|block_power1|b
lock_power2};
```

END;

RAM Style XST Command Line Syntax Example

Define RAM Style globally with the **-ram\_style** command line option of the **run** command:

-ram\_style {auto|block|distributed}

The default is **auto**.

The **pipe\_distributed** value is not accessible through the command line.

RAM Style Project Navigator Syntax Example

Define RAM Style globally in **Project Navigator** > **Process Properties** > **HDL Options** > **RAM Style**.

# Reduce Control Sets (REDUCE\_CONTROL\_SETS)

Reduce Control Sets (REDUCE\_CONTROL\_SETS) allows you to reduce the number of control sets and, as a consequence, reduce the design area. Reducing the control set number should improve the packing process in **map**, and therefore reduce the number of used slices even if the number of LUTs is increased.

Reduce Control Sets supports two values:

• auto

XST optimizes automatically, and reduces the existing control sets in the design.

• no

XST performs no control set optimization.

#### Reduce Control Sets Architecture Support

Reduce Control Sets applies to FPGA Virtex-5 devices only. Reduce Control Sets does not apply to CPLD devices.

#### Reduce Control Sets Applicable Elements

Reduce Control Sets applies globally.

# **Reduce Control Sets Propagation Rules**

Not applicable

## Reduce Control Sets Syntax Examples

Following are syntax examples using Reduce Control Sets with particular tools or methods. If a tool or method is not listed, Reduce Control Sets may not be used with it.

Reduce Control Sets XST Command Line Syntax Example

Define Reduce Control Sets globally with the **-reduce\_control\_sets** command line option of the run command:

-reduce\_control\_sets {auto|no}

The default is **no**.

Reduce Control Sets Project Navigator Syntax Example

Define Reduce Control Sets globally in Project Navigator > Process Properties > Xilinx-

Specific Options > Reduce Control Sets.

# **Register Balancing (REGISTER\_BALANCING)**


Register Balancing (REGISTER\_BALANCING) enables flip-flop retiming. The main goal of register balancing is to move flip-flops and latches across logic to increase clock frequency.

The two categories of Register Balancing are:

- "Forward Register Balancing"
- "Backward Register Balancing"


## Forward Register Balancing

Forward Register Balancing moves a set of flip-flops at the inputs of a LUT to a single flipflop at its output.



*Figure 5-3:* Forward Register Balancing

www.xilinx.com



LutName\_FRBId

#### **Backward Register Balancing**

Backward Register Balancing moves a flip-flop at the output of a LUT to a set of flip-flops at its inputs.




Figure 5-4: Backward Register Balancing

As a consequence the number of flip-flops in the design can be increased or decreased.

The new flip-flop has the same name as the original flip-flop with an indexed suffix as shown in the following:

OriginalFFName\_BRBId

#### **Register Balancing Values**

Register Balancing values are:

• yes

Both forward and backward retiming are allowed.

• no (default)

Neither forward nor backward retiming is allowed.

• forward

**O**nly forward retiming is allowed

- **backward** Only backward retiming is allowed.
- true (XCF only)
- false (XCF only)

# Additional Constraints That Affect Register Balancing

Two additional constraints control register balancing:

- "Move First Stage (MOVE\_FIRST\_STAGE)"
- "Move Last Stage (MOVE\_LAST\_STAGE)"

Several other constraints also influence register balancing:

- "Keep Hierarchy (KEEP\_HIERARCHY)"
  - If the hierarchy is preserved, flip-flops are moved only inside the block boundaries.
  - If the hierarchy is flattened, flip-flops may leave the block boundaries.
- "Pack I/O Registers Into IOBs (IOB)"
  - If IOB=TRUE, register balancing is not applied to the flip-flops having this property.
- "Optimize Instantiated Primitives (OPTIMIZE\_PRIMITIVES)"
  - Instantiated flip-flops are moved only if OPTIMIZE\_PRIMITIVES=YES.
  - Flip-flops are moved across instantiated primitives only if OPTIMIZE\_PRIMITIVES=YES.
- "Keep (KEEP)"

If applied to the output flip-flop signal, the flip-flop is not moved forward.




Figure 5-5: Applied to the Output Flip-Flop Signal

If applied to the input flip-flop signal, the flip-flop is not moved backward.




Figure 5-6: Applied to the Input Flip-Flop Signal

If applied to both the input and output of the flip-flop, it is equivalent to *REGISTER\_BALANCING=no*.

www.xilinx.com



## **Register Balancing Architecture Support**

Register Balancing applies to all FPGA devices. Register Balancing does not apply to CPLD devices.

#### Register Balancing Applicable Elements

Register Balancing can be applied:

- Globally to the entire design using the command line or Project Navigator
- To an entity or module
- To a signal corresponding to the flip-flop description (RTL)
- To a flip-flop instance
- To the Primary Clock Signal

In this case the register balancing is performed only for flip-flops synchronized by this clock.

#### **Register Balancing Propagation Rules**

Register Balancing applies to the entity, module, or signal to which it is attached.

#### Register Balancing Syntax Examples

Following are syntax examples using Register Balancing with particular tools or methods. If a tool or method is not listed, Register Balancing may not be used with it.

Register Balancing VHDL Syntax Example

Before using Register Balancing, declare it with the following syntax:

attribute register\_balancing: string;

After declaring Register Balancing, specify the VHDL constraint:

```
attribute register_balancing of {signal_name/entity_name}:
{signal|entity} is "{yes|no|foward|backward}";
```

Register Balancing Verilog Syntax Example

Place Register Balancing immediately before the module or signal declaration:

(\* register\_balancing = "{yes no foward backward}" \*)

The default is **no**.

Register Balancing XCF Syntax Example One

```
MODEL "entity_name"
register_balancing={yes | no | true | false | forward | backward};
```

Register Balancing XCF Syntax Example Two

```
BEGIN MODEL "entity_name"
```

```
NET "primary_clock_signal"
register_balancing={yes | no | true | false | forward | backward};
END;
```

Register Balancing XCF Syntax Example Three

```
BEGIN MODEL "entity_name"
INST "instance_name"
register_balancing={yes | no | true | false | forward | backward};
END;
```

Register Balancing XST Command Line Syntax Example

Define Register Balancing globally with the **-register\_balancing** command line option of the **run** command:

-register\_balancing {yes | no | forward | backward}

The default is **no**.

Register Balancing Project Navigator Syntax Example

Define Register Balancing globally in **Project Navigator > Process Properties** > Xilinx-Specific Options > Register Balancing.

# Register Duplication (REGISTER\_DUPLICATION)

Register Duplication (REGISTER\_DUPLICATION) enables or disables register replication.

Register Duplication values are:

- yes (default)
- no
- true (XCF only)
- false (XCF only)

The default is **yes**. Register replication is enabled, and is performed during timing optimization and fanout control.

#### Register Duplication Architecture Support

Register Duplication applies to all FPGA devices. Register Duplication does not apply to CPLD devices.

#### Register Duplication Applicable Elements

Register Duplication applies globally, or to an entity or module.

#### Register Duplication Propagation Rules

Register Duplication applies to the entity or module to which it is attached.

#### Register Duplication Syntax Examples

Following are syntax examples using Register Duplication with particular tools or methods. If a tool or method is not listed, Register Duplication may not be used with it.

Register Duplication VHDL Syntax Example

Before Register Duplication can be used, declared it with the following syntax:

attribute register\_duplication: string;



After declaring Register Duplication, specify the VHDL constraint:

attribute register\_duplication of *entity\_name*: entity is "{yes no}";

Register Duplication Verilog Syntax Example

Place Register Duplication immediately before the module declaration or instantiation:

```
(* register_duplication = "{yes | no}" *)
```

Register Duplication XCF Syntax Example One

**MODEL** "entity\_name" register\_duplication={yes|no|true|false};

Register Duplication XCF Syntax Example Two

**BEGIN MODEL** "entity\_name"

**NET** "signal\_name" register\_duplication={yes|no|true|false};

END;

Register Duplication Project Navigator Syntax Example

Define Register Duplication globally in **Project Navigator > Process Properties** > Xilinx-Specific Options > Register Duplication.

# **ROM Extraction (ROM\_EXTRACT)**

ROM Extraction (ROM\_EXTRACT) enables or disables ROM macro inference.

ROM Extraction values are:

- yes (default)
- no
- true (XCF only)
- false (XCF only)

The default is **yes**. Typically, a ROM can be inferred from a Case statement where all assigned contexts are constant values.

#### **ROM Extraction Architecture Support**

ROM Extraction applies to all FPGA devices. ROM Extraction does not apply to CPLD devices.

#### **ROM Extraction Applicable Elements**

ROM Extraction applies globally, or to a design element or signal.

#### **ROM Extraction Propagation Rules**

ROM Extraction applies to the entity, module, or signal to which it is attached.

#### ROM Extraction Syntax Examples

Following are syntax examples using ROM Extraction with particular tools or methods. If a tool or method is not listed, ROM Extraction may not be used with it.

ROM Extraction VHDL Syntax Example

Before using ROM Extraction, declare it with the following syntax:

attribute rom\_extract: string;

After declaring ROM Extraction, specify the VHDL constraint:

```
attribute rom_extract of {signal_name|entity_name}: {signal|entity} is
"{yes|no}";
```

ROM Extraction Verilog Syntax Example

Place ROM Extraction immediately before the module or signal declaration:

(\* rom\_extract = "{yes | no}" \*)

ROM Extraction XCF Syntax Example One

**MODEL** "entity\_name" rom\_extract={yes | no | true | false};

ROM Extraction XCF Syntax Example Two

BEGIN MODEL "entity\_name"

**NET** "signal\_name" rom\_extract={yes|no|true|false};

END;

ROM Extraction XST Command Line Syntax Example

Define ROM Extraction globally with the **-rom\_extract** command line option of the **run** command:

-rom\_extract {yes|no}

The default is **yes**.

ROM Extraction Project Navigator Syntax Example

Define ROM Extraction globally in **Project Navigator > Process Properties > HDL Options > ROM Extraction**.

# ROM Style (ROM\_STYLE)

ROM Style (ROM\_STYLE) controls the way the macrogenerator implements the inferred ROM macros. "ROM Extraction (ROM\_EXTRACT)" must be set to **yes** to use ROM\_STYLE.

ROM Style values are:

- auto (default)
- block

The default is **auto**. XST looks for the best implementation for each inferred ROM. The implementation style can be manually forced to use block ROM or distributed ROM resources.

#### ROM Style Architecture Support

ROM Style applies to all FPGA devices. ROM Style does not apply to CPLD devices.

#### ROM Style Applicable Elements

ROM Style applies globally, or to an entity, module, or signal.

# **ROM Style Propagation Rules**

ROM Style applies to the entity, module, or signal to which it is attached.

#### ROM Style Syntax Examples

Following are syntax examples using ROM Style with particular tools or methods. If a tool or method is not listed, ROM Style may not be used with it.

ROM Style VHDL Syntax Example

"ROM Extraction (ROM\_EXTRACT)" must be set to yes to use ROM\_STYLE.

Before using ROM Style, declare it with the following syntax:

attribute rom\_style: string;

After declaring ROM Style, specify the VHDL constraint:

```
attribute rom_style of {signal_name|entity_name}: {signal|entity} is
"{auto|block|distributed}";
```

The default is **auto**.

ROM Style Verilog Syntax Example

"ROM Extraction (ROM\_EXTRACT)" must be set to yes to use ROM\_STYLE.

Place ROM Style immediately before the module or signal declaration:

(\* rom\_style = "{auto|block|distributed}" \*)

The default is **auto**.

ROM Style XCF Syntax Example One

"ROM Extraction (ROM\_EXTRACT)" must be set to **yes** to use ROM Style.

**MODEL** "entity\_name" rom\_style={auto|block|distributed};

ROM Style XCF Syntax Example Two

"ROM Extraction (ROM\_EXTRACT)" must be set to **yes** to use ROM Style.

**BEGIN MODEL** "entity\_name"

**NET** "signal\_name" rom\_style={auto|block|distributed};

END;

ROM Style XST Command Line Syntax Example

"ROM Extraction (ROM\_EXTRACT)" must be set to yes to use ROM Style.

Define ROM Style globally with the **-rom\_style** command line option of the **run** command:

-rom\_style {auto|block|distributed}

The default is **auto**.

ROM Style Project Navigator Syntax Example

"ROM Extraction (ROM\_EXTRACT)" must be set to yes to use ROM Style.

Define ROM Style globally in **Project Navigator > Process Properties > HDL** Options > ROM Style.

# Shift Register Extraction (SHREG\_EXTRACT)

Shift Register Extraction (SHREG\_EXTRACT) enables or disables shift register macro inference.

Shift Register Extraction values are:

- **yes** (default)
- no
- true (XCF only)
- false (XCF only)

Enabling Shift Register Extraction for FPGA devices results in the usage of dedicated hardware resources such as SRL16 and SRLC16. For more information, see "Shift Registers HDL Coding Techniques."

#### Shift Register Extraction Architecture Support

Shift Register Extraction applies to all FPGA devices. Shift Register Extraction does not apply to CPLD devices.

#### Shift Register Extraction Applicable Elements

Shift Register Extraction applies globally, or to design elements and signals.

#### Shift Register Extraction Propagation Rules

Shift Register Extraction applies to design elements or signals to which it is attached.

#### Shift Register Extraction Syntax Examples

Following are syntax examples using Shift Register Extraction with particular tools or methods. If a tool or method is not listed, Shift Register Extraction may not be used with it.

Shift Register Extraction VHDL Syntax Example

Before using Shift Register Extraction, declare it with the following syntax:

```
attribute shreg_extract : string;
```

After declaring Shift Register Extraction, specify the VHDL constraint:

```
attribute shreg_extract of {signal_name|entity_name}: {signal|entity}
is "{yes|no}";
```

Shift Register Extraction Verilog Syntax Example

Place Shift Register Extraction immediately before the module or signal declaration:

```
(* shreg_extract = "{yes | no}" *)
```

Shift Register Extraction XCF Syntax Example One

**MODEL** "entity\_name" **shreg\_extract**={**yes** | **no** | **true** | **false**};

Shift Register Extraction XCF Syntax Example Two

**BEGIN MODEL** "entity\_name"

```
NET "signal_name" shreg_extract={yes | no | true | false};
```

END;



Shift Register Extraction XST Command Line Syntax Example

Define Shift Register Extraction globally with the **-shreg\_extract** command line option of the **run** command:

-shreg\_extract {yes | no}

The default is **yes**.

Shift Register Extraction Project Navigator Syntax Example

Define Shift Register Extraction globally in **Project Navigator > Process Properties > HDL Options > Shift Register Extraction**.

# Slice Packing (-slice\_packing)

Slice Packing (**-slice\_packing**) enables the XST internal packer. The packer attempts to pack critical LUT-to-LUT connections within a slice or a CLB. This exploits the fast feedback connections among the LUTs in a CLB.

#### Slice Packing Architecture Support

Slice Packing applies to all FPGA devices. Slice Packing does not apply to CPLD devices.

#### Slice Packing Applicable Elements

Slice Packing applies globally.

#### Slice Packing Propagation Rules

Not applicable

#### Slice Packing Syntax Examples

Following are syntax examples using Slice Packing with particular tools or methods. If a tool or method is not listed, Slice Packing may not be used with it.

Slice Packing XST Command Line Syntax Example

Define Slice Packing globally with the **-slice\_packing** command line option of the **run** command:

-slice\_packing {yes|no}

Slice Packing Project Navigator Syntax Example

Define Slice Packing globally in **Project Navigator** > **Process Properties** > **Xilinx-Specific Options** > **Slice Packing**.

## Use Low Skew Lines (USELOWSKEWLINES)

Use Low Skew Lines (USELOWSKEWLINES) is a basic routing constraint. During synthesis, Use Low Skew Lines prevents XST from using dedicated clock resources and logic replication, based on the value of the "Max Fanout (MAX\_FANOUT)" constraint.Use Low Skew Lines specifies the use of low skew routing resources for any net. For more information, see "USELOWSKEWLINES" in the Xilinx *Constraints Guide*.

# XOR Collapsing (XOR\_COLLAPSE)

XOR Collapsing (XOR\_COLLAPSE) controls whether cascaded XORs should be collapsed into a single XOR.

XOR Collapsing values are:

- **yes** (default)
- no
- true (XCF only)
- false (XCF only)

## XOR Collapsing Architecture Support

XOR Collapsing applies to all FPGA devices. XOR Collapsing does not apply to CPLD devices.

#### XOR Collapsing Applicable Elements

XOR Collapsing applies to cascaded XORs.

## XOR Collapsing Propagation Rules

Not applicable

#### XOR Collapsing Syntax Examples

Following are syntax examples using XOR Collapsing with particular tools or methods. If a tool or method is not listed, XOR Collapsing may not be used with it.

XOR Collapsing VHDL Syntax Example

Before using XOR Collapsing, declare it with the following syntax:

attribute xor\_collapse: string;

After declaring XOR Collapsing, specify the VHDL constraint:

```
attribute xor_collapse {signal_name|entity_name}: {signal|entity} is
"{yes|no}";
```

The default is **yes**.

XOR Collapsing Verilog Syntax Example

Place XOR Collapsing immediately before the module or signal declaration:

(\* xor\_collapse = "{yes | no}" \*)

The default is **yes**.

XOR Collapsing XCF Syntax Example One

**MODEL** "entity\_name" **xor\_collapse=**{**yes**|**no**|**true**|**false**};

XOR Collapsing XCF Syntax Example Two

**BEGIN MODEL** "entity\_name"

**NET** "signal\_name" **xor\_collapse=**{**yes**|**no**|**true**|**false**};

XOR Collapsing END;



XOR Collapsing XST Command Line Syntax Example

Define XOR Collapsing globally with the **-xor\_collapse** command line option of the **run** command:

-xor\_collapse {yes no}

XOR Collapsing The default is **yes**.

XOR Collapsing Project Navigator Syntax Example

Define XOR Collapsing globally in **Project Navigator > Process Properties > HDL Options > XOR Collapsing**.

# Slice (LUT-FF Pairs) Utilization Ratio (SLICE\_UTILIZATION\_RATIO)

Slice (LUT-FF Pairs) Utilization Ratio (SLICE\_UTILIZATION\_RATIO) defines the area size in absolute numbers or percent of total numbers of

- LUT-FF pairs (Virtex-5 devices)
- slices (all other devices)

that XST must not exceed during timing optimization.

If the area constraint cannot be satisfied, XST will make timing optimization regardless of the area constraint. To disable automatic resource management, specify **-1** as a constraint value. For more information, see "Speed Optimization Under Area Constraint."

#### Slice (LUT-FF Pairs) Utilization Ratio Architecture Support

Slice (LUT-FF Pairs) Utilization Ratio applies to all FPGA devices. Slice (LUT-FF Pairs) Utilization Ratio does not apply to CPLD devices.

#### Slice (LUT-FF Pairs) Utilization Ratio Applicable Elements

Slice (LUT-FF Pairs) Utilization Ratio applies globally, or to a VHDL entity or Verilog module.

#### Slice (LUT-FF Pairs) Utilization Ratio Propagation Rules

Slice (LUT-FF Pairs) Utilization Ratio applies to the entity or module to which it is attached.

#### Slice (LUT-FF Pairs) Utilization Ratio Syntax Examples

Following are syntax examples using Slice (LUT-FF Pairs) Utilization Ratio with particular tools or methods. If a tool or method is not listed, Slice (LUT-FF Pairs) Utilization Ratio may not be used with it.

Slice (LUT-FF Pairs) Utilization Ratio VHDL Syntax Examples

Before using Slice (LUT-FF Pairs) Utilization Ratio, declare it with the following syntax:

attribute slice\_utilization\_ratio: string;

After declaring Slice (LUT-FF Pairs) Utilization Ratio, specify the VHDL constraint:

```
attribute slice_utilization_ratio of entity_name : entity is "integer";
attribute slice_utilization_ratio of entity_name : entity is
"integer%";
```

```
attribute slice_utilization_ratio of entity_name : entity is
"integer#";
```

In the preceding example, XST interprets the integer values in the first two attributes as a percentage and in the last attribute as an absolute number of slices or FF-LUT pairs.

Slice (LUT-FF Pairs) Utilization Ratio Verilog Syntax Examples

Place Slice (LUT-FF Pairs) Utilization Ratio immediately before the module declaration or instantiation:

```
(* slice_utilization_ratio = "integer" *)
(* slice_utilization_ratio = "integer%" *)
(* slice_utilization_ratio = "integer#" *)
```

In the preceding examples, XST interprets the integer values in the first two attributes as a percentage and in the last attribute as an absolute number of slices

Slice (LUT-FF Pairs) Utilization Ratio XCF Syntax Example One

MODEL "entity\_name" slice\_utilization\_ratio=integer;

Slice (LUT-FF Pairs) Utilization Ratio XCF Syntax Example Two

MODEL "entity\_name" slice\_utilization\_ratio="integer%";

Slice (LUT-FF Pairs) Utilization Ratio XCF Syntax Example Three

**MODEL** "entity\_name" **slice\_utilization\_ratio=**"integer**#";** 

In the preceding examples, XST interprets the integer values in the first two lines as a percentage and in the last line as an absolute number of slices or FF-LUT pairs.

There must be no space between the integer value and the percent (%) or pound (#) characters.

The integer value range is **-1** to **100** when percent (%) is used or both percent (%) and pound (**#**) are omitted.

You must surround the integer value and the percent (%) and pound (#) characters with double quotes ("...") because the percent (%) and pound (#) characters are special characters in the XST Constraint File (XCF)

Slice (LUT-FF Pairs) Utilization Ratio XST Command Line Syntax Examples

Define Slice (LUT-FF Pairs) Utilization Ratio globally with the – **slice\_utilization\_ratio** command line option of the **run** command:

```
-slice_utilization_ratio integer
-slice_utilization_ratio integer%
-slice_utilization_ratio integer#
```

In the preceding example, XST interprets the integer values in the first two lines as a percentage and in the last line as an absolute number of slices or FF-LUT pairs.

The integer value range is **-1** to **100** when percent (%) is used or both percent (%) and pound (**#**) are omitted.

Slice (LUT-FF Pairs) Utilization Ratio Project Navigator Syntax Example

Define Slice (LUT-FF Pairs) Utilization Ratio globally in **Project Navigator** > **Process Properties** > **Synthesis Options** > **Slice Utilization Ratio** or



#### Project Navigator > Process Properties > Synthesis Options > LUT-FF Pairs Utilization Ratio.

In Project Navigator, you can define the value of Slice (LUT-FF Pairs) Utilization Ratio only as a percentage. You can not define the value as an absolute number of slices.

# Slice (LUT-FF Pairs) Utilization Ratio Delta (SLICE\_UTILIZATION\_RATIO\_MAXMARGIN)

Slice (LUT-FF Pairs) Utilization Ratio Delta

(SLICE\_UTILIZATION\_RATIO\_MAXMARGIN) is closely related to "Slice (LUT-FF Pairs) Utilization Ratio (SLICE\_UTILIZATION\_RATIO)." Slice (LUT-FF Pairs) Utilization Ratio Delta defines the tolerance margin for "Slice (LUT-FF Pairs) Utilization Ratio (SLICE\_UTILIZATION\_RATIO)." The value of the parameter can be defined in the form of percentage as well as an absolute number of slices or LUT-FF pairs.

If the ratio is within the margin set, the constraint is met and timing optimization can continue. For more information, see "Speed Optimization Under Area Constraint."

# Slice (LUT-FF Pairs) Utilization Ratio Delta Architecture Support

Slice (LUT-FF Pairs) Utilization Ratio Delta applies to all FPGA devices. Slice (LUT-FF Pairs) Utilization Ratio Delta does not apply to CPLD devices.

# Slice (LUT-FF Pairs) Utilization Ratio Delta Applicable Elements

Slice (LUT-FF Pairs) Utilization Ratio Delta applies globally, or to a VHDL entity or Verilog module.

# Slice (LUT-FF Pairs) Utilization Ratio Delta Propagation Rules

Slice (LUT-FF Pairs) Utilization Ratio Delta applies to the entity or module to which it is attached.

# Slice (LUT-FF Pairs) Utilization Ratio Delta Syntax Examples

Following are syntax examples using Slice (LUT-FF Pairs) Utilization Ratio Delta with particular tools or methods. If a tool or method is not listed, Slice (LUT-FF Pairs) Utilization Ratio Delta may not be used with it.

Slice (LUT-FF Pairs) Utilization Ratio Delta VHDL Syntax Examples

Before using Slice (LUT-FF Pairs) Utilization Ratio Delta, declare it with the following syntax:

```
attribute slice_utilization_ratio_maxmargin: string;
```

After declaring Slice (LUT-FF Pairs) Utilization Ratio Delta, specify the VHDL constraint:

attribute slice\_utilization\_ratio\_maxmargin of entity\_name : entity is
"integer";

attribute slice\_utilization\_ratio\_maxmargin of entity\_name : entity is "integer%";

attribute slice\_utilization\_ratio\_maxmargin of entity\_name : entity is "integer#";

In the preceding examples, XST interprets the integer values in the first two attributes as a percentage, and in the last attribute as an absolute number of slices or FF-LUT pairs.

The integer value range is **0** to **100** when percent (%) is used or both percent (%) and pound (**#**) are omitted.

Slice (LUT-FF Pairs) Utilization Ratio Delta Verilog Syntax Examples

Place Slice (LUT-FF Pairs) Utilization Ratio Delta immediately before the module declaration or instantiation:

```
(* slice_utilization_ratio_maxmargin = "integer" *)
(* slice_utilization_ratio_maxmargin = "integer%" *)
```

```
(* slice_utilization_ratio_maxmargin = "integer#" *)
```

In the preceding examples, XST interprets the integer values in the first two attributes as a percentage, and in the last attribute as an absolute number of slices or FF-LUT pairs.

Slice (LUT-FF Pairs) Utilization Ratio Delta XCF Syntax Example One

**MODEL** "entity\_name" slice\_utilization\_ratio\_maxmargin=integer;

Slice (LUT-FF Pairs) Utilization Ratio Delta XCF Syntax Example Two

MODEL "entity\_name" slice\_utilization\_ratio\_maxmargin="integer%";

Slice (LUT-FF Pairs) Utilization Ratio Delta XCF Syntax Example Three

MODEL "entity\_name" slice\_utilization\_ratio\_maxmargin="integer#";

In the preceding examples, XST interprets the integer values in the first two lines as a percentage and in the last line as an absolute number of slices or FF-LUT pairs.

There must be no space between the integer value and the percent (%) or pound (#) characters.

You must surround the integer value and the percent (%) and pound (#) characters with double quotes ("...") because the percent (%) and pound (#) characters are special characters in the XST Constraint File (XCF).

The integer value range is **0** to **100** when percent (%) is used or both percent (%) and pound (**#**) are omitted.

Slice (LUT-FF Pairs) Utilization Ratio Delta XST Command Line Syntax Examples

Define Slice (LUT-FF Pairs) Utilization Ratio Delta globally with the – **slice\_utilization\_ratio\_maxmargin** command line option of the **run** command:

-slice\_utilization\_ratio\_maxmargin integer -slice\_utilization\_ratio\_maxmargin integer%

-slice\_utilization\_ratio\_maxmargin integer#

In the preceding example, XST interprets the integer values in the first two lines as a percentage and in the last line as an absolute number of slices or FF-LUT pairs.

The integer value range is **0** to **100** when percent (%) is used or both percent (%) and pound (**#**) are omitted.

# Map Entity on a Single LUT (LUT\_MAP)

Map Entity on a Single LUT (LUT\_MAP) forces XST to map a single block into a single LUT. If a described function on an RTL level description does not fit in a single LUT, XST issues an error message.

www.xilinx.com

Use the UNISIM library to directly instantiate LUT components in your Hardware Description Language (HDL) code. To specify a function that a particular LUT must execute, apply an INIT constraint to the instance of the LUT. To place an instantiated LUT or register in a particular slice, attach an "RLOC" constraint to the same instance.

It is not always convenient to calculate INIT functions and different methods can be used to achieve this. Instead, you can describe the function that you want to map onto a single LUT in your VHDL or Verilog code in a separate block. Attaching a LUT\_MAP constraint to this block indicates to XST that this block must be mapped on a single LUT. XST automatically calculates the INIT value for the LUT and preserves this LUT during optimization. For more information, see "Specifying INIT and RLOC."

XST automatically recognizes the XC\_MAP constraint supported by Synplicity.

# Map Entity on a Single LUT Architecture Support

Map Entity on a Single LUT applies to all FPGA devices. Map Entity on a Single LUT does not apply to CPLD devices.

## Map Entity on a Single LUT Applicable Elements

Map Entity on a Single LUT applies to a VHDL entity or Verilog module.

## Map Entity on a Single LUT Propagation Rules

Map Entity on a Single LUT applies to the entity or module to which it is attached.

#### Map Entity on a Single LUT Syntax Examples

Following are syntax examples using Map Entity on a Single LUT with particular tools or methods. If a tool or method is not listed, Map Entity on a Single LUT may not be used with it.

Map Entity on a Single LUT VHDL Syntax Example

Before using Map Entity on a Single LUT, declare it with the following syntax:

attribute lut\_map: string;

After declaring Map Entity on a Single LUT, specify the VHDL constraint:

attribute lut\_map of entity\_name : entity is "{yes|no}";

Map Entity on a Single LUT Verilog Syntax Example

Place Map Entity on a Single LUT immediately before the module declaration or instantiation:

(\* lut\_map = "{yes | no}" \*)

Map Entity on a Single LUT XCF Syntax Example

**MODEL** "entity\_name" lut\_map={yes | no | true | false};

# Use Carry Chain (USE\_CARRY\_CHAIN)

XST uses carry chain resources to implement certain macros, but there are situations where you can obtain better results by not using carry chain. Use Carry Chain (USE\_CARRY\_CHAIN) can deactivate carry chain use for macro generation. Use Carry Chain is both a global and a local constraint.

Use Carry Chain values are:

- **yes** (default)
- no

# Use Carry Chain Architecture Support

Use Carry Chain applies to all FPGA devices. Use Carry Chain does not apply to CPLD devices.

# Use Carry Chain Applicable Elements

Use Carry Chain applies globally, or to signals.

## Use Carry Chain Propagation Rules

Use Carry Chain applies to the signal to which it is attached.

# Use Carry Chain Syntax Examples

Following are syntax examples using Use Carry Chain with particular tools or methods. If a tool or method is not listed, Use Carry Chain may not be used with it.

Use Carry Chain Schematic Syntax Example

- Attach to a valid instance
- Attribute Name
   USE\_CARRY\_CHAIN
- Attribute Values
  - yes
  - no

Use Carry Chain VHDL Syntax Example

Before using Use Carry Chain, declare it with the following syntax:

```
attribute use_carry_chain: string;
```

After declaring Use Carry Chain specify the VHDL constraint:

attribute use\_carry\_chain of signal\_name: signal is "{yes|no}";

Use Carry Chain Verilog Syntax Example

Place Use Carry Chain immediately before the signal declaration:

```
(* use_carry_chain = "{yes|no}" *)
```

Use Carry Chain XCF Syntax Example One

MODEL "entity\_name" use\_carry\_chain={yes | no | true | false};

Use Carry Chain XCF Syntax Example Two

```
BEGIN MODEL "entity_name"
```

```
NET "signal_name" use_carry_chain={yes|no|true|false};
```

END;



Use Carry Chain XST Command Line Syntax Example

Define Use Carry Chain globally with the **-use\_carry\_chain** command line option of the **run** command:

-use\_carry\_chain {yes no}

The default is **yes**.

# Convert Tristates to Logic (TRISTATE2LOGIC)

Since some devices do not support internal tristates, XST automatically replaces tristates with equivalent logic. Because the logic generated from tristates can be combined and optimized with surrounding logic, the replacement of internal tristates by logic for other devices can lead to better speed, and in some cases, better area optimization. But in general tristate to logic replacement may lead to area increase. If the optimization goal is Area, you should apply Convert Tristates to Logic (TRISTATE2LOGIC) set to **no**.

## Convert Tristates to Logic Limitations

- Only internal tristates are replaced by logic. The tristates of the top module connected to output pads are preserved.
- Internal tristates are not replaced by logic for modules when incremental synthesis is active.
- Convert Tristates to Logic does not apply to technologies that do not have internal tristates, such as Spartan-3 or Virtex-4 devices. In this case, the conversion of tristates to logic is performed automatically. In some situations XST is unable to make the replacement automatically, due to the fact that this may lead to wrong design behavior or multi-source. This may happen when the hierarchy is preserved or XST does not have full design visibility (for example, design is synthesized on a block-by-block basis). In these cases, XST issues a warning at the low level optimization step. Depending on the particular design situation, you may continue the design flow and the replacement could be done by MAP, or you can force the replacement by applying Convert Tristates to Logic set to **yes** on a particular block or signal.
- The situations in which XST is unable to replace a tristate by logic are:
  - The tristate is connected to a black box.
  - The tristate is connected to the output of a block, and the hierarchy of the block is preserved.
  - The tristate is connected to a top-level output.
  - Convert Tristates to Logic is set to **no** on the block where tristates are placed, or on the signals to which tristates are connected.

Convert Tristates to Logic values are:

- yes (default)
- no
- true (XCF only)
- false (XCF only)

# Convert Tristates to Logic Architecture Support

Convert Tristates to Logic applies to the following FPGA devices only:

- Virtex, Virtex-E
- Spartan-II, Spartan-IIE
- Virtex-II, Virtex-II Pro

Convert Tristates to Logic does not apply to CPLD devices.

#### Convert Tristates to Logic Applicable Elements

Convert Tristates to Logic applies to:

- An entire design through the XST command line
- A particular block (entity, architecture, component)
- A signal

#### Convert Tristates to Logic Propagation Rules

Convert Tristates to Logic applies to an entity, component, module or signal to which it is attached.

#### Convert Tristates to Logic Syntax Examples

Following are syntax examples using Convert Tristates to Logic with particular tools or methods. If a tool or method is not listed, Convert Tristates to Logic may not be used with it.

#### Convert Tristates to Logic VHDL Syntax Example

Before using Convert Tristates to Logic, declare it with the following syntax:

attribute tristate2logic: string;

After declaring Convert Tristates to Logic, specify the VHDL constraint:

```
attribute tristate2logic of {entity_name|component_name|signal_name}:
{entity|component|signal} is "{yes|no}";
```

#### Convert Tristates to Logic Verilog Syntax Example

Place Convert Tristates to Logic immediately before the module or signal declaration:

(\* tristate2logic = "{yes | no}" \*)

Convert Tristates to Logic XCF Syntax Example One

**MODEL** "entity\_name" tristate2logic={yes|no|true|false};

Convert Tristates to Logic XCF Syntax Example Two

**BEGIN MODEL** "entity\_name"

**NET** "signal\_name" tristate2logic={yes|no|true|false};

END;



Convert Tristates to Logic XST Command Line Syntax Example

Define Convert Tristates to Logic globally with the **-tristate2logic** command line option of the **run** command:

-tristate2logic {yes|no}

The default is **yes**.

Convert Tristates to Logic Project Navigator Syntax Example

Define Convert Tristates to Logic globally in **Project Navigator > Process Properties > Xilinx-Specific Options > Convert Tristates to Logic**.

# Use Clock Enable (USE\_CLOCK\_ENABLE)

Clock Enable (USE\_CLOCK\_ENABLE) enables or disables the clock enable function in flip-flops. The disabling of the clock enable function is typically used for ASIC prototyping on FPGA devices.

By detecting Use Clock Enable with a value of **no** or **false**, XST avoids using CE resources in the final implementation. Moreover, for some designs, putting the Clock Enable function on the data input of the flip-flop allows better logic optimization and therefore better QOR. In **auto** mode, XST tries to estimate a trade off between using a dedicated clock enable input of a flip-flop input and putting clock enable logic on the D input of a flip-flop. In a case where a flip-flop is instantiated by you, XST removes the clock enable only if the Optimize Instantiated Primitives option is set to **yes**.

Use Clock Enable values are:

- **auto** (default)
- yes
- no
- true (XCF only)
- false (XCF only)

#### Use Clock Enable Architecture Support

Use Clock Enable applies to all FPGA devices. Use Clock Enable does not apply to CPLD devices.

#### Use Clock Enable Applicable Elements

Use Clock Enable applies to:

- An entire design through the XST command line
- A particular block (entity, architecture, component)
- A signal representing a flip-flop
- An instance representing an instantiated flip-flop

#### Use Clock Enable Propagation Rules

Use Clock Enable applies to an entity, component, module, signal, or instance to which it is attached.

# Use Clock Enable Syntax Examples

Following are syntax examples using Use Clock Enable with particular tools or methods. If a tool or method is not listed, Use Clock Enable may not be used with it.

Use Clock Enable VHDL Syntax Example

Before using Use Clock Enable, declare it with the following syntax:

attribute use\_clock\_enable: string;

After declaring Use Clock Enable, specify the VHDL constraint:

```
attribute use_clock_enable of
{entity_name/component_name/signal_name/instance_name}:
{entity|component|signal|label} is "{auto|yes|no}";
```

Use Clock Enable Verilog Syntax Example

Place Use Clock Enable immediately before the instance, module or signal declaration:

(\* use\_clock\_enable = "{auto|yes|no}" \*)

Use Clock Enable XCF Syntax Example One

```
MODEL "entity_name" use_clock_enable={auto|yes|no|true|false};
```

Use Clock Enable XCF Syntax Example Two

**BEGIN MODEL** "entity\_name"

```
NET "signal_name" use_clock_enable={auto|yes|no|true|false};
```

END;

Use Clock Enable XCF Syntax Example Three

BEGIN MODEL "entity\_name"

```
INST "instance_name" use_clock_enable={auto|yes|no|true|false};
END;
```

Use Clock Enable XST Command Line Syntax Example

Define Use Clock Enable globally with the **-use\_clock\_enable** command line option of the **run** command:

-use\_clock\_enable {auto|yes|no}

The default is **auto**.

Use Clock Enable Project Navigator Syntax Example

Define Use Clock Enable globally in **Project Navigator > Process Properties >** Xilinx-Specific Options > Use Clock Enable.

# Use Synchronous Set (USE\_SYNC\_SET)

Synchronous Set (USE\_SYNC\_SET) enables or disables the synchronous set function in flip-flops. The disabling of the synchronous set function is typically used for ASIC prototyping on FPGA devices. Detecting Use Synchronous Set with a value of **no** or **false**, XST avoids using synchronous reset resources in the final implementation. Moreover, for some designs, putting synchronous reset function on data input of the flip-flop allows better logic optimization and therefore better QOR.



In **auto** mode, XST tries to estimate a trade off between using dedicated Synchronous Set input of a flip-flop input and putting Synchronous Set logic on the D input of a flip-flop. In a case where a flip-flop is instantiated by you, XST removes the synchronous reset only if the Optimize Instantiated Primitives option is set to **yes**.

Use Synchronous Set values are:

- **auto** (default)
- yes
- no
- true (XCF only)
- false (XCF only)

#### Use Synchronous Set Architecture Support

Use Synchronous Set applies to all FPGA devices. Use Synchronous Set does not apply to CPLD devices.

#### Use Synchronous Set Applicable Elements

Use Synchronous Set applies to:

- An entire design through the XST command line
- A particular block (entity, architecture, component)
- A signal representing a flip-flop
- An instance representing an instantiated flip-flop

#### Use Synchronous Set Propagation Rules

Use Synchronous Set applies to an entity, component, module, signal, or instance to which it is attached.

#### Use Synchronous Set Syntax Examples

Following are syntax examples using Use Synchronous Set with particular tools or methods. If a tool or method is not listed, Use Synchronous Set may not be used with it.

#### Use Synchronous Set VHDL Syntax Example

Before using Use Synchronous Set, declare it with the following syntax:

attribute use\_sync\_set: string;

After declaring Use Synchronous Set, specify the VHDL constraint:

```
attribute use_sync_set of
{entity_name/component_name/signal_name/instance_name}:
{entity|component|signal|label} is "{auto|yes|no}";
```

Use Synchronous Set Verilog Syntax Example

Place Use Synchronous Set immediately before the instance, module or signal declaration:

(\* use\_sync\_set = "{auto|yes|no}" \*)

Use Synchronous Set XCF Syntax Example One

```
MODEL "entity_name" use_sync_set={auto|yes|no|true|false};
```

Use Synchronous Set XCF Syntax Example Two

**BEGIN MODEL** "entity\_name"

```
NET "signal_name" use_sync_set={auto|yes|no|true|false};
```

END;

Use Synchronous Set XCF Syntax Example Three

```
BEGIN MODEL "entity_name"
```

**INST** "instance\_name" use\_sync\_set={auto|yes|no|true|false};

END;

Use Synchronous Set XST Command Line Syntax Example

Define Use Synchronous Set globally with the **-use\_sync\_set** command line option of the **run** command:

-use\_sync\_set {auto|yes|no}

The default is **auto**.

Use Synchronous Set Project Navigator Syntax Example

Define Use Synchronous Set globally in **Project Navigator > Process Properties > Xilinx-Specific Options > Use Synchronous Set**.

# Use Synchronous Reset (USE\_SYNC\_RESET)

Synchronous Reset (USE\_SYNC\_RESET) enables or disables the usage of synchronous reset function of flip-flops. The disabling of the Synchronous Reset function could be used for ASIC prototyping flow on FPGA devices.

Detecting Use Synchronous Reset with a value of **no** or **false**, XST avoids using synchronous reset resources in the final implementation. Moreover, for some designs, putting synchronous reset function on data input of the flip-flop allows better logic optimization and therefore better QOR.

In **auto** mode, XST tries to estimate a trade off between using a dedicated Synchronous Reset input on a flip-flop input and putting Synchronous Reset logic on the D input of a flip-flop. In a case where a flip-flop is instantiated by you, XST removes the synchronous reset only if the Optimize Instantiated Primitives option is set to **yes**.

Use Synchronous Reset values are:

- auto (default)
- yes
- no
- true (XCF only)
- false (XCF only)

#### Use Synchronous Reset Architecture Support

Use Synchronous Reset applies to all FPGA devices. Use Synchronous Reset does not apply to CPLD devices.



## Use Synchronous Reset Applicable Elements

Use Synchronous Reset applies to:

- An entire design through the XST command line
- A particular block (entity, architecture, component)
- A signal representing a flip-flop
- An instance representing an instantiated flip-flop

#### Use Synchronous Reset Propagation Rules

Use Synchronous Reset applies to an entity, component, module, signal, or instance to which it is attached.

#### Use Synchronous Reset Syntax Examples

Following are syntax examples using Use Synchronous Reset with particular tools or methods. If a tool or method is not listed, Use Synchronous Reset may not be used with it.

Use Synchronous Reset VHDL Syntax Example

Before using Use Synchronous Reset, declare it with the following syntax:

attribute use\_sync\_reset: string;

After declaring Use Synchronous Reset, specify the VHDL constraint:

```
attribute use_sync_reset of
{entity_name/component_name/signal_name/instance_name}:
{entity|component|signal|label} is "{auto|yes|no}";
```

Use Synchronous Reset Verilog Syntax Example

Place this attribute immediately before the instance, module, or signal declaration:

(\* use\_sync\_reset = "{auto|yes|no}" \*)

Use Synchronous Reset XCF Syntax Example One

**MODEL** "entity\_name" use\_sync\_reset={auto|yes|no|true|false};

Use Synchronous Reset XCF Syntax Example Two

```
BEGIN MODEL "entity_name"
```

**NET** "signal\_name" use\_sync\_reset={auto|yes|no|true|false};

END;

Use Synchronous Reset XCF Syntax Example Three

```
BEGIN MODEL "entity_name"
```

INST "instance\_name" use\_sync\_reset={auto|yes|no|true|false};

END;

Use Synchronous Reset XST Command Line Syntax Example

Define Use Synchronous Reset globally with the **-use\_sync\_reset** command line option of the **run** command:

```
-use_sync_reset {auto|yes|no}
```

The default is **auto**.

Use Synchronous Reset Project Navigator Syntax Example

Define Use Synchronous Reset globally in **Project Navigator > Process Properties > Xilinx-Specific Options > Use Synchronous Reset**.

# Use DSP48 (USE\_DSP48)

This option is called:

- Use DSP48 (Virtex-4 devices)
- Use DSP Block (Virtex-5 devices)

XST enables you to use the resources of the DSP48 blocks introduced in Virtex-4 devices. The default is **auto**. In **auto** mode, XST automatically implements such macros as MAC and accumulates on DSP48, but some of them as adders are implemented on slices. You have to force their implementation on DSP48 using a value of **yes** or **true**. For more information on supported macros and their implementation control, see "XST HDL Coding Techniques."

Several macros (for example, MAC) that can be placed on DSP48 are in fact a composition of simpler macros such as multipliers, accumulators, and registers. To achieve the best performance, XST by default tries to infer and implement the maximum macro configuration. To shape a macro in a specific way, use the "Keep (KEEP)" constraint. For example, DSP48 allows you to implement a multiple with two input registers. To leave the first register stage outside of the DSP48, place the "Keep (KEEP)" constraint in their outputs.

Use DSP48 values are:

- **auto** (default)
- yes
- no
- **true** (XCF only)
- false (XCF only)

In **auto** mode you can control the number of available DSP48 resources for synthesis using "DSP Utilization Ratio (DSP\_UTILIZATION\_RATIO)." By default, XST tries to utilize, as much as possible, all available DSP48 resources. For more information, see "DSP48 Block Resources."

# Use DSP48 Architecture Support

Use DSP48 applies to the following FPGA devices only:

- Spartan-3A D
- Virtex-4, Virtex-5

Use DSP48 does not apply to CPLD devices.

#### Use DSP48 Applicable Elements

Use DSP48 applies to:

- An entire design through the XST command line
- A particular block (entity, architecture, component)
- A signal representing a macro described at the RTL level



# **Use DSP48 Propagation Rules**

Use DSP48 applies to an entity, component, module, or signal to which it is attached.

## Use DSP48 Syntax Examples

Following are syntax examples using Use DSP48 with particular tools or methods. If a tool or method is not listed, Use DSP48 may not be used with it.

#### Use DSP48 VHDL Syntax Example

Before using Use DSP48, declare it with the following syntax:

attribute use\_dsp48: string;

After declaring Use DSP48, specify the VHDL constraint:

```
attribute use_dsp48 of {entity_name|component_name|signal_name}:
{entity|component|signal} is "{auto|yes|no}";
```

#### Use DSP48 Verilog Syntax Example

Place Use DSP48 immediately before the module or signal declaration:

(\* use\_dsp48 = "{auto|yes|no}" \*)

Use DSP48 XCF Syntax Example One

**MODEL** "entity\_name" use\_dsp48={auto|yes|no|true|false};

Use DSP48 XCF Syntax Example Two

```
BEGIN MODEL "entity_name"
```

**NET** "signal\_name" use\_dsp48={auto|yes|no|true|false};

END;

Use DSP48 XST Command Line Syntax Example

Define Use DSP48 globally with the **-use\_dsp48** command line option of the **run** command:

Use DSP48 Project Navigator Syntax Example

Define Use DSP48 globally in **Project Navigator > Process Properties > HDL** Options > Use DSP48.

# XST CPLD Constraints (Non-Timing)

The section discusses XST CPLD constraints (non-timing). The constraints in this section apply to CPLD devices only. They do not apply to FPGA devices. This section discusses the following constraints:

- "Clock Enable (-pld\_ce)"
- "Data Gate (DATA\_GATE)"
- "Macro Preserve (-pld\_mp)"
- "No Reduce (NOREDUCE)"
- "WYSIWYG (–wysiwyg)"
- "XOR Preserve (-pld\_xp)"

# Clock Enable (-pld\_ce)

Clock Enable (**-pld\_ce**) specifies how sequential logic should be implemented when it contains a clock enable, either using the specific device resources available for that or generating equivalent logic.

Clock Enable allows you to specify the way the clock enable function is implemented if presented in the design.

Clock Enable values are:

• yes

The synthesizer implements the clock enable signal of the device.

• no

The clock enable function is implemented through equivalent logic.

Keeping or not keeping the clock enable signal depends on the design logic. Sometimes, when the clock enable is the result of a Boolean expression, setting Clock Enable to **no** may improve the fitting result. The input data of the flip-flop is simplified when it is merged with the clock enable expression.

## **Clock Enable Architecture Support**

Clock Enable applies to all CPLD devices. Clock Enable does not apply to FPGA devices.

#### **Clock Enable Applicable Elements**

Clock Enable applies to an entire design through the XST command line.

#### **Clock Enable Propagation Rules**

Not applicable

#### **Clock Enable Syntax Examples**

Following are syntax examples using Clock Enable with particular tools or methods. If a tool or method is not listed, Clock Enable may not be used with it.

Clock Enable XST Command Line Syntax Example

Define Clock Enable globally with the **-pld\_ce** command line option of the **run** command:

-pld\_ce {yes | no}

The default is **yes**.

Clock Enable Project Navigator Syntax Example

Define Clock Enable globally in **Project Navigator > Process Properties >** Xilinx-Specific Options > Clock Enable.

# Data Gate (DATA\_GATE)

Data Gate applies to CoolRunner-II devices only.

Data Gate (DATA\_GATE) provides direct means of reducing power consumption in your design. Each I/O pin input signal passes through a latch that can block the propagation of

www.xilinx.com

incident transitions during periods when such transitions are not of interest to your CPLD design.

Input transitions that do not affect the CPLD design function still consume power, if not latched, as they are routed among the CPLD's Function Blocks. By asserting the Data Gate control I/O pin on the device, selected I/O pin inputs become latched, thereby eliminating the power dissipation associated with external transitions on those pins.

For more information, see "DATA\_GATE" in the Xilinx *Constraints Guide*.

# Macro Preserve (-pld\_mp)

Macro Preserve (-pld\_mp) makes macro handling independent of design hierarchy processing. This allows you to merge all hierarchical blocks in the top module, while still keeping the macros as hierarchical modules. You can also keep the design hierarchy except for the macros, which are merged with the surrounding logic. Merging the macros sometimes gives better results for design fitting.

Macro Preserve values are:

• yes

Macros are preserved and generated by Macro+.

• no

Macros are rejected and generated by HDL synthesizer

Depending on the Macro Preserve value, a rejected macro is either merged in the design logic, or becomes a hierarchical block. See Table 5-7, "Disposition of Rejected Macros."

Table 5-7: Disposition of Rejected Macros

Flatten Hierarchy Value	Disposition
yes	Merged in the design logic
no	Becomes a hierarchical block

Very small macros such as 2-bit adders and 4-bit multiplexers are always merged, independent of the Macro Preserve or Flatten Hierarchy options.

#### Macro Preserve Architecture Support

Macro Preserve applies to all CPLD devices. Macro Preserve does not apply to FPGA devices.

#### Macro Preserve Applicable Elements

Macro Preserve applies to an entire design through the XST command line.

#### Macro Preserve Propagation Rules

Not applicable

#### Macro Preserve Syntax Examples

Following are syntax examples using Macro Preserve with particular tools or methods. If a tool or method is not listed, Macro Preserve may not be used with it.

Macro Preserve XST Command Line Syntax Example

Define Macro Preserve globally with the **-pld\_mp** command line option of the **run** command:

-pld\_mp {yes | no}

The default is **yes**.

Macro Preserve Project Navigator Syntax Example

Define Macro Preserve globally in **Project Navigator > Process Properties >** Xilinx-Specific Options > Macro Preserve.

## No Reduce (NOREDUCE)

No Reduce (NOREDUCE):

- Prevents minimization of redundant logic terms that are typically included in a design to avoid logic hazards or race conditions
- Identifies the output node of a combinatorial feedback loop to ensure correct mapping

For more information, see "NOREDUCE" in the Xilinx Constraints Guide.

## WYSIWYG (-wysiwyg)

WYSIWYG (**-wysiwyg**) makes a netlist reflect the user specification as closely as possible. That is, all the nodes declared in the Hardware Description Language (HDL) design are preserved.

If WYSIWYG mode is enabled (yes), XST:

- Preserves all user internal signals (nodes)
- Creates SOURCE\_NODE constraints in the NGC file for all these nodes
- Skips design optimization (collapse, factorization)

Only boolean equation minimization is performed.

#### WYSIWYG Architecture Support

WYSIWYG applies to all CPLD devices. WYSIWYG does not apply to FPGA devices.

#### WYSIWYG Applicable Elements

WYSIWYG applies to an entire design through the XST command line.

#### WYSIWYG Propagation Rules

Not applicable

#### WYSIWYG Syntax Examples

Following are syntax examples using WYSIWYG with particular tools or methods. If a tool or method is not listed, WYSIWYG may not be used with it.

#### WYSIWYG XST Command Line Syntax Example

Define WYSIWYG globally with the **-wysiwyg** command line option of the **run** command:



-wysiwyg {yes|no}

The default is **no**.

WYSIWYG Project Navigator Syntax Example

Define WYSIWYG globally in **Project Navigator** > **Process Properties** > **Xilinx-Specific Options** > **WYSIWYG**.

## XOR Preserve (-pld\_xp)

XOR Preserve (-pld\_xp) enables or disables hierarchical flattening of XOR macros.

The XORs inferred by Hardware Description Language (HDL) synthesis are also considered as macro blocks in the CPLD flow. They are processed separately to give more flexibility for using device macrocells XOR gates. Therefore, you can decide to flatten its design (Flatten Hierarchy **yes**, Macro Preserve **no**) but you want to preserve the XORs. Preserving XORs has a great impact on reducing design complexity.

XOR Preserve values are:

• yes (default)

XOR macros are preserved

• no

XOR macros are merged with surrounded logic

Preserving XORs generally gives better results. That is, the number of PTerms is lower. Use the **no** value to obtain completely flat netlists. Applying global optimization on a completely flat design sometimes improves design fitting.

To obtain a completely flattened design, select the following options:

• Flatten Hierarchy

yes

- Macro Preserve
  - no
- XOR Preserve

no

The **no** value does not guarantee the elimination of the XOR operator from the Electronic Data Interchange Format (EDIF) netlist. During the netlist generation, the netlist mapper tries to recognize and infer XOR gates in order to decrease the logic complexity. This process is independent of the XOR preservation done by Hardware Description Language (HDL) synthesis, and is guided only by the goal of complexity reduction.

#### XOR Preserve Architecture Support

XOR Preserve applies to all CPLD devices. XOR Preserve does not apply to FPGA devices.

#### **XOR Preserve Applicable Elements**

XOR Preserve applies to an entire design through the XST command line.

#### XOR Preserve Propagation Rules

Not applicable

## **XOR Preserve Syntax Examples**

Following are syntax examples using XOR Preserve with particular tools or methods. If a tool or method is not listed, XOR Preserve may not be used with it.

XOR Preserve XST Command Line Syntax Example

Define XOR Preserve globally with the **-pld\_xp** command line option of the **run** command:

-pld\_xp {yes | no}

The default is **yes**.

XOR Preserve Project Navigator Syntax Example

Define XOR Preserve globally in **Project Navigator > Process Properties > Xilinx-Specific Options > XOR Preserve**.

# **XST Timing Constraints**

This section discusses XST timing constraints:

- "Cross Clock Analysis (–cross\_clock\_analysis)"
- "Write Timing Constraints (-write\_timing\_constraints)"
- "Clock Signal (CLOCK\_SIGNAL)"
- "Global Optimization Goal (-glob\_opt)"
- "XCF Timing Constraint Support"
- "Period (PERIOD)"
- "Offset (OFFSET)"
- "From-To (FROM-TO)"
- "Timing Name (TNM)"
- "Timing Name on a Net (TNM\_NET)"
- "Timegroup (TIMEGRP)"
- "Timing Ignore (TIG)"

## **Applying Timing Constraints**

Apply XST-supported timing constraints with:

- Global Optimization Goal (-glob\_opt)
- Project Navigator > Process Properties > Synthesis Options > Global Optimization Goal
- User Constraints File (UCF)

## Applying Timing Constraints Using Global Optimization Goal

Global Optimization Goal (**-glob\_opt**) allows you to apply the five global timing constraints:

- ALLCLOCKNETS
- OFFSET\_IN\_BEFORE
- OFFSET\_OUT\_AFTER

- INPAD\_TO\_OUTPAD
- MAX\_DELAY

These constraints are applied globally to the entire design. You cannot specify a value for these constraints, since XST optimizes them for the best performance. These constraints are overridden by constraints specified in the User Constraints File (UCF).

## Applying Timing Constraints Using the User Constraints File (UCF)

The User Constraints File (UCF allows you to specify timing constraints using native UCF syntax. XST supports constraints such as:

- "Timing Name (TNM)"
- "Timegroup (TIMEGRP)"
- "Period (PERIOD)"
- "Timing Ignore (TIG)"
- "From-To (FROM-TO)"

XST supports wildcards and hierarchical names with these constraints.

#### Writing Constraints to the NGC file

Timing constraints are not written to the NGC file by default. Timing constraints are written to the NGC file only when:

- Write Timing Constraints is checked yes in Project Navigator > Process Properties, or
- The **-write\_timing\_constraints** option is specified when using the command line.

#### Additional Options Affecting Timing Constraint Processing

Three additional options affect timing constraint processing, regardless of how the timing constraints are specified:

- "Cross Clock Analysis (–cross\_clock\_analysis)"
- "Write Timing Constraints (-write\_timing\_constraints)"
- "Clock Signal (CLOCK\_SIGNAL)"

## Cross Clock Analysis (-cross\_clock\_analysis)

Cross Clock Analysis (**-cross\_clock\_analysis**) allows inter-clock domain analysis during timing optimization. By default (**no**), XST does not perform this analysis.

#### Cross Clock Analysis Architecture Support

Cross Clock Analysis applies to all FPGA devices. Cross Clock Analysis does not apply to CPLD devices.

#### **Cross Clock Analysis Applicable Elements**

Cross Clock Analysis applies to an entire design through the XST command line.

## **Cross Clock Analysis Propagation Rules**

Not applicable

#### Cross Clock Analysis Syntax Examples

Following are syntax examples using Cross Clock Analysis with particular tools or methods. If a tool or method is not listed, Cross Clock Analysis may not be used with it.

Cross Clock Analysis XST Command Line Syntax Example

Define Cross Clock Analysis globally with the **-cross\_clock\_analysis** command line option of the **run** command:

-cross\_clock\_analysis {yes|no}

The default is **yes**.

Cross Clock Analysis Project Navigator Syntax Example

Define Cross Clock Analysis globally in **Project Navigator > Process Properties > Synthesis Options > Cross Clock Analysis**.

## Write Timing Constraints (-write\_timing\_constraints)

Timing constraints are written to the NGC file only when:

- Write Timing Constraints is checked yes in Project Navigator > Process Properties, or
- The -write\_timing\_constraints option is specified when using the command line.

Timing constraints are not written to the NGC file by default.

#### Write Timing Constraints Architecture Support

Write Timing Constraints is architecture independent.

#### Write Timing Constraints Applicable Elements

Write Timing Constraints applies to an entire design through the XST command line.

#### Write Timing Constraints Propagation Rules

Not applicable

#### Write Timing Constraints Syntax Examples

Following are syntax examples using Write Timing Constraints with particular tools or methods. If a tool or method is not listed, Write Timing Constraints may not be used with it.

Write Timing Constraints XST Command Line Syntax Example

Define Write Timing Constraints globally with the **-write\_timing\_constraints** command line option of the **run** command:

-write\_timing\_constraints {yes | no }

The default is **yes**.



Write Timing Constraints Project Navigator Syntax Example

Define Write Timing Constraints globally in **Project Navigator > Process Properties > Synthesis Options > Write Timing Constraints**.

## Clock Signal (CLOCK\_SIGNAL)

If a clock signal goes through combinatorial logic before being connected to the clock input of a flip-flop, XST cannot identify what input pin or internal signal is the real clock signal. Clock Signal (CLOCK\_SIGNAL) allows you to define the clock signal.

#### **Clock Signal Architecture Support**

Clock Signal applies to all FPGA devices. Clock Signal does not apply to CPLD devices.

#### **Clock Signal Applicable Elements**

Clock Signal applies to signals.

#### Clock Signal Propagation Rules

Clock Signal applies to clock signals.

#### **Clock Signal Syntax Examples**

Following are syntax examples using Clock Signal with particular tools or methods. If a tool or method is not listed, Clock Signal may not be used with it.

Clock Signal VHDL Syntax Example

Before using Clock Signal, declare it with the following syntax:

attribute clock\_signal : string;

After declaring CLOCK\_SIGNAL, specify the VHDL constraint:

```
attribute clock_signal of signal_name : signal is "{yes | no}";
```

Clock Signal Verilog Syntax Example

Place Clock Signal immediately before the signal declaration:

```
(* clock_signal = "{yes | no}" *)
```

Clock Signal XCF Syntax Example

```
BEGIN MODEL "entity_name"
NET "primary_clock_signal" clock_signal={yes|no|true|false};
END;
```

## Global Optimization Goal (–glob\_opt)

Depending on the Global Optimization Goal, XST can optimize the following design regions:

- Register to register
- Inpad to register
- Register to outpad

• Inpad to outpad)

Global Optimization Goal (-glob\_opt) selects the global optimization goal. For a detailed description of supported timing constraints, see "Partitions."

You cannot specify a value for Global Optimization Goal. XST optimizes the entire design for the best performance.

Apply the following constraints with Global Optimization Goal:

ALLCLOCKNETS

Optimizes the period of the entire design

• OFFSET\_IN\_BEFORE

Optimizes the maximum delay from input pad to clock, either for a specific clock or for an entire design

#### • OFFSET\_OUT\_AFTER

Optimizes the maximum delay from clock to output pad, either for a specific clock or for an entire design

#### • INPAD\_TO\_OUTPAD

Optimizes the maximum delay from input pad to output pad throughout an entire design

• MAX\_DELAY

Incorporates all previously mentioned constraints

These constraints affect the entire design. They apply only if no timing constraints are specified in the constraint file.

Define Global Optimization Goal globally with the **-glob\_opt** command line option of the **run** command:

Specify Global Optimization Goal globally in **Project Navigator > Process Properties > Synthesis Options > Global Optimization Goal**.

## **Global Optimization Goal Domain Definitions**

The possible domains are shown in the following schematic.

• ALLCLOCKNETS (register to register)

Identifies, by default, all paths from register to register on the same clock for all clocks in a design. To take inter-clock domain delays into account, set "Cross Clock Analysis (–cross\_clock\_analysis)" to **yes**.

OFFSET\_IN\_BEFORE (inpad to register)

Identifies all paths from all primary input ports to either all sequential elements or the sequential elements driven by the given clock signal name.

• **OFFSET\_OUT\_AFTER** (register to outpad)

Similar to the previous constraint, but sets the constraint from the sequential elements to all primary output ports.

• INPAD\_TO\_OUTPAD (inpad to outpad)


Sets a maximum combinational path constraint.



#### • MAX\_DELAY

Identifies all paths defined by the following timing constraints:

- ♦ ALLCLOCKNETS
- OFFSET\_IN\_BEFORE
- OFFSET\_OUT\_AFTER
- INPAD\_TO\_OUTPAD



# **XCF Timing Constraint Support**

If you specify timing constraints in the XST Constraint File (XCF), Xilinx recommends that you use a forward slash (/) as a hierarchy separator instead of an underscore (\_). For more information, see "Hierarchy Separator (-hierarchy\_separator)"

If all or part of a specified timing constraint is not supported by XST, XST issues a warning, and ignores the unsupported timing constraint (or unsupported part of it) in the Timing Optimization step. If the Write Timing Constraints option is set to **yes**, XST propagates the entire constraint to the final netlist, even if it was ignored at the Timing Optimization step.

The following timing constraints are supported in the XCF:

- "Period (PERIOD)"
- "Offset (OFFSET)"
- "From-To (FROM-TO)"
- "Timing Name (TNM)"
- "Timing Name on a Net (TNM\_NET)"
- "Timegroup (TIMEGRP)"
- "Timing Ignore (TIG)"

## Period (PERIOD)

Period (PERIOD) is a basic timing constraint and synthesis constraint. A clock period specification checks timing between all synchronous elements within the clock domain as defined in the destination element group. The group may contain paths that pass between

clock domains if the clocks are defined as a function of one or the other. For more information, see "PERIOD" in the Xilinx *Constraints Guide*.

Period XCF Syntax Example

**NET** netname **PERIOD =** value [{**HIGH** | **LOW**} value];

# **Offset (OFFSET)**

Offset (OFFSET) is a basic timing constraint. It specifies the timing relationship between an external clock and its associated data-in or data-out pin. OFFSET is used only for pad-related signals, and cannot be used to extend the arrival time specification method to the internal signals in a design.

OFFSET allows you to:

- Calculate whether a setup time is being violated at a flip-flop whose data and clock inputs are derived from external nets
- Specify the delay of an external output net derived from the Q output of an internal flip-flop being clocked from an external device pin

For more information, see "OFFSET" in the Xilinx Constraints Guide.

Offset XCF Syntax Example

## From-To (FROM-TO)

From-To (FROM-TO) defines a timing constraint between two groups. A group can be user-defined or predefined (FFS, PADS, RAMS). For more information, see "FROM-TO" in the Xilinx *Constraints Guide*.

From-To XCF Syntax Example

**TIMESPEC** TSname = FROM group1 TO group2 value;

## Timing Name (TNM)

Timing Name (TNM) is a basic grouping constraint. Use TNM to identify the elements that make up a group which you can then use in a timing specification. TNM tags specific FFS, RAMs, LATCHES, PADS, BRAMS\_PORTA, BRAMS\_PORTB, CPUS, HSIOS, and MULTS as members of a group to simplify the application of timing specifications to the group.

The RISING and FALLING keywords may also be used with TNMs. For more information, see "TNM" in the Xilinx *Constraints Guide*.

Timing Name XCF Syntax Example

```
{INST |NET |PIN} inst_net_or_pin_name TNM = [predefined_group:]
identifier;
```

## Timing Name on a Net (TNM\_NET)

Timing Name on a Net (TNM\_NET) is essentially equivalent to TNM on a net *except* for input pad nets. Special rules apply when using TNM\_NET with the PERIOD constraint for Virtex, Virtex-E, Virtex-II, Virtex-II Pro, Virtex-4 or Spartan-3 LL/DCMs. For more

information, see "PERIOD Specifications on CLKDLLs and DCMs" in the Xilinx *Constraints Guide*.

A TNM\_NET is a property that you normally use in conjunction with a Hardware Description Language (HDL) design to tag a specific net. All downstream synchronous elements and pads tagged with the TNM\_NET identifier are considered a group. For more information, see "TNM\_NET"" in the Xilinx *Constraints Guide*.

Timing Name on a Net XCF Syntax Example

**NET** netname **TNM\_NET** = [predefined\_group:] identifier;

# **Timegroup (TIMEGRP)**

Timegroup (TIMEGRP) is a basic grouping constraint. In addition to naming groups using the TNM identifier, you can also define groups in terms of other groups. You can create a group that is a combination of existing groups by defining a TIMEGRP constraint.

You can place TIMEGRP constraints in a constraints file (XST Constraint File (XCF) or Netlist Constraints File (NCF). You can use TIMEGRP attributes to create groups using the following methods.

- Combining multiple groups into one
- Defining flip-flop subgroups by clock sense

For more information, see "TIMEGRP" in the Xilinx Constraints Guide.

Timegroup XCF Syntax Example

**TIMEGRP** newgroup = existing\_grp1 existing\_grp2 [existing\_grp3 ...];

## Timing Ignore (TIG)

Timing Ignore (TIG) causes all paths going through a specific net to be ignored for timing analyses and optimization purposes. Timing Ignore can be applied to the name of the signal affected. For more information, see "TIG" in the Xilinx *Constraints Guide*.

Timing Ignore XCF Syntax Example

**NET** net\_name **TIG;** 

# **XST Implementation Constraints**

This section discusses XST implementation constraints. For more information, see the Xilinx *Constraints Guide*. This section includes:

- "About Implementation Constraints"
- "Implementation Constraints Syntax Examples"
- "RLOC"
- "NOREDUCE"
- "PWR\_MODE"

## About Implementation Constraints

Implementation constraints control placement and routing. They are not directly used by XST, but are simply propagated and made available to the implementation tools. The object to which an implementation constraint is attached is preserved.

A binary equivalent of the implementation constraints is written to the NGC file. Since the file is binary, you cannot edit implementation constraints in the NGC file.

Alternatively, you can code implementation constraints in the XST Constraint File (XCF) using the syntaxes shown in "Implementation Constraints Syntax Examples."

## Implementation Constraints Syntax Examples

This section gives the following Implementation Constraints coding examples:

- "Implementation Constraints XCF Syntax Examples"
- "Implementation Constraints VHDL Syntax Examples"
- "Implementation Constraints Verilog Syntax Examples"

#### Implementation Constraints XCF Syntax Examples

To apply an implementation constraint to an entire entity, use either of the following XST Constraint File (XCF) syntaxes:

MODEL EntityName PropertyName; MODEL EntityName PropertyName=PropertyValue;

To apply an implementation constraint to specific instances, nets, or pins within an entity, use either of the following syntaxes:

BEGIN MODEL EntityName
{NET | INST | PIN} {NetName | InstName | SigName} PropertyName;
END;
BEGIN MODEL EntityName
{NET | INST | PIN} {NetName | InstName | SigName} PropertyName=Propertyvalue;

END;

## Implementation Constraints VHDL Syntax Examples

Specify implementation constraints in VHDL as follows:

```
attribute PropertyName of {NetName | InstName | PinName } : {signal | label }
is "PropertyValue";
```

#### Implementation Constraints Verilog Syntax Examples

Specify implementation constraints in Verilog as follows:

// synthesis attribute PropertyName of {NetName | InstName | PinName} is
"PropertyValue";

In Verilog-2001, where descriptions precede the signal, module, or instance to which they refer, specify implementation constraints as follows:

```
(* PropertyName="PropertyValue" *)
```

# RLOC

RLOC applies to all FPGA devices. RLOC does not apply to CPLD devices.

Use RLOC to indicate the placement of a design element on the FPGA die relative to other elements. Assuming an SRL16 instance of name srl1 to be placed at location R9C0.S0, you may specify the following in the Verilog code:

// synthesis attribute RLOC of srl1 : "R9C0.S0";

You may specify the same attribute in the XST Constraint File (XCF) as follows:

BEGIN MODEL ENTNAME

INST sr11 RLOC=R9C0.SO;

END;

The binary equivalent of the following line is written to the output NGC file:

INST srl1 RLOC=R9C0.S0;

For more information, see "RLOC" in the Xilinx Constraints Guide.

## NOREDUCE

NOREDUCE applies to all CPLD devices. NOREDUCE does not apply to FPGA devices.

NOREDUCE prevents the optimization of the boolean equation generating a given signal. Assuming a local signal is assigned the arbitrary function below, and NOREDUCE attached to the signal *s*:

```
signal s : std_logic;
attribute NOREDUCE : boolean;
attribute NOREDUCE of s : signal is "true";
...
s <= a or (a and b);</pre>
```

Specify NOREDUCE in the XST Constraint File (XCF) as follows:

```
BEGIN MODEL ENTNAME
NET s NOREDUCE;
NET s KEEP;
END;
```

XST writes the following statements to the NGC file:

```
NET S NOREDUCE;
```

NET s KEEP;

For more information, see "NOREDUCE" in the Xilinx Constraints Guide.

## PWR\_MODE

PWR\_MODE applies to all CPLD devices. PWR\_MODE does not apply to FPGA devices.

PWR\_MODE controls the power consumption characteristics of macrocells. The following VHDL statement specifies that the function generating signal *s* should be optimized for low power consumption:

attribute PWR\_MODE : string; attribute PWR\_MODE of s : signal is "LOW";

Specify PWR\_MODE in the XST Constraint File (XCF) as follows:

```
MODEL ENTNAME
NET S PWR_MODE=LOW;
NET S KEEP;
END;
```

XST writes the following statement to the NGC file:

```
NET S PWR_MODE=LOW;
NET S KEEP;
```

The Hardware Description Language (HDL) attribute can be applied to the signal on which XST infers the instance if:

- The attribute applies to an instance (for example, "Pack I/O Registers Into IOBs (IOB)", DRIVE, IOSTANDARD), and
- The instance is not available (not instantiated) in the HDL source

# **XST-Supported Third Party Constraints**

This section describes constraints of third-party synthesis vendors that are supported by XST. This section includes:

- "XST Equivalents to Third Party Constraints"
- "Third Party Constraints Syntax Examples"

## XST Equivalents to Third Party Constraints

Table 5-8, "XST Equivalents to Third Party Constraints," shows the XST equivalent for each of the third party constraints. For specific information on these constraints, see the vendor documentation.

Several third party constraints are automatically supported by XST, as shown in Table 5-8, "XST Equivalents to Third Party Constraints." Constraints marked **yes** are fully supported. If a constraint is only partially supported, the support conditions are shown in the Automatic Recognition column.

The following rules apply:

- VHDL uses standard attribute syntax. No changes are needed to the Hardware Description Language (HDL) code.
- For Verilog with third party metacomment syntax, the metacomment syntax must be changed to conform to XST conventions. The constraint name and its value can be used as shown in the third party tool.



• For Verilog 2001 attributes, no changes are needed to the HDL code. The constraint is automatically translated as in the case of VHDL attribute syntax

Table 5-8: XST Equivalents to Third Party Constraints

Name	Vendor	XST Equivalent	Automatic Recognition	Available For
black_box	Synplicity	"BoxType (BOX_TYPE)"	N/A	VHDL Verilog
black_box_pad_pin	Synplicity	N/A	N/A	N/A
black_box_tri_pins	Synplicity	N/A	N/A	N/A
cell_list	Synopsys	N/A	N/A	N/A
clock_list	Synopsys	N/A	N/A	N/A
Enum	Synopsys	N/A	N/A	N/A
full_case	Synplicity Synopsys	"Full Case (FULL_CASE)"	N/A	Verilog
ispad	Synplicity	N/A	N/A	N/A
map_to_module	Synopsys	N/A	N/A	N/A
net_name	Synopsys	N/A	N/A	N/A
parallel_case	Synplicity Synopsys	"Parallel Case (PARALLEL_CASE)"	N/A	Verilog
return_port_name	Synopsys	N/A	N/A	N/A
resource_sharing directives	Synopsys	"Resource Sharing (RESOURCE_SHARI NG)"	N/A	VHDL Verilog
set_dont_touch_network	Synopsys	not required	N/A	N/A
set_dont_touch	Synopsys	not required	N/A	N/A
<pre>set_dont_use_cel_name</pre>	Synopsys	not required	N/A	N/A
set_prefer	Synopsys	N/A	N/A	N/A
state_vector	Synopsys	N/A	N/A	N/A
syn_allow_retiming	Synplicity	"Register Balancing (REGISTER_BALAN CING)"	N/A	VHDL Verilog
syn_black_box	Synplicity	"BoxType (BOX_TYPE)"	Yes	VHDL Verilog
syn_direct_enable	Synplicity	N/A	N/A	N/A
syn_edif_bit_format	Synplicity	N/A	N/A	N/A
syn_edif_scalar_format	Synplicity	N/A	N/A	N/A

T.I.I. C 0		
Table 5-8:	XST Equivalents to Third Party Constraints (Cont'd)	

Name	Vendor	XST Equivalent	Automatic Recognition	Available For
syn_encoding	Synplicity	"FSM Encoding Algorithm (FSM_ENCODING)"	Yes (The value <i>safe</i> is not supported for automatic recognition. Use "Safe Implementation (SAFE_IMPLEMENTAT ION)" in XST to activate this mode.)	VHDL Verilog
syn_enum_encoding	Synplicity	"Enumerated Encoding (ENUM_ENCODING )"	N/A	VHDL
syn_hier	Synplicity	"Keep Hierarchy (KEEP_HIERARCHY )"	Yes syn_hier = hard recognized as keep_hierarchy = soft syn_hier = remove recognized as keep_hierarchy = no (XST supports only the values <i>hard</i> and <i>remove</i> for syn_hier in automatic recognition.)	VHDL Verilog
syn_isclock	Synplicity	N/A	N/A	N/A
syn_keep	Synplicity	"Keep (KEEP)"	Yes	VHDL Verilog
syn_maxfan	Synplicity	"Max Fanout (MAX_FANOUT)"	Yes	VHDL Verilog
syn_netlist_hierarchy	Synplicity	"Netlist Hierarchy (- netlist_hierarchy)"	N/A	VHDL Verilog
syn_noarrayports	Synplicity	N/A	N/A	N/A
syn_noclockbuf	Synplicity	"Buffer Type (BUFFER_TYPE)"	Yes	VHDL Verilog
syn_noprune	Synplicity	"Optimize Instantiated Primitives (OPTIMIZE_PRIMITI VES)"	Yes	VHDL Verilog
syn_pipeline	Synplicity	"Register Balancing (REGISTER_BALAN CING)"	N/A	VHDL Verilog



Name	Vendor	XST Equivalent	Automatic Recognition	Available For	
syn_preserve	Synplicity	"Equivalent Register Removal (EQUIVALENT_REG ISTER_REMOVAL)"	Yes	VHDL Verilog	
syn_ramstyle	Synplicity	ram_extract and ram_style	<ul> <li>Yes</li> <li>XST implements RAMs in no_rw_check mode regardless if no_rw_check is specified or not</li> <li>the area value is ignored</li> </ul>	VHDL Verilog	
syn_reference_clock	Synplicity	N/A	N/A	N/A	
syn_replicate	Synplicity	"Register Duplication (REGISTER_DUPLIC ATION)"	Yes	VHDL Verilog	
syn_romstyle	Synplicity	rom_extract and rom_style	Yes	VHDL Verilog	
syn_sharing	Synplicity	N/A	N/A	VHDL Verilog	
syn_state_machine	Synplicity	"Automatic FSM Extraction (FSM_EXTRACT)"	Yes	VHDL Verilog	
syn_tco <n></n>	Synplicity	N/A	N/A	N/A	
syn_tpd <n></n>	Synplicity	N/A	N/A	N/A	
syn_tristate	Synplicity	N/A	N/A	N/A	
syn_tristatetomux	Synplicity	N/A	N/A	N/A	
syn_tsu <n></n>	Synplicity	N/A	N/A	N/A	
syn_useenables	Synplicity	N/A	N/A	N/A	
syn_useioff	Synplicity	"Pack I/O Registers Into IOBs (IOB)"	N/A	VHDL Verilog	
synthesis translate_off synthesis translate_on	Synplicity Synopsys	"Translate Off (TRANSLATE_OFF) and Translate On (TRANSLATE_ON)"	Yes	VHDL Verilog	
xc_alias	Synplicity	N/A	N/A	N/A	
xc_clockbuftype	Synplicity	"Buffer Type (BUFFER_TYPE)"	N/A	VHDL Verilog	

Name	Vendor	XST Equivalent	Automatic Recognition	Available For
xc_fast	Synplicity	"FAST"	N/A	VHDL Verilog
xc_fast_auto	Synplicity	"FAST"	N/A	VHDL Verilog
xc_global_buffers	Synplicity	"BUFG (XST)"	N/A	VHDL Verilog
xc_ioff	Synplicity	"Pack I/O Registers Into IOBs (IOB)"	N/A	VHDL Verilog
xc_isgsr	Synplicity	N/A	N/A	N/A
xc_loc	Synplicity	"LOC"	Yes	VHDL Verilog
xc_map	Synplicity	LUT_MAP	Yes (XST supports only the value lut for automatic recognition.)	VHDL Verilog
xc_ncf_auto_relax	Synplicity	N/A	N/A	N/A
xc_nodelay	Synplicity	"NODELAY"	N/A	VHDL Verilog
xc_padtype	Synplicity	"I/O Standard (IOSTANDARD)"	N/A	VHDL Verilog
xc_props	Synplicity	N/A	N/A	N/A
xc_pullup	Synplicity	"PULLUP"	N/A	VHDL Verilog
xc_rloc	Synplicity	"RLOC"	Yes	VHDL Verilog
xc_fast	Synplicity	"FAST"	N/A	VHDL Verilog
xc_slow	Synplicity	N/A	N/A	N/A
xc_uset	Synplicity	"U_SET"	Yes	VHDL Verilog

Table 5-8: XST Equivalents to Third Party Constraints (Cont'd)

# Third Party Constraints Syntax Examples

This section contains the following third party constraints syntax examples:

- "Third Party Constraints Verilog Syntax Example"
- "Third Party Constraints XCF Syntax Example"

Third Party Constraints Verilog Syntax Example

```
module testkeep (in1, in2, out1);
input in1;
input in2;
```



```
output out1;
(* keep = "yes" *) wire aux1;
(* keep = "yes" *) wire aux2;
assign aux1 = in1;
assign aux2 = in2;
assign out1 = aux1 & aux2;
endmodule
```

Third Party Constraints XCF Syntax Example

The "Keep (KEEP)" constraint can also be applied through the separate synthesis constraint file:

```
BEGIN MODEL testkeep
NET aux1 KEEP=true;
END;
```

These are the only two ways of preserving a signal/net in a Hardware Description Language (HDL) design and preventing optimization on the signal or net during synthesis.



# Chapter 6

# XST VHDL Language Support

This chapter (*XST VHDL Language Support*) explains how XST supports the VHDL hardware description language, and provides details on VHDL, supported constructs, and synthesis options. This chapter includes:

- "About XST VHDL Language Support"
- "VHDL IEEE Support"
- "XST VHDL File Type Support"
- "Debugging Using Write Operation in VHDL"
- "VHDL Data Types"
- "VHDL Record Types"
- "VHDL Initial Values"
- "VHDL Objects"
- "VHDL Operators"
- "Entity and Architecture Descriptions in VHDL"
- "VHDL Combinatorial Circuits"
- "VHDL Sequential Circuits"
- "VHDL Functions and Procedures"
- "VHDL Assert Statements"
- "Using Packages to Define VHDL Models"
- "VHDL Constructs Supported in XST"
- "VHDL Reserved Words"


For more information, see the following:

- For a complete specification of VHDL, see the IEEE VHDL Language Reference Manual.
- For a description of supported design constraints, see "XST Design Constraints."
- For a description of VHDL attribute syntax, see "VHDL Attribute Syntax."

# About XST VHDL Language Support

VHDL offers a broad set of constructs for compactly describing complicated logic:

- VHDL allows the description of the structure of a system how it is decomposed into subsystems, and how those subsystems are interconnected.
- VHDL allows the specification of the function of a system using familiar programming language forms.



• VHDL provides a mechanism for easily producing a detailed, device-dependent version of a design to be synthesized from a more abstract specification. This feature allows you to concentrate on more strategic design decisions, and reduce the overall time to market for the design.

# **VHDL IEEE Support**

This section discusses VHDL IEEE Support, and includes:

- "About VHDL IEEE Support"
- "VHDL IEEE Conflicts"
- "Non-LRM Compliant Constructs in VHDL"

## About VHDL IEEE Support

XST supports:

- VHDL IEEE std 1076-1987
- VHDL IEEE std 1076-1993
- VHDL IEEE std 1076-2006 (partially implemented)

XST allows instantiation for VHDL IEEE std 1076-2006 when:

- The formal port is a buffer and the associated actual is an out
- The formal port is an out and the associated actual is a buffer

## VHDL IEEE Conflicts

VHDL IEEE std 1076-1987 constructs are accepted if they do not conflict with VHDL IEEE std 1076-1993. In case of a conflict, Std 1076-1993 behavior overrides std 1076-1987.

In cases where:

- Std 1076-1993 requires a construct to be an erroneous case, but
- Std 1076-1987 accepts it,

XST issues a warning instead of an error. An error would stop analysis.

#### VHDL IEEE Conflict Example

Following is an example of a VHDL IEEE conflict:

- Std 1076-1993 requires an impure function to use the **impure** keyword while declaring a function.
- Std 1076-1987 has no such requirement.

In this case, XST:

- Accepts the VHDL code written for Std 1076-1987
- Issues a warning stating Std 1076-1993 behavior

# Non-LRM Compliant Constructs in VHDL

XST supports some non-LRM compliant constructs. XST supports a specific non-LRM compliant construct when:

- The construct is supported by majority of synthesis or simulation third-party tools, and
- It is a real language limitation for design coding, and has no impact on quality of results or problem detection in the design.

For example, the LRM does not allow instantiation when the formal port is a **buffer** and the effective one is an **out** (and vice-versa).

# **XST VHDL File Type Support**

This section discusses XST File Type Support, and includes:

- "About XST VHDL File Type Support"
- "XST VHDL File Type Support Table"

# About XST VHDL File Type Support

XST supports a limited File Read and File Write capability for VHDL:

- Use File Read capability, for example, to initialize RAMs from an external file.
- Use File Write capability for debugging processes, or to write a specific constant or generic value to an external file.

For more information, see "Initializing RAM Coding Examples."

Use any of the read functions shown in Table 6-1, "XST VHDL File Type Support." These read functions are supported by the following packages:

- standard
- std.textio
- ieee.std\_logic\_textio

# XST VHDL File Type Support Table

Function	Package
file (type text only)	standard
access (type <b>line</b> only)	standard
file_open (file, name, open_kind)	standard
file_close (file)	standard
endfile (file)	standard
text	std.textio
line	std.textio

Table 6-1: XST VHDL File Type Support

Function	Package	
width	std.textio	
readline (text, line)	std.textio	
readline (line, bit, boolean)	std.textio	
read (line, bit)	std.textio	
readline (line, bit_vector, boolean)	std.textio	
read (line, bit_vector)	std.textio	
read (line, boolean, boolean)	std.textio	
read (line, boolean)	std.textio	
read (line, character, boolean)	std.textio	
read (line, character)	std.textio	
read (line, string, boolean)	std.textio	
read (line, string)	std.textio	
write (file, line)	std.textio	
write (line, bit, boolean)	std.textio	
write (line, bit)	std.textio	
write (line, bit_vector, boolean)	std.textio	
write (line, bit_vector)	std.textio	
write (line, boolean, boolean)	std.textio	
write (line, boolean)	std.textio	
write (line, character, boolean)	std.textio	
write (line, character)	std.textio	
write (line, integer, boolean)	std.textio	
write (line, integer)	std.textio	
write (line, string, boolean)	std.textio	
write (line, string)	std.textio	
read (line, std_ulogic, boolean)	ieee.std_logic_textio	
read (line, std_ulogic)	ieee.std_logic_textio	
read (line, std_ulogic_vector), boolean	ieee.std_logic_textio	
read (line, std_ulogic_vector)	ieee.std_logic_textio	
read (line, std_logic_vector, boolean)	ieee.std_logic_textio	
read (line, std_logic_vector)	ieee.std_logic_textio	
write (line, std_ulogic, boolean)	ieee.std_logic_textio	

Table 6-1: XST VHDL File Type Support (Cont'd)

Function	Package		
write (line, std_ulogic)	ieee.std_logic_textio		
write (line, std_ulogic_vector, boolean)	ieee.std_logic_textio		
write (line, std_ulogic_vector)	ieee.std_logic_textio		
write (line, std_logic_vector, boolean)	ieee.std_logic_textio		
write (line, std_logic_vector)	ieee.std_logic_textio		
hread	ieee.std_logic_textio		

Table 6-1: XST VHDL File Type Support (Cont'd)

For more information on how to use a file read operation, see "Initializing RAM Coding Examples."

# **Debugging Using Write Operation in VHDL**

This section discusses Debugging Using Write Operation in VHDL, and includes:

- "Debugging Using Write Operation in VHDL Coding Example"
- "Rules for Debugging Using Write Operation in VHDL"

Debugging Using Write Operation in VHDL Coding Example

```
-- Print 2 constants to the output file
_ _
library IEEE;
use IEEE.STD_LOGIC_1164.ALL;
use IEEE.STD_LOGIC_arith.ALL;
use IEEE.STD_LOGIC_UNSIGNED.ALL;
use STD.TEXTIO.all;
use IEEE.STD_LOGIC_TEXTIO.all;
entity file_support_1 is
   generic (data_width: integer:= 4);
   port( clk, sel: in std_logic;
            din: in std_logic_vector (data_width - 1 downto 0);
            dout: out std_logic_vector (data_width - 1 downto 0));
end file_support_1;
architecture Behavioral of file_support_1 is
   file results : text is out "test.dat";
   constant base_const: std_logic_vector(data_width - 1 downto 0):=
conv_std_logic_vector(3,data_width);
   constant new_const: std_logic_vector(data_width - 1 downto 0):=
base_const + "1000";
begin
   process(clk)
       variable txtline : LINE;
   begin
       write(txtline, string'("-----"));
       writeline(results, txtline);
       write(txtline,string'("Base Const: "));
```

www.xilinx.com



end Behavioral;

## Rules for Debugging Using Write Operation in VHDL

Follow these rules for rules for debugging using write operation in VHDL:

- During a **std\_logic** read operation, the only allowed characters are **0** and **1**. Other values such as **x** and **z** are not allowed. XST rejects the design if the file includes characters other than **0** and **1**, except that XST ignores a blank space character.
- Do not use identical names for files placed in different directories.
- Do not use conditional calls to read procedures, as shown in the following coding example:

```
if SEL = '1' then
  read (MY_LINE, A(3 downto 0));
else
  read (MY_LINE, A(1 downto 0));
end if;
```

• When using the endfile function, if you use the following description style:

```
while (not endfile (MY_FILE)) loop
readline (MY_FILE, MY_LINE);
read (MY_LINE, MY_DATA);
end loop;
```

XST rejects the design, and issues the following error message:

Line <MY\_LINE> has not enough elements for target <MY\_DATA>.

To fix the problem, add **exit when endfile (MY\_FILE)**; to the while loop as shown in the following coding example:

```
while (not endfile (MY_FILE)) loop
readline (MY_FILE, MY_LINE);
exit when endfile (MY_FILE);
read (MY_LINE, MY_DATA);
end loop;
```

# **VHDL Data Types**

This section discusses VHDL Data Types, and includes:

- "Accepted VHDL Data Types"
- "VHDL Overloaded Data Types"
- "VHDL Multi-Dimensional Array Types"

## Accepted VHDL Data Types

XST accepts the following VHDL data types:

- "VHDL Enumerated Types"
- "VHDL User-Defined Enumerated Types"
- "VHDL Bit Vector Types"
- "VHDL Integer Types"
- "VHDL Predefined Types"
- "VHDL STD\_LOGIC\_1164 IEEE Types"

## VHDL Enumerated Types

Table 6-2:	VHDL Enumerat	ed Types
------------	---------------	----------

Туре	Values	Meaning	Comment
BIT	0, 1		
BOOLEAN	false, true		
REAL	\$ to \$+.		
STD_LOGIC	U	unitialized	Not accepted by XST
	Х	unknown	Treated as don't care
	0	low	Treated identically to L
	1	high	Treated identically to H
	Z	high impedance	Treated as high impedance
	W	weak unknown	Not accepted by XST
	L	weak low	Treated identically to 0
	Н	weak high	Treated identically to 1
	-	don't care	Treated as don't care

## VHDL User-Defined Enumerated Types

type COLOR is (RED, GREEN, YELLOW);



## VHDL Bit Vector Types

- BIT\_VECTOR
- STD\_LOGIC\_VECTOR

Unconstrained types (types whose length is not defined) are not accepted.

#### VHDL Integer Types

INTEGER

#### VHDL Predefined Types

- BIT
- BOOLEAN
- BIT\_VECTOR
- INTEGER
- REAL

#### VHDL STD\_LOGIC\_1164 IEEE Types

The following types are declared in the STD\_LOGIC\_1164 IEEE package:

- STD\_LOGIC
- STD\_LOGIC\_VECTOR

This package is compiled in the IEEE library. To use one of these types, add the following two lines to the VHDL specification:

```
library IEEE;
use IEEE.STD_LOGIC_1164.all;
```

## VHDL Overloaded Data Types

The following data types can be overloaded:

- "VHDL Overloaded Enumerated Types"
- "VHDL Overloaded Bit Vector Types"
- "VHDL Overloaded Integer Types"
- "VHDL Overloaded STD\_LOGIC\_1164 IEEE Types"
- "VHDL Overloaded STD\_LOGIC\_ARITH IEEE Types"

#### VHDL Overloaded Enumerated Types

• STD\_ULOGIC

Contains the same nine values as the STD\_LOGIC type, but does not contain predefined resolution functions

- X01 Subtype of STD\_ULOGIC containing the X, 0 and 1 values
- X01Z

Subtype of STD\_ULOGIC containing the X, 0, 1 and Z values

- UX01
  - Subtype of STD\_ULOGIC containing the U, X, 0 and 1 values
- UX01Z Subtype of STD\_ULOGIC containing the U, X, 0,' and Z values

## VHDL Overloaded Bit Vector Types

- STD\_ULOGIC\_VECTOR
- UNSIGNED
- SIGNED

Unconstrained types (types whose length is not defined) are not accepted.

## VHDL Overloaded Integer Types

- NATURAL
- POSITIVE

Any integer type within a user-defined range. For example, **type MSB is range 8 to 15**; means any integer greater than 7 or less than 16.

The types NATURAL and POSITIVE are VHDL predefined types.

## VHDL Overloaded STD\_LOGIC\_1164 IEEE Types

The following types are declared in the STD\_LOGIC\_1164 IEEE package:

- STD\_ULOGIC (and subtypes X01, X01Z, UX01, UX01Z)
- STD\_LOGIC
- STD\_ULOGIC\_VECTOR
- STD\_LOGIC\_VECTOR

This package is compiled in the library IEEE. To use one of these types, add the following two lines to the VHDL specification:

```
library IEEE;
use IEEE.STD_LOGIC_1164.all;
```

## VHDL Overloaded STD\_LOGIC\_ARITH IEEE Types

The types UNSIGNED and SIGNED (defined as an array of STD\_LOGIC) are declared in the STD\_LOGIC\_ARITH IEEE package.

This package is compiled in the library IEEE. To use these types, add the following two lines to the VHDL specification:

library IEEE; use IEEE.STD\_LOGIC\_ARITH.all;



## VHDL Multi-Dimensional Array Types

This section discusses Multi-Dimensional Array Types, and includes:

- "About VHDL Multi-Dimensional Array Types"
- "Multi-Dimensional Array VHDL Coding Examples"

#### About VHDL Multi-Dimensional Array Types

XST supports multi-dimensional array types of up to three dimensions. Arrays can be:

- Signals
- Constants
- VHDL variables

You can do assignments and arithmetic operations with arrays. You can also pass multidimensional arrays to functions, and use them in instantiations.

The array must be fully constrained in all dimensions, as shown in the following coding example:

subtype WORD8 is STD\_LOGIC\_VECTOR (7 downto 0); type TAB12 is array (11 downto 0) of WORD8; type TAB03 is array (2 downto 0) of TAB12;

You can also declare an array as a matrix, as shown in the following coding example:

subtype TAB13 is array (7 downto 0,4 downto 0)
 of STD\_LOGIC\_VECTOR (8 downto 0);

#### Multi-Dimensional Array VHDL Coding Examples

The following coding examples demonstrate the uses of multi-dimensional array signals and variables in assignments:

- "Multi-Dimensional Array VHDL Coding Example One"
- "Multi-Dimensional Array VHDL Coding Example Two"

Multi-Dimensional Array VHDL Coding Example One

Consider the declarations:

```
subtype WORD8 is STD_LOGIC_VECTOR (7 downto 0);
type TAB05 is array (4 downto 0) of WORD8;
type TAB03 is array (2 downto 0) of TAB05;
signal WORD_A : WORD8;
signal TAB_A, TAB_B : TAB05;
signal TAB_C, TAB_D : TAB03;
constant CNST_A : TAB03 := (
   ("0000000","0000001","0000010","0000011","0000100"),
   ("0010000","0010001","0100010","0100011","0010100"),
   ("0100000","0100001","0100010","0100011","0100100");
```

The following can now be specified:

• A multi-dimensional array signal or variable:

```
TAB_A <= TAB_B;
TAB_C <= TAB_D;
TAB_C <= CNST_A;
```

• An index of one array:

TAB\_A (5) <=  $WORD_A$ ;

TAB\_C (1) <= TAB\_A;

• Indexes of the maximum number of dimensions:

TAB\_A (5) (0) <= '1';

TAB\_C (2) (5) (0) <= '0';

• A slice of the first array:

TAB\_A (4 downto 1) <= TAB\_B (3 downto 0);</pre>

• An index of a higher level array and a slice of a lower level array:

TAB\_C (2) (5) (3 downto 0) <= TAB\_B (3) (4 downto 1);

TAB\_D (0) (4) (2 downto 0) <= CNST\_A (5 downto 3);

Multi-Dimensional Array VHDL Coding Example Two

Add the following declaration:

```
subtype MATRIX151 is array(4 downto 0, 2 downto 0) of STD_LOGIC_VECTOR
(7 downto 0);
```

signal MATRIX15 : MATRIX151;

The following can now be specified:

• A multi-dimensional array signal or variable:

MATRIX15 <= CNST\_A;

• An index of one row of the array:

MATRIX15 (5) <= TAB\_A;

• Indexes of the maximum number of dimensions:

MATRIX15 (5,0) (0) <= '1';

# **VHDL Record Types**

XST supports record types, as shown in the following coding example:

```
type REC1 is record
field1: std_logic;
field2: std_logic_vector (3 downto 0)
end record;
```

- Record types can contain other record types.
- Constants can be record types.
- Record types cannot contain attributes.
- XST supports aggregate assignments to record signals.

# VHDL Initial Values

This section discusses VHDL Initial Values, and includes:

- "About VHDL Initial Values"
- "VHDL Local Reset/Global Reset"
- "Default Initial Values on Memory Elements in VHDL"
- "Default Initial Values on Unconnected Ports in VHDL"



## About VHDL Initial Values

In VHDL, you can initialize registers when you declare them.

The value:

- Is a constant
- Cannot depend on earlier initial values
- Cannot be a function or task call
- Can be a parameter value propagated to a register

When you give a register an initial value in a declaration, XST sets this value on the output of the register at global reset, or at power up. The assigned value is carried in the NGC file as an INIT attribute on the register, and is independent of any local reset.

```
signal arb_onebit : std_logic := '0';
signal arb_priority : std_logic_vector(3 downto 0) := "1011";
```

You can also assign a set/reset value to a register in behavioral VHDL code. Assign a value to a register when the register reset line goes to the appropriate value. See the following coding example:

```
process (clk, rst)
begin
  if rst='1' then
     arb_onebit <= '0';
  end if;
end process;</pre>
```

When you set the initial value of a variable in the behavioral code, it is implemented in the design as a flip-flop whose output can be controlled by a local reset. As such, it is carried in the NGC file as an FDP or FDC flip-flop.

## VHDL Local Reset/Global Reset

This section discusses VHDL Local Reset/Global Reset, and includes:

- "About VHDL Local Reset/Global Reset"
- "Local Reset/Global Reset VHDL Coding Examples"

## About VHDL Local Reset/Global Reset

Local reset is independent of global reset. Registers controlled by a local reset may be set to a different value from registers whose value is only reset at global reset (power up). In the "Local Reset/Global Reset VHDL Coding Example," the register arb\_onebit is set to 1 at global reset, but a pulse on the local reset (rst) can change its value to 0.

## Local Reset/Global Reset VHDL Coding Examples

This section gives the following Local Reset/Global Reset VHDL coding examples:

"Local Reset/Global Reset VHDL Coding Example"

Local Reset/Global Reset VHDL Coding Example

The following coding example sets the initial value on the register output to **1** (one) at initial power up, but since this is dependent upon a local reset, the value changes to **0** (zero) whenever the local set/reset is activated.

```
entity top is
 Port (
    clk, rst : in std_logic;
    a_in : in std_logic;
    dout : out std_logic);
end top;
architecture Behavioral of top is
signal arb_onebit : std_logic := '1';
begin
 process (clk, rst)
 begin
    if rst='1' then
      arb_onebit <= '0';</pre>
    elsif (clk'event and clk='1') then
      arb_onebit <= a_in;</pre>
    end if;
  end process;
  dout <= arb_onebit;</pre>
end Behavioral;
```

## Default Initial Values on Memory Elements in VHDL

This section discusses Default Initial Values on Memory Elements in VHDL, and includes:

- "About Default Initial Values on Memory Elements in VHDL"
- "VHDL Initital Values Table"
- "Default Initial Values on Unconnected Ports in VHDL"

## About Default Initial Values on Memory Elements in VHDL

Because every memory element in a Xilinx<sup>®</sup> FPGA device must come up in a known state, in certain cases, XST does not use IEEE standards for initial values. In the "Local Reset/Global Reset VHDL Coding Example," if signal **arb\_onebit** were not initialized to **1** (one), XST would assign it a default of **0** (zero) as its initial state. In this case, XST does not follow the IEEE standard, where **u** is the default for **std\_logic**. This process of initialization is the same for both registers and RAMs.

## **VHDL** Initital Values Table

Where possible, XST adheres to the IEEE VHDL standard when initializing signal values. If no initial values are supplied in the VHDL code, XST uses the default values (where possible) as shown in the XST column of Table 6-3, "VHDL Initial Values.",

Туре	IEEE	XST
bit	'0'	'0'
std_logic	'U'	'0'

Table 6-3: VHDL Initial Values

Туре	IEEE	XST
bit_vector (3 downto 0)	0000	0000
std_logic_vector (3 downto 0)	0000	0000
integer (unconstrained)	integer'left	integer'left
integer range 7 downto 0	integer'left = 7	integer'left = 7 (coded as <b>111</b> )
integer range 0 to 7	integer'left = 0	integer'left = 0 (coded as <b>000</b> )
Boolean	FALSE	FALSE (coded as <b>0</b> )
enum(S0,S1,S2,S3)	type'left = S0	type'left = S0 (coded as <b>000</b> )

Table 6-3: VHDL Initial Values (Cont'd)

#### Default Initial Values on Unconnected Ports in VHDL

Unconnected output ports default to the values shown in the XST column of Table 6-3, "VHDL Initial Values." If the output port has an initial condition, XST ties the unconnected output port to the explicitly defined initial condition. According to the IEEE VHDL specification, input ports cannot be left unconnected. As a result, XST issues an error message if an input port is not connected. Even the **open** keyword is not sufficient for an unconnected input port.

## **VHDL Objects**

This section discusses VHDL Objects, and includes:

- "Signals in VHDL"
- "Variables in VHDL"
- "Constants in VHDL"

## Signals in VHDL

Signals in VHDL can be declared in an architecture declarative part and used anywhere within the architecture. Signals can also be declared in a block and used within that block. Signals can be assigned by the assignment operator <=.

```
signal sig1 : std_logic;
sig1 <= '1';</pre>
```

## Variables in VHDL

Variables in VHDL are declared in a process or a subprogram, and used within that process or that subprogram. Variables can be assigned by the assignment operator **:=**.

```
variable var1 : std_logic_vector (7 downto 0);
var1 := "01010011";
```

## Constants in VHDL

Constants in VHDL can be declared in any declarative region, and can be used within that region. Their value cannot be changed once declared.

```
signal sig1 : std_logic_vector (5 downto 0);
constant init0 : std_logic_vector (5 downto 0) := "010111";
sig1 <= init0;</pre>
```

## VHDL Operators

Supported operators are listed in Table 6-21, "VHDL Operators." This section provides examples of how to use each shift operator.

Operators VHDL Coding Example One

sll (Shift Left Logical)

sig1 <= A(4 downto 0) sll 2

logically equivalent to:

sig1 <= A(2 downto 0) & "00";

#### Operators VHDL Coding Example Two

srl (Shift Right Logical)

sig1 <= A(4 downto 0) srl 2

logically equivalent to:

sig1 <= "00" & A(4 downto 2);

#### Operators VHDL Coding Example Three

sla (Shift Left Arithmetic)

 $sig1 \le A(4 \text{ downto } 0) sla 2$ 

logically equivalent to:

sig1 <= A(2 downto 0) & A(0) & A(0);

#### Operators VHDL Coding Example Four

sra (Shift Right Arithmetic)

 $sig1 \le A(4 \text{ downto } 0) \text{ sra } 2$ 

logically equivalent to:

sig1 <= <= A(4) & A(4) & A(4 downto 2);

#### Operators VHDL Coding Example Five

rol (Rotate Left)

sig1 <= A(4 downto 0) rol 2

logically equivalent to:

sig1 <= A(2 downto 0) & A(4 downto 3);</pre>



Operators VHDL Coding Example Six

ror (Rotate Right)

A(4 downto 0) ror 2

logically equivalent to:

sig1 <= A(1 downto 0) & A(4 downto 2);</pre>

# **Entity and Architecture Descriptions in VHDL**

This section discusses Entity and Architecture Descriptions in VHDL, and includes:

- "VHDL Circuit Descriptions"
- "VHDL Entity Declarations"
- "VHDL Architecture Declarations"
- "VHDL Component Instantiation"
- "VHDL Recursive Component Instantiation"
- "VHDL Component Configuration"
- "VHDL Generic Parameter Declarations"
- "VHDL Generic and Attribute Conflicts"

## **VHDL** Circuit Descriptions

A circuit description in VHDL consists of two parts:

- The interface (defining the I/O ports)
- The body

In VHDL:

- The entity corresponds to the interface
- The architecture describes the behavior

## **VHDL Entity Declarations**

The I/O ports of the circuit are declared in the entity. Each port has:

- A name
- A mode (in, out, inout, or buffer)
- A type (ports A, B, C, D, E in the "Entity and Architecture Declaration VHDL Coding Example")

Types of ports must be constrained. Not more than one-dimensional array types are accepted as ports.

## **VHDL** Architecture Declarations

Internal signals may be declared in the architecture. Each internal signal has:

- A name
- A type (signal T in the "Entity and Architecture Declaration VHDL Coding Example")

#### Entity and Architecture Declaration VHDL Coding Example

```
Library IEEE;
use IEEE.std_logic_1164.all;
entity EXAMPLE is
  port (
        A,B,C : in std_logic;
        D,E : out std_logic );
end EXAMPLE;
architecture ARCHI of EXAMPLE is
    signal T : std_logic;
begin
...
end ARCHI;
```

## VHDL Component Instantiation

Structural descriptions assemble several blocks, and allow the introduction of hierarchy in a design. The basic concepts of hardware structure are:

Component

The component is the building or basic block.

Port

A port is a component I/O connector.

Signal

A signal corresponds to a wire between components.

In VHDL, a component is represented by a design entity. The design entity is a composite consisting of:

• Entity declaration

The entity declaration provides the external view of the component. It describes what can be seen from the outside, including the component ports.

• Architecture body

The architecture body provides an internal view. It describes the behavior or the structure of the component.

The connections between components are specified within component instantiation statements. These statements specify an instance of a component occurring inside an architecture of another component. Each component instantiation statement is labeled with an identifier.

Besides naming a component declared in a local component declaration, a component instantiation statement contains an association list -- the parenthesized list following the reserved word port map. The association list specifies which actual signals or ports are associated with which local ports of the component declaration.

XST supports unconstrained vectors in component declarations.





Structural Description of Half Adder VHDL Coding Example

The following coding example shows the structural description of a half adder composed of four nand2 components:

```
entity NAND2 is
  port (
    A,B : in BIT;
    Y : out BIT );
end NAND2;
architecture ARCHI of NAND2 is
begin
  Y \leq A nand B;
end ARCHI;
entity HALFADDER is
  port (
    X,Y : in BIT;
    C,S : out BIT );
end HALFADDER;
architecture ARCHI of HALFADDER is
  component NAND2
    port (
      A,B : in BIT;
      Y : out BIT );
  end component;
  for all : NAND2 use entity work.NAND2(ARCHI);
  signal S1, S2, S3 : BIT;
  begin
    NANDA : NAND2 port map (X,Y,S3);
    NANDB : NAND2 port map (X,S3,S1);
    NANDC : NAND2 port map (S3,Y,S2);
    NANDD : NAND2 port map (S1,S2,S);
    C <= S3;
end ARCHI;
```

The synthesized top level netlist is shown in Figure 6-1, "Synthesized Top Level Netlist."





# **VHDL Recursive Component Instantiation**

XST supports recursive component instantiation. Direct instantiation is not supported for recursion.

4-Bit Shift Register With Recursive Component Instantiation VHDL Coding Example

```
library ieee;
use ieee.std_logic_1164.all;
library unisim;
use unisim.vcomponents.all;
entity single_stage is
 generic (sh_st: integer:=4);
 port (
   CLK : in std_logic;
   DI : in std_logic;
   DO : out std_logic );
end entity single_stage;
architecture recursive of single_stage is
 component single_stage
   generic (sh_st: integer);
   port (
     CLK : in std_logic;
      DI : in std_logic;
     DO : out std_logic );
 end component;
 signal tmp : std_logic;
 begin
   GEN_FD_LAST: if sh_st=1 generate
     inst_fd: FD port map (D=>DI, C=>CLK, Q=>DO);
   end generate;
   GEN_FD_INTERM: if sh_st /= 1 generate
     inst_fd: FD port map (D=>DI, C=>CLK, Q=>tmp);
      inst_sstage: single_stage generic map (sh_st => sh_st-1)
       port map (DI=>tmp, CLK=>CLK, DO=>DO);
    end generate;
end recursive;
```

## VHDL Component Configuration

Associating an entity and architecture pair to a component instance provides the means of linking components with the appropriate model (entity and architecture pair). XST supports component configuration in the declarative part of the architecture:

```
for instantiation_list: component_name use
LibName.entity_Name(Architecture_Name);
```

The "Structural Description of Half Adder VHDL Coding Example" shows how to use a configuration clause for component instantiation. The example contains the following **for all** statement:

```
for all : NAND2 use entity work.NAND2(ARCHI);
```

This statement indicates that all NAND2 components use the entity NAND2 and Architecture ARCHI.

When the configuration clause is missing for a component instantiation, XST links the component to the entity with the same name (and same interface) and the selected architecture to the most recently compiled architecture. If no entity or architecture is found, a black box is generated during synthesis.

## VHDL Generic Parameter Declarations

Generic parameters may be declared in the entity declaration part. XST supports all types for generics including, for example:

- Integer
- Boolean
- String
- Real
- Std\_logic\_vector.

An example of using generic parameters is setting the width of the design. In VHDL, describing circuits with generic ports has the advantage that the same component can be repeatedly instantiated with different values of generic ports as shown in "Describing Circuits With Generic Ports VHDL Coding Example."

Describing Circuits With Generic Ports VHDL Coding Example

```
Library IEEE;
use IEEE.std_logic_1164.all;
use IEEE.std_logic_unsigned.all;
entity addern is
 generic (width : integer := 8);
 port (
   A,B : in std_logic_vector (width-1 downto 0);
   Y : out std_logic_vector (width-1 downto 0) );
end addern;
architecture bhv of addern is
 begin
   Y <= A + B;
end bhv;
Library IEEE;
use IEEE.std_logic_1164.all;
entity top is
 port (
   X, Y, Z : in std_logic_vector (12 downto 0);
   A, B : in std_logic_vector (4 downto 0);
   S :out std_logic_vector (16 downto 0) );
end top;
architecture bhv of top is
 component addern
   generic (width : integer := 8);
   port (
      A,B : in std_logic_vector (width-1 downto 0);
     Y : out std_logic_vector (width-1 downto 0) );
  end component;
```

XILINX

```
for all : addern use entity work.addern(bhv);
signal C1 : std_logic_vector (12 downto 0);
signal C2, C3 : std_logic_vector (16 downto 0);
begin
    U1 : addern generic map (n=>13) port map (X,Y,C1);
    C2 <= C1 & A;
    C3 <= Z & B;
    U2 : addern generic map (n=>17) port map (C2,C3,S);
end bhv;
```

The GENERICS command line option allows you to redefine generics (VHDL) values defined in the top-level design block. This allows you to easily modify the design configuration without any Hardware Description Language (HDL) source modifications, such as for IP core generation and testing flows. For more information, see "Generics (-generics)"

# VHDL Generic and Attribute Conflicts

Since generics and attributes can be applied to both instances and components in the VHDL code, and attributes can also be specified in a constraints file, from time to time, conflicts may arise. To resolve these conflicts, XST uses the following rules of precedence:

- 1. Whatever is specified on an instance (lower level) takes precedence over what is specified on a component (higher level).
- 2. If a generic and an attribute are specified on either the same instance or the same component, the generic takes precedence, and XST issues a message warning of the conflict.
- 3. An attribute specified in the XST Constraint File (XCF) always takes precedence over attributes or generics specified in the VHDL code.

When an attribute specified on an instance overrides a generic specified on a component in XST, it is possible that your simulation tool may nevertheless use the generic. This may cause the simulation results to not match the synthesis results.

Use Table 6-4, "Precedence in VHDL," as a guide in determining precedence.

	Generic on an Instance	Generic on a Component
Attribute on an Instance	Apply Generic (XST issues warning)	Apply Attribute (possible simulation mismatch)
Attribute on a Component	Apply Generic	Apply Generic (XST issues warning)
Attribute in XCF	Apply Attribute (XST issues warning)	Apply Attribute

Table 6-4: Precedence in VHDL

Security attributes on the block definition always have higher precedence than any other attribute or generic.

XILINX<sup>®</sup>

# VHDL Combinatorial Circuits

This section discusses VHDL Combinatorial Circuits, and includes:

- "VHDL Concurrent Signal Assignments" .
- "VHDL Generate Statements" .
- "VHDL Combinatorial Processes" •
- "VHDL If ... Else Statements" •
- "VHDL Case Statements" •
- "VHDL For...Loop Statements"

# VHDL Concurrent Signal Assignments

This section discusses VHDL Concurrent Signal Assignments, and includes:

- "About VHDL Concurrent Signal Assignments"
- "Concurrent Signal Assignments VHDL Coding Examples"

## About VHDL Concurrent Signal Assignments

Combinatorial logic in VHDL may be described using concurrent signal assignments. These can be defined within the body of the architecture. VHDL offers three types of concurrent signal assignments:

- Simple
- Selected
- Conditional

You can describe as many concurrent statements as needed. The order of concurrent signal definition in the architecture is irrelevant.

A concurrent assignment consists of two sides:

- Left hand
- **Right hand**

The assignment changes when any signal in the right side changes. In this case, the result is assigned to the signal on the left side.

## Concurrent Signal Assignments VHDL Coding Examples

This section gives the following VHDL Concurrent Signal Assignments coding examples:

- "Simple Signal Assignment VHDL Coding Example" •
- "MUX Description Using Selected Signal Assignment VHDL Coding Example"
- "MUX Description Using Conditional Signal Assignment VHDL Coding Example"

#### Simple Signal Assignment VHDL Coding Example

 $T \leq A$  and B;

MUX Description Using Selected Signal Assignment VHDL Coding Example

```
library IEEE;
use IEEE.std_logic_1164.all;
entity select_bhv is
 generic (width: integer := 8);
 port (
    a, b, c, d : in std_logic_vector (width-1 downto 0);
    selector : in std_logic_vector (1 downto 0);
    T : out std_logic_vector (width-1 downto 0) );
end select_bhv;
architecture bhv of select_bhv is
begin
 with selector select
    T \leq a \text{ when "00"},
         b when "01",
         c when "10",
         d when others;
end bhv;
```

MUX Description Using Conditional Signal Assignment VHDL Coding Example

```
entity when_ent is
generic (width: integer := 8);
port (
    a, b, c, d : in std_logic_vector (width-1 downto 0);
    selector : in std_logic_vector (1 downto 0);
    T : out std_logic_vector (width-1 downto 0) );
end when_ent;
architecture bhv of when_ent is
begin
    T <= a when selector = "00" else
        b when selector = "01" else
        c when selector = "10" else
        d;
end bhv;
```

# **VHDL** Generate Statements

This section discusses VHDL Generate Statements, and includes:

- "About VHDL Generate Statements"
- "Generate Statement VHDL Coding Examples"

#### About VHDL Generate Statements

Repetitive structures are declared with the **generate** VHDL statement. For this purpose, **for I in 1 to N generate** means that the bit slice description is repeated **N** times.

#### Generate Statement VHDL Coding Examples

This section gives the following Generate Statement VHDL coding examples:

- "8-Bit Adder Described With For...Generate Statement VHDL Coding Example"
- "N-Bit Adder Described With If...Generate" and For... Generate Statement VHDL Coding Example"



8-Bit Adder Described With For...Generate Statement VHDL Coding Example

The following coding example describes an 8-bit adder by declaring the bit slice structure (8-bit adder described with a **for...generate** statement):

```
entity EXAMPLE is
  port (
    A,B : in BIT_VECTOR (0 to 7);
    CIN : in BIT;
    SUM : out BIT_VECTOR (0 to 7);
    COUT : out BIT );
end EXAMPLE;
architecture ARCHI of EXAMPLE is
  signal C : BIT_VECTOR (0 to 8);
  begin
    C(0) \leq CIN;
    COUT <= C(8);
    LOOP_ADD : for I in 0 to 7 generate
    SUM(I) \leq A(I) \text{ xor } B(I) \text{ xor } C(I);
    C(I+1) \leq (A(I) \text{ and } B(I)) \text{ or } (A(I) \text{ and } C(I)) \text{ or } (B(I) \text{ and } C(I));
    end generate;
end ARCHI;
```

The **if** *condition* **generate** statement is supported for static (non-dynamic) conditions. The "N-Bit Adder Described With If...Generate" and For... Generate Statement VHDL Coding Example" shows such an example. It is a generic N-bit adder with a width ranging between 4 and 32 (N-bit adder described with an **if...generate** and a **for... generate** statement).

N-Bit Adder Described With If...Generate" and For... Generate Statement VHDL Coding Example

```
entity EXAMPLE is
  generic (N : INTEGER := 8);
  port (
    A,B : in BIT_VECTOR (N downto 0);
    CIN : in BIT;
    SUM : out BIT_VECTOR (N downto 0);
    COUT : out BIT );
end EXAMPLE;
architecture ARCHI of EXAMPLE is
  signal C : BIT_VECTOR (N+1 downto 0);
  begin
  L1: if (N>=4 and N<=32) generate
    C(0) \ll CIN;
    COUT <= C(N+1);
    LOOP_ADD : for I in 0 to N generate
       SUM(I) \leq A(I) \text{ xor } B(I) \text{ xor } C(I);
      C(I+1) \leq (A(I) \text{ and } B(I)) \text{ or } (A(I) \text{ and } C(I)) \text{ or } (B(I) \text{ and } C(I));
    end generate;
  end generate;
end ARCHI;
```

# **VHDL** Combinatorial Processes

This section discusses VHDL Combinatorial Processes, and includes:

- "About VHDL Combinatorial Processes"
- "Combinatorial Processes VHDL Coding Examples"

## About VHDL Combinatorial Processes

A process assigns values to signals differently than when using concurrent signal assignments. The value assignments are made in a sequential mode. Later assignments may cancel previous ones. See "Assignments in a Process VHDL Coding Example." First the signal *S* is assigned to 0, but later on (for (A and B) =1), the value for *S* is changed to 1.

A process is combinatorial when its inferred hardware does not involve any memory elements. Said differently, when all assigned signals in a process are always explicitly assigned in all paths of the Process statements, the process is combinatorial.

A combinatorial process has a sensitivity list appearing within parentheses after the word **process**. A process is activated if an event (value change) appears on one of the sensitivity list signals. For a combinatorial process, this sensitivity list must contain:

- All signals in conditions (for example, **if** and **case**)
- All signals on the right hand side of an assignment

If one or more signals are missing from the sensitivity list, XST issues a warning message for the missing signals and adds them to the sensitivity list. In this case, the result of the synthesis may be different from the initial design specification.

A process may contain local variables. The variables are handled in a similar manner as signals (but are not, of course, outputs to the design).

In "Combinatorial Process VHDL Coding Example One," a variable named AUX is declared in the declarative part of the process, and is assigned to a value (with :=) in the statement part of the process.

In combinatorial processes, if a signal is not explicitly assigned in all branches of **if** or **case** statements, XST generates a latch to hold the last value. To avoid latch creation, ensure that all assigned signals in a combinatorial process are always explicitly assigned in all paths of the Process statements.

Different statements can be used in a process:

- Variable and signal assignment
- If statement
- Case statement
- For...Loop statement
- Function and procedure call

The "Combinatorial Processes VHDL Coding Examples" provide examples of each of these statements



#### Combinatorial Processes VHDL Coding Examples

This section gives the following Combinatorial Processes VHDL coding examples:

- "Assignments in a Process VHDL Coding Example"
- "Combinatorial Process VHDL Coding Example One"
- "Combinatorial Process VHDL Coding Example Two"

Assignments in a Process VHDL Coding Example

```
entity EXAMPLE is
port (
    A, B : in BIT;
    S : out BIT );
end EXAMPLE;
architecture ARCHI of EXAMPLE is
begin
    process (A, B)
    begin
    S <= '0';
    if ((A and B) = '1') then
        S <= '1';
    end if;
    end process;
end ARCHI;</pre>
```

Combinatorial Process VHDL Coding Example One

```
library ASYL;
use ASYL.ARITH.all;
entity ADDSUB is
 port (
   A,B : in BIT_VECTOR (3 downto 0);
   ADD_SUB : in BIT;
    S : out BIT_VECTOR (3 downto 0));
end ADDSUB;
architecture ARCHI of ADDSUB is
 begin
   process (A, B, ADD_SUB)
     variable AUX : BIT_VECTOR (3 downto 0);
 begin
    if ADD SUB = '1' then
     AUX := A + B;
    else
     AUX := A - B;
    end if;
    S <= AUX;
  end process;
end ARCHI;
```

Combinatorial Process VHDL Coding Example Two

```
entity EXAMPLE is
  port (
     A, B : in BIT;
     S : out BIT );
end EXAMPLE;
```

```
architecture ARCHI of EXAMPLE is
begin
  process (A,B)
   variable X, Y : BIT;
   begin
   X := A and B;
   Y := B and A;
   if X = Y then
      S <= '1' ;
   end if;
   end process;
end ARCHI;
```

# VHDL If...Else Statements

This section discusses VHDL **if...else** Statements, and includes:

- "About VHDL If...Else Statements"
- "VHDL If...Else Statements VHDL Coding Examples"

#### About VHDL If...Else Statements

**If...else** statements use true/false conditions to execute statements. If the expression evaluates to **true**, the first statement is executed. If the expression evaluates to **false** (or **x** or **z**), the **Else** statement is executed. A block of multiple statements may be executed using begin and end keywords. **If... else** statements may be nested.

#### VHDL If...Else Statements VHDL Coding Examples

This section gives the following **If...Else** Statement VHDL coding examples:

"If...Else Statement VHDL Coding Example"

#### If...Else Statement VHDL Coding Example

```
library IEEE;
use IEEE.std_logic_1164.all;
entity mux4 is
 port (
    a, b, c, d : in std_logic_vector (7 downto 0);
    sel1, sel2 : in std_logic;
    outmux : out std_logic_vector (7 downto 0));
end mux4;
architecture behavior of mux4 is
begin
 process (a, b, c, d, sel1, sel2)
 begin
    if (sel1 = '1') then
      if (sel2 = '1') then
        outmux <= a;</pre>
      else
        outmux <= b;</pre>
      end if;
    else
      if (sel2 = '1') then
```



```
outmux <= c;
else
outmux <= d;
end if;
end if;
end process;
end behavior;
```

# VHDL Case Statements

This section discusses VHDL Case Statements, and includes:

- "About VHDL Case Statements"
- "Case Statements VHDL Coding Examples"

#### About VHDL Case Statements

Case statements perform a comparison to an expression to evaluate one of a number of parallel branches. The Case statement evaluates the branches in the order they are written. The first branch that evaluates to true is executed. If none of the branches match, the default branch is executed.

#### Case Statements VHDL Coding Examples

This section gives the following Case Statement VHDL coding examples:

"Case Statement VHDL Coding Example"

Case Statement VHDL Coding Example

```
library IEEE;
use IEEE.std_logic_1164.all;
entity mux4 is
 port (
   a, b, c, d : in std_logic_vector (7 downto 0);
   sel : in std_logic_vector (1 downto 0);
   outmux : out std_logic_vector (7 downto 0));
end mux4;
architecture behavior of mux4 is
begin
 process (a, b, c, d, sel)
 begin
   case sel is
     when "00" => outmux <= a;
     when "01" => outmux <= b;
     when "10" => outmux <= c;
     when others => outmux <= d; -- case statement must be complete
   end case;
  end process;
end behavior;
```

## VHDL For...Loop Statements

This section discusses VHDL For...Loop Statements, and includes:

- "About VHDL For...Loop Statements"
- "For...Loop Statements VHDL Coding Examples"

#### About VHDL For...Loop Statements

The **for** statement is supported for:

- Constant bounds
- Stop test condition using any of the following operators:
  - <
  - ♦ <=
  - ♦ >
  - ♦ >=
- Next step computation falling within one of the following specifications:
  - var = var + step
  - var = var step

(where var is the loop variable and step is a constant value)

Next and exit statements are supported

#### For...Loop Statements VHDL Coding Examples

This section gives the following **For...Loop** Statement VHDL coding example:

"For...Loop Statement VHDL Coding Example"

For...Loop Statement VHDL Coding Example

```
library IEEE;
use IEEE.std_logic_1164.all;
use IEEE.std_logic_unsigned.all;
entity countzeros is
  port (
    a : in std_logic_vector (7 downto 0);
    Count : out std_logic_vector (2 downto 0) );
end mux4;
architecture behavior of mux4 is
  signal Count_Aux: std_logic_vector (2 downto 0);
  begin
    process (a)
    begin
      Count_Aux <= "000";</pre>
      for i in a range loop
        if (a[i] = '0') then
          Count_Aux <= Count_Aux + 1; -- operator "+" defined
                                       -- in std_logic_unsigned
        end if;
      end loop;
      Count <= Count_Aux;</pre>
  end process;
end behavior;
```



# **VHDL Sequential Circuits**

This section discusses VHDL Sequential Circuits, and includes:

- "About VHDL Sequential Circuits"
- "VHDL Sequential Process With a Sensitivity List"
- "VHDL Sequential Process Without a Sensitivity List"
- "Register and Counter Descriptions VHDL Coding Examples"
- "VHDL Multiple Wait Statements Descriptions"

## About VHDL Sequential Circuits

Sequential circuits can be described using sequential processes. XST allows:

- "VHDL Sequential Process With a Sensitivity List"
- "VHDL Sequential Process Without a Sensitivity List"

## VHDL Sequential Process With a Sensitivity List

This section discusses VHDL Sequential Process With a Sensitivity List, and includes:

- "About VHDL Sequential Process With a Sensitivity List"
- "Sequential Process With a Sensitivity List VHDL Coding Examples"

#### About VHDL Sequential Process With a Sensitivity List

A process is sequential when it is not a combinatorial process. In other words, a process is sequential when some assigned signals are not explicitly assigned in all paths of the statements. In this case, the hardware generated has an internal state or memory (flip-flops or latches).

The "Sequential Process With Asynchronous, Synchronous Parts VHDL Coding Example" provides a template for describing sequential circuits. For more information, see "XST HDL Coding Techniques" describing macro inference (for example, registers and counters).

#### Sequential Process With a Sensitivity List VHDL Coding Examples

This section gives the following Sequential Process With a Sensitivity List VHDL coding examples:

"Sequential Process With Asynchronous, Synchronous Parts VHDL Coding Example"

Sequential Process With Asynchronous, Synchronous Parts VHDL Coding Example

Declare asynchronous signals in the sensitivity list. Otherwise, XST issues a warning and adds them to the sensitivity list. In this case, the behavior of the synthesis result may be different from the initial specification.

```
process (CLK, RST) ...
begin
  if RST = <'0' | '1'> then
    -- an asynchronous part may appear here
    -- optional part
    .....
elsif <CLK'EVENT | not CLK'STABLE>
```

```
and CLK = <'0' | '1'> then
-- synchronous part
-- sequential statements may appear here
end if;
end process;
```

# VHDL Sequential Process Without a Sensitivity List

This section discusses VHDL Sequential Process Without a Sensitivity List, and includes:

- "About VHDL Sequential Process Without a Sensitivity List"
- "Sequential Process Without a Sensitivity List VHDL Coding Examples"

#### About VHDL Sequential Process Without a Sensitivity List

Sequential processes without a sensitivity list must contain a Wait statement. The Wait statement must be the first statement of the process. The condition in the Wait statement must be a condition on the clock signal. Several Wait statements in the same process are accepted, but a set of specific conditions must be respected. For more information, see "VHDL Multiple Wait Statements Descriptions." An asynchronous part cannot be specified within processes without a sensitivity list.

#### Sequential Process Without a Sensitivity List VHDL Coding Examples

This section gives the following Sequential Process Without a Sensitivity List coding examples:

- "Sequential Process Without a Sensitivity List VHDL Coding Example"
- "Clock and Clock Enable (Not Supported) VHDL Coding Example"
- "Clock and Clock Enable (Supported) VHDL Coding Example"

#### Sequential Process Without a Sensitivity List VHDL Coding Example

The following VHDL coding example shows the skeleton of the process described in "About VHDL Sequential Process Without a Sensitivity List." The clock condition may be a falling or a rising edge.

```
process ...
begin
  wait until <CLK'EVENT | not CLK' STABLE> and CLK = <'0' | '1'>;
   ... -- a synchronous part may be specified here.
end process;
```

XST does not support clock and clock enable descriptions within the same Wait statement. Instead, code these descriptions as shown in "Clock and Clock Enable (Not Supported) VHDL Coding Example."

XST does not support Wait statements for latch descriptions.

#### Clock and Clock Enable (Not Supported) VHDL Coding Example

```
wait until CLOCK'event and CLOCK = '0' and ENABLE = '1';
```

#### Clock and Clock Enable (Supported) VHDL Coding Example

```
"8 Bit Counter Description Using a Process with a Sensitivity List" if ENABLE = '1' then ...
```

# Register and Counter Descriptions VHDL Coding Examples

Following are VHDL coding examples of register and counter descriptions:

- "8-Bit Register Description Using a Process With a Sensitivity List Example VHDL Coding Example"
- "8 Bit Register Description Using a Process Without a Sensitivity List Containing a Wait Statement VHDL Coding Example"
- "8-Bit Register With Clock Signal and Asynchronous Reset Signal VHDL Coding Example"
- "8-Bit Counter Description Using a Process With a Sensitivity List VHDL Coding Example"

8-Bit Register Description Using a Process With a Sensitivity List Example VHDL Coding Example

```
entity EXAMPLE is
  port (
    DI : in BIT_VECTOR (7 downto 0);
    CLK : in BIT;
    DO : out BIT_VECTOR (7 downto 0) );
end EXAMPLE;
architecture ARCHI of EXAMPLE is
begin
    process (CLK)
    begin
        if CLK'EVENT and CLK = '1' then
        DO <= DI ;
        end if;
    end process;
end ARCHI;</pre>
```

8 Bit Register Description Using a Process Without a Sensitivity List Containing a Wait Statement VHDL Coding Example

```
entity EXAMPLE is
port (
    DI : in BIT_VECTOR (7 downto 0);
    CLK : in BIT;
    DO : out BIT_VECTOR (7 downto 0) );
end EXAMPLE;
architecture ARCHI of EXAMPLE is
begin
    process begin
    wait until CLK'EVENT and CLK = '1';
    DO <= DI;
    end process;
end ARCHI;</pre>
```

8-Bit Register With Clock Signal and Asynchronous Reset Signal VHDL Coding Example

```
entity EXAMPLE is
  port (
   DI : in BIT_VECTOR (7 downto 0);
    CLK : in BIT;
    RST : in BIT;
    DO : out BIT_VECTOR (7 downto 0));
end EXAMPLE;
architecture ARCHI of EXAMPLE is
begin
  process (CLK, RST)
  begin
   if RST = '1' then
      DO <= "00000000";
    elsif CLK'EVENT and CLK = '1' then
      DO <= DI ;
    end if;
  end process;
end ARCHI;
```

8-Bit Counter Description Using a Process With a Sensitivity List VHDL Coding Example

```
library ASYL;
use ASYL.PKG_ARITH.all;
entity EXAMPLE is
 port (
   CLK : in BIT;
   RST : in BIT;
   DO : out BIT_VECTOR (7 downto 0));
end EXAMPLE;
architecture ARCHI of EXAMPLE is
begin
 process (CLK, RST)
   variable COUNT : BIT_VECTOR (7 downto 0);
 begin
   if RST = '1' then
     COUNT := "00000000";
    elsif CLK'EVENT and CLK = '1' then
     COUNT := COUNT + "00000001";
   end if;
   DO <= COUNT;
  end process;
end ARCHI;
```

## VHDL Multiple Wait Statements Descriptions

Sequential circuits can be described in VHDL with multiple Wait statements in a process. Follow these rules when using multiple Wait statements:

- The process contains only one Loop statement.
- The first statement in the loop is a Wait statement.
- After each Wait statement, a Next or Exit statement is defined.
- The condition in the Wait statements is the same for each Wait statement.
- This condition use only one signal the clock signal.



• This condition has the following form:

```
"wait [on clock_signal] until [(clock_signal'EVENT |
    not clock_signal'STABLE) and ] clock_signal = {'0' | '1'};"
```

Sequential Circuit Using Multiple Wait Statements VHDL Coding Example

The following VHDL coding example uses multiple Wait statements. This example describes a sequential circuit performing four different operations in sequence. The design cycle is delimited by two successive rising edges of the clock signal. A synchronous reset is defined providing a way to restart the sequence of operations at the beginning. The sequence of operations consists of assigning each of the following four inputs to the output RESULT:

- DATA1
- DATA2
- DATA3
- DATA4

```
library IEEE;
use IEEE.STD_LOGIC_1164.all;
entity EXAMPLE is
 port (
    DATA1, DATA2, DATA3, DATA4 : in STD_LOGIC_VECTOR (3 downto 0);
    RESULT : out STD_LOGIC_VECTOR (3 downto 0);
    CLK : in STD_LOGIC;
    RST : in STD_LOGIC );
end EXAMPLE;
architecture ARCH of EXAMPLE is
begin
 process begin
    SEQ_LOOP : loop
      wait until CLK'EVENT and CLK = '1';
      exit SEQ_LOOP when RST = '1';
      RESULT <= DATA1;
      wait until CLK'EVENT and CLK = '1';
      exit SEO LOOP when RST = '1';
      RESULT <= DATA2;
      wait until CLK'EVENT and CLK = '1';
      exit SEQ_LOOP when RST = '1';
      RESULT <= DATA3;
      wait until CLK'EVENT and CLK = '1';
      exit SEQ_LOOP when RST = '1';
      RESULT <= DATA4;
    end loop;
  end process;
```

end ARCH;

# **VHDL Functions and Procedures**

This section discusses VHDL Functions and Procedures, and includes:

- "About VHDL Functions and Procedures"
- "VHDL Functions and Procedures Examples"

## About VHDL Functions and Procedures

The declaration of a function or a procedure in VHDL provides a mechanism for handling blocks used multiple times in a design. Functions and procedures can be declared in the declarative part of an entity, in an architecture or in packages. The heading part contains:

- Input parameters for functions and input
- Output and inout parameters for procedures.

These parameters can be unconstrained. They are not constrained to a given bound. The content is similar to the combinatorial process content.

Resolution functions are not supported except the one defined in the IEEE **std\_logic\_1164** package.

## VHDL Functions and Procedures Examples

This section gives examples of the following VHDL functions and procedures:

- "Function Declaration and Function Call VHDL Coding Example"
- "Procedure Declaration and Procedure Call VHDL Coding Example"
- "Recursive Function VHDL Coding Example"

Function Declaration and Function Call VHDL Coding Example

The following VHDL coding example shows a function declared within a package. The ADD function declared here is a single bit adder. This function is called four times with the proper parameters in the architecture to create a 4-bit adder. The same example using a procedure is shown in "Procedure Declaration and Procedure Call VHDL Coding Example."

```
package PKG is
  function ADD (A, B, CIN : BIT )
 return BIT_VECTOR;
end PKG;
package body PKG is
  function ADD (A, B, CIN : BIT )
  return BIT_VECTOR is
   variable S, COUT : BIT;
   variable RESULT : BIT_VECTOR (1 downto 0);
 begin
    S := A xor B xor CIN;
    COUT := (A and B) or (A and CIN) or (B and CIN);
    RESULT := COUT & S;
   return RESULT;
 end ADD:
end PKG;
use work.PKG.all;
```



```
entity EXAMPLE is
 port (
    A, B : in BIT_VECTOR (3 downto 0);
    CIN : in BIT;
    S : out BIT_VECTOR (3 downto 0);
    COUT : out BIT );
end EXAMPLE;
architecture ARCHI of EXAMPLE is
 signal S0, S1, S2, S3 : BIT_VECTOR (1 downto 0);
begin
 S0 <= ADD (A(0), B(0), CIN);
 S1 <= ADD (A(1), B(1), S0(1));
 S2 \ll ADD (A(2), B(2), S1(1));
 S3 \le ADD(A(3), B(3), S2(1));
 S \ll S3(0) \& S2(0) \& S1(0) \& S0(0);
 COUT <= S3(1);
end ARCHI;
```

Procedure Declaration and Procedure Call VHDL Coding Example

```
package PKG is
procedure ADD (
 A,B, CIN : in BIT;
 C : out BIT_VECTOR (1 downto 0) );
end PKG;
package body PKG is
 procedure ADD (
   A,B, CIN : in BIT;
    C : out BIT_VECTOR (1 downto 0)
    ) is
   variable S, COUT : BIT;
 begin
   S := A xor B xor CIN;
   COUT := (A and B) or (A and CIN) or (B and CIN);
   C := COUT \& S;
 end ADD;
end PKG;
use work.PKG.all;
entity EXAMPLE is
 port (
   A,B : in BIT_VECTOR (3 downto 0);
   CIN : in BIT;
   S : out BIT_VECTOR (3 downto 0);
   COUT : out BIT );
end EXAMPLE;
architecture ARCHI of EXAMPLE is
 begin
 process (A, B, CIN)
   variable S0, S1, S2, S3 : BIT_VECTOR (1 downto 0);
 begin
   ADD (A(0), B(0), CIN, S0);
   ADD (A(1), B(1), SO(1), S1);
    ADD (A(2), B(2), S1(1), S2);
```

```
ADD (A(3), B(3), S2(1), S3);

S <= S3(0) & S2(0) & S1(0) & S0(0);

COUT <= S3(1);

end process;

end ARCHI;
```

#### Recursive Function VHDL Coding Example

XST supports recursive functions. The following coding example represents n! function:

```
function my_func(x : integer) return integer is
  begin
    if x = 1 then
        return x;
    else
        return (x*my_func(x-1));
    end if;
end function my_func;
```

# VHDL Assert Statements

This section discusses VHDL Assert Statements, and includes:

- "About VHDL Assert Statements"
- "SINGLE\_SRL Describing a Shift Register"

## About VHDL Assert Statements

XST supports Assert statements. Assert statements enable you to detect undesirable conditions in VHDL designs, such as bad values for generics, constants, and generate conditions, or bad values for parameters in called functions. For any failed condition in an Assert statement, XST, according to the severity level, issues a warning message, or rejects the design and issues an error message. XST supports the Assert statement only with static condition.

#### SINGLE\_SRL Describing a Shift Register

The following coding example contains a block, SINGLE\_SRL, which describes a shift register. The size of the shift register depends on the SRL\_WIDTH generic value. The Assert statement ensures that the implementation of a single shift register does not exceed the size of a single SRL.

Since the size of the SRL is 16 bit, and XST implements the last stage of the shift register using a flip-flop in a slice, then the maximum size of the shift register cannot exceed 17 bits. The SINGLE\_SRL block is instantiated twice in the entity named TOP, the first time with SRL\_WIDTH equal to 13, and the second time with SRL\_WIDTH equal to 18.

SINGLE\_SRL Describing a Shift Register VHDL Coding Example

```
library ieee;
use ieee.std_logic_1164.all;
entity SINGLE_SRL is
generic (SRL_WIDTH : integer := 16);
port (
    clk : in std_logic;
    inp : in std_logic;
```



```
outp : out std_logic);
end SINGLE_SRL;
architecture beh of SINGLE_SRL is
  signal shift_reg : std_logic_vector (SRL_WIDTH-1 downto 0);
begin
  assert SRL_WIDTH <= 17
  report "The size of Shift Register exceeds the size of a single SRL"
  severity FAILURE;
  process (clk)
  begin
    if (clk'event and clk = '1') then
      shift_reg <= shift_reg (SRL_WIDTH-1 downto 1) & inp;</pre>
    end if;
    end process;
  outp <= shift_reg(SRL_WIDTH-1);</pre>
end beh;
library ieee;
use ieee.std_logic_1164.all;
entity TOP is
  port (
    clk : in std_logic;
    inp1, inp2 : in std_logic;
    outp1, outp2 : out std_logic);
end TOP;
architecture beh of TOP is
  component SINGLE_SRL is
  generic (SRL_WIDTH : integer := 16);
  port(
    clk : in std_logic;
    inp : in std_logic;
    outp : out std_logic);
  end component;
begin
  inst1: SINGLE_SRL generic map (SRL_WIDTH => 13)
    port map(
      clk => clk,
      inp => inp1,
      outp => outp1 );
  inst2: SINGLE_SRL generic map (SRL_WIDTH => 18)
    port map(
      clk => clk,
      inp => inp2,
      outp => outp2 );
end beh;
```



#### SINGLE\_SRL Describing a Shift Register VHDL Error Message

If you run the "SINGLE\_SRL Describing a Shift Register VHDL Coding Example," XST issues the following error message:

```
* HDL Analysis *
Analyzing Entity <top> (Architecture <beh>).
Entity <top> analyzed. Unit <top> generated.
Analyzing generic Entity <single_srl> (Architecture <beh>).
SRL_WIDTH = 13
Entity <single_srl> analyzed. Unit <single_srl> generated.
Analyzing generic Entity <single_srl> (Architecture <beh>).
SRL_WIDTH = 18
ERROR:Xst - assert_1.vhd line 15: FAILURE: The size of Shift Register
exceeds the size of a single SRL
...
```

# Using Packages to Define VHDL Models

This section discusses Using Packages to Define VHDL Models, and includes:

- "About Using Packages to Define VHDL Models"
- "Using Standard Packages to Define VHDL Models"
- "Using IEEE Packages to Define VHDL Models"
- "Using Synopsys Packages to Define VHDL Models"

#### About Using Packages to Define VHDL Models

VHDL models may be defined using packages. Packages contain:

- Type and subtype declarations
- Constant definitions
- Function and procedure definitions
- Component declarations

Using packages to define VHDL models provides the ability to change parameters and constants of the design, such as constant values and function definitions.

Packages may contain two declarative parts:

- Package declaration
- Body declaration

The body declaration includes the description of function bodies declared in the package declaration.



XST provides full support for packages. To use a given package, include the following lines at the beginning of the VHDL design:

```
library lib_pack;
-- lib_pack is the name of the library specified
-- where the package has been compiled (work by default)
use lib_pack.pack_name.all;
-- pack_name is the name of the defined package.
```

XST also supports predefined packages. These packages are pre-compiled and can be included in VHDL designs. These packages are intended for use during synthesis, but may also be used for simulation.

# Using Standard Packages to Define VHDL Models

The Standard package contains basic types:

- bit
- bit\_vector
- integer

The Standard package is included by default.

# Using IEEE Packages to Define VHDL Models

This section discusses Using IEEE Packages to Define VHDL Models, and includes:

- "XST-Supported IEEE Packages"
- "VHDL Real Number Constants"
- "VHDL Real Number Functions"

## XST-Supported IEEE Packages

XST supports the following IEEE packages:

std\_logic\_1164

Supports the following types:

- std\_logic
- std\_ulogic
- std\_logic\_vector
- std\_ulogic\_vector

It also supports conversion functions based on these types.

• numeric\_bit

Supports the following types based on type bit:

- Unsigned vectors
- Signed vectors

It also supports:

- All overloaded arithmetic operators on these types
- Conversion and extended functions for these types
- numeric\_std

Supports the following types based on type **std\_logic**:

- Unsigned vectors
- Signed vectors

This package is equivalent to **std\_logic\_arith**.

math\_real

Supports the following:

- Real number constants as shown in Table 6-5, "VHDL Real Number Constants"
- Real number functions as shown in Table 6-6, "VHDL Real Number Constants"
- The procedure **uniform**, which generates successive values between 0.0 and 1.0

## VHDL Real Number Constants

Constant	Value	Constant	Value
math_e	е	math_log_of_2	ln2
math_1_over_e	1/e	math_log_of_10	ln10
math_pi	π	math_log2_of_e	log <sub>2</sub> e
math_2_pi	2π	math_log10_of_e	log <sub>10</sub> e
math_1_over_pi	1/ π	math_sqrt_2	$\sqrt{2}$
math_pi_over_2	π/ 2	math_1_oversqrt_2	$1/\sqrt{2}$
math_pi_over_3	π/ 3	math_sqrt_pi	$\sqrt{\pi}$
math_pi_over_4	π/ 4	math_deg_to_rad	2π/ 360
math_3_pi_over_2	3π/ 2	math_rad_to_deg	360/ 2π

Table 6-5: VHDL Real Number Constants

## VHDL Real Number Functions

Table 6-6: VHDL Real Number Functions

ceil(x)	realmax(x,y)	exp(x)	cos(x)	cosh(x)
floor(x)	realmin(x,y)	log(x)	tan(x)	tanh(x)
round(x)	sqrt(x)	log2(x)	arcsin(x)	arcsinh(x)
trunc(x)	cbrt(x)	log10(x)	arctan(x)	arccosh(x)
sign(x)	"**"(n,y)	log(x,y)	arctan(y,x)	arctanh(x)
"mod"(x,y)	''**''(x,y)	sin(x)	sinh(x)	

Functions and procedures in the **math\_real** packages, as well as the **real** type, are for calculations only. They are not supported for synthesis in XST.

Following is an example:

```
library ieee;
use IEEE.std_logic_signed.all;
signal a, b, c : std_logic_vector (5 downto 0);
c <= a + b;
-- this operator "+" is defined in package std_logic_signed.
-- Operands are converted to signed vectors, and function "+"
-- defined in package std_logic_arith is called with signed
-- operands.
```

# Using Synopsys Packages to Define VHDL Models

The following Synopsys packages are supported in the IEEE library:

• std\_logic\_arith

Supports types unsigned, signed vectors, and all overloaded arithmetic operators on these types. It also defines conversion and extended functions for these types.

• std\_logic\_unsigned

Defines arithmetic operators on **std\_ulogic\_vector** and considers them as unsigned operators.

std\_logic\_signed

Defines arithmetic operators on **std\_logic\_vector** and considers them as signed operators.

std\_logic\_misc

Defines supplemental types, subtypes, constants, and functions for the **std\_logic\_1164** package, such as:

- and\_reduce
- or\_reduce

# VHDL Constructs Supported in XST

This section discusses VHDL Constructs Supported in XST, and includes:

- "VHDL Design Entities and Configurations"
- "VHDL Expressions"
- "VHDL Statements"

## VHDL Design Entities and Configurations

XST supports the design entities and configurations shown in:

- Table 6-7, "VHDL Entity Headers"
- Table 6-8, "VHDL Architecture Bodies"
- Table 6-9, "VHDL Configuration Declarations"
- Table 6-10, "VHDL Subprograms"
- Table 6-11, "VHDL Packages"
- Table 6-12, "VHDL Enumeration Types"
- Table 6-13, "VHDL Integer Types"
- Table 6-14, "VHDL Physical Types"
- Table 6-15, "VHDL Composites"
- Table 6-16, "VHDL Modes"
- Table 6-17, "VHDL Declarations"
- Table 6-18, "VHDL Objects"
- Table 6-19, "VHDL Specifications"
- Table 6-20, "VHDL Names"

Table 6-7: VHDL Entity Headers

Entity Header	Supported/Unsupported
Generics	Supported
	(integer type only)
Ports	Supported
	(no unconstrained ports)
Entity Declarative Part	Supported
Entity Statement Part	Unsupported

#### Table 6-8: VHDL Architecture Bodies

Architecture Body	Supported/Unsupported
Architecture Declarative Part	Supported
Architecture Statement Part	Supported

#### *Table 6-9:* VHDL Configuration Declarations

Configuration Declaration	Supported/Unsupported
Block Configuration	Supported
Component Configuration	Supported

#### Table 6-10: VHDL Subprograms

Subprogram	Supported/Unsupported
Functions	Supported
Procedures	Supported

#### Table 6-11: VHDL Packages

Package	Supported/Unsupported
STANDARD	Type TIME is not supported
TEXTIO	Supported
STD_LOGIC_1164	Supported
STD_LOGIC_ARITH	Supported
STD_LOGIC_SIGNED	Supported
STD_LOGIC_UNSIGNED	Supported
STD_LOGIC_MISC	Supported
NUMERIC_BIT	Supported
NUMERIC_UNSIGNED	Supported
NUMERIC_STD	Supported

Table 6-11: VHDL Packages (Cont'd)

Package	Supported/Unsupported
MATH_REAL	Supported
ASYL.ARITH	Supported
ASYL.SL_ARITH	Supported
ASYL.PKG_RTL	Supported
ASYL.ASYL1164	Supported

Table 6-12: VHDL Enumeration Types

Enumeration Type	Supported/Unsupported
BOOLEAN, BIT	Supported
STD_ULOGIC,	Supported
STD_LOGIC	
XO1, UX01, XO1Z, UX01Z	Supported

Table 6-13: VHDL Integer Types

Integer Type	Supported/Unsupported
INTEGER	Supported
POSITIVE	Supported
NATURAL	Supported

## Table 6-14: VHDL Physical Types

Physical Type	Supported/Unsupported
TIME	Ignored
REAL	Supported (only in functions for constant calculations)

## Table 6-15: VHDL Composites

Composite	Supported/Unsupported
BIT_VECTOR	Supported
STD_ULOGIC_VECTOR	Supported
STD_LOGIC_VECTOR	Supported
UNSIGNED	Supported
SIGNED	Supported
Record	Supported
Access	Supported
File	Supported



#### *Table 6-16:* VHDL Modes

Mode	Supported/Unsupported
In, Out, Inout	Supported
Buffer	Supported
Linkage	Unsupported

#### Table 6-17: VHDL Declarations

Declaration	Supported/Unsupported
Туре	Supported for enumerated types, types with positive range having constant bounds, bit vector types, and multi- dimensional arrays
Subtype	Supported

#### Table 6-18: VHDL Objects

Object	Supported/Unsupported
Constant Declaration	Supported (deferred constants are not supported)
Signal Declaration	Supported (register and bus type signals are not supported)
Variable Declaration	Supported
File Declaration	Supported
Alias Declaration	Supported
Attribute Declaration	Supported for some attributes, otherwise skipped (see "XST Design Constraints")
Component Declaration	Supported

## Table 6-19: VHDL Specifications

Specification	Supported/Unsupported
Attribute	Supported for some predefined attributes only: HIGH, LOW, LEFT, RIGHT, RANGE, REVERSE_RANGE, LENGTH, POS, ASCENDING, EVENT, LAST_VALUE. Otherwise, ignored.
Configuration	Supported only with the <b>all</b> clause for instances list. If no clause is added, XST looks for the entity or architecture compiled in the default library.
Disconnection	Unsupported

#### Table 6-20: VHDL Names

Name	Supported/Unsupported
Simple Names	Supported
Selected Names	Supported
Indexed Names	Supported
Slice Names	Supported (including dynamic ranges)

XST does not allow underscores as the first character of signal names (for example, \_DATA\_1).

## **VHDL Expressions**

XST supports the following expressions:

- Table 6-21, "VHDL Operators"
- Table 6-22, "VHDL Operands"

Table 6-21: VHDL Operators

Operator	Supported/Unsupported
Logical Operators:	Supported
and, or, nand, nor, xor, xnor, not	
Relational Operators:	Supported
=, /=, <, <=, >, >=	
& (concatenation)	Supported
Adding Operators: +, -	Supported
*	Supported
/,rem	Supported if the right operand is a constant power of 2
mod	Supported if the right operand is a constant power of 2
Shift Operators:	Supported
sll, srl, sla, sra, rol, ror	
abs	Supported
**	Only supported if the left operand is 2
Sign: +, -	Supported

#### Table 6-22: VHDL Operands

Operand	Supported/Unsupported
Abstract Literals	Only integer literals are supported
Physical Literals	Ignored
Enumeration Literals	Supported

www.xilinx.com

Operand	Supported/Unsupported
String Literals	Supported
Bit String Literals	Supported
Record Aggregates	Supported
Array Aggregates	Supported
Function Call	Supported
Qualified Expressions	Supported for accepted predefined attributes
Types Conversions	Supported
Allocators	Unsupported
Static Expressions	Supported

Table 6-22: VHDL Operands (Cont'd)

# **VHDL Statements**

XST supports the following VHDL statements:

- Table 6-23, "VHDL Wait Statements"
- Table 6-24, "VHDL Loop Statements"
- Table 6-25, "VHDL Concurrent Statements"
- Table 6-23: VHDL Wait Statements

Wait Statement	Supported/Unsupported
Wait on <i>sensitivity_list</i> until <i>Boolean_expression</i> . For more information, see "VHDL Sequential Circuits."	Supported with one signal in the sensitivity list and in the Boolean expression. In case of multiple Wait statements, the sensitivity list and the Boolean expression must be the same for each Wait statement.
	<i>Note:</i> XST does not support Wait statements for latch descriptions.
Wait for <i>time_expression</i> For more information, see "VHDL Sequential Circuits."	Unsupported
Assertion Statement	Supported (only for static conditions)
Signal Assignment	Supported (delay is ignored)
Statement	
Variable Assignment	Supported
Statement	
Procedure Call Statement	Supported
If Statement	Supported
Case Statement	Supported

Loop Statement	Supported/Unsupported
for loop end loop	Supported for constant bounds only. Disable statements are not supported.
while loop end loop	Supported
loop end loop	Only supported in the particular case of multiple Wait statements
Next Statement	Supported
Exit Statement	Supported
Return Statement	Supported
Null Statement	Supported

*Table 6-24:* VHDL Loop Statements

Table 6-25. VHDL Concurrent Statements	Table 6-25:	VHDL	Concurrent Statements
--	-------------	------	-----------------------

Concurrent Statement	Supported/Unsupported
Process Statement	Supported
Concurrent Procedure Call	Supported
Concurrent Assertion Statement	Ignored
Concurrent Signal Assignment Statement	Supported (no <b>after</b> clause, no <b>transport</b> or <b>guarded</b> options, no waveforms) <b>UNAFFECTED</b> is supported.
Component Instantiation Statement	Supported
For Generate	Statement supported for constant bounds only
If Generate	Statement supported for static condition only

# **VHDL Reserved Words**

Table 6-26: VHDL Reserved Words

abs	access	after	alias
all	and	architecture	array
assert	attribute	begin	block
body	buffer	bus	case
component	configuration	constant	disconnect
downto	else	elsif	end
entity	exit	file	for
function	generate	generic	group



Table 0-20. VIDL Reserved Words (Conta)				
if	impure	in		
inout	is	label		
linkage	literal	loop		
mod	nand	new		
nor	not	null		
on	open	or		
out	package	port		
procedure	process	pure		
record	register	reject		
report	return	rol		
select	severity	signal		
sla	sll	sra		
subtype	then	to		
type	unaffected	units		
use	variable	wait		
while	with	xnor		
	if inout linkage mod nor on out procedure record report select sla subtype type use	ifimpureinoutislinkageliteralmodnandnornotonopenoutpackageprocedureprocessrecordregisterreportselectselectseverityslasllsubtypethentypeunaffectedusevariable		

Table 6-26: VHDL Reserved Words (Cont'd)



# Chapter 7

# XST Verilog Language Support

This chapter (*XST Verilog Language Support*) describes XST support for Verilog constructs and meta comments. This chapter includes:

- "About XST Verilog Language Support"
- "Behavioral Verilog"
- "Variable Part Selects"
- "Structural Verilog Features"
- "Verilog Parameters"
- "Verilog Parameter and Attribute Conflicts"
- "Verilog Limitations in XST"
- "Verilog Attributes and Meta Comments"
- "Verilog Constructs Supported in XST"
- "Verilog System Tasks and Functions Supported in XST"
- "Verilog Primitives"
- "Verilog Reserved Keywords"
- "Verilog-2001 Support in XST"

For more information on Verilog design constraints and options, see "XST Design Constraints." For more information on Verilog attribute syntax, see "Verilog-2001 Attributes." For more information on setting Verilog options in the Process window of Project Navigator, see "XST General Constraints."

# About XST Verilog Language Support

Complex circuits are commonly designed using a top down methodology. Various specification levels are required at each stage of the design process. As an example, at the architectural level, a specification may correspond to a block diagram or an Algorithmic State Machine (ASM) chart. A block or ASM stage corresponds to a register transfer block (for example register, adder, counter, multiplexer, glue logic, finite state machine) where the connections are N-bit wires. A Hardware Description Language (HDL) such as Verilog allows the expression of notations such as ASM charts and circuit diagrams in a computer language.

Verilog provides both behavioral and structural language structures. These structures allow expressing design objects at high and low levels of abstraction. Designing hardware with a language such as Verilog allows using software concepts such as parallel processing and object-oriented programming. Verilog has a syntax similar to C and Pascal, and is supported by XST as IEEE 1364.

www.xilinx.com

The Verilog support in XST provides an efficient way to describe both the global circuit and each block according to the most efficient style. Synthesis is then performed with the best synthesis flow for each block. Synthesis in this context is the compilation of high-level behavioral and structural Verilog Hardware Description Language (HDL) statements into a flattened gate-level netlist, which can then be used to custom program a programmable logic device such as Virtex<sup>™</sup> FPGA devices. Different synthesis methods are used for arithmetic blocks, glue logic, and finite state machines.

The XST User Guide assumes that you are familiar with basic Verilog concepts. For more information, see the *IEEE Verilog HDL Reference Manual*.

# **Behavioral Verilog**

For information about Behavioral Verilog, see "XST Behavioral Verilog Language Support."

# Variable Part Selects

Verilog 2001 adds the capability of using variables to select a group of bits from a vector. A variable part select is defined by the starting point of its range and the width of the vector, instead of being bounded by two explicit values. The starting point of the part select can vary, but the width of the part select remains constant.

Table 7-1: Variable Part Select Symbols

Symbol	Meaning
+ (plus)	The part select increases from the starting point
- (minus)	The part select decreases from the starting point

Variable Part Select Verilog Coding Example

```
reg [3:0] data;
reg [3:0] select; // a value from 0 to 7
wire [7:0] byte = data[select +: 8];
```

# **Structural Verilog Features**

This section discusses Structural Verilog Features, and includes:

- "About Structural Verilog Features"
- "Structural Verilog Coding Examples"

## About Structural Verilog Features

Structural Verilog descriptions assemble several blocks of code and allow the introduction of hierarchy in a design. The basic concepts of hardware structure are:

Component

The building or basic block

• Port

A component I/O connector

Signal

Corresponds to a wire between components

In Verilog, a component is represented by a design module. The module declaration provides the external view of the component. It describes what can be seen from the outside, including the component ports. The module body provides an internal view. It describes the behavior or the structure of the component.

The connections between components are specified within component instantiation statements. These statements specify an instance of a component occurring within another component or the circuit. Each component instantiation statement is labeled with an identifier. Besides naming a component declared in a local component declaration, a component instantiation statement contains an association list (the parenthesized list) that specifies which actual signals or ports are associated with which local ports of the component declaration.

Verilog provides a large set of built-in logic gates which can be instantiated to build larger logic circuits. The set of logical functions described by the built-in gates includes:

- AND
- OR
- XOR
- NAND
- NOR
- NOT

## Structural Verilog Coding Examples

This section gives the following Structural Verilog coding examples:

- "Building a Basic XOR Function Structural Verilog Coding Example"
- "Structural Description of a Half Adder Structural Verilog Coding Example"
- "Structural Instantiation of REGISTER and BUFG Structural Verilog Coding Example"

Building a Basic XOR Function Structural Verilog Coding Example

Following is an example of building a basic XOR function of two single bit inputs a and b:

```
module build_xor (a, b, c);
input a, b;
output c;
wire c, a_not, b_not;
not a_inv (a_not, a);
not b_inv (b_not, b);
and a1 (x, a_not, b);
and a2 (y, b_not, a);
or out (c, x, y);
endmodule
```

Each instance of the built-in modules has a unique instantiation name such as:

- a\_inv
- b\_inv
- out



Structural Description of a Half Adder Structural Verilog Coding Example

The following coding example shows the structural description of a half adder composed of four, 2 input nand modules:

```
module halfadd (X, Y, C, S);
input X, Y;
output C, S;
wire S1, S2, S3;
nand NANDA (S3, X, Y);
nand NANDB (S1, X, S3);
nand NANDC (S2, S3, Y);
nand NANDD (S, S1, S2);
assign C = S3;
endmodule
```




Figure 7-1: Synthesized Top Level Netlist

The structural features of Verilog also allow you to design circuits by instantiating predefined primitives such as gates, registers and Xilinx® specific primitives such as CLKDLL and BUFGs. These primitives are other than those included in Verilog. These pre-defined primitives are supplied with the XST Verilog libraries (unisim\_comp.v).

Structural Instantiation of REGISTER and BUFG Structural Verilog Coding Example

```
module foo (sysclk, in, reset, out);
input sysclk, in, reset;
output out;
reg out;
wire sysclk_out;
FDC register (out, sysclk_out, reset, in); //position based referencing
BUFG clk (.0(sysclk_out),.I(sysclk)); //name based referencing
...
endmodule
```

The unisim\_comp.v library file supplied with XST, includes the definitions for FDC and BUFG.

```
(* BOX_TYPE="PRIMITIVE" *) // Verilog-2001
module FDC (Q, C, CLR, D);
parameter INIT = 1'b0;
output Q;
```

```
input C;
input CLR;
input D;
endmodule
(* BOX_TYPE="PRIMITIVE" *) // Verilog-2001
module BUFG ( 0, I);
output 0;
input I;
endmodule
```

# **Verilog Parameters**

Verilog modules allow you to define constants known as parameters. Parameters can be passed to module instances to define circuits of arbitrary widths. Parameters form the basis of creating and using parameterized blocks in a design to achieve hierarchy and stimulate modular design techniques.

Verilog Parameters Coding Example

The following Verilog coding example shows the use of parameters. Null string parameters are not supported:

```
module lpm_reg (out, in, en, reset, clk);
 parameter SIZE = 1;
  input in, en, reset, clk;
 output out;
 wire [SIZE-1 : 0] in;
 reg [SIZE-1 : 0] out;
always @(posedge clk or negedge reset)
 begin
    if (!reset)
     out <= 1'b0;
    else
      if (en)
       out <= in;
      else
        out <= out;
                     //redundant assignment
  end
endmodule
                  //portlist left blank intentionally
module top ();
  . . .
 wire [7:0] sys_in, sys_out;
 wire sys_en, sys_reset, sysclk;
 lpm_reg #8 buf_373 (sys_out, sys_in, sys_en, sys_reset, sysclk);
  . . .
endmodule
```

Instantiation of the module lpm\_reg with a instantiation width of 8 causes the instance buf\_373 to be 8 bits wide.

The "Generics (-generics)" command line option allows you to redefine parameters (Verilog) values defined in the top-level design block. This allows you to easily modify the design configuration without any Hardware Description Language (HDL) source modifications, such as for IP core generation and testing flows.



# **Verilog Parameter and Attribute Conflicts**

This section discusses Verilog Parameter and Attribute Conflicts, and includes:

- "About Verilog Parameter and Attribute Conflicts"
- "Verilog Parameter and Attribute Conflicts Precedence"

## About Verilog Parameter and Attribute Conflicts

Since parameters and attributes can be applied to both instances and modules in your Verilog code, and attributes can also be specified in a constraints file, conflicts will occasionally arise. To resolve these conflicts, XST uses the following rules of precedence:

- 1. Specifications on an instance (lower level) takes precedence over specifications on a module (higher level).
- 2. If a parameter and an attribute are specified on either the same instance or the same module, the parameter takes precedence. XST issues a warning message.
- 3. An attribute specified in the XST Constraint File (XCF) takes precedence over attributes or parameters specified in the Verilog code.

When an attribute specified on an instance overrides a parameter specified on a module in XST, it is possible that your simulation tool may nevertheless use the parameter. This may cause the simulation results to not match the synthesis results.

## Verilog Parameter and Attribute Conflicts Precedence

Use Table 7-2, "Verilog Parameter and Attribute Conflicts Precedence," as a guide in determining precedence.

Table 7-2:	Verilog Parameter and Attribute Conflicts Precedence	
------------	--	--

	Parameter on an Instance	Parameter on a Module
Attribute on an Instance     Apply Parameter (XST issues warning)		Apply Attribute (possible simulation mismatch)
Attribute on a Module Apply Parameter		Apply Parameter (XST issues warning)
Attribute in XCF	ute in XCF Apply Attribute (XST issues warning)	

Security attributes on the module definition always have higher precedence than any other attribute or parameter.

# Verilog Limitations in XST

This section describes Verilog Limitations in XST, and includes:

- "Verilog Case Sensitivity"
- "Verilog Blocking and Nonblocking Assignments"
- "Verilog Integer Handling"

## Verilog Case Sensitivity

This section discusses Case Sensitivity, and includes:

- "About Verilog Case Sensitivity"
- "XST Support for Verilog Case Sensitivity"
- "Verilog Restrictions Within XST"

### About Verilog Case Sensitivity

Since Verilog is case sensitive, module and instance names can be made unique by changing capitalization. However, for compatibility with file names, mixed language support, and other tools, Xilinx recommends that you do not rely on capitalization only to make instance names unique.

XST does not allow module names to differ by capitalization only. It renames instances and signal names to ensure that lack of case sensitivity support in other tools in your flow does not adversely impact your design.

### XST Support for Verilog Case Sensitivity

XST supports Verilog case sensitivity as follows:

- Designs can use case equivalent names for I/O ports, nets, regs and memories.
- Equivalent names are renamed using a postfix (rnm<Index>).
- A rename construct is generated in the NGC file.
- Designs can use Verilog identifiers that differ in case only. XST renames them using a
  postfix as with equivalent names.

### Renaming Verilog Coding Example

```
module upperlower4 (input1, INPUT1, output1, output2);
input input1;
input INPUT1;
```

For this example, INPUT1 is renamed to INPUT1\_rnm0.

### Verilog Restrictions Within XST

The following coding examples show Verilog restrictions within XST:

- "Equivalent Names Verilog Coding Example"
- "Case Equivalent Module Names Verilog Coding Example"

### Equivalent Names Verilog Coding Example

Code using equivalent names (named blocks, tasks, and functions) such as the following is rejected:

```
...
always @(clk)
begin: fir_main5
  reg [4:0] fir_main5_w1;
  reg [4:0] fir_main5_W1;
```

XST issues the following error message:

```
ERROR:Xst:863 - "design.v", line 6: Name conflict
(<fir_main5/fir_main5_w1> and <fir_main5/fir_main5_W1>)
```

www.xilinx.com



Case Equivalent Module Names Verilog Coding Example

Code using case equivalent module names such as the following is rejected:

```
module UPPERLOWER10 (...);
...
module upperlower10 (...);
...
```

XST issues the following error message:

ERROR:Xst:909 - Module name conflict (UPPERLOWER10 and upperlower10)

### Verilog Blocking and Nonblocking Assignments

XST rejects Verilog designs if a given signal is assigned through both blocking and nonblocking assignments as shown in the following coding example:

```
always @(in1)
begin
    if (in2)
        out1 = in1;
    else
        out1 <= in2;
end</pre>
```

If a variable is assigned in both a blocking and nonblocking assignment, XST issues the following error message:

```
ERROR:Xst:880 - "design.v", line n: Cannot mix blocking and non-
blocking assignments on signal <out1>.
```

There are also restrictions when mixing blocking and nonblocking assignments on bits and slices.

The following coding example is rejected even if there is no real mixing of blocking and non-blocking assignments:

```
if (in2)
    begin
    out1[0] = 1'b0;
    out1[1] <= in1;
    end
else
    begin
    out1[0] = in2;
    out1[1] <= 1'b1;
    end</pre>
```

Errors are checked at the signal level, not at the bit level.

If there is more than one blocking or non-blocking error, only the first is reported.

In some cases, the line number for the error might be incorrect (as there might be multiple lines where the signal has been assigned).

## Verilog Integer Handling

This section discusses Integer Handling, and includes:

- "About Integer Verilog Handling"
- "Integer Handling in Verilog Case Statements"
- "Integer Handling in Verilog Concatenations"

### About Integer Verilog Handling

XST handles integers differently from other synthesis tools in several instances. They must be coded in a particular way.

### Integer Handling in Verilog Case Statements

Unsized integers in case item expressions may cause unpredictable results. In the following coding example, the case item expression **4** is an unsized integer that causes unpredictable results. To avoid problems, size the **4** to **3** bits as follows:

```
reg [2:0] condition1;
always @(condition1)
begin
    case(condition1)
    4    : data_out = 2; // < will generate bad logic
    3'd4 : data_out = 2; // < will work
    endcase
end
```

### Integer Handling in Verilog Concatenations

Unsized integers in concatenations may cause unpredictable results. If you use an expression that results in an unsized integer, assign the expression to a temporary signal, and use the temporary signal in the concatenation as follows:

```
reg [31:0] temp;
assign temp = 4'b1111 % 2;
assign dout = {12/3,temp,din};
```

## Verilog Attributes and Meta Comments

This section discusses Verilog Attributes and Meta Comments, and includes:

- "About Verilog Attributes and Meta Comments"
- "Verilog-2001 Attributes"
- "Verilog Meta Comments"

### About Verilog Attributes and Meta Comments

XST supports both Verilog-2001 style attributes and meta comments in Verilog. Xilinx recommends Verilog-2001 attributes since they are more generally accepted. Meta comments are comments that are understood by the Verilog parser.



### Verilog-2001 Attributes

Verilog-2001 attributes are bounded by the asterisk character (\*). Use the following syntax:

```
(* attribute_name = "attribute_value" *)
```

where

- The attribute precedes the signal, module, or instance declaration it refers to.
- The attribute\_value is a string. No integer or scalar values are allowed.
- The attribute\_value is between quotes.
- The default is 1. (\* attribute\_name \*) is the same as

(\* attribute\_name = "1" \*)

Verilog-2001 Attributes Coding Examples

```
(* RLOC = "R11C1.S0" *)
(* HUSET = "MY_SET" *)
(* fsm_extract = "yes" *)
(* fsm_encoding = "gray" *)
```

## Verilog Meta Comments

This section discusses Verilog Meta Comments, and includes:

- "Using Verilog Meta Comments"
- "Writing Verilog Meta Comments"
- "Verilog Meta Comments Coding Examples"

### Using Verilog Meta Comments

Use Verilog meta comments to:

- Set constraints on individual objects such as:
  - module
  - instance
  - net
- Set directives on synthesis:
  - parallel\_case and full\_case directives
  - translate\_on translate\_off directives
  - all tool specific directives (for example, syn\_sharing)

For more information, see "XST Design Constraints."

### Writing Verilog Meta Comments

Meta comments can be written using the C-style (/\* ... \*/) or the Verilog style (// ...) for comments. C-style comments can be multiple line. Verilog style comments end at the end of the line.

XST supports:

- Both C-style and Verilog style meta comments
- "Translate Off (TRANSLATE\_OFF) and Translate On (TRANSLATE\_ON)" constraints

```
// synthesis translate_on
// synthesis translate_off
```

- // synthesis translate\_off
- "Parallel Case (PARALLEL\_CASE)" constraints
  - // synthesis parallel\_case full\_case
  - // synthesis parallel\_case
  - // synthesis full\_case
- Constraints on individual objects

The general syntax is:

```
// synthesis attribute AttributeName [of] ObjectName [is] AttributeValue
```

### Verilog Meta Comments Coding Examples

- // synthesis attribute RLOC of u123 is R11C1.S0
- // synthesis attribute HUSET u1 MY\_SET
- // synthesis attribute fsm\_extract of State2 is "yes"
- // synthesis attribute fsm\_encoding of State2 is "gray"

# **Verilog Constructs Supported in XST**

This section discusses Verilog Constructs Supported in XST, and includes:

- "Verilog Constants Supported in XST"
- "Verilog Data Types Supported in XST"
- "Verilog Continuous Assignments Supported in XST"
- "Verilog Procedural Assignments Supported in XST"
- "Verilog Design Hierarchies Supported in XST"
- "Verilog Compiler Directives Supported in XST"

XST does not allow underscores as the first character of signal names (for example, \_DATA\_1)

## Verilog Constants Supported in XST

 $\pm i i = 0$   $\lambda i = 1$ 

Table 7-3:	verling Constants Supported in XST	
------------	------------------------------------	--

Constant	Supported/Unsupported
Integer Constants	Supported
Real Constants	Supported
Strings Constants	Unsupported

1 · VOT



## Verilog Data Types Supported in XST

This section discusses Verilog Data Types Supported in XST, and includes:

- "Verilog Net Types Supported in XST"
- "Verilog Drive Strengths Supported in XST"
- "Verilog Registers Supported in XST"
- "Verilog Vectors Supported in XST"
- "Verilog Multi-Dimensional Arrays Supported in XST"
- "Verilog Parameters Supported in XST"
- "Verilog Named Events Supported in XST"

### Verilog Net Types Supported in XST

Table 7-4: Verilog Net Types Supported in XST

Net Type	Supported/Unsupported
wire	Supported
tri	Supported
supply0, supply1	Supported
wand, wor, triand, trior	Supported
tri0, tri1, trireg	Unsupported

### Verilog Drive Strengths Supported in XST

Table 7-5: Verilog Drive Strengths Supported in XST

Drive Strength	Supported/Unsupported
All drive strengths	Ignored

### Verilog Registers Supported in XST

Table 7-6: Verilog Registers Supported in XST

Register	Supported/Unsupported
reg	Supported
integer	Supported
real	Unsupported
realtime	Unsupported

### Verilog Vectors Supported in XST

Table 7-7: Verilog Vectors Supported in XST

Vector	Supported/Unsupported
net	Supported
reg	Supported

Table 7-7:	Verilog	Vectors	Supported	l in XST
10010 1 11	•••••9	1001010	04990100	

Vector	Supported/Unsupported
vectored	Supported
scalared	Supported

Verilog Multi-Dimensional Arrays Supported in XST

Table 7-8: Verilog Multi-Dimensional Arrays Supported in XST

Multi-Dimensional Array	Supported/Unsupported
All multi-dimensional arrays	Supported

### Verilog Parameters Supported in XST

Table 7-9: Verilog Parameters Supported in XST

Parameter	Supported/Unsupported
All parameters	Supported

### Verilog Named Events Supported in XST

Table 7-10: Verilog Named Events Supported in XST

Named Event	Supported/Unsupported
All named events	Unsupported

## Verilog Continuous Assignments Supported in XST

Table 7-11: Verilog Continuous Assignments Supported in XST

Continuous Assignment	Supported/Unsupported
Drive Strength	Ignored
Delay	Ignored

## Verilog Procedural Assignments Supported in XST

This section discusses Verilog Procedural Assignments Supported in XST, and includes:

- "Verilog Blocking Assignments Supported in XST"
- "Verilog Non-Blocking Assignments Supported in XST"
- "Verilog Continuous Procedural Assignments Supported in XST"
- "Verilog If Statements Supported in XST"
- "Verilog Case Statements Supported in XST"
- "Verilog Forever Statements Supported in XST"
- "Verilog Repeat Statements Supported in XST"
- "Verilog While Statements Supported in XST"
- "Verilog For Statements Supported in XST"
- "Verilog Fork/Join Statements Supported in XST"

- "Verilog Timing Control on Procedural Assignments Supported in XST"
- "Verilog Sequential Blocks Supported in XST"
- "Verilog Parallel Blocks Supported in XST"
- "Verilog Specify Blocks Supported in XST"
- "Verilog Initial Statements Supported in XST"
- "Verilog Always Statements Supported in XST"
- "Verilog Tasks Supported in XST"
- "Verilog Functions Supported in XST"
- "Verilog Disable Statement Supported in XST"

### Verilog Blocking Assignments Supported in XST

Table 7-12: Verilog Blocking Assignments Supported in XST

Blocking Assignment	Supported/Unsupported
All blocking assignments	Supported

### Verilog Non-Blocking Assignments Supported in XST

Table 7-13: Verilog Non-Blocking Assignments Supported in XST

Non-Blocking Assignment	Supported/Unsupported
All non-blocking assignments	Supported

### Verilog Continuous Procedural Assignments Supported in XST

Table 7-14: Verilog Continuous Procedural Assignments Supported in XST

Continuous Procedural Assignment	Supported/Unsupported
assign	Supported with limitations. See "Behavioral Verilog Assign and Deassign Statements."
deassign	Supported with limitations. See "Behavioral Verilog Assign and Deassign Statements."
force	Unsupported
release	Unsupported

### Verilog If Statements Supported in XST

Table 7-15: Verilog If Statements Supported in XST

If Statement	Supported/Unsupported
if, if else	Supported

### Verilog Case Statements Supported in XST

Table 7-16: Verilog Case Statements Supported in XST

Case Statement	Supported/Unsupported
case, casex, casez	Supported

### Verilog Forever Statements Supported in XST

Table 7-17: Verilog Forever Statements Supported in XST

Forever Statement	Supported/Unsupported
All forever statements	Unsupported

### Verilog Repeat Statements Supported in XST

Table 7-18: Verilog Repeat Statements Supported in XST

Repeat Statement	Supported/Unsupported
	Supported (repeat value must be constant)

### Verilog While Statements Supported in XST

Table 7-19: Verilog While Statements Supported in XST

While Statement	Supported/Unsupported
All While statements	Supported

### Verilog For Statements Supported in XST

Table 7-20: Verilog For Statements Supported in XST

For Statement	Supported/Unsupported
All For statements	Supported (bounds must be static)

### Verilog Fork/Join Statements Supported in XST

Table 7-21: Verilog Fork/Join Statements Supported in XST

Fork/Join Statement	Supported/Unsupported
All Fork/Join statements	Unsupported

Verilog Timing Control on Procedural Assignments Supported in XST

Table 7-22: Verilog Timing Control on Procedural Assignments Supported in XST

Timing Control on Procedural Assignment	Supported/Unsupported
delay ( <b>#</b> )	Ignored
event (@)	Unsupported

Table 7-22: Verilog Timing Control on Procedural Assignments Supported in XST

Timing Control on Procedural Assignment	Supported/Unsupported
wait	Unsupported
named events	Unsupported

### Verilog Sequential Blocks Supported in XST

Table 7-23: Verilog Sequential Blocks Supported in XST

Sequential Blocks	Supported/Unsupported
All Sequential Blocks	Supported

### Verilog Parallel Blocks Supported in XST

Table 7-24: Verilog Parallel Blocks Supported in XST

Parallel Blocks	Supported/Unsupported
All Parallel Blocks	Unsupported

### Verilog Specify Blocks Supported in XST

Table 7-25: Verilog Specify Blocks Supported in XST

Specify Blocks	Supported/Unsupported
All Specify Blocks	Ignored

### Verilog Initial Statements Supported in XST

Table 7-26: Verilog Initial Statements Supported in XST

Initial Statements	Supported/Unsupported
All Initial Statements	Supported

### Verilog Always Statements Supported in XST

Table 7-27: Verilog Always Statements Supported in XST

Always Statements	Supported/Unsupported
All Always Statements	Supported

## Verilog Tasks Supported in XST

Table 7-28: Verilog Tasks Supported in XST

Task	Supported/Unsupported
All Tasks	Supported

### Verilog Functions Supported in XST

Table 7-29: Verilog Functions Supported in XST

Functions	Supported/Unsupported
All Functions	Supported

## Verilog Disable Statement Supported in XST

Table 7-30: Verilog Disable Statement Supported in XST

Disable Statements	Supported/Unsupported
All Disable Statements	Supported

## Verilog Design Hierarchies Supported in XST

Table 7-31: Verilog Design Hierarchies Supported in XST

Design Hierarchy	Supported/Unsupported
module definition	Supported
macromodule definition	Unsupported
hierarchical names	Unsupported
defparam	Supported
array of instances	Supported

## Verilog Compiler Directives Supported in XST

Table 7-32: Verilog Compiler Directives Supported in XST

Compiler Directive	Supported/Unsupported
`celldefine `endcelldefine	Ignored
`default_nettype	Supported
`define	Supported
`ifdef `else `endif	Supported
`undef, `ifndef, `elsif,	Supported
`include	Supported
`resetall	Ignored
`timescale	Ignored
`unconnected_drive	Ignored
`nounconnected_drive	
`uselib	Unsupported
`file, `line	Supported

# Verilog System Tasks and Functions Supported in XST

Table 7-33: Verilog System Tasks and Functions Supported in XST

System Task or Function	Supported/Unsupported	Comment
\$display	Supported	Escape sequences are limited to %d, %b, %h, %o, %c and %s
\$fclose	Supported	
\$fdisplay	Supported	
\$fgets	Supported	
\$finish	Supported	\$finish is supported for statically never active conditional branches only
\$fopen	Supported	
\$fscanf	Supported	Escape sequences are limited to %b and %d
\$fwrite	Supported	
\$monitor	Ignored	
\$random	Ignored	
\$readmemb	Supported	
\$readmemh	Supported	
\$signed	Supported	
\$stop	Ignored	
\$strobe	Ignored	
\$time	Ignored	
\$unsigned	Supported	
\$write	Supported	Escape sequences are limited to %d, %b, %h, %o, %c and %s
all others	Ignored	
	L	1

The XST Verilog compiler ignores unsupported system tasks.

The \$signed and \$unsigned system tasks can be called on any expression using the following syntax:

\$signed(expr) or \$unsigned(expr)

The return value from these calls is the same size as the input value. Its sign is forced regardless of any previous sign.

The **\$readmemb** and **\$readmemh** system tasks can be used to initialize block memories. For more information, see "Initializing RAM From an External File."

Use **\$readmemb** for binary and **\$readmemh** for hexadecimal representation. To avoid the possible difference between XST and simulator behavior, Xilinx recommends that you use index parameters in these system tasks. See the following coding example:

```
$readmemb("rams_20c.data",ram, 0, 7);
```

The remainder of the system tasks can be used to display information to your computer screen and log file during processing, or to open and use a file during synthesis. You must call these tasks from within initial blocks. XST supports a subset of escape sequences, specifically:

- %h
- %d
- %0
- %b
- %C
- %s

### Verilog \$display Syntax Example

The following example shows the syntax for **\$display** that reports the value of a binary constant in decimal format:

```
parameter c = 8'b00101010;
initial
begin
$display ("The value of c is %d", c);
end
```

The following information is written to the log file during the HDL Analysis phase:

```
Analyzing top module <example>.
c = 8'b00101010
"foo.v" line 9: $display : The value of c is 42
```

## **Verilog Primitives**

This section discusses Verilog Primitives, and includes:

- "About Verilog Primitives"
- "Verilog Primitives Support"

### About Verilog Primitives

XST supports certain gate-level primitives. The supported syntax is:

gate\_type instance\_name (output, inputs, ...);

Following is a gate-level primitive instantiations coding example:

and U1 (out, in1, in2); bufif1 U2 (triout, data, trienable);



### Verilog Primitives Support

XST supports the following Verilog primitives:

- "Verilog Gate-Level Primitives Supported in XST"
- "Verilog Switch-Level Primitives Supported in XST"

"Verilog User-Defined Primitives Supported in XST"

Table 7-34: Verilog Gate-Level Primitives Supported in XST

Primitive	Supported/Unsupported
and nand nor or xnor xor	Supported
buf not	Supported
bufif0 bufif1 notif0 notif1	Supported
pulldown pullup	Unsupported
drive strength	Ignored
delay	Ignored
array of primitives	Supported

Table 7-35: Verilog Switch-Level Primitives Supported in XST

Primitive	Supported/Unsupported
cmos nmos pmos rcmos rnmos rpmos	Unsupported
rtran rtranif0 rtranif1 tran tranif0 tranif1	Unsupported

Table 7-36: Verilog User-Defined Primitives Supported in XST

Primitive	Supported/Unsupported		
All user-defined primitives	Unsupported		

# **Verilog Reserved Keywords**

Keywords marked with an asterisk (\*) are reserved by Verilog, but are not supported by XST.

Table 7-37: Verilog Reserved Keywords

always	and	assign	automatic
begin	buf	bufif0	bufif1
case	casex	casez	cell*
cmos	config*	deassign	default
defparam	design*	disable	edge
else	end	endcase	endconfig*
endfunction	endgenerate	endmodule	endprimitive

Table 7-37: Veril	og Reserved Keyword	s (Conta)	
endspecify	endtable	endtask	event
for	force	forever	fork
function	generate	genvar	highz0
highz1	if	ifnone	incdir*
include*	initial	inout	input
instance*	integer	join	large
liblist*	library*	localparam*	macromodule
medium	module	nand	negedge
nmos	nor	noshow-cancelled*	not
notif0	notif1	or	output
parameter	pmos	posedge	primitive
pull0	pull1	pullup	pulldown
pulsestyle- _ondetect*	pulsestyle- _onevent*	rcmos	real
realtime	reg	release	repeat
rnmos	rpmos	rtran	rtranif0
rtranif1	scalared	show-cancelled*	signed
small	specify	specparam	strong0
strong1	supply0	supply1	table
task	time	tran	tranif0
tranif1	tri	tri0	tri1
triand	trior	trireg	use*
vectored	wait	wand	weak0
weak1	while	wire	wor
xnor	xor		
	1	1	- I

Table 7-37: Verilog Reserved Keywords (Cont'd)

# Verilog-2001 Support in XST

XST supports the following Verilog-2001 features. For more information, see *Verilog-2001: A Guide to the New Features* by Stuart Sutherland, or *IEEE Standard Verilog Hardware Description Language* manual, (IEEE Standard 1364-2001).

- Generate statements
- Combined port/data type declarations
- ANSI-style port lists
- Module parameter port lists
- ANSI C style task/function declarations



- Comma separated sensitivity list
- Combinatorial logic sensitivity
- Default nets with continuous assigns
- Disable default net declarations
- Indexed vector part selects
- Multi-dimensional arrays
- Arrays of net and real data types
- Array bit and part selects
- Signed reg, net, and port declarations
- Signed based integer numbers
- Signed arithmetic expressions
- Arithmetic shift operators
- Automatic width extension past 32 bits
- Power operator
- N sized parameters
- Explicit in-line parameter passing
- Fixed local parameters
- Enhanced conditional compilation
- File and line compiler directives
- Variable part selects
- Recursive Tasks and Functions
- Constant Functions



# Chapter 8

# **XST Behavioral Verilog Language** Support

This chapter (*XST Behavioral Verilog Language Support*) describes XST support for Behavioral Verilog. This chapter includes:

- "Behavioral Verilog Variable Declarations"
- "Behavioral Verilog Initial Values"
- "Behavioral Verilog Local Reset"
- "Behavioral Verilog Arrays"
- "Behavioral Verilog Multi-Dimensional Arrays"
- "Behavioral Verilog Data Types"
- "Behavioral Verilog Legal Statements"
- "Behavioral Verilog Expressions"
- "Behavioral Verilog Blocks"
- "Behavioral Verilog Modules"
- "Behavioral Verilog Module Declarations"
- "Behavioral Verilog Continuous Assignments"
- "Behavioral Verilog Procedural Assignments"
- "Behavioral Verilog Constants"
- "Behavioral Verilog Macros"
- "Behavioral Verilog Include Files"
- "Behavioral Verilog Comments"
- "Behavioral Verilog Generate Statements"
- "Behavioral Verilog Generate Statements"

# **Behavioral Verilog Variable Declarations**

This section discusses Behavioral Verilog Variable Declarations, and includes:

- "About Behavioral Verilog Variable Declarations"
- "Behavioral Verilog Variable Declarations Coding Examples"



## About Behavioral Verilog Variable Declarations

Variables in Verilog may be declared as integers or real. These declarations are intended for use in test code only. Verilog provides data types such as reg and wire for actual hardware description.

The difference between reg and wire is whether the variable is given its value in a procedural block (reg) or in a continuous assignment (wire) Verilog code. Both reg and wire have a default width being one bit wide (scalar). To specify an N-bit width (vectors) for a declared reg or wire, the left and right bit positions are defined in square brackets separated by a colon. In Verilog-2001, both reg and wire data types can be signed or unsigned.

## Behavioral Verilog Variable Declarations Coding Examples

This section gives the following Behavioral Verilog Variable Declarations coding examples:

• "Behavioral Verilog Variable Declarations Coding Example"

### Behavioral Verilog Variable Declarations Coding Example

```
reg [3:0] arb_priority;
wire [31:0] arb_request;
wire signed [8:0] arb_signed;
```

where

- arb\_request[31] is the MSB
- arb\_request[0] is the LSB

# **Behavioral Verilog Initial Values**

This section discusses Behavioral Verilog Initial Values, and includes:

- "About Behavioral Verilog Initial Values"
- "Behavioral Verilog Initial Values Coding Examples"

## About Behavioral Verilog Initial Values

In Verilog-2001, you can initialize registers when you declare them.

The value:

- Is a constant
- Cannot depend on earlier initial values
- Cannot be a function or task call
- Can be a parameter value propagated to the register
- Specifies all bits of a vector

## Behavioral Verilog Initial Values Coding Examples

This section gives the following Behavioral Verilog Variable Declarations coding examples:

• "Behavioral Verilog Initial Values Coding Example"

Behavioral Verilog Initial Values Coding Example

When you give a register an initial value in a declaration, XST sets this value on the output of the register at global reset, or at power up. A value assigned this way is carried in the NGC file as an INIT attribute on the register, and is independent of any local reset.

```
reg arb_onebit = 1'b0;
reg [3:0] arb_priority = 4'b1011;
```

You can also assign a set/reset (initial) value to a register in your behavioral Verilog code. Assign value to a register when the register reset line goes to the appropriate value as shown in the following coding example:

```
always @(posedge clk)
   begin
    if (rst)
        arb_onebit <= 1'b0;
   end
end</pre>
```

When you set the initial value of a variable in the behavioral code, it is implemented in the design as a flip-flop whose output can be controlled by a local reset. As such, it is carried in the NGC file as an FDP or FDC flip-flop.

# **Behavioral Verilog Local Reset**

This section discusses Behavioral Verilog Local Reset and includes:

- "About Behavioral Verilog Local Reset"
- "Behavioral Verilog Local Reset Coding Examples"

### About Behavioral Verilog Local Reset

Local reset is independent of global reset. Registers controlled by a local reset may be set to a different value than ones whose value is only reset at global reset (power up). In the "Behavioral Verilog Local Reset Coding Example," the register, arb\_onebit, is set to 0 at global reset, but a pulse on the local reset (rst) can change its value to 1.

### Behavioral Verilog Local Reset Coding Examples

This section gives the following Behavioral Verilog Local Reset coding examples:

"Behavioral Verilog Local Reset Coding Example"

Behavioral Verilog Local Reset Coding Example

```
module mult(clk, rst, A_IN, B_OUT);
input clk,rst,A_IN;
output B_OUT;
reg arb_onebit = 1'b0;
```

www.xilinx.com



```
always @(posedge clk or posedge rst)
begin
    if (rst)
        arb_onebit <= 1'b1;
    else
        arb_onebit <= A_IN;
    end
end
B_OUT <= arb_onebit;
endmodule</pre>
```

This sets the set/reset value on the register output at initial power up, but since this is dependent upon a local reset, the value changes whenever the local set/reset is activated.

# **Behavioral Verilog Arrays**

Verilog allows arrays of reg and wires to be defined as shown in the following coding examples:

- "Behavioral Verilog Arrays Coding Example"
- "Structural Verilog Arrays Coding Example"

Behavioral Verilog Arrays Coding Example

The following coding example describes an array of 32 elements each, 4 bits wide which can be assigned in *behavioral* Verilog code:

reg [3:0] mem\_array [31:0];

Structural Verilog Arrays Coding Example

The following coding example describes an array of 64 elements each 8 bits wide which can be assigned only in *structural* Verilog code:

wire [7:0] mem\_array [63:0];

# **Behavioral Verilog Multi-Dimensional Arrays**

This section discusses Behavioral Verilog Multi-Dimensional Arrays and includes:

- "About Behavioral Verilog Multi-Dimensional Arrays"
- "Behavioral Verilog Multi-Dimensional Arrays Coding Examples"

## About Behavioral Verilog Multi-Dimensional Arrays

XST supports multi-dimensional array types of up to two dimensions. Multi-dimensional arrays can be any net or any variable data type. You can code assignments and arithmetic operations with arrays, but you cannot select more than one element of an array at one time. You cannot pass multi-dimensional arrays to system tasks or functions, or regular tasks or functions.

## Behavioral Verilog Multi-Dimensional Arrays Coding Examples

This section gives the following Behavioral Verilog Multi-Dimensional Arrays coding examples:

- "Behavioral Verilog Multi-Dimensional Arrays Coding Example One"
- "Behavioral Verilog Multi-Dimensional Arrays Coding Example Two"
- "Behavioral Verilog Multi-Dimensional Arrays Coding Example Three"

### Behavioral Verilog Multi-Dimensional Arrays Coding Example One

The following Verilog coding example describes an array of 256 x 16 wire elements each 8 bits wide, which can be assigned only in *structural* Verilog code:

wire [7:0] array2 [0:255][0:15];

Behavioral Verilog Multi-Dimensional Arrays Coding Example Two

The following Verilog coding example describes an array of 256 x 8 register elements, each 64 bits wide, which can be assigned in *behavioral* Verilog code:

reg [63:0] regarray2 [255:0][7:0];

Behavioral Verilog Multi-Dimensional Arrays Coding Example Three

The following Verilog coding example is a three dimensional array. It can be described as an array of 15 arrays of 256 x 16 wire elements, each 8 bits wide, which can be assigned in *structural* Verilog code:

wire [7:0] array3 [0:15][0:255][0:15];

# **Behavioral Verilog Data Types**

This section discusses Behavioral Verilog Data Types and includes:

- "About Behavioral Verilog Data Types"
- "Behavioral Verilog Data Types Coding Examples"

### About Behavioral Verilog Data Types

The Verilog representation of the bit data type contains the following values:

• 0

logic zero

• 1

logic one

- **x** unknown logic value
- **z** high impedance



XST includes support for the following Verilog data types:

- Net
  - ♦ wire
    - ♦ tri
    - triand/wand
    - trior/wor
- Registers
  - reg
  - integer
- Supply nets
  - ♦ supply0
  - ♦ supply1
- Constants parameter
  - parameter
- Multi-Dimensional Arrays (Memories)

Net and registers can be either single bit (scalar) or multiple bit (vectors).

### Behavioral Verilog Data Types Coding Examples

This section gives the following Behavioral Verilog Data Types coding examples:

"Behavioral Verilog Data Types Coding Example"

### Behavioral Verilog Data Types Coding Example

The following Behavioral Verilog coding example shows sample Verilog data types found in the declaration section of a Verilog module:

```
wire net1; // single bit net
reg r1; // single bit register
tri [7:0] bus1; // 8 bit tristate bus
reg [15:0] bus1; // 15 bit register
reg [7:0] mem[0:127]; // 8x128 memory register
parameter state1 = 3'b001; // 3 bit constant
parameter component = "TMS380C16"; // string
```

## **Behavioral Verilog Legal Statements**

The following statements are legal in behavioral Verilog:

Variable and signal assignment:

- Variable = expression
- if (condition) statement
- if (condition) statement else statement

case (expression)

. . .

expression: statement

```
default: statement
```

```
endcase
```

- for (variable = expression; condition; variable = variable + expression) statement
- while (condition) statement
- forever statement
- functions and tasks

All variables are declared as integer or reg. A variable cannot be declared as a wire.

# **Behavioral Verilog Expressions**

This section discusses Behavioral Verilog Expressions, and includes:

- "About Behavioral Verilog Expressions"
- "Operators Supported in Behavioral Verilog"
- "Expressions Supported in Behavioral Verilog"
- "Results of Evaluating Expressions in Behavioral Verilog"

## About Behavioral Verilog Expressions

An expression involves constants and variables with arithmetic, logical, relational, and conditional operators as shown in Table 8-1, "Operators Supported in Behavioral Verilog." The logical operators are further divided as bit-wise versus logical, depending on whether it is applied to an expression involving several bits or a single bit.

## **Operators Supported in Behavioral Verilog**

### Table 8-1: Operators Supported in Behavioral Verilog

Arithmetic	Logical	Relational	Conditional
+	&	<	?
-	&&	==	
*		===	
**		<=	
/	^	>=	
%	~	>=	
	~^	!=	
	^~	!==	
	<<	>	
	>>		

www.xilinx.com



Table 8-1: Operators Supported in Behavioral Verilog (Cont'd)

Arithmetic	Logical	Relational	Conditional
	<<<		
	>>>		

# Expressions Supported in Behavioral Verilog

Table 8-2:	Expressions	Supported in	Behavioral Verilog

Expression	Symbol	Supported/Unsupported
Concatenation	{}	Supported
Replication	{{}}	Supported
	+, -, *,**	Supported
Arithmetic	/	Supported only if second operand is a power of 2
Modulus	%	Supported only if second operand is a power of 2
Addition	+	Supported
Subtraction	-	Supported
Multiplication	*	Supported
Power	**	Supported
Division		<ul> <li>Both operands are constants, with the second operand being non-negative.</li> <li>If the first operand is a 2, then the second operand may be a variable.</li> <li>XST does not support the real data type. Any combination of operands that results in a real type causes an error.</li> <li>The values X (unknown) and Z (high impedance) are not allowed.</li> <li>Supported</li> <li>XST generates incorrect logic for the division operator between signed and unsigned constants.</li> </ul>
		Example: -1235/3'b111
Relational	>, <, >=, <=	Supported
Logical Negation	!	Supported
Logical AND	&&	Supported
Logical OR		Supported
Logical Equality	==	Supported
Logical Inequality	!=	Supported
Case Equality	===	Supported

Expression	Symbol	Supported/Unsupported		
Case Inequality	!==	Supported		
Bitwise Negation	~	Supported		
Bitwise AND	&	Supported		
Bitwise Inclusive OR		Supported		
Bitwise Exclusive OR	^	Supported		
Bitwise Equivalence	~^, ^~	Supported		
Reduction AND	&	Supported		
Reduction NAND	~&	Supported		
Reduction OR		Supported		
Reduction NOR	~	Supported		
Reduction XOR	^	Supported		
Reduction XNOR	~^, ^~	Supported		
Left Shift	<<	Supported		
Right Shift Signed	>>>	Supported		
Left Shift Signed	<<<	Supported		
Right Shift	>>	Supported		
Conditional	?:	Supported		
Event OR	or, ','	Supported		

Table 8-2: Expressions Supported in Behavioral Verilog (Cont'd)

# Results of Evaluating Expressions in Behavioral Verilog

Table 8-3, "Results of Evaluating Expressions in Behavioral Verilog," lists the results of evaluating expressions using the more frequently used operators supported by XST.

The (===) and (!==) operators are special comparison operators useful in simulations to check if a variable is assigned a value of (x) or (z). They are treated as (==) or (!=) in synthesis.

a b	a==b	a===b	a!=b	a!==b	a&b	a&&b	alb	allb	a^b
0 0	1	1	0	0	0	0	0	0	0
01	0	0	1	1	0	0	1	1	1
0 x	x	0	х	1	0	0	x	x	x
0 z	x	0	х	1	0	0	x	x	x
10	0	0	1	1	0	0	1	1	1
11	1	1	0	0	1	1	1	1	0
1 x	x	0	x	1	x	x	1	1	x

Table 8-3: Results of Evaluating Expressions in Behavioral Verilog



			0 1		( )		0		
a b	a==b	a===b	a!=b	a!==b	a&b	a&&b	alb	allb	a^b
1 z	х	0	х	1	х	x	1	1	x
x 0	х	0	х	1	0	0	x	х	х
x 1	х	0	х	1	х	x	1	1	x
x x	х	1	х	0	х	x	x	х	х
x z	х	0	х	1	х	x	x	х	х
z 0	х	0	х	1	0	0	х	х	х
z 1	х	0	х	1	х	x	1	1	х
z x	х	0	х	1	х	x	x	x	x
z z	x	1	x	0	x	x	x	x	x

Table 8-3: Results of Evaluating Expressions (Cont'd)in Behavioral Verilog

# **Behavioral Verilog Blocks**

Block statements are used to group statements together. XST supports sequential blocks only. Within these blocks, the statements are executed in the order listed. Parallel blocks are not supported by XST. Block statements are designated by **begin** and **end** keywords.

# **Behavioral Verilog Modules**

In Verilog a design component is represented by a module. The connections between components are specified within module instantiation statements. Such a statement specifies an instance of a module. Each module instantiation statement has a name (instance name). In addition to the name, a module instantiation statement contains an association list that specifies which actual nets or ports are associated with which local ports (formals) of the module declaration.

All procedural statements occur in blocks that are defined inside modules. The two kinds of procedural blocks are:

- Initial block
- Always block

Within each block, Verilog uses a begin and end to enclose the statements. Since initial blocks are ignored during synthesis, only always blocks are discussed. Always blocks usually take the following format:

```
always
begin
statement
....
end
```

Each statement is a procedural assignment line terminated by a semicolon.

# **Behavioral Verilog Module Declarations**

This section discusses Behavioral Verilog Module Declarations, and includes:

- "About Behavioral Verilog Module Declarations"
- "Behavioral Verilog Module Declaration Coding Examples"

## About Behavioral Verilog Module Declarations

The I/O ports of the circuit are declared in the module declaration. Each port has:

- A name
- A mode (in, out, and inout)

The input and output ports defined in the module declaration called EXAMPLE are the basic input and output I/O signals for the design. The inout port in Verilog is analogous to a bi-directional I/O pin on the device with the data flow for output versus input being controlled by the enable signal to the tristate buffer.

The "Behavioral Verilog Module Declaration Coding Example" describes E as a tristate buffer with a high-true output enable signal.

- If oe = 1, the value of signal A is output on the pin represented by E.
- If oe = 0, the buffer is in high impedance (Z), and any input value driven on the pin E (from the external logic) is brought into the device and fed to the signal represented by D.

### Behavioral Verilog Module Declaration Coding Examples

This section gives the following Behavioral Verilog Module Declaration coding examples:

"Behavioral Verilog Module Declaration Coding Example"

Behavioral Verilog Module Declaration Coding Example

```
module EXAMPLE (A, B, C, D, E);
input A, B, C;
output D;
inout E;
wire D, E;
...
assign E = oe ? A : 1'bz;
assign D = B & E;
...
endmodule
```

# **Behavioral Verilog Continuous Assignments**

This section discusses Behavioral Verilog Continuous Assignments, and includes:

- "About Behavioral Verilog Continuous Assignments"
- "Behavioral Verilog Continuous Assignments Coding Examples"

### About Behavioral Verilog Continuous Assignments

Continuous assignments are used to model combinatorial logic in a concise way. Both explicit and implicit continuous assignments are supported. Explicit continuous

www.xilinx.com

assignments are introduced by the **assign** keyword after the net has been separately declared. Implicit continuous assignments combine declaration and assignment. Delays and strengths given to a continuous assignment are ignored by XST.

## Behavioral Verilog Continuous Assignments Coding Examples

This section gives the following Behavioral Verilog Continuous Assignments coding examples:

- "Behavioral Verilog Explicit Continuous Assignment Coding Example"
- "Behavioral Verilog Implicit Continuous Assignment Coding Example"

Behavioral Verilog Explicit Continuous Assignment Coding Example

```
wire par_eq_1;
....
assign par_eq_1 = select ? b : a;
```

Behavioral Verilog Implicit Continuous Assignment Coding Example

```
wire temp_hold = a \mid b;
```

Continuous assignments are allowed on wire and tri data types only.

# **Behavioral Verilog Procedural Assignments**

This section discusses Behavioral Verilog Procedural Assignments, and includes:

- "About Behavioral Verilog Procedural Assignments"
- "Behavioral Verilog Combinatorial Always Blocks"
- "Behavioral Verilog If...Else Statement"
- "Behavioral Verilog Case Statements"
- "Behavioral Verilog For and Repeat Loops"
- "Behavioral Verilog While Loops"
- "Behavioral Verilog Sequential Always Blocks"
- "Behavioral Verilog Assign and Deassign Statements"
- "Behavioral Verilog Assign/Deassign Statement Performed in Same Always Block"
- "Cannot Assign Bit/Part Select of Signal Through Assign/Deassign Statement"
- "Behavioral Verilog Assignment Extension Past 32 Bits"
- "Behavioral Verilog Tasks and Functions"
- "Behavioral Verilog Recursive Tasks and Functions"
- "Behavioral Verilog Constant Functions"
- "Behavioral Verilog Blocking Versus Non-Blocking Procedural Assignments"

### About Behavioral Verilog Procedural Assignments

Procedural assignments are used to assign values to variables declared as regs and are introduced by always blocks, tasks, and functions. Procedural assignments are usually used to model registers and FSMs.

XST includes support for combinatorial functions, combinatorial and sequential tasks, and combinatorial and sequential always blocks.

## Behavioral Verilog Combinatorial Always Blocks

Combinatorial logic can be modeled efficiently using two forms of time control, the **#** (pound) and **@** (asterisk) Verilog time control statements. The **#** (pound) time control is ignored for synthesis and hence this section describes modeling combinatorial logic with the **@** (asterisk) statement.

A combinatorial always block has a sensitivity list appearing within parentheses after the word **always @**. An always block is activated if an event (value change or edge) appears on one of the sensitivity list signals. This sensitivity list can contain any signal that appears in conditions (**If** or **Case**, for example), and any signal appearing on the right hand side of an assignment. By substituting an **@** (asterisk) without parentheses for a list of signals, the always block is activated for an event in any of the **always** block's signals as described above.

In combinatorial processes, if a signal is not explicitly assigned in all branches of **If** or **Case** statements, XST generates a latch to hold the last value. To avoid latch creation, be sure that all assigned signals in a combinatorial process are always explicitly assigned in all paths of the process statements.

Different statements can be used in a process:

- Variable and signal assignment
- If... else statement
- Case statement
- For and while loop statement
- Function and task call

The following sections provide examples of each of these statements.

## Behavioral Verilog If...Else Statement

**If...** else statements use true/false conditions to execute statements. If the expression evaluates to **true**, the first statement is executed. If the expression evaluates to **false** (or **x** or **z**), the **else** statement is executed. A block of multiple statements may be executed using begin and end keywords. **If...else** statements may be nested.

Behavioral Verilog If...Else Statement Coding Example

The following coding example shows how a MUX can be described using an **If...else** statement:

```
module mux4 (sel, a, b, c, d, outmux);
input [1:0] sel;
input [1:0] a, b, c, d;
output [1:0] outmux;
reg [1:0] outmux;
always @(sel or a or b or c or d)
begin
    if (sel[1])
        if (sel[0])
            outmux = d;
        else
            outmux = c;
        else
            if (sel[0])
```



```
outmux = b;
else
outmux = a;
end
endmodule
```

## **Behavioral Verilog Case Statements**

This section discusses Behavioral Verilog Case Statements, and includes:

- "About Behavioral Verilog Continuous Assignments"
- "Behavioral Verilog Continuous Assignments Coding Examples"

### About Behavioral Verilog Case Statements

**Case** statements perform a comparison to an expression to evaluate one of a number of parallel branches. The **Case** statement evaluates the branches in the order they are written. The first branch that evaluates to **true** is executed. If none of the branches match, the default branch is executed.

Do not use unsized integers in case statements. Always size integers to a specific number of bits, or results can be unpredictable.

**Casez** treats all **z** values in any bit position of the branch alternative as a **don't** care.

**Casex** treats all **x** and **z** values in any bit position of the branch alternative as a **don't care**.

The question mark (?) can be used as a **don't care** in either the **casez** or **casex** case statements.

### Behavioral Verilog Case Statement Coding Examples

This section gives the following Behavioral Verilog Case Statement coding examples:

• "Behavioral Verilog Case Statement Coding Example"

Behavioral Verilog Case Statement Coding Example

The following coding example shows how a MUX can be described using a **Case** statement:

```
module mux4 (sel, a, b, c, d, outmux);
input [1:0] sel;
input [1:0] a, b, c, d;
output [1:0] outmux;
reg [1:0] outmux;
always @(sel or a or b or c or d)
begin
    case (sel)
    2'b00: outmux = a;
    2'b01: outmux = b;
    2'b10: outmux = b;
    2'b10: outmux = c;
    default: outmux = d;
    endcase
end
endmodule
```

The preceding **Case** statement evaluates the values of the input **sel** in priority order. To avoid priority processing, Xilinx recommends that you use a parallel-case Verilog attribute to ensure parallel evaluation of the **sel** inputs as shown in the following:

(\* parallel\_case \*) case(sel)

## Behavioral Verilog For and Repeat Loops

This section discusses Behavioral Verilog For and Repeat Loops, and includes:

- "About Behavioral Verilog For and Repeat Loops"
- "Behavioral Verilog For Loop Coding Examples"

### About Behavioral Verilog For and Repeat Loops

When using always blocks, repetitive or bit slice structures can also be described using the **for** statement or the **repeat** statement.

The **for** statement is supported for:

- Constant bounds
- Stop test condition using operators <, <=, > or >=
- Next step computation falling in one of the following specifications:
  - var = var + step
  - var = var step

(where *var* is the loop variable and *step* is a constant value).

The repeat statement is supported for constant values only.

Disable statements are not supported.

### Behavioral Verilog For Loop Coding Examples

This section gives the following Behavioral Verilog For Loop coding examples:

"Behavioral Verilog For Loop Coding Example"

### Behavioral Verilog For Loop Coding Example

```
module countzeros (a, Count);
input [7:0] a;
output [2:0] Count;
reg [2:0] Count;
reg [2:0] Count_Aux;
integer i;
always @(a)
  begin
   Count_Aux = 3'b0;
  for (i = 0; i < 8; i = i+1)
   begin
      if (!a[i])
        Count_Aux = Count_Aux+1;
      end
  Count = Count_Aux;
  end
endmodule
```

www.xilinx.com



## **Behavioral Verilog While Loops**

When using always blocks, use the **while** statement to execute repetitive procedures. A **while** loop executes other statements until its test expression becomes **false**. It is not executed if the test expression is initially **false**.

- The test expression is any valid Verilog expression.
- To prevent endless loops, use the **-loop\_iteration\_limit** option.
- While loops can have **disable** statements. The **disable** statement is used inside a labeled block, since the syntax is **disable** *<blockname>*.

### Behavioral Verilog While Loop Coding Example

```
parameter P = 4;
always @(ID_complete)
begin : UNIDENTIFIED
integer i;
reg found;
unidentified = 0;
i = 0;
found = 0;
while (!found && (i < P))
begin
found = !ID_complete[i];
unidentified[i] = !ID_complete[i];
i = i + 1;
end
end
```

## Behavioral Verilog Sequential Always Blocks

Sequential circuit description is based on always blocks with a sensitivity list. The sensitivity list contains a maximum of three edge-triggered events:

- A clock signal event (mandatory)
- A reset signal event (possibly)
- A set signal event

One, and only one, **if...else** statement is accepted in such an always block.

An asynchronous part may appear before the synchronous part in the first and the second branch of the **if...else** statement. Signals assigned in the asynchronous part are assigned to the following constant values:

- 0
- 1
- x
- Z
- any vector composed of these values

These same signals are also assigned in the synchronous part (that is, the last branch of the **if...else** statement). The clock signal condition is the condition of the last branch of the **if...else** statement.

8 Bit Register Using an Always Block Behavioral Verilog Coding Example

```
module seq1 (DI, CLK, DO);
input [7:0] DI;
input CLK;
output [7:0] DO;
reg [7:0] DO;
always @(posedge CLK)
DO <= DI ;</pre>
```

8 Bit Register with Asynchronous Reset (High-True) Using an Always Block Behavioral Verilog Coding Example

```
module EXAMPLE (DI, CLK, RST, DO);
input [7:0] DI;
input CLK, RST;
output [7:0] DO;
reg [7:0] DO;
always @(posedge CLK or posedge RST)
if (RST == 1'b1)
DO <= 8'b00000000;
else
DO <= DI;
endmodule
```

8 Bit Counter with Asynchronous Reset (Low-True) Using an Always Block Behavioral Verilog Coding Example

```
module seq2 (CLK, RST, DO);
input CLK, RST;
output [7:0] DO;
reg [7:0] DO;
always @(posedge CLK or posedge RST)
if (RST == 1'b1)
    DO <= 8'b00000000;
else
    DO <= DO + 8'b0000001;
endmodule
```

### Behavioral Verilog Assign and Deassign Statements

Assign and deassign statements are supported within simple templates.

Behavioral Verilog Assign and Deassign Statements General Template Coding Example

```
module assig (RST, SELECT, STATE, CLOCK, DATA_IN);
input RST;
input SELECT;
input CLOCK;
input [0:3] DATA_IN;
output [0:3] STATE;
reg [0:3] STATE;
always @ (RST)
if(RST)
begin
assign STATE = 4'b0;
```



```
end
else
begin
deassign STATE;
end
always @ (posedge CLOCK)
begin
STATE <= DATA_IN;
end
endmodule</pre>
```

The main limitations on support of the assign/deassign statement in XST are:

- For a given signal, there is only one assign/deassign statement.
- The assign/deassign statement is performed in the same always block through an if/else statement.
- You cannot assign a bit/part select of a signal through an assign/deassign statement.

### Behavioral Verilog Assign/Deassign Statement Coding Example

For a given signal, there is only one assign/deassign statement. For example, XST rejects the following design:

```
module dflop (RST, SET, STATE, CLOCK, DATA_IN);
  input RST;
  input SET;
  input CLOCK;
  input DATA_IN;
  output STATE;
  reg STATE;
                         // block b1
always @ (RST)
  if(RST)
    assign STATE = 1'b0;
  else
    deassign STATE;
always @ (SET)
                          // block b1
  if(SET)
    assign STATE = 1'b1;
  else
    deassign STATE;
always @ (posedge CLOCK) // block b2
  begin
    STATE <= DATA_IN;
  end
endmodule
```

Behavioral Verilog Assign/Deassign Statement Performed in Same Always Block

The assign/deassign statement is performed in the same always block through an **if...else** statement. For example, XST rejects the following design:

```
module dflop (RST, SET, STATE, CLOCK, DATA_IN);
  input RST;
 input SET;
 input CLOCK;
 input DATA_IN;
 output STATE;
 reg STATE;
                            // block b1
always @ (RST or SET)
case ({RST,SET})
 2'b00: assign STATE = 1'b0;
 2'b01: assign STATE = 1'b0;
 2'b10: assign STATE = 1'b1;
 2'b11: deassign STATE;
endcase
always @ (posedge CLOCK) // block b2
 begin
   STATE <= DATA_IN;
 end
endmodule
```

#### Cannot Assign Bit/Part Select of Signal Through Assign/Deassign Statement

You cannot assign a bit/part select of a signal through an assign/deassign statement. For example, XST rejects the following design:

```
module assig (RST, SELECT, STATE, CLOCK, DATA_IN);
  input RST;
  input SELECT;
  input CLOCK;
  input [0:7] DATA_IN;
 output [0:7] STATE;
 reg [0:7] STATE;
 always @ (RST)
                             // block b1
    if(RST)
      begin
        assign STATE[0:7] = 8'b0;
      end
    else
      begin
        deassign STATE[0:7];
      end
always @ (posedge CLOCK)
                             // block b2
 begin
    if (SELECT)
      STATE [0:3] <= DATA_IN[0:3];</pre>
    else
      STATE [4:7] <= DATA_IN[4:7];</pre>
```

end

## Behavioral Verilog Assignment Extension Past 32 Bits

If the expression on the left-hand side of an assignment is wider than the expression on the right-hand side, the left-hand side is padded to the left according to the following rules:

- If the right-hand expression is signed, the left-hand expression is padded with the sign bit:
  - **0** for positive
  - 1 for negative
  - **z** for high impedance
  - **x** for unknown
- If the right-hand expression is unsigned, the left-hand expression is padded with **0**s (zeroes).
- For unsized **x** or **z** constants only, the following rule applies. If the value of the righthand expression's left-most bit is **z** (high impedance) or **x** (unknown), regardless of whether the right-hand expression is signed or unsigned, the left-hand expression is padded with that value (**z** or **x**, respectively).

The above rules follow the Verilog-2001 standard. They are not backward compatible with Verilog-1995.

## Behavioral Verilog Tasks and Functions

The declaration of a function or task is intended for handling blocks used multiple times in a design. They must be declared and used in a module. The heading part contains the parameters: input parameters (only) for functions and input/output/inout parameters for tasks. The return value of a function can be declared either signed or unsigned. The content is similar to the combinatorial always block content.

The "Behavioral Verilog Function Declared Within a Module Coding Example" shows a function declared within a module. The ADD function declared is a single-bit adder. This function is called four times with the proper parameters in the architecture to create a 4-bit adder.

The "Behavioral Verilog Function Declared Within a Module Coding Example," described with a task, is shown in the "Behavioral Verilog Task Declaration and Task Enable Coding Example."

Behavioral Verilog Function Declared Within a Module Coding Example

```
module comb15 (A, B, CIN, S, COUT);
input [3:0] A, B;
input CIN;
output [3:0] S;
output COUT;
wire [1:0] S0, S1, S2, S3;
function signed [1:0] ADD;
input A, B, CIN;
reg S, COUT;
begin
    S = A ^ B ^ CIN;
COUT = (A&B) | (A&CIN) | (B&CIN);
ADD = {COUT, S};
```

```
end
endfunction
assign S0 = ADD (A[0], B[0], CIN),
S1 = ADD (A[1], B[1], S0[1]),
S2 = ADD (A[2], B[2], S1[1]),
S3 = ADD (A[3], B[3], S2[1]),
S = {S3[0], S2[0], S1[0], S0[0]},
COUT = S3[1];
endmodule
```

#### Behavioral Verilog Task Declaration and Task Enable Coding Example

The following coding example shows the "Behavioral Verilog Function Declared Within a Module Coding Example" described with a task:

```
module EXAMPLE (A, B, CIN, S, COUT);
  input [3:0] A, B;
  input CIN;
 output [3:0] S;
 output COUT;
 reg [3:0] S;
 reg COUT;
 reg [1:0] S0, S1, S2, S3;
  task ADD;
    input A, B, CIN;
    output [1:0] C;
    reg [1:0] C;
   reg S, COUT;
   begin
      S = A ^ B ^ CIN;
      COUT = (A\&B) | (A\&CIN) | (B\&CIN);
      C = \{COUT, S\};
    end
  endtask
  always @(A or B or CIN)
 begin
    ADD (A[0], B[0], CIN, S0);
    ADD (A[1], B[1], S0[1], S1);
   ADD (A[2], B[2], S1[1], S2);
   ADD (A[3], B[3], S2[1], S3);
    S = {S3[0], S2[0], S1[0], S0[0]};
    COUT = S3[1];
  end
endmodule
```

#### Behavioral Verilog Recursive Tasks and Functions

Verilog-2001 adds support for recursive tasks and functions. You can use recursion only with the *automatic* keyword.

Behavioral Verilog Syntax Using Recursion Coding Example

```
function automatic [31:0] fac;
input [15:0] n;
```



```
if (n == 1)
  fac = 1;
else
  fac = n * fac(n-1); //recursive function call
endfunction
```

## **Behavioral Verilog Constant Functions**

Verilog-2001 adds support for constant functions. XST now supports function calls to calculate constant values.

Evaluation of a Constant Function Behavioral Verilog Coding Example

```
module rams_cf (clk, we, a, di, do);
parameter DEPTH=1024;
input clk;
input we;
input [4:0] a;
input [3:0] di;
output [3:0] do;
reg [3:0] ram [size(DEPTH):0];
always @(posedge clk) begin
if (we)
ram[a] <= di;</pre>
end
assign do = ram[a];
function integer size;
input depth;
integer i;
begin
    size=1;
  for (i=0; 2**i<depth; i=i+1)</pre>
    size=i+1;
end
endfunction
```

endmodule

## Behavioral Verilog Blocking Versus Non-Blocking Procedural Assignments

The pound (**#**) and asterisk (**@**) time control statements delay execution of the statement following them until the specified event is evaluated as true. Blocking and non-blocking procedural assignments have time control built into their respective assignment statement. The pound (**#**) delay is ignored for synthesis.

Behavioral Verilog Blocking Procedural Assignment Syntax Example

The syntax for a blocking procedural assignment is shown in the following coding example:

```
reg a;
a = #10 (b | c);
or
if (in1) out = 1'b0;
else out = in2;
```

As the name implies, these types of assignments block the current process from continuing to execute additional statements at the same time. These should mainly be used in simulation.

Non-blocking assignments, on the other hand, evaluate the expression when the statement executes, but allow other statements in the same process to execute as well at the same time. The variable change occurs only after the specified delay.

Behavioral Verilog Non-Blocking Procedural Assignment Syntax Example

The syntax for a non-blocking procedural assignment is shown in the following coding example:

```
variable <= @(posedge_or_negedge_bit) expression;</pre>
```

Behavioral Verilog Non-Blocking Procedural Assignment Example

The following shows an example of how to use a non-blocking procedural assignment:

if (in1) out <= 1'b1; else out <= in2;</pre>

## **Behavioral Verilog Constants**

By default, constants in Verilog are assumed to be decimal integers. They can be specified explicitly in binary, octal, decimal, or hexadecimal by prefacing them with the appropriate syntax. For example, the following all represent the same value:

- 4'b1010
- 4'o12
- 4'd10
- 4'ha

## **Behavioral Verilog Macros**

Verilog provides a way to define macros as shown in the following coding example:

```
`define TESTEQ1 4'b1101
```

Later in the design code a reference to the defined macro is made as follows:

if (request == `TESTEQ1)

This is shown in the following coding example:

```
`define myzero 0
assign mysig = `myzero;
```

The Verilog `ifdef and `endif constructs determine whether or not a macro is defined. These constructs are used to define conditional compilation. If the macro called out by the `ifdef command has been defined, that code is compiled. If not, the code following the `else command is compiled. The `else is not required, but `endif must complete the conditional statement.

The `ifdef and `endif constructs are shown in the following coding example:

```
`ifdef MYVAR
module if_MYVAR_is_declared;
...
endmodule
```

www.xilinx.com



```
`else
module if_MYVAR_is_not_declared;
...
endmodule
`endif
```

The "Verilog Macros (-define)" command line option allows you to define (or redefine) Verilog macros. This allows you to easily modify the design configuration without any Hardware Description Language (HDL) source modifications, such as for IP core generation and testing flows.

## **Behavioral Verilog Include Files**

Verilog allows separating source code into more than one file. To use the code contained in another file, the current file uses the following syntax:

`include "path/file-to-be-included"

The path can be relative or absolute.

Multiple `**include** statements are allowed in a single Verilog file. This feature makes your code modular and more manageable in a team design environment where different files describe different modules of the design.

To enable the file in your `**include** statement to be recognized, identify the directory where it resides, either to ISE<sup>TM</sup> or to XST.

- Since ISE searches the ISE project directory by default, adding the file to your project directory identifies the file to ISE.
- To direct ISE to a different directory, include a path (relative or absolute) in the `include statement in your source code.
- To point XST directly to your include file directory, use "Verilog Include Directories (-vlgincdir)"
- If the include file is required for ISE to construct the design hierarchy, this file must either reside in the project directory, or be referenced by a relative or absolute path. The file *need not* be added to the project.

Be aware that conflicts can occur. For example, at the top of a Verilog file you might see the following:

```
`timescale 1 ns/1 ps
`include "modules.v"
```

If the specified file (modules.v) has been added to an ISE project directory *and* is specified with `include, conflicts may occur. In that case, XST issues an error message:

```
ERROR:Xst:1068 - fifo.v, line 2. Duplicate declarations of module'RAMB4_S8_S8'
```

## **Behavioral Verilog Comments**

Verilog supports two forms of comments as shown in Table 8-4, "Behavioral Verilog Comments." Verilog comments are similar to the comments used in a language such as C++.

Table 8-4: Behavioral Verilog Comments

Symbol	Description	Used for	Example			
11	Double forward slash	One-line comments	// Define a one-line comment as illustrated by this sentence			
/*	Slash asterisk	Multi-line comments	<pre>/* Define a multi-line comment by enclosing it as illustrated by this sentence */</pre>			

## **Behavioral Verilog Generate Statements**

A **generate** statement allows you to dynamically create Verilog code from conditional statements. This allows you to create repetitive structures or structures that are appropriate only under certain conditions.

Structures likely to be created using a **generate** statement are:

- Primitive or module instances
- Initial or always procedural blocks
- Continuous assignments
- Net and variable declarations
- Parameter redefinitions
- Task or function definitions

XST supports the following **generate** statements:

- "Behavioral Verilog Generate For Statements"
- "Behavioral Verilog Generate If... else Statements"
- "Behavioral Verilog Generate Case Statements"

## Behavioral Verilog Generate For Statements

Use a **generate for** loop to create one or more instances that can be placed inside a module. Use the **generate for** loop the same way you would a normal Verilog **for** loop, with the following limitations:

- The index for a **generate** for loop has a **genvar** variable.
- The assignments in the **for** loop control refers to the **genvar** variable.
- The contents of the **for** loop are enclosed by **begin** and **end** statements. The **begin** statement is named with a unique qualifier.

8-Bit Adder Using a Generate For Loop Behavioral Verilog Coding Example

```
generate
genvar i;
for (i=0; i<=7; i=i+1)
    begin : for_name</pre>
```



## Behavioral Verilog Generate If... else Statements

Use a **generate if... else** statement inside a **generate** block to conditionally control which objects are generated.

Generate If... else Statement Behavioral Verilog Coding Example

In the following coding example of a **generate if... else** statement, **generate** controls the type of multiplier that is instantiated.

- The contents of each branch of the **if... else** statement are enclosed by **begin** and **end** statements.
- The **begin** statement is named with a unique qualifier.

```
generate
  if (IF_WIDTH < 10)
    begin : if_name
      adder # (IF_WIDTH) u1 (a, b, sum_if);
    end
  else
    begin : else_name
      subtractor # (IF_WIDTH) u2 (a, b, sum_if);
    end
endgenerate</pre>
```

#### Behavioral Verilog Generate Case Statements

Use a **generate case** statement inside a generate block to conditionally control which objects are generated. Use a **generate case** statement when there are several conditions to be tested to determine what the generated code would be.

- Each test statement in a generate case is enclosed by begin and end statements.
- The **begin** statement is named with a unique qualifier.

Behavioral Verilog Generate Case Statement Coding Example

In the following coding example of a **generate case** statement, **generate** controls the type of adder that is instantiated:

```
generate
case (WIDTH)
1:
    begin : case1_name
    adder #(WIDTH*8) x1 (a, b, ci, sum_case, c0_case);
    end
2:
    begin : case2_name
    adder #(WIDTH*4) x2 (a, b, ci, sum_case, c0_case);
    end
    default:
    begin : d_case_name
    adder x3 (a, b, ci, sum_case, c0_case);
    end
```



endcase endgenerate





## Chapter 9

## XST Mixed Language Support

This chapter (*XST Mixed Language Support*) describes how to run an XST project that mixes Verilog and VHDL designs. This chapter includes:

- "About Mixed Language Support"
- "Mixed Language Project Files"
- "VHDL and Verilog Boundary Rules in Mixed Language Projects"
- "Port Mapping in Mixed Language Projects"
- "Generics Support in Mixed Language Projects"
- "Library Search Order (LSO) Files in Mixed Language Projects"

## About Mixed Language Support

XST supports mixed VHDL and Verilog projects.

- Mixing VHDL and Verilog is restricted to design unit (cell) instantiation only.
  - A VHDL design can instantiate a Verilog module
  - A Verilog design can instantiate a VHDL entity.
  - No other mixing between VHDL and Verilog is not supported.
- In a VHDL design, a restricted subset of VHDL types, generics, and ports is allowed on the boundary to a Verilog module.
- In a Verilog design, a restricted subset of Verilog types, parameters, and ports is allowed on the boundary to a VHDL entity or configuration.
- XST binds VHDL design units to a Verilog module during the Elaboration step.
- Component instantiation based on default binding is used for binding Verilog modules to a VHDL design unit.
- Configuration specification, direct instantiation and component configurations are not supported for a Verilog module instantiation in VHDL.
- VHDL and Verilog project files are unified.
- VHDL and Verilog libraries are logically unified.
- Specification of the work directory for compilation (xsthdpdir), previously available only for VHDL, is now available for Verilog.
- The xhdp.ini mechanism for mapping a logical library name to a physical directory name on the host file system, previously available only for VHDL, is also available for Verilog.

• Mixed language projects accept a search order used for searching unified logical libraries in design units (cells). During elaboration, XST follows this search order for picking and binding a VHDL entity or a Verilog module to the mixed language project.

## **Mixed Language Project Files**

XST uses dedicated mixed language project files to support mixed VHDL and Verilog designs. You can use this mixed language format not only for mixed projects, but also for purely VHDL or Verilog projects.

- If you run XST from Project Navigator, Project Navigator creates the project file. It is always a mixed language project file.
- If you run XST from the command line, you must create the mixed language project file yourself.

To create a mixed language project file at the command line, use the **-ifmt** command line option set to *mixed* or with its value is omitted. You can still use the VHDL and Verilog formats for existing designs. To use the VHDL format, set **-ifmt** to *vhdl*, and to use the Verilog format, set **-ifmt** to *verilog*.

The syntax for invoking a library or any external file in a mixed language project is:

language library file\_name.ext

The following example shows how to invoke libraries in a mixed language project:

```
vhdlworkmy_vhdl1.vhdverilogworkmy_vlg1.vvhdlmy_vhdl_libmy_vhdl2.vhdverilogmy_vlg_libmy_vlg2.v
```

Each line specifies a single Hardware Description Language (HDL) design file:

- The first column specifies whether the HDL file is VHDL or Verilog.
- The second column specifies the logic library where the HDL is compiled. The default logic library is **work**.
- The third column specifies the name of the HDL file.

## VHDL and Verilog Boundary Rules in Mixed Language Projects

This section discusses VHDL and Verilog Boundary Rules in Mixed Language Projects, and includes:

- "Instantiating a Verilog Module in a VHDL Design"
- "Instantiating a VHDL Design Unit in a Verilog Design"

The boundary between VHDL and Verilog is enforced at the design unit level. A VHDL design can instantiate a Verilog module. A Verilog design can instantiate a VHDL entity.

## Instantiating a Verilog Module in a VHDL Design

To instantiate a Verilog module in your VHDL design:

- 1. Declare a VHDL component with the same name (respecting case sensitivity) as the Verilog module you want to instantiate. If the Verilog module name is not all lower case, use the **case** property to preserve the case of your Verilog module.
  - a. Select Project Navigator > Process Properties > Synthesis
     Options > Case > Maintain, or
  - b. Set the **-case** command line option to **maintain** at the command line.
- 2. Instantiate your Verilog component as if you were instantiating a VHDL component.

Using a VHDL configuration declaration, you could attempt to bind this component to a particular design unit from a particular library. Such binding is not supported. Only default Verilog module binding is supported.

The only Verilog construct that can be instantiated in a VHDL design is a Verilog module. No other Verilog constructs are visible to VHDL code.

During elaboration, all components subject to default binding are regarded as design units with the same name as the corresponding component name. During binding, XST treats a component name as a VHDL design unit name and searches for it in the logical library **work**. If XST finds a VHDL design unit, XST binds it. If XST cannot find a VHDL design unit, it treats the component name as a Verilog module name, and searches for it using a case sensitive search. XST searches for the Verilog module in the user-specified list of unified logical libraries in the user-specified search order. For more information, see "Library Search Order (LSO) Files in Mixed Language Projects." XST selects the first Verilog module matching the name, and binds it.

Since libraries are unified, a Verilog cell by the same name as that of a VHDL design unit cannot co-exist in the same logical library. A newly compiled cell/unit overrides a previously compiled one.

## Instantiating a VHDL Design Unit in a Verilog Design

To instantiate a VHDL entity:

- 1. Declare a module name with the same as name as the VHDL entity (optionally followed by an architecture name) that you want to instantiate.
- 2. Perform a normal Verilog instantiation.

The only VHDL construct that can be instantiated in a Verilog design is a VHDL entity. No other VHDL constructs are visible to Verilog code. When you do this, XST uses the entity/architecture pair as the Verilog/VHDL boundary.

XST performs the binding during elaboration. During binding, XST searches for a Verilog module name using the name of the instantiated module in the user-specified list of unified logical libraries in the user-specified order. XST ignores any architecture name specified in the module instantiation. For more information, see "Library Search Order (LSO) Files in Mixed Language Projects."

If found, XST binds the name. If XST cannot find a Verilog module, it treats the name of the instantiated module as a VHDL entity, and searches for it using a case sensitive search for a VHDL entity. XST searches for the VHDL entity in the user-specified list of unified logical libraries in the user-specified order, assuming that a VHDL design unit was stored with extended identifier. For more information, see "Library Search Order (LSO) Files in Mixed



Language Projects." If found, XST binds the name. XST selects the first VHDL entity matching the name, and binds it.

XST has the following limitations when instantiating a VHDL design unit from a Verilog module:

- Use explicit port association. Specify formal and effective port names in the port map.
- All parameters are passed at instantiation, even if they are unchanged.
- The parameter override is named and not ordered. The parameter override occurs through instantiation, and not through defparams.

#### Correct Use of Parameter Override Coding Example

ff #(.init(2'b01)) u1 (.sel(sel), .din(din), .dout(dout));

Correct Use of Parameter Override Coding Example

The following example is not accepted by XST.

```
ff u1 (.sel(sel), .din(din), .dout(dout));
defparam u1.init = 2'b01;
```

## Port Mapping in Mixed Language Projects

This section discusses Port Mapping in Mixed Language Projects, and includes:

- "VHDL in Verilog Port Mapping"
- "Verilog in VHDL Port Mapping"
- "VHDL in Mixed Language Port Mapping"
- "Verilog in Mixed Language Port Mapping"

#### VHDL in Verilog Port Mapping

For VHDL entities instantiated in Verilog designs, XST supports the following port types:

- in
- out
- inout

XST does not support VHDL buffer and linkage ports.

#### Verilog in VHDL Port Mapping

For Verilog modules instantiated in VHDL designs, XST supports the following port types:

- input
- output
- inout

XST does not support connection to bi-directional pass options in Verilog.

XST does not support unnamed Verilog ports for mixed language boundaries.

Use an equivalent component declaration for connecting to a case sensitive port in a Verilog module. By default, XST assumes Verilog ports are in all lower case.

## VHDL in Mixed Language Port Mapping

XST supports the following VHDL data types for mixed language designs:

- bit
- bit\_vector
- std\_logic
- std\_ulogic
- std\_logic\_vector
- std\_ulogic\_vector

### Verilog in Mixed Language Port Mapping

XST supports the following Verilog data types for mixed language designs:

- wire
- reg

## **Generics Support in Mixed Language Projects**

XST supports the following VHDL generic types, and their Verilog equivalents for mixed language designs:

- integer
- real
- string
- boolean

## Library Search Order (LSO) Files in Mixed Language Projects

This section discusses Library Search Order (LSO) Files in Mixed Language Projects, and includes:

- "About the Library Search Order (LSO) File"
- "Specifying the Library Search Order (LSO) File in Project Navigator"
- "Specifying the Library Search Order (LSO) File in the Command Line"
- "Library Search Order (LSO) Rules"

## About the Library Search Order (LSO) File

The Library Search Order (LSO) file specifies the search order that XST uses to link the libraries used in VHDL and Verilog mixed language designs. By default, XST searches the files specified in the project file in the order in which they appear in that file. XST uses the default search order when either the DEFAULT\_SEARCH\_ORDER keyword is used in the LSO file, or the LSO file is not specified.

## Specifying the Library Search Order (LSO) File in Project Navigator

In Project Navigator, the default name for the Library Search Order (LSO) file is *project\_name.lso*. If a *project\_name.lso* file does not already exist, Project Navigator automatically creates one.

If Project Navigator detects an existing *project\_name.lso* file, this file is preserved and used as is. In Project Navigator, the name of the project is the name of the top-level block. In creating a default LSO file, Project Navigator places the DEFAULT\_SEARCH\_ORDER keyword in the first line of the file.

## Specifying the Library Search Order (LSO) File in the Command Line

Library Search Order (LSO) (-lso) specifies the Library Search Order (LSO) file when using XST from the command line. If the -lso option is omitted, XST automatically uses the default library search order without using an LSO file.

## Library Search Order (LSO) Rules

When processing a mixed language project, XST obeys the following search order rules, depending on the contents of the Library Search Order (LSO) file:

- "Library Search Order (LSO) Empty"
- "DEFAULT\_SEARCH\_ORDER Keyword Only"
- "DEFAULT\_SEARCH\_ORDER Keyword and List of Libraries"
- "List of Libraries Only"
- "DEFAULT\_SEARCH\_ORDER Keyword and Non-Existent Library Name"

#### Library Search Order (LSO) Empty

When the Library Search Order (LSO) file is empty, XST:

- Issues a warning stating that the LSO file is empty
- Searches the files specified in the project file using the default library search order
- Updates the LSO file by adding the list of libraries in the order that they appear in the project file.

#### DEFAULT\_SEARCH\_ORDER Keyword Only

When the Library Search Order (LSO) file contains only the DEFAULT\_SEARCH\_ORDER keyword, XST:

- Searches the specified library files in the order in which they appear in the project file
- Updates the LSO file by:
  - Removing the DEFAULT\_SEARCH\_ORDER keyword
  - Adding the list of libraries to the LSO file in the order in which they appear in the project file

Library Search Order (LSO) File Example One

For a project file, my\_proj.prj, with the following contents:

vhdl vhlib1 f1.vhd verilog rtfllib f1.v vhdl vhlib2 f3.vhd LSO file Created by ProjNav

and an LSO file, my\_proj.lso, created by Project Navigator, with the following contents:

DEFAULT\_SEARCH\_ORDER

XST uses the following search order.

vhlib1 rtfllib vhlib2

After processing, the contents of my\_proj.lso is:

```
vhlib1
rtfllib
vhlib2
```

#### DEFAULT\_SEARCH\_ORDER Keyword and List of Libraries

When the Library Search Order (LSO) file contains the DEFAULT\_SEARCH\_ORDER keyword, and a list of the libraries, XST:

- Searches the specified library files in the order in which they appear in the project file
- Ignores the list of library files in the LSO file
- Leaves the LSO file unchanged

Library Search Order (LSO) File Example Two

For a project file, my\_proj.prj, with the following contents:

vhdl vhlib1 fl.vhd verilog rtfllib fl.v vhdl vhlib2 f3.vhd

and an LSO file, my\_proj.lso, created with the following contents:

```
rtfllib
vhlib2
vhlib1
DEFAULT_SEARCH_ORDER
```

XST uses the following search order:

vhlib1 rtfllib vhlib2



After processing, the contents of my\_proj.lso is:

```
rtfllib
vhlib2
vhlib1
DEFAULT_SEARCH_ORDER
```

#### List of Libraries Only

When the Library Search Order (LSO) file contains a list of the libraries without the DEFAULT\_SEARCH\_ORDER keyword, XST:

- Searches the library files in the order in which they appear in the LSO file
- Leaves the LSO file unchanged

Library Search Order (LSO) File Example Three

For a project file, my\_proj.prj, with the following contents:

vhdl vhlib1 f1.vhd verilog rtfllib f1.v vhdl vhlib2 f3.vhd

and an LSO file, my\_proj.lso, created with the following contents:

rtfllib vhlib2 vhlib1

XST uses the following search order:

```
rtfllib
vhlib2
vhlib1
```

After processing, the contents of my\_proj.lso is:

rtfllib vhlib2 vhlib1

#### DEFAULT\_SEARCH\_ORDER Keyword and Non-Existent Library Name

When the Library Search Order (LSO) file contains a library name that does not exist in the project or INI file, and the LSO file does not contain the DEFAULT\_SEARCH\_ORDER keyword, XST ignores the library.

Library Search Order (LSO) File Example Four

For a project file, my\_proj.prj, with the following contents:

vhdl vhlib1 f1.vhd verilog rtfllib f1.v vhdl vhlib2 f3.vhd and an LSO file, my\_proj.lso, created with the following contents:

personal\_lib rtfllib vhlib2 vhlib1

XST uses the following search order:

rtfllib vhlib2 vhlib1

After processing, the contents of my\_proj.lso is:

rtfllib vhlib2 vhlib1





## *Chapter 10*

# XST Log Files

This chapter (*XST Log Files*) describes the XST log file. This chapter includes:

- "XST FPGA Log File Contents"
- "Reducing the Size of the XST Log File"
- "Macros in XST Log Files"
- "XST Log File Examples"

## **XST FPGA Log File Contents**

This section discusses XST FPGA log file Contents, and includes:

- "XST FPGA Log File Copyright Statement"
- "XST FPGA Log File Table of Contents"
- "XST FPGA Log File Synthesis Options Summary"
- "XST FPGA Log File HDL Compilation"
- "XST FPGA Log File Design Hierarchy Analyzer"
- "XST FPGA Log File HDL Analysis"
- "XST FPGA Log File HDL Synthesis Report"
- "XST FPGA Log File Advanced HDL Synthesis Report"
- "XST FPGA Log File Low Level Synthesis"
- "XST FPGA Log File Partition Report"
- "XST FPGA Log File Final Report"

## XST FPGA Log File Copyright Statement

The XST FPGA log file copyright statement contains:

- ISE <sup>TM</sup> release number
- Xilinx <sup>®</sup> notice of copyright.

## XST FPGA Log File Table of Contents

The XST FPGA log file table of contents lists the major sections in the log file. Use the table of contents to navigate to different log file sections. These headings are not linked. Use the Find function in your text editor.

## XST FPGA Log File Synthesis Options Summary

The XST FPGA log file Synthesis Options Summary contains information relating to:

- Source Parameters
- Target Parameters
- Source Options
- Target Options
- General Options
- Other Options

## XST FPGA Log File HDL Compilation

For information on HDL Compilation, see "XST FPGA Log File HDL Analysis."

## XST FPGA Log File Design Hierarchy Analyzer

For information on Design Hierarchy Analyzer, see "XST FPGA Log File HDL Analysis."

## XST FPGA Log File HDL Analysis

During HDL Compilation, Design Hierarchy Analyzer, and HDL Analysis, XST:

- Parses and analyzes VHDL and Verilog files
- Recognizes the design hierarchy
- Gives the names of the libraries into which they are compiled

During this step, XST may report potential mismatches between synthesis and simulation results, potential multi-sources, and other issues.

## XST FPGA Log File HDL Synthesis Report

During HDL Synthesis, XST tries to recognize as many basic macros as possible to create a technology specific implementation. This is done on a block by block basis. At the end of this step, XST issues the HDL Synthesis Report. For more information about the processing of each macro and the corresponding messages issued during synthesis, see "XST HDL Coding Techniques."

## XST FPGA Log File Advanced HDL Synthesis Report

XST performs advanced macro recognition and inference. In this step, XST:

- Recognizes, for example, dynamic shift registers
- Implements pipelined multipliers
- Codes state machines

The Advanced HDL Synthesis Report contains a summary of recognized macros in the overall design, sorted by macro type.

## XST FPGA Log File Low Level Synthesis

XST reports the potential removal of, for example, equivalent flip-flops and register replication. For more information, see "FPGA Optimization Log File."

## XST FPGA Log File Partition Report

If the design is partitioned, the XST FPGA log file Partition Report contains information detailing the design partitions.

## XST FPGA Log File Final Report

The XST FPGA log file Final Report includes:

- Final Results, including
  - RTL Top Level Output File Name (for example, stopwatch.ngr)
  - Top Level Output File Name (for example, stopwatch)
  - Output Format (for example, NGC)
  - Optimization Goal (for example, Speed)
  - Whether the Keep Hierarchy constraint is used (for example, No)
- Cell usage

Cell usage reports on, for example, the number and type of BELS, Clock Buffers, and IO Buffers.

• Device Utilization Summary

The Device Utilization Summary estimates the number of slices, and gives, for example, the number of flip-flops, IOBs, and BRAMS. The Device Utilization Summary closely approximates the report produced by MAP.

• Partition Resource Summary

The Partition Resource Summary estimates the number of slices, and gives, for example, the number of flip-flops, IOBs, and BRAMS for each partition. The Partition Resource Summary closely resembles the report produced by MAP.

• Timing Report

At the end of synthesis, XST reports the timing information for the design. The Timing Report shows the information for all four possible domains of a netlist:

- register to register
- input to register
- register to outpad
- inpad to outpad

For an example, see the Timing Report section in "XST FPGA Log File Example." For more information, see "FPGA Optimization Log File."

Encrypted Modules

If a design contains encrypted modules, XST hides the information about these modules.

## Reducing the Size of the XST Log File

This section discusses Reducing the Size of the XST log file, and includes:

- "Use Message Filtering"
- "Use Quiet Mode" .
- "Use Silent Mode"
- "Hide Specific Messages"

## Use Message Filtering

When running XST from Project Navigator, use the Message Filtering wizard to select specific messages to filter out of the log file. For more information, see Using the Message *Filters* in the ISE<sup>TM</sup> Help.

## Use Quiet Mode

Quiet Mode limits the number of messages printed to the computer screen (**stdout**). To invoke Quiet Mode, set the **-intstyle** command line option to either of the following:

ise

Formats messages for ISE

xflow

Formats messages for XFLOW

Normally, XST prints the entire log to **stdout**. In Quiet Mode, XST does *not* print the following portions of the log to **stdout**:

- Copyright Message •
- Table of Contents
- Synthesis Options Summary .
- The following portions of the Final Report
  - Final Results header for CPLD devices ٠
  - Final Results section for FPGA devices
  - A note in the Timing Report stating that the timing numbers are only a synthesis estimate.
  - **Timing Detail**
  - CPU (XST run time) ٠
  - Memory usage ٠

The following sections are still available for FPGA devices:

- Device Utilization Summary
- **Clock Information**
- **Timing Summary**

## **Use Silent Mode**

Silent Mode prevents any messages from being sent to the computer screen (**stdout**), although XST continues to generate the entire log file. To invoke Silent Mode, set the **-intstyle** command line option to **silent**.

## Hide Specific Messages

To hide specific messages at the HDL or Low Level Synthesis steps, set the XIL\_XST\_HIDEMESSAGES environment variable to one of the values shown in Table 10-1, "XIL\_XST\_HIDEMESSAGES Environment Variable Values."

Value	Meaning			
<b>none</b> (default)	Maximum verbosity. All messages are printed out.			
hdl_level	Reduce verbosity during VHDL or Verilog Analysis and HDL Basic and Advanced Synthesis.			
low_level	Reduce verbosity during Low-level Synthesis.			
hdl_and_low_levels	Reduce verbosity at all stages.			

Table 10-1:	XIL_XST_HIDEMESSAGES Environment Variable Values
-------------	--

#### Messages Hidden When Value is Set to hdl\_level and hdl\_and\_low\_levels

The following messages are hidden when the value of the XIL\_XST\_HIDEMESSAGES environment variable is set to hdl\_level and hdl\_and\_low\_levels:

• WARNING:HDLCompilers:38 - *design*.v line 5 Macro '*my\_macro*' redefined

*Note:* This message is issued by the Verilog compiler only.

- WARNING:Xst:916 *design*.vhd line 5: Delay is ignored for synthesis.
- WARNING:Xst:766 *design*.vhd line 5: Generating a Black Box for component *comp*.
- Instantiating component *comp* from Library *lib*.
- Set user-defined property "LOC = X1Y1" for instance *inst* in unit *block*.
- Set user-defined property "RLOC = X1Y1" for instance *inst* in unit *block*.
- Set user-defined property "INIT = 1" for instance *inst* in unit *block*.
- Register reg1 equivalent to reg2 has been removed.

#### Messages Hidden When Value is Set to low\_level and hdl\_and\_low\_levels

The following messages are hidden when the value of the XIL\_XST\_HIDEMESSAGES environment variable is set to **low\_level** and **hdl\_and\_low\_levels**:

- WARNING:Xst:382 Register *reg1* is equivalent to *reg2*.
- Register *reg1* equivalent to *reg2* has been removed.



- WARNING:Xst:1710 FF/Latch reg (without init value) is constant in block block.
- WARNING:Xst 1293 FF/Latch reg is constant in block block.
- WARNING:Xst:1291 FF/Latch reg is unconnected in block block.
- WARNING:Xst:1426 The value init of the FF/Latch *reg* hinders the constant cleaning in the block *block*. You could achieve better results by setting this init to *value*.

## Macros in XST Log Files

XST log files contain detailed information about the set of macros and associated signals inferred by XST from the VHDL or Verilog source on a block by block basis.

Macro inference is done in two steps:

1. HDL Synthesis

XST recognizes as many simple macro blocks as possible, such as adders, subtractors, and registers.

2. Advanced HDL Synthesis

XST does additional macro processing by improving the macros (for example, pipelining of multipliers) recognized at the HDL synthesis step, or by creating the new, more complex ones, such as dynamic shift registers. The Macro Recognition report at the Advanced HDL Synthesis step is formatted the same as the corresponding report at the HDL Synthesis step.

XST gives overall statistics of recognized macros twice:

- After the HDL Synthesis step
- After the Advanced HDL Synthesis step

XST no longer lists statistics of preserved macros in the final report.

## XST Log File Examples

This section gives the following XST log file examples:

- "Recognized Macros XST Log File Example"
- "Additional Macro Processing XST Log File Example"
- "XST FPGA Log File Example"
- "XST CPLD Log File Example"

#### Recognized Macros XST Log File Example

The following log file example shows the set of recognized macros on a block by block basis, as well as the overall macro statistics after this step.

\* HDL Synthesis \*
....
Synthesizing Unit <decode>.
 Related source file is "decode.vhd".
 Found 16x10-bit ROM for signal <one\_hot>.
 Summary:

```
inferred 1 ROM(s).
Unit <decode> synthesized.
Synthesizing Unit <statmach>.
   Related source file is "statmach.vhd".
   Found finite state machine <FSM_0> for signal <current_state>.
   _____
                   6
    States
    Transitions | 11
    Inputs
                  | 1
    Outputs
                 | 2
    Clock
                 CLK (rising_edge)

    Reset type
    | RESET (posit:

    Reset State
    clear

                 RESET (positive)
   Power Up State
                 | clear
   Encoding
                  automatic
   Implementation
                  LUT
   _____
   Summary:
     inferred 1 Finite State Machine(s).
Unit <statmach> synthesized.
. . .
_____
HDL Synthesis Report
Macro Statistics
# ROMs
                                         : 3
16x10-bit ROM
                                         • 1
                                         : 2
16x7-bit ROM
# Counters
                                         : 2
4-bit up counter
                                         : 2
______
. . .
```

#### Additional Macro Processing XST Log File Example

The following XST FPGA log file example shows the additional macro processing done during the Advanced HDL Synthesis step and the overall macro statistics after this step.

```
* Advanced HDL Synthesis *
Advanced HDL Synthesis *
Analyzing FSM <FSM_0> for best encoding.
Optimizing FSM <MACHINE/current_state/FSM_0> on signal
<current_state[1:3]> with gray encoding.
.....
State | Encoding
.....
clear | 000
zero | 001
start | 011
counting | 010
stop | 110
stopped | 111
```

www.xilinx.com



\_\_\_\_\_ Advanced HDL Synthesis Report Macro Statistics # FSMs : 1 # ROMs : 3 16x10-bit ROM : 1 16x7-bit ROM : 2 # Counters : 2 4-bit up counter : 2 # Registers : 3 Flip-Flops/Latches : 3 \_\_\_\_\_ . . .

#### XST FPGA Log File Example

The following is an example of an XST log file for FPGA synthesis.

```
Release 10.1 - xst K.31 (nt64)
Copyright (c) 1995-2008 Xilinx, Inc. All rights reserved.
TABLE OF CONTENTS
 1) Synthesis Options Summary
 2) HDL Compilation
 3) Design Hierarchy Analysis
 4) HDL Analysis
 5) HDL Synthesis
    5.1) HDL Synthesis Report
 6) Advanced HDL Synthesis
    6.1) Advanced HDL Synthesis Report
 7) Low Level Synthesis
 8) Partition Report
 9) Final Report
    9.1) Device utilization summary
    9.2) Partition Resource Summary
    9.3) TIMING REPORT
_____
*
                  Synthesis Options Summary
_____
---- Source Parameters
Input File Name
                             : "stopwatch.prj"
Input Format
                             : mixed
Ignore Synthesis Constraint File : NO
---- Target Parameters
Output File Name
                              : "stopwatch"
Output Format
                              : NGC
Target Device
                              : xc4vlx15-12-sf363
---- Source Options
Top Module Name
                             : stopwatch
Automatic FSM Extraction
                            : YES
FSM Encoding Algorithm
                             : Auto
Safe Implementation
                             : No
```

FSM Style RAM Extraction	: lut : Yes
RAM Style	: Auto
ROM Extraction	: Yes : Auto
Mux Style	
Decoder Extraction	: YES
Priority Encoder Extraction	: YES
Shift Register Extraction	: YES
Logical Shifter Extraction	: YES
XOR Collapsing	: YES
ROM Style	: Auto
Mux Extraction	: YES
Resource Sharing	: YES
Asynchronous To Synchronous	: NO
Use DSP Block	: auto
Automatic Register Balancing	: No
Target Options	
Add IO Buffers	: YES
Global Maximum Fanout	: 500
Add Generic Clock Buffer(BUFG)	: 32
Number of Regional Clock Buffers	: 16
Register Duplication	: YES
Slice Packing	: YES
Optimize Instantiated Primitives	: NO
Use Clock Enable	: Auto
Use Synchronous Set	: Auto
Use Synchronous Reset	: Auto
Pack IO Registers into IOBs	: auto
Equivalent register Removal	: YES
General Options	
Optimization Goal	: Speed
Optimization Effort	: 1
Power Reduction	: NO
Library Search Order	: stopwatch.lso
Keep Hierarchy	: NO
Netlist Hierarchy	: as_optimized
RTL Output	: Yes
Global Optimization	: AllClockNets
Read Cores	: YES
Write Timing Constraints	: NO
Cross Clock Analysis	: NO
Hierarchy Separator	: /
Bus Delimiter	· / : <>
Case Specifier	. <> : maintain
Slice Utilization Ratio	: 100
BRAM Utilization Ratio	: 100
DSP48 Utilization Ratio	: 100
Verilog 2001	: YES
Auto BRAM Packing	: YES : NO
Slice Utilization Ratio Delta	: 5
Siice Uliization Katio Delta	: 5

www.xilinx.com



Compiling verilog file "smallcntr.v" in library work Compiling verilog file "statmach.v" in library work Module <smallcntr> compiled Compiling verilog file "hex2led.v" in library work Module <statmach> compiled Compiling verilog file "decode.v" in library work Module <hex2led> compiled Compiling verilog file "cnt60.v" in library work Module <decode> compiled Compiling verilog file "stopwatch.v" in library work Module <cnt60> compiled Module <stopwatch> compiled No errors in compilation Analysis of file <"stopwatch.prj"> succeeded. Compiling vhdl file "C:/xst/watchver/tenths.vhd" in Library work. Entity <tenths> compiled. Entity <tenths> (Architecture <tenths\_a>) compiled. Compiling vhdl file "C:/xst/watchver/dcm1.vhd" in Library work. Entity <dcm1> compiled. Entity <dcml> (Architecture <BEHAVIORAL>) compiled. \_\_\_\_\_ Design Hierarchy Analysis \_\_\_\_\_ Analyzing hierarchy for module <stopwatch> in library <work>. Analyzing hierarchy for entity <dcml> in library <work> (architecture <BEHAVIORAL>). Analyzing hierarchy for module <statmach> in library <work> with parameters. clear = "000001" counting = "001000" start = "000100"stop = "010000"stopped = "100000" zero = "000010" Analyzing hierarchy for module <decode> in library <work>. Analyzing hierarchy for module <cnt60> in library <work>. Analyzing hierarchy for module <hex2led> in library <work>. Analyzing hierarchy for module <smallcntr> in library <work>. \_\_\_\_\_ HDL Analysis \_\_\_\_\_ Analyzing top module <stopwatch>. Module <stopwatch> is correct for synthesis. Analyzing Entity <dcml> in library <work> (Architecture <BEHAVIORAL>). Set user-defined property "CAPACITANCE = DONT\_CARE" for instance <CLKIN\_IBUFG\_INST> in unit <dcm1>. Set user-defined property "IBUF\_DELAY\_VALUE = 0" for instance <CLKIN\_IBUFG\_INST> in unit < dcm1 >. Set user-defined property "IOSTANDARD = DEFAULT" for instance <CLKIN\_IBUFG\_INST> in unit <dcm1>.

in unit <dcm1>. Set user-defined property "CLKFX\_DIVIDE = 1" for instance <DCM\_INST> in unit <dcml>. Set user-defined property "CLKFX\_MULTIPLY = 4" for instance <DCM\_INST> in unit <dcml>. Set user-defined property "CLKIN\_DIVIDE\_BY\_2 = FALSE" for instance <DCM\_INST> in unit <dcm1>. Set user-defined property "CLKIN\_PERIOD = 20.00000000000000" for instance <DCM\_INST> in unit <dcm1>. Set user-defined property "CLKOUT\_PHASE\_SHIFT = NONE" for instance <DCM\_INST> in unit  $< d_{Cm1} > .$ Set user-defined property "CLK\_FEEDBACK = 1X" for instance <DCM\_INST> in unit <dcml>. Set user-defined property "DESKEW\_ADJUST = SYSTEM\_SYNCHRONOUS" for instance <DCM\_INST> in unit <dcm1>. Set user-defined property "DFS\_FREQUENCY\_MODE = LOW" for instance <DCM\_INST> in unit < dcm1 >. Set user-defined property "DLL FREQUENCY MODE = LOW" for instance <DCM INST> in unit < dcm1 >. Set user-defined property "DSS\_MODE = NONE" for instance <DCM\_INST> in unit <dcml>. Set user-defined property "DUTY\_CYCLE\_CORRECTION = TRUE" for instance <DCM\_INST> in unit <dcm1>. Set user-defined property "FACTORY\_JF = C080" for instance <DCM\_INST> in unit <dcml>. Set user-defined property "PHASE\_SHIFT = 0" for instance <DCM\_INST> in unit <dcml>. Set user-defined property "SIM\_MODE = SAFE" for instance <DCM\_INST> in unit <dcml>. Set user-defined property "STARTUP\_WAIT = TRUE" for instance <DCM\_INST> in unit <dcml>. Entity <dcml> analyzed. Unit <dcml> generated. Analyzing module <statmach> in library <work>. clear = 6'b000001counting = 6'b001000start = 6'b000100stop = 6'b010000stopped = 6'b100000zero = 6'b000010Module <statmach> is correct for synthesis. Analyzing module <decode> in library <work>. Module <decode> is correct for synthesis. Analyzing module <cnt60> in library <work>. Module <cnt60> is correct for synthesis. Analyzing module <smallcntr> in library <work>. Module <smallcntr> is correct for synthesis. Analyzing module <hex2led> in library <work>. Module <hex2led> is correct for synthesis. \_\_\_\_\_ \* HDL Synthesis \_\_\_\_\_ Performing bidirectional port resolution... Synthesizing Unit <statmach>. Related source file is "statmach.v". Found finite state machine <FSM\_0> for signal <current\_state>. \_\_\_\_\_ States 6

Set user-defined property "CLKDV\_DIVIDE = 2.00000000000000" for instance <DCM\_INST>

XILINX®

www.xilinx.com



```
Transitions
                      | 15
     Inputs
                      2
    Outputs
                      2
                     | CLK (rising_edge)
    Clock
    Reset
                      | RESET (positive)
    Reset type
                     asynchronous
                      000001
    Reset State
    Encoding
                      automatic
                     LUT
    Implementation
   _____
   Found 1-bit register for signal <CLKEN>.
   Found 1-bit register for signal <RST>.
   Summary:
 inferred 1 Finite State Machine(s).
 inferred 2 D-type flip-flop(s).
Unit <statmach> synthesized.
Synthesizing Unit <decode>.
   Related source file is "decode.v".
   Found 16x10-bit ROM for signal <ONE_HOT>.
   Summary:
 inferred 1 ROM(s).
Unit <decode> synthesized.
Synthesizing Unit <hex2led>.
   Related source file is "hex2led.v".
   Found 16x7-bit ROM for signal <LED>.
   Summary:
 inferred 1 ROM(s).
Unit <hex2led> synthesized.
Synthesizing Unit <smallcntr>.
   Related source file is "smallcntr.v".
   Found 4-bit up counter for signal <QOUT>.
   Summary:
 inferred 1 Counter(s).
Unit <smallcntr> synthesized.
Synthesizing Unit <dcm1>.
   Related source file is "C:/xst/watchver/dcm1.vhd".
Unit <dcml> synthesized.
Synthesizing Unit <cnt60>.
   Related source file is "cnt60.v".
Unit <cnt60> synthesized.
Synthesizing Unit <stopwatch>.
   Related source file is "stopwatch.v".
Unit <stopwatch> synthesized.
_____
HDL Synthesis Report
```



Macro Statistics # ROMs : 3 16x10-bit ROM : 1 16x7-bit ROM : 2 # Counters : 2 4-bit up counter : 2 # Registers : 2 1-bit register : 2 \_\_\_\_\_ \_\_\_\_\_ \* Advanced HDL Synthesis \_\_\_\_\_ Analyzing FSM <FSM\_0> for best encoding. Optimizing FSM <MACHINE/current\_state/FSM> on signal <current\_state[1:3]> with sequential encoding. \_\_\_\_\_ State | Encoding \_\_\_\_\_ 000001 | 000 000010 | 001 000100 | 010 001000 | 011 010000 | 100 100000 | 101 \_\_\_\_\_ Loading device for application Rf\_Device from file '4vlx15.nph' in environment C:\xilinx. Executing edif2ngd -noa "tenths.edn" "tenths.ngo" Release 10.1 - edif2ngd K.31 (nt64) Copyright (c) 1995-2008 Xilinx, Inc. All rights reserved. INFO:NgdBuild - Release 10.1 edif2ngd K.31 (nt64) INFO:NgdBuild - Copyright (c) 1995-2008 Xilinx, Inc. All rights reserved. Writing module to "tenths.ngo"... Reading core <tenths\_c\_counter\_binary\_v8\_0\_xst\_1.ngc>. Loading core <tenths\_c\_counter\_binary\_v8\_0\_xst\_1> for timing and area information for instance <BU2>. Loading core <tenths> for timing and area information for instance <xcounter>. \_\_\_\_\_ Advanced HDL Synthesis Report Macro Statistics # ROMs : 3 16x10-bit ROM : 1 16x7-bit ROM : 2 # Counters : 2 4-bit up counter : 2 # Registers : 5 Flip-Flops : 5 \_\_\_\_\_ \_\_\_\_\_ \* Low Level Synthesis \_\_\_\_\_

www.xilinx.com



Optimizing unit <stopwatch> ... Mapping all equations... Building and optimizing final netlist ... Found area constraint ratio of 100 (+ 5) on block stopwatch, actual ratio is 0. Number of LUT replicated for flop-pair packing : 0 Final Macro Processing ... \_\_\_\_\_ Final Register Report Macro Statistics # Registers : 13 Flip-Flops : 13 \_\_\_\_\_ \_\_\_\_\_ \* Partition Report \* \_\_\_\_\_ Partition Implementation Status \_\_\_\_\_ No Partitions were found in this design. \_\_\_\_\_ \_\_\_\_\_ \* Final Report \* \_\_\_\_\_ Final Results RTL Top Level Output File Name : stopwatch.ngr Top Level Output File Name : stopwatch : NGC Output Format Optimization Goal : Speed Keep Hierarchy : NO Design Statistics # IOs : 27 Cell Usage : # BELS : 70 # GND : 2 # INV : 1 # LUT1 : 3 # LUT2 : 1 # LUT2\_L : 1 # LUT3 : 8 # LUT3\_D : 1 # LUT3\_L : 1 # LUT4 : 37 # LUT4\_D : 1 LUT4\_L # : 4 # MUXCY : 3 # MUXF5 : 2 # VCC : 1 : 4 # XORCY



<pre># FDC # FDCE # FDCE # Clock Buffers # BUFG # IO Buffers # IBUFG # IBUFG # OBUF # OBUF # DCM_ADVs</pre>	: 17 : 13 : 4 : 1 : 27 : 2 : 1 : 24 : 1 : 1								
Device utilization summary:									
Selected Device : 4vlx15sf363-12									
Number of Slices: Number of Slice Flip Flops: Number of 4 input LUTs: Number of IOs: Number of bonded IOBs: Number of GCLKs: Number of DCM_ADVs:	1 58 2 2	ou ou ou ou ou	t of t of t of t of	6144 12288 12288 240 32 4	09 09 119 39	5 5 5			
No Partitions were found in this o	-								
TIMING REPORT NOTE: THESE TIMING NUMBERS ARE ONLY A SYNTHESIS ESTIMATE. FOR ACCURATE TIMING INFORMATION PLEASE REFER TO THE TRACE REPORT GENERATED AFTER PLACE-and-ROUTE.									
Clock Information:									
Clock Signal	Clock buffer(FF name)				Loa	ad			
CLK	Inst_dcm1/DCM_INST:CLK0		17 	+   +					
Asynchronous Control Signals Information:									
Control Signal	Buffer(FF name)					+   Load			
MACHINE/RST(MACHINE/RST:Q) RESET sixty/msbclr(sixty/msbclr_f5:0)	<pre>+ NONE(sixty/lsbcount/QOUT   IBUF   NONE(sixty/msbcount/QOUT +</pre>					5			



Timing Summary: \_\_\_\_\_ Speed Grade: -12 Minimum period: 2.282ns (Maximum Frequency: 438.212MHz) Minimum input arrival time before clock: 1.655ns Maximum output required time after clock: 4.617ns Maximum combinational path delay: No path found Timing Detail: \_\_\_\_\_ All values displayed in nanoseconds (ns) Timing constraint: Default period analysis for Clock 'CLK' Clock period: 2.282ns (frequency: 438.212MHz) Total number of paths / destination ports: 134 / 21 \_\_\_\_\_ Delay: 2.282ns (Levels of Logic = 4) xcounter/BU2/U0/q\_i\_1 (FF) Source: Destination: sixty/msbcount/QOUT\_1 (FF) Source Clock: CLK rising Destination Clock: CLK rising Data Path: xcounter/BU2/U0/q\_i\_1 to sixty/msbcount/QOUT\_1 Gate Net Cell:in->out fanout Delay Delay Logical Name (Net Name) \_\_\_\_\_ 12 0.272 0.672 U0/q\_i\_1 (q(1)) FDCE:C->Q 11 0.147 0.492 U0/thresh0\_i\_cmp\_eq00001 (thresh0) LUT4:I0->0 end scope: 'BU2' end scope: 'xcounter' 

 LUT4\_D:I3->0
 1
 0.147
 0.388
 sixty/msbce (sixty/msbce)

 LUT3:I2->0
 1
 0.147
 0.000
 sixty/msbcount/QOUT\_1\_rstpot

 (sixty/msbcount/QOUT\_1\_rstpot) FDC:D 0.017 sixty/msbcount/QOUT\_1 \_\_\_\_\_ 2.282ns (0.730ns logic, 1.552ns route) Total (32.0% logic, 68.0% route) \_\_\_\_\_ Timing constraint: Default OFFSET IN BEFORE for Clock 'CLK' Total number of paths / destination ports: 4 / 3 \_\_\_\_\_ Offset: 1.655ns (Levels of Logic = 3) Source: STRTSTOP (PAD) Destination: MACHINE/current\_state\_FSM\_FFd3 (FF) Destination Clock: CLK rising Data Path: STRTSTOP to MACHINE/current\_state\_FSM\_FFd3 Gate Net Cell:in->out fanout Delay Delay Logical Name (Net Name) \_\_\_\_\_ 4 0.754 0.446 STRTSTOP\_IBUF (STRTSTOP\_IBUF) IBUF:I->O 1 0.147 0.000 MACHINE/current\_state\_FSM\_FFd3-In\_F (N48) LUT4:I2->0 MUXF5:I0->0 1 0.291 0.000 MACHINE/current\_state\_FSM\_FFd3-In (MACHINE/current\_state\_FSM\_FFd3-In) FDC:D 0.017 MACHINE/current\_state\_FSM\_FFd3

\_\_\_\_\_ Total 1.655ns (1.209ns logic, 0.446ns route) (73.0% logic, 27.0% route) \_\_\_\_\_ Timing constraint: Default OFFSET OUT AFTER for Clock 'CLK' Total number of paths / destination ports: 96 / 24 \_\_\_\_\_ Offset: 4.617ns (Levels of Logic = 2) Source: sixty/lsbcount/QOUT\_1 (FF) ONESOUT<6> (PAD) Destination: CLK rising Source Clock: Data Path: sixty/lsbcount/QOUT\_1 to ONESOUT<6> Gate Net Cell:in->out fanout Delay Delay Logical Name (Net Name) \_\_\_\_\_ 13 0.272 0.677 sixty/lsbcount/QOUT\_1 (sixty/lsbcount/QOUT\_1)  $FDC:C \rightarrow O$ 1 0.147 0.266 lsbled/Mrom\_LED21 (lsbled/Mrom\_LED2) LUT4:I0->0 3.255 OBUF:I->O ONESOUT\_2\_OBUF (ONESOUT<2>) \_\_\_\_\_ Total 4.617ns (3.674ns logic, 0.943ns route) (79.6% logic, 20.4% route) \_\_\_\_\_ Total REAL time to Xst completion: 20.00 secs Total CPU time to Xst completion: 19.53 secs --> Total memory usage is 333688 kilobytes Number of errors : 0 ( 0 filtered)

Number	of	warnings	:	0	(	0	filtered)
Number	of	infos	:	1	(	0	filtered)

#### XST CPLD Log File Example

#### The following is an example of an XST log file for CPLD synthesis.

Release 10.1 - xst K.31 (nt64) Copyright (c) 1995-2008 Xilinx, Inc. All rights reserved.

#### TABLE OF CONTENTS

- 1) Synthesis Options Summary
- 2) HDL Compilation
- 3) Design Hierarchy Analysis
- 4) HDL Analysis
- 5) HDL Synthesis
  - 5.1) HDL Synthesis Report
- 6) Advanced HDL Synthesis
  - 6.1) Advanced HDL Synthesis Report
- 7) Low Level Synthesis
- 8) Partition Report

www.xilinx.com



9) Final Report

\* Synthesis Options Summary \* ---- Source Parameters : "stopwatch.prj" Input File Name Input Format : mixed Ignore Synthesis Constraint File : NO ---- Target Parameters Output File Name : "stopwatch" Output Format : NGC Target Device : CoolRunner2 CPLDs ---- Source Options Top Module Name : stopwatch Automatic FSM Extraction : YES FSM Encoding Algorithm : Auto Safe Implementation : No Mux Extraction : YES Resource Sharing : YES ---- Target Options Add IO Buffers : YES MACRO Preserve : YES XOR Preserve : YES Equivalent register Removal : YES ---- General Options Optimization Goal : Speed Optimization Effort : 1 Library Search Order : stopwatch.lso Keep Hierarchy : YES Netlist Hierarchy : as\_optimized RTL Output : Yes Hierarchy Separator : / Bus Delimiter : <> Case Specifier : maintain Verilog 2001 : YES ---- Other Options Clock Enable : YES wysiwyg : NO \_\_\_\_\_ \_\_\_\_\_ \* HDL Compilation \_\_\_\_\_ Compiling verilog file "smallcntr.v" in library work Compiling verilog file "tenths.v" in library work Module <smallcntr> compiled Compiling verilog file "statmach.v" in library work Module <tenths> compiled Compiling verilog file "hex2led.v" in library work Module <statmach> compiled Compiling verilog file "decode.v" in library work



Module <hex2led> compiled Compiling verilog file "cnt60.v" in library work Module <decode> compiled Compiling verilog file "stopwatch.v" in library work Module <cnt60> compiled Module <stopwatch> compiled No errors in compilation Analysis of file <"stopwatch.prj"> succeeded. \_\_\_\_\_ \* Design Hierarchy Analysis \_\_\_\_\_ Analyzing hierarchy for module <stopwatch> in library <work>. Analyzing hierarchy for module <statmach> in library <work> with parameters. clear = "000001" counting = "001000" start = "000100"stop = "010000" stopped = "100000" zero = "000010" Analyzing hierarchy for module <tenths> in library <work>. Analyzing hierarchy for module <decode> in library <work>. Analyzing hierarchy for module <cnt60> in library <work>. Analyzing hierarchy for module <hex2led> in library <work>. Analyzing hierarchy for module <smallcntr> in library <work>. \_\_\_\_\_ HDL Analysis \_\_\_\_\_ Analyzing top module <stopwatch>. Module <stopwatch> is correct for synthesis. Analyzing module <statmach> in library <work>. clear = 6'b000001counting = 6'b001000start = 6'b000100stop = 6'b010000stopped = 6'b100000zero = 6'b000010Module <statmach> is correct for synthesis. Analyzing module <tenths> in library <work>. Module <tenths> is correct for synthesis. Analyzing module <decode> in library <work>. Module <decode> is correct for synthesis. Analyzing module <cnt60> in library <work>. Module <cnt60> is correct for synthesis. Analyzing module <smallcntr> in library <work>.



Module <smallcntr> is correct for synthesis. Analyzing module <hex2led> in library <work>. Module <hex2led> is correct for synthesis. \_\_\_\_\_ \* HDL Synthesis \_\_\_\_\_ Performing bidirectional port resolution... Synthesizing Unit <statmach>. Related source file is "statmach.v". Found finite state machine <FSM\_0> for signal <current\_state>. \_\_\_\_\_ States 6 Transitions | 15 2 Inputs Outputs 2 | CLK (rising\_edge) | RESET (positive) Clock Reset asynchronous Reset type | 000001 Reset State Encoding automatic Implementation automatic \_\_\_\_\_ Found 1-bit register for signal <CLKEN>. Found 1-bit register for signal <RST>. Summary: inferred 1 Finite State Machine(s). inferred 2 D-type flip-flop(s). Unit <statmach> synthesized. Synthesizing Unit <tenths>. Related source file is "tenths.v". Found 4-bit up counter for signal <Q>. Summary: inferred 1 Counter(s). Unit <tenths> synthesized. Synthesizing Unit <decode>. Related source file is "decode.v". Found 16x10-bit ROM for signal <ONE\_HOT>. Summary: inferred 1 ROM(s). Unit <decode> synthesized. Synthesizing Unit <hex2led>. Related source file is "hex2led.v". Found 16x7-bit ROM for signal <LED>. Summary: inferred 1 ROM(s).

Unit <hex2led> synthesized.

# 

```
Synthesizing Unit <smallcntr>.
  Related source file is "smallcntr.v".
  Found 4-bit up counter for signal <QOUT>.
  Summary:
 inferred 1 Counter(s).
Unit <smallcntr> synthesized.
Synthesizing Unit <cnt60>.
  Related source file is "cnt60.v".
Unit <cnt60> synthesized.
Synthesizing Unit <stopwatch>.
  Related source file is "stopwatch.v".
  Found 1-bit register for signal <strtstopinv>.
  Summary:
 inferred
        1 D-type flip-flop(s).
Unit <stopwatch> synthesized.
_____
HDL Synthesis Report
Macro Statistics
# ROMs
                                        : 3
16x10-bit ROM
                                        : 1
16x7-bit ROM
                                        : 2
# Counters
                                        : 3
4-bit up counter
                                        : 3
# Registers
                                        : 3
1-bit register
                                        : 3
_____
_____
*
                 Advanced HDL Synthesis
                                                     *
_____
Analyzing FSM <FSM_0> for best encoding.
Optimizing FSM <MACHINE/current_state/FSM> on signal <current_state[1:3]> with sequential
encoding.
_____
State | Encoding
_____
000001 | 000
000010 | 001
000100 | 010
001000 | 011
010000 | 100
100000 | 101
_____
_____
Advanced HDL Synthesis Report
Macro Statistics
# ROMs
                                        : 3
16x10-bit ROM
                                        : 1
```

www.xilinx.com



16x7-bit ROM : 2 # Counters : 3 4-bit up counter : 3 # Registers : 6 Flip-Flops : 6 \_\_\_\_\_ \_\_\_\_\_ \* Low Level Synthesis \* Optimizing unit <stopwatch> ... Optimizing unit <statmach> ... Optimizing unit <decode> ... Optimizing unit <hex2led> ... Optimizing unit <tenths> ... Optimizing unit <smallcntr> ... Optimizing unit <cnt60> ... \_\_\_\_\_ \* Partition Report Partition Implementation Status \_\_\_\_\_ No Partitions were found in this design. -----\_\_\_\_\_ \* Final Report \* \_\_\_\_\_ Final Results RTL Top Level Output File Name : stopwatch.ngr Top Level Output File Name : stopwatch Output Format : NGC Optimization Goal : Speed Keep Hierarchy : YES Target Technology : CoolRunner2 CPLDs Macro Preserve : YES XOR Preserve : YES Clock Enable : YES wysiwyg : NO Design Statistics # IOs : 28 Cell Usage : # BELS : 413 # AND2 : 120 AND3 # : 10

#	AND4	:	6
#	INV	:	174
#	OR2	:	93
#	OR3	:	1
#	XOR2	:	9
#	FlipFlops/Latches	:	18
#	FD	:	1
#	FDC	:	5
#	FDCE	:	12
#	IO Buffers	:	28
#	IBUF	:	4
#	OBUF	:	24
=		=======================================	

Total REAL time to Xst completion: 7.00 secs Total CPU time to Xst completion: 6.83 secs

-->

Total memory usage is 196636 kilobytes

Number of errors : 0 ( 0 filtered) Number of warnings : 0 ( 0 filtered) Number of infos : 0 ( 0 filtered)





# Chapter 11

# **XST Naming Conventions**

This chapter (*XST Naming Conventions*) describes XST Naming Conventions. This chapter includes:

- "XST Net Naming Conventions"
- "XST Instance Naming Conventions"
- "XST Name Generation Control"

## XST Net Naming Conventions

This section discusses XST Net Naming Conventions. These rules are listed in order of naming priority:

- 1. Maintain external pin names.
- 2. Keep hierarchy in signal names, using forward slashes (/) or underscores (\_) as hierarchy designators.
- 3. Maintain output signal names of registers, including state bits. Use the hierarchical name from the level where the register was inferred.
- 4. Ensure that output signals of clock buffers **get** \_*clockbuffertype* (such as \_**BUFGP** or \_**IBUFG**) follow the clock signal name.
- 5. Maintain input nets to registers and tristates names.
- 6. Maintain names of signals connected to primitives and black boxes.
- 7. Name output net names of IBUFs using the form **net\_name\_IBUF**. For example, for an IBUF with an output net name of DIN, the output IBUF net name is DIN\_IBUF.
- 8. Name input net names to OBUFs using the form *net\_name\_*OBUF. For example, for an OBUF with an input net name of DOUT, the input OBUF net name is DOUT\_OBUF.
- 9. Base names for internal (combinatorial) nets on user HDL signal names where possible.

# **XST Instance Naming Conventions**

This section discusses XST Instance Naming Conventions. These rules are listed in order of naming priority:

1. Keep hierarchy in instance names, using forward slashes (/) or underscores (\_) as hierarchy designators.

When instance names are generated from VHDL or Verilog generate statements, labels from generate statements are used in composition of instance names.



For example, for the following VHDL generate statement:

```
i1_loop: for i in 1 to 10 generate
inst_lut: LUT2 generic map (INIT => "00")
```

XST generates the following instance names for LUT2:

i1\_loop[1].inst\_lut i1\_loop[2].inst\_lut i1\_loop[9].inst\_lut ... i1\_loop[10].inst\_lut

- 2. Name register instances, including state bits, for the output signal.
- 3. Name clock buffer instances \_*clockbuffertype* (such as \_**BUFGP** or \_**IBUFG**) after the output signal.
- 4. Maintain instantiation instance names of black boxes.
- 5. Maintain instantiation instance names of library primitives.
- 6. Name input and output buffers using the form **\_IBUF** or **\_OBUF** after the pad name.
- 7. Name Output instance names of IBUFs using the form *instance\_name\_IBUF*.
- 8. Name input instance names to OBUFs using the form *instance\_name\_OBUF*.

Xilinx highly recommends these instance naming conventions. To use instance naming conventions from previous releases of ISE<sup>TM</sup>, insert the following command line option in the XST command line:

-old\_instance\_names 1

# **XST Name Generation Control**

Use the following properties to control aspects of the manner in which names are written. Apply these properties using **Project Navigator > Synthesis Properties**, or the appropriate command line options. For more information, see "XST Design Constraints."

- "Hierarchy Separator (–hierarchy\_separator)"
- "Bus Delimiter (–bus\_delimiter)"
- "Case (-case)"
- "Duplication Suffix (-duplication\_suffix)"



# Chapter 12

# **XST Command Line Mode**

This chapter (*XST Command Line Mode*) describes how to run XST using the command line, including the XST run and set commands and their options. This chapter includes:

- "Running XST in Command Line Mode"
- "XST File Types in Command Line Mode"
- "Temporary Files in Command Line Mode"
- "Names With Spaces in Command Line Mode"
- "Launching XST in Command Line Mode"
- "Setting Up an XST Script"
- "Synthesizing VHDL Designs Using Command Line Mode"
- "Synthesizing Verilog Designs Using Command Line Mode"
- "Synthesizing Mixed Designs Using Command Line Mode"

# **Running XST in Command Line Mode**

To run XST in command line mode:

- On a workstation, run **xst**
- On a PC, run **xst.exe**

# **XST File Types in Command Line Mode**

XST generates the following files types in command line mode:

• Design output file, NGC (.ngc)

This file is generated in the current output directory (see the **-ofn** option). If run in incremental synthesis mode, XST generates multiple NGC files.

- RTL netlist for RTL and Technology Viewers (.ngr)
- Synthesis log file (.srp)
- Temporary files

# **Temporary Files in Command Line Mode**

Temporary files are generated in the XST temp directory in command line mode. By default, the XST temp directory is:

• Workstations

/tmp

• Windows

The directory specified by either the TEMP or TMP environment variable

Use **set –tmpdir** *<directory>* to change the XST temp directory.

VHDL or Verilog compilation files are generated in the temp directory. The default temp directory is the xst subdirectory of the current directory.

Xilinx recommends that you clean the XST temp directory regularly. The temp directory contains the files resulting from the compilation of all VHDL and Verilog files during all XST sessions. Eventually, the number of files stored in the temp directory may severely impact CPU performance. XST does not automatically clean the temp directory directory.

# Names With Spaces in Command Line Mode

XST supports file and directory names with spaces in command line mode. Enclose file or directory names containing spaces in double quotes (""):

"C:\my project"

The command line syntax for options supporting multiple directories (**-sd**, **-vlgincdir**) has changed. Enclose multiple directories in braces (**{}**):

-vlgincdir {"C:\my project" C:\temp}

In previous releases, multiple directories were included in double quotes ("..."). XST still supports this convention, provided directory names do not contain spaces. Xilinx<sup>®</sup> recommends that you change existing scripts to the new syntax.

# Launching XST in Command Line Mode

This section discusses Launching XST in command line mode, and includes:

- "Launching XST in Command Line Mode Using the XST Shell"
- "Launching XST in Command Line Mode Using a Script File"

#### Launching XST in Command Line Mode Using the XST Shell

Type **xst** to enter directly into an XST shell. Enter your commands and execute them. To run synthesis, specify a complete command with all required options. XST does not accept a mode where you can first enter **set** *option\_1*, then **set** *option\_2*, and then enter **run**.

Since all options are set at the same time, Xilinx recommends that you use a script file.

### Launching XST in Command Line Mode Using a Script File

Store your commands in a separate script file and run them all at once. To execute your script file, run the following workstation or PC command:

xst -ifn in\_file\_name -ofn out\_file\_name -intstyle {silent|ise|xflow}

The **-ofn** option is not mandatory. If you omit it, XST automatically generates a log file with the file extension .srp, and all messages display on the screen. Use the following to limit the number of messages printed to the screen:

- The -intstyle silent option
- The XIL\_XST\_HIDEMESSAGES environment variable
- The message filter feature in Project Navigator

For more information, see "Reducing the Size of the XST Log File."

For example, assume that the following text is contained in a file foo.scr:

```
run
-ifn tt1.prj
-top tt1
-ifmt MIXED
-opt_mode SPEED
-opt_level 1
-ofn tt1.ngc
-p <parttype>
```

This script file can be executed under XST using the following command:

xst -ifn foo.scr

You can also generate a log file with the following command:

xst -ifn foo.scr -ofn foo.log

A script file can be run either using **xst**-ifn *script name*, or executed under the XST prompt, by using the **script** *script\_name* command.

script foo.scr

If you make a mistake in an XST command, command option or its value, XST issues an error message and stops execution. For example, if in the previous script example VHDL is incorrectly spelled (VHDLL), XST gives the following error message:

```
--> ERROR:Xst:1361 - Syntax error in command run for option "-ifmt" : parameter "VHDLL" is not allowed.
```

If you created your project using ISE<sup>TM</sup>, and have run XST at least once from ISE, you can switch to XST command line mode and use the script and project files that were created by ISE. To run XST from the command line, run the following command from project directory:

xst -ifn <top\_level\_block>.xst -ofn <top\_level\_block>.syr



# Setting Up an XST Script

This section discusses Setting Up an XST Script, and includes:

- "Setting Up an XST Script Using the Run Command"
- "Setting Up an XST Script Using the Set Command"
- "Setting Up an XST Script Using the Elaborate Command"

An XST script is a set of commands, each command having various options.

#### Setting Up an XST Script Using the Run Command

The **run** command is the main synthesis command. It allows you to run synthesis in its entirety, beginning with the parsing of the Hardware Description Language (HDL) files, and ending with the generation of the final netlist. The run keyword can be used only once per script file.

• The **run** command begins with a keyword **run**, which is followed by a set of options and its values:

run option\_1 value option\_2 value ...

To improve the readability of your script file, place each option-value pair on a separate line:

```
run
option_1 value
option_2 value
```

Use the pound (**#**) character to comment out options, or place additional comments in the script file:

```
run
option_1 value
# option_2 value
option_3 value
```

- Each option name begins with dash (–). For example: **-ifn**, **-ifmt**, **-ofn**.
- Each option has one value. There are no options without a value.
- The value for a given option can be one of the following:
  - Predefined by XST (for instance, **yes** or **no**)
  - Any string (for instance, a file name or a name of the top level entity). Options such as -vlgincdir accept several directories as values. Separate the directories by spaces, and enclose them in braces ({}):

-vlgincdir {c:\vlg1 c:\vlg2}

For more information, see "Names With Spaces in Command Line Mode."

• An integer

Table 5-1, "XST-Specific Non-Timing Options," and Table 5-2, "XST-Specific Non-Timing Options: XST Command Line Only," summarize XST-specific non-timing related options, including **run** command options and their values.

XST provides online Help from the Unix command line. The following information is available by typing *help* at the command line. The XST help function provides a list of

supported families, available commands, options and their values for each supported device family.

• To see a detailed explanation of an XST command, use the following syntax.

```
help -arch family_name -command command_name
where:
```

- *family\_name* is a list of supported Xilinx® families in the current version of XST
- *command\_name* is one of the following XST commands: **run**, **set**, **elaborate**, **time**
- To see a list of supported families, type *help* at the command line prompt with no argument. XST issues the following message.

```
--> help
ERROR:Xst:1356 - Help : Missing "-arch <family>". Please specify what
family you want to target
available families:
    acr2
    aspartan2e
    aspartan3
    fpgacore
    grvirtex
    qrvirtex2
    qvirtex
    qvirtex2
    qvirtexe
    spartan2
    spartan2e
    spartan3
    spartan3a
    spartan3e
    virtex
    virtex2
    virtex2p
    virtex4
    virtex5
    virtexe
    xa9500xl
    xbr
    xc9500
    xc9500x1
    xc9500xv
    xpla3
```

• To see a list of commands for a specific device, type the following at the command line prompt with no argument.

```
help -arch family_name.
```

For example:



help -arch virtex

Use the following command to see a list of options and values for the **run** command for Virtex-II devices.

--> help -arch virtex2 -command run

This command gives the following output:

```
-mult_style
                            : Multiplier Style
        block / lut / auto / pipe_lut
-bufg
                            : Maximum Global Buffers
        *
-bufgce
                            : BUFGCE Extraction
       YES / NO
-decoder_extract
                           : Decoder Extraction
       YES / NO
. . . .
-ifn : *
-ifmt : Mixed / VHDL / Verilog
-ofn : *
-ofmt : NGC / NCD
-p : *
-ent : *
-top : *
-opt_mode : AREA / SPEED
-opt_level : 1 / 2
-keep_hierarchy : YES / NO
-vlgincdir : *
-verilog2001 : YES / NO
-vlgcase : Full / Parallel / Full-Parallel
. . . .
```

#### Setting Up an XST Script Using the Set Command

XST recognizes the Set command. The Set command accepts the options shown in Table 12-1, "Set Command Options." For more information about these options, see "XST Design Constraints."

Set Command Options	Description	Values
-tmpdir	Location of all temporary files generated by XST during a session	Any valid path to a directory
-xsthdpdir	Work Directory — location of all files resulting from VHDL or Verilog compilation	Any valid path to a directory
-xsthdpini	HDL Library Mapping File (.INI File)	file_name

Table 12-1: Set Command Options

### Setting Up an XST Script Using the Elaborate Command

Use the Elaborate command to pre-compile VHDL and Verilog files in a specific library, or to verify Verilog files without synthesizing the design. Since compilation is included in the run, the Elaborate command is optional.

The Elaborate command accepts the options shown in Table 12-2, "Elaborate Command Options." For more information about these options, see "XST Design Constraints."

Table 12-2: Elaborate Command Options

Elaborate Command Options	Description	Values
-ifn	Project File	file_name
-ifmt	Format	vhdl, verilog, <b>mixed</b>
-lso	Library Search Order	file_name.lso
-work_lib	Work Library for Compilation — library where the top level block was compiled	name, <b>work</b>
-verilog2001	Verilog-2001	yes, no
-vlgpath	Verilog Search Paths	Any valid path to directories separated by spaces, and enclosed in double quotes ("")
-vlgincdir	Verilog Include Directories	Any valid path to directories separated by spaces, and enclosed in braces ({})

# Synthesizing VHDL Designs Using Command Line Mode

This section discusses Synthesizing VHDL Designs Using command line mode, and includes:

- "Synthesizing VHDL Designs Using Command Line Mode (Example)"
- "Running XST in Script Mode (VHDL)"

### Synthesizing VHDL Designs Using Command Line Mode (Example)

This example shows how to synthesize a hierarchical VHDL design for a Virtex<sup>™</sup> FPGA device using command line mode.

The example uses a VHDL design, called watchvhd. The files for watchvhd can be found in the ISEexamples \watchvhd directory of the ISE<sup>TM</sup> installation directory.

This design contains seven entities:

- stopwatch
- statmach
- tenths (a CORE Generator<sup>TM</sup> core)
- decode



- smallcntr
- cnt60
- hex2led

Following is an example of how to synthesize a VHDL design using command line mode.

- 1. Create a new directory, named vhdl\_m.
- 2. Copy the following files from the ISEexamples\watchvhd directory of the ISE installation directory to the newly created vhdl\_m directory.
  - stopwatch.vhd
  - statmach.vhd
  - ♦ decode.vhd
  - cnt60.vhd
  - smallcntr.vhd
  - tenths.vhd
  - hex2led.vhd

To synthesize the design, which is now represented by seven VHDL files, create a project.

XST supports mixed VHDL and Verilog projects. Xilinx recommends that you use the new project format, whether or not it is a real mixed language project. In this example we use the new project format. To create a project file containing only VHDL files, place a list of VHDL files preceded by keyword *VHDL* in a separate file. The order of the files is not important. XST can recognize the hierarchy, and compile VHDL files in the correct order.

For the example, perform the following steps:

- 1. Open a new file, called watchvhd.prj
- 2. Enter the names of the VHDL files in any order into this file and save the file:

vhdl	work	statmach.vhd
vhdl	work	decode.vhd
vhdl	work	stopwatch.vhd
vhdl	work	cnt60.vhd
vhdl	work	smallcntr.vhd
vhdl	work	tenths.vhd
vhdl	work	hex2led.vhd

3. To synthesize the design, execute the following command from the XST shell or the script file:

```
run -ifn watchvhd.prj -ifmt mixed -top stopwatch -ofn watchvhd.ngc -
ofmt NGC
        -p xcv50-bg256-6 -opt_mode Speed -opt_level 1
```

You must specify a top-level design block with the **-top** command line option.

To synthesize just **hex21ed** and check its performance independently of the other blocks, you can specify the top-level entity to synthesize on the command line, using the **-top** option. For more information, see Table 5-1, "XST-Specific Non-Timing Options."

run -ifn watchvhd.prj -ifmt mixed -ofn watchvhd.ngc -ofmt NGC
-p xcv50-bg256-6 -opt\_mode Speed -opt\_level 1 -top hex2led

During VHDL compilation, XST uses the library **work** as the default. If some VHDL files are to be compiled to different libraries, add the library name before the file name. For example, to compile **hex121ed** into the library **my\_lib**, write the project file as follows:

vhdl work statmach.vhd
vhdl work decode.vhd
vhdl work stopwatch.vhd
vhdl work cnt60.vhd
vhdl work smallcntr.vhd
vhdl work tenths.vhd
vhdl my\_lib hex2led.vhd

If XST does not recognize the order, it issues the following warning:

WARNING:XST:3204. The sort of the vhdl files failed, they will be compiled in the order of the project file.

In this case, you must:

- Put all VHDL files in the correct order.
- Add the **-hdl\_compilation\_order** option with value **user** to the XST **run** command:

```
run -ifn watchvhd.prj -ifmt mixed -top stopwatch -ofn watchvhd.ngc
-ofmt NGC -p xcv50-bg256-6 -opt_mode Speed -opt_level 1 -top hex2led
-hdl_compilation_order user
```

#### Running XST in Script Mode (VHDL)

It can be tedious to enter XST commands directly in the XST shell, especially when you have to specify several options and execute the same command several times. You can run XST in a script mode as follows:

1. Open a new file named stopwatch.xst in the current directory. Put the previously executed XST shell command into this file and save it.

run -ifn watchvhd.prj -ifmt mixed -top stopwatch -ofn watchvhd.ngc

-ofmt NGC -p xcv50-bg256-6 -opt\_mode Speed -opt\_level 1

2. From the tcsh or other shell, enter the following command to begin synthesis.

xst -ifn stopwatch.xst


During this run, XST creates the following files.

- watchvhd.ngc: an NGC file ready for the implementation tools
- xst.srp: the xst log file
- 3. To save XST messages in a different log file (for example, watchvhd.log), run the following command:

xst -ifn stopwatch.xst -ofn watchvhd.log

To improve the readability of the stopwatch.xst file, especially if you use many options to run synthesis, place each option with its value on a separate line. Observe these rules:

- The first line contains only the **run** command without any options.
- There are no blank lines in the middle of the command.
- Each line (except the first one) begins with a dash (–).



For the previous command example, stopwatch.xst should look like the following:

- run
- -ifn watchvhd.prj
- -ifmt mixed
- -top stopwatch
- -ofn watchvhd.ngc
- -ofmt NGC
- -p xcv50-bg256-6
- -opt\_mode Speed
- -opt\_level 1

# Synthesizing Verilog Designs Using Command Line Mode

This section discusses Synthesizing Verilog Designs Using command line mode, and includes:

- "Synthesizing Verilog Designs Using Command Line Mode (Example)"
- "Running XST in Script Mode (Verilog)"

#### Synthesizing Verilog Designs Using Command Line Mode (Example)

This example shows the synthesis of a hierarchical Verilog design for a Virtex FPGA using command line mode.

The following coding example uses a Verilog design, called watchver. These files are found in the ISEexamples\watchver directory of the ISE installation directory.

- stopwatch.v
- statmach.v
- decode.v
- cnt60.v
- smallcntr.v
- tenths.v
- hex2led.v

This design contains seven modules:

- stopwatch
- statmach
- tenths (a CORE Generator<sup>TM</sup> core)
- decode
- cnt60

- smallcntr
- hex2led

For the example, perform the following steps:

- 1. Create a new directory named vlg\_m.
- 2. Copy the watchver design files from the ISEexamples\watchver directory of the ISE installation directory to the newly created vlg\_m directory.

Specify the top-level design block with the **-top** command line option.

To synthesize the design, which is now represented by seven Verilog files, create a project. XST now supports mixed VHDL and Verilog projects. Therefore, Xilinx recommends that you use the new project format whether it is a real mixed language project or not. In this example, we use the new project format. To create a project file containing only Verilog files, place a list of Verilog files preceded by the keyword *verilog* in a separate file. The order of the files is not important. XST can recognize the hierarchy and compile Verilog files in the correct order.

For our example:

- 1. Open a new file, called watchver.v.
- 2. Enter the names of the Verilog files into this file in any order and save it:

```
verilog work decode.v
verilog work statmach.v
verilog work stopwatch.v
verilog work cnt60.v
verilog work smallcntr.v
verilog work hex2led.v
```

3. To synthesize the design, execute the following command from the XST shell or a script file:

```
run -ifn watchver.v -ifmt mixed -top stopwatch -ofn watchver.ngc
        -ofmt NGC -p xcv50-bg256-6 -opt_mode Speed -opt_level 1
```

To synthesize just HEX2LED and check its performance independently of the other blocks, specify the top-level module to synthesize in the command line, using the **-top** option. For more information, see Table 5-1, page 318.

```
run -ifn watchver.v -ifmt Verilog -ofn watchver.ngc -ofmt NGC
-p xcv50-bg256-6 -opt_mode Speed -opt_level 1 -top HEX2LED
```

#### Running XST in Script Mode (Verilog)

It can be tedious to enter XST commands directly into the XST shell, especially when you have to specify several options and execute the same command several times.

To run XST in script mode:

1. Open a new file called design.xst in the current directory. Put the previously executed XST shell command into this file and save it.

```
run -ifn watchver.prj -ifmt mixed -ofn watchver.ngc
-ofmt NGC -p xcv50-bg256-6 -opt_mode Speed -opt_level 1
```

2. From the tcsh or other shell, enter the following command to begin synthesis.

xst -ifn design.xst



During this run, XST creates the following files.

- watchvhd.ngc: an NGC file ready for the implementation tools
- design.srp: the xst script log file
- 3. To save XST messages in a different log file (for example, watchver.log), run the following command:

xst -ifn design.xst -ofn watchver.log

To improve the readability of the design.xst file, especially if you use many options to run synthesis, place each option with its value on a separate line. Observe the following rules:

- The first line contains only the **run** command without any options.
- There are no blank lines in the middle of the command.
- Each line (except the first one) begins with a dash (–).

For the previous command example, the design.xst file should look like the following:

```
run
-ifn watchver.prj
-ifmt mixed
-top stopwatch
-ofn watchver.ngc
-ofmt NGC
-p xcv50-bg256-6
-opt_mode Speed
-opt_level 1
```

### Synthesizing Mixed Designs Using Command Line Mode

This example shows the synthesis of a hierarchical mixed VHDL and Verilog design for a Virtex FPGA using command line mode.

- 1. Create a new directory named vhdl\_verilog.
- 2. Copy the following files from the ISEexamples\watchvhd directory of the ISE installation directory to the newly-created vhdl\_verilog directory.
  - stopwatch.vhd
  - statmach.vhd
  - decode.vhd
  - cnt60.vhd
  - smallcntr.vhd
  - tenths.vhd
- 3. Copy the hex2led.v file from the ISEexamples\watchver directory of the ISE installation directory to the newly created vhdl\_verilog directory.

To synthesize the design, which is now represented by six VHDL files and one Verilog file, create a project. To create a project file, place a list of VHDL files preceded by keyword *vhdl*, and a list of Verilog files preceded by keyword *verilog* in a separate file. The order of the files is not important. XST recognizes the hierarchy and compiles Hardware Description Language (HDL) files in the correct order.

### Synthesizing Mixed Designs Using Command Line Mode (Example)

- 1. Open a new file called watchver.prj.
- 2. Enter the names of the files into this file in any order and save it:

```
vhdl work decode.vhd
vhdl work statmach.vhd
vhdl work stopwatch.vhd
vhdl work cnt60.vhd
vhdl work smallcntr.vhd
vhdl work tenths.vhd
verilog work hex2led.v
```

3. To synthesize the design, execute the following command from the XST shell or a script file:

run -ifn watchver.prj -ifmt mixed -top stopwatch -ofn watchver.ngc -ofmt NGC -p xcv50-bg256-6 -opt\_mode Speed -opt\_level 1

You must specify the top-level design block with the **-top** command line option.

and check its performance independently of the other blocks, you can specify it as the top level module to synthesize on the command line by using the **-top** option. For more information, see Table 5-1, page 318.

```
run -ifn watchver.prj -ifmt mixed -top hex2led -ofn watchver.ngc
-ofmt NGC -p xcv50-bg256-6 -opt_mode Speed -opt_level 1
```

#### Running XST in Script Mode (Mixed Language)

It can be tedious to enter XST commands directly into the XST shell, especially when you have to specify several options and execute the same command several times. You can run XST in a script mode as follows.

1. Open a new file called stopwatch.xst in the current directory. Put the previously executed XST shell command into this file and save it.

```
run -ifn watchver.prj -ifmt mixed -top stopwatch -ofn watchver.ngc
-ofmt NGC -p xcv50-bg256-6 -opt_mode Speed -opt_level 1
```

2. From the tcsh or other shell, enter the following command to begin synthesis.

xst -ifn stopwatch.xst

During this run, XST creates the following files:

- watchver.ngc: an NGC file ready for the implementation tools
- xst.srp: the xst script log file
- 3. If you want to save XST messages in a different log file for example, watchver.log, execute the following command.

xst -ifn stopwatch.xst -ofn watchver.log

To improve the readability of the stopwatch.xst file, especially if you use many options to run synthesis, place each option with its value on a separate line. Observe the following rules:

- The first line contains only the **run** command without any options.
- There are no blank lines in the middle of the command.
- Each line (except the first one) begins with a dash (–).



For the previous command example, the stopwatch.xst file should look like the following:

run
-ifn watchver.prj
-ifmt mixed
-ofn watchver.ngc
-ofmt NGC
-p xcv50-bg256-6
-opt\_mode Speed
-opt\_level 1